

# **TIDE and Tibbo BASIC User Manual**

Tibbo Technology Inc.

# Table of Contents

<b>Taiko R2</b>	<b>1</b>
Legal Information .....	1
<b>Overview</b>	<b>4</b>
Our Language Philosophy .....	4
System Components .....	7
Objects .....	8
Events .....	8
<b>Getting Started</b>	<b>9</b>
Preparing Your Hardware .....	9
Starting a New Project .....	10
Writing Code .....	11
Building, Uploading and Running .....	14
Compiling a Final Binary .....	15
<b>Programming with TIDE</b>	<b>15</b>
<b>Managing Projects</b> .....	<b>15</b>
The Structure of a Project .....	16
Creating, Opening and Saving Projects .....	17
Adding, Removing and Saving Files .....	18
Resource Files .....	20
Built-in Image Editor .....	20
<b>Coding Your Project</b> .....	<b>22</b>
Project Browser .....	22
Code Auto-completion .....	23
Code Hinting .....	24
Tooltips .....	24
Supported HTML Tags .....	26
<b>Making, Uploading and Running an Executable Binary</b> .....	<b>26</b>
Two Modes of Target Execution.....	27
<b>Debugging Your Project</b> .....	<b>28</b>
Target States .....	28
Exceptions .....	29
Program Pointer .....	30
Breakpoints .....	30
The Call Stack and Stack Pointer.....	31
Stepping .....	33
The Watch .....	33
Scopes in Watch .....	37
Code Profiling .....	37
<b>Project Settings</b> .....	<b>38</b>
<b>Device Explorer</b> .....	<b>39</b>
Upload Function .....	41
Protecting Your Device with a Password .....	41
<b>Programming Fundamentals</b> .....	<b>43</b>
Program Structure .....	43
Code Basics .....	45
Naming Conventions .....	47

<b>Introduction to Variables, Constants and Scopes .....</b>	<b>47</b>
Variables And Their Types .....	48
Type Conversion .....	50
Type conversion in expressions.....	52
Compile-time Calculations .....	53
Arrays .....	54
Structures .....	58
Enumeration Types .....	59
Understanding the Scope of Variables.....	61
Declaring Variables .....	64
Constants .....	65
<b>Introduction to Procedures .....</b>	<b>66</b>
Passing Arguments to Procedures .....	68
Memory Allocation for Procedures.....	70
<b>Introduction to Control Structures .....</b>	<b>72</b>
Decision Structures .....	72
Loop Structures .....	72
Doevents .....	73
<b>Using Preprocessor .....</b>	<b>76</b>
Scope of Preprocessor Directives.....	78
<b>Working with HTML .....</b>	<b>79</b>
Embedding Code Within an HTML File.....	80
<b>Understanding Platforms .....</b>	<b>82</b>
Objects, Events and Platform Functions .....	82

## Language Reference

**83**

<b>Statements .....</b>	<b>83</b>
<b>Const Statement .....</b>	<b>84</b>
<b>Declare Statement .....</b>	<b>84</b>
<b>Dim Statement .....</b>	<b>86</b>
<b>Doevents Statement .....</b>	<b>87</b>
<b>Do... Loop Statement .....</b>	<b>87</b>
<b>Enum Statement .....</b>	<b>88</b>
<b>Exit Statement .....</b>	<b>89</b>
<b>For... Next Statement .....</b>	<b>90</b>
<b>Function Statement .....</b>	<b>91</b>
<b>Goto Statement .....</b>	<b>93</b>
<b>If... Then... Else Statement .....</b>	<b>94</b>
<b>Include Statement .....</b>	<b>95</b>
<b>Includepp Statement .....</b>	<b>96</b>
<b>Select-Case Statement .....</b>	<b>97</b>
<b>Sub Statement .....</b>	<b>99</b>
<b>Type Statement .....</b>	<b>100</b>
<b>While-Wend Statement .....</b>	<b>101</b>
<b>Keywords .....</b>	<b>102</b>
<b>As .....</b>	<b>102</b>
<b>Boolean .....</b>	<b>102</b>
<b>ByRef .....</b>	<b>102</b>
<b>Byte .....</b>	<b>102</b>
<b>ByVal .....</b>	<b>102</b>
<b>Char .....</b>	<b>103</b>
<b>Else .....</b>	<b>103</b>
<b>End .....</b>	<b>103</b>
<b>False .....</b>	<b>103</b>
<b>For .....</b>	<b>103</b>
<b>Integer .....</b>	<b>103</b>
<b>Next .....</b>	<b>103</b>

Public	104
Short	104
Step	104
String	104
Then	104
Type	104
To	104
True	104
Word	104
<b>Operators</b>	<b>105</b>
<b>Error Messages</b>	<b>106</b>
C1001	107
C1002	107
C1003	107
C1004	108
C1005	108
C1006	108
C1007	109
C1008	109
C1009	110
C1010	110
C1011	111
C1012	111
C1013	111
C1014	112
C1015	112
C1016	113
C1017	113
C1018	113
C1019	114
C1020	114
C1021	114
C1022	115
C1023	115
C1024	116
L1001	116
L1002	116
L1003	117
L1004	117
L1005	117
L1006	117
L1007	118
L1008	118
L1009	118
<b>Objects, Properties, Methods, Events</b>	<b>119</b>
<b>Development Environment</b>	<b>119</b>
<b>Installation Requirements</b>	<b>119</b>
<b>User Interface</b>	<b>119</b>
Main Window	120
Operation Modes	120
Menu Bar	121
File Menu	121
Edit Menu	122
View Menu	122
Project Menu	123

Debug Menu .....	124
Image Menu .....	124
Window Menu .....	125
Help Menu .....	125
<b>Toolbars .....</b>	<b>126</b>
Project Toolbar .....	126
Debug Toolbar .....	126
Image Editor Toolbar .....	127
Tool Properties Toolbar .....	128
Selection Tool Properties .....	128
Paint Tool Properties .....	128
Eraser Tool Properties .....	128
Text Tool Properties .....	129
Line Tool Properties .....	129
Rectangle Tool Properties .....	129
Ellipse Tool Properties .....	130
Zoom Tool Properties .....	130
<b>Status Bar .....</b>	<b>130</b>
<b>Dialogs .....</b>	<b>131</b>
Project Settings .....	131
New Project .....	132
Add File to Project .....	132
Graphic File Properties Dialog .....	133
<b>Panes .....</b>	<b>133</b>
Call Stack .....	133
Output .....	133
Project .....	134
Browser .....	134
Files .....	134
Watch .....	135
Colors .....	135
<b>Language Element Icons .....</b>	<b>136</b>
<b>Glossary of Terms .....</b>	<b>136</b>
<b>Compilation Unit .....</b>	<b>136</b>
<b>Compiler .....</b>	<b>136</b>
<b>Construct .....</b>	<b>136</b>
<b>Cross-Debugging .....</b>	<b>136</b>
<b>Identifier .....</b>	<b>137</b>
<b>Keyword .....</b>	<b>137</b>
<b>Label .....</b>	<b>137</b>
<b>Linker .....</b>	<b>137</b>
<b>P-Code .....</b>	<b>137</b>
<b>Syscall .....</b>	<b>137</b>
<b>Target .....</b>	<b>137</b>
<b>Virtual Machine .....</b>	<b>137</b>
<b>Platforms .....</b>	<b>138</b>
<b>Platform Specifications .....</b>	<b>138</b>
<b>EM500W .....</b>	<b>138</b>
Platform-specific Constants .....	140
Enum pl_redir .....	140
Enum pl_io_num .....	141

Enum pl_io_port_num .....	142
Enum pl_int_num .....	142
Enum pl_sock_interfaces .....	142
Connecting External Flash IC.....	143
<b>EM1000 and EM1000W Platforms .....</b>	<b>143</b>
Platform-specific Constants.....	146
Enum pl_redir .....	146
Enum pl_io_num .....	147
Enum pl_io_port_num .....	149
Enum pl_int_num .....	150
Enum pl_sock_interfaces .....	150
<b>EM1202 and EM1202W Platforms .....</b>	<b>151</b>
Platform-specific Constants.....	153
Enum pl_redir .....	153
Enum pl_io_num .....	154
Enum pl_io_port_num .....	156
Enum pl_int_num .....	157
Enum pl_sock_interfaces .....	157
<b>EM1206 and EM1206W Platforms .....</b>	<b>158</b>
Platform-specific Constants.....	160
Enum pl_redir .....	160
Enum pl_io_num .....	161
Enum pl_io_port_num .....	163
Enum pl_int_num .....	163
Enum pl_sock_interfaces .....	163
<b>DS1100 Platform .....</b>	<b>164</b>
Platform-specific Constants.....	165
Enum pl_redir .....	166
Enum pl_io_num .....	167
Enum pl_io_port_num .....	167
Enum pl_int_num .....	167
Enum pl_sock_interfaces .....	168
<b>DS1101W Platform .....</b>	<b>168</b>
Platform-specific Constants.....	170
Enum pl_redir .....	170
Enum pl_io_num .....	171
Enum pl_io_port_num .....	173
Enum pl_int_num .....	174
Enum pl_sock_interfaces .....	174
<b>DS1102W Platform .....</b>	<b>174</b>
Platform-specific Constants.....	176
Enum pl_redir .....	177
Enum pl_io_num .....	178
Enum pl_io_port_num .....	180
Enum pl_int_num .....	180
Enum pl_sock_interfaces .....	180
<b>DS1202 Platform .....</b>	<b>181</b>
Platform-specific Constants.....	182
Enum pl_redir .....	183
Enum pl_io_num .....	184
Enum pl_io_port_num .....	185
Enum pl_int_num .....	185
Enum pl_sock_interfaces .....	186
<b>DS1206 Platform .....</b>	<b>186</b>
Platform-specific Constants.....	188
Enum pl_redir .....	188
Enum pl_io_num .....	189
Enum pl_io_port_num .....	190
Enum pl_int_num .....	191

Enum pl_sock_interfaces .....	191
<b>Common Information .....</b>	<b>191</b>
Supported Variable Types .....	192
Supported Functions .....	192
GPIO Type .....	194
RTS/CTS Remapping .....	195
Serial Port FIFOs .....	196
Clock Frequency (PLL) Control.....	196
Special Configuration Section of the EEPROM.....	197
Device Serial Number .....	199
Flash Memory Configuration.....	200
Status LEDs .....	200
Setup (MD) Button (Line) .....	201
Connecting GA1000 .....	201
Debug Communications .....	204
Serial Channels vs. Serial Ports.....	205
<b>Function Reference .....</b>	<b>205</b>
<b>Aes128dec Function .....</b>	<b>205</b>
<b>Aes128enc Function .....</b>	<b>206</b>
<b>Asc Function .....</b>	<b>206</b>
<b>Bin Function .....</b>	<b>207</b>
<b>Cfloat Function .....</b>	<b>207</b>
<b>Chr Function .....</b>	<b>208</b>
<b>Date Function .....</b>	<b>208</b>
<b>Daycount Function .....</b>	<b>209</b>
<b>Ddstr Function .....</b>	<b>210</b>
<b>Ddval Function .....</b>	<b>210</b>
<b>Ftostr Function .....</b>	<b>211</b>
<b>Hex Function .....</b>	<b>212</b>
<b>Hours Function .....</b>	<b>213</b>
<b>.Insert Function .....</b>	<b>213</b>
<b>Instr Function .....</b>	<b>214</b>
<b>Lbin Function .....</b>	<b>214</b>
<b>Left Function .....</b>	<b>215</b>
<b>Len Function .....</b>	<b>215</b>
<b>Lhex Function .....</b>	<b>216</b>
<b>Lstr Function .....</b>	<b>216</b>
<b>Lstri Function .....</b>	<b>217</b>
<b>Lval Function .....</b>	<b>218</b>
<b>Md5 Function .....</b>	<b>218</b>
<b>Mid Function .....</b>	<b>219</b>
<b>Mincount Function .....</b>	<b>220</b>
<b>Minutes Function .....</b>	<b>221</b>
<b>Month Function .....</b>	<b>221</b>
<b>Random Function .....</b>	<b>222</b>
<b>Rc4 Function .....</b>	<b>222</b>
<b>Right Function .....</b>	<b>223</b>
<b>Sha1 Function .....</b>	<b>223</b>
<b>Str Function .....</b>	<b>225</b>
<b>Strand Function .....</b>	<b>225</b>
<b>Strgen Function .....</b>	<b>226</b>
<b>Stri Function .....</b>	<b>226</b>
<b>Stror Function .....</b>	<b>227</b>
<b>Strsum Function .....</b>	<b>227</b>
<b>Strtof Function .....</b>	<b>228</b>
<b>Strxor Function .....</b>	<b>228</b>
<b>Val Function .....</b>	<b>229</b>
<b>Vali Function .....</b>	<b>230</b>

<b>Weekday Function</b> .....	<b>230</b>
<b>Year Function</b> .....	<b>230</b>
<b>Object Reference</b> .....	<b>231</b>
<b>Beep Object</b> .....	<b>232</b>
.Divider Property .....	232
.On_beep Event .....	233
.Play Method .....	233
<b>Button Object</b> .....	<b>234</b>
.On_button_pressed Event .....	234
.On_button_released Event .....	235
.Pressed R/O Property .....	235
.Time R/O Property .....	235
<b>Fd Object</b> .....	<b>236</b>
Overview .....	236
Sharing Flash Between Your Application and Data .....	237
Fd Object's Status Codes .....	239
Direct Sector Access .....	240
Using Checksums .....	242
Upgrading the Firmware/Application .....	243
File-based Access .....	245
Formatting the Flash Disk .....	245
Disk Area Allocation Details .....	246
Mounting the Flash Disk .....	249
Checking Disk Vitals .....	249
File Names and Attributes .....	249
Creating, Deleting, and Renaming Files .....	250
Reading and Writing File Attributes .....	251
Walking Through File Directory .....	252
Opening Files .....	253
Writing To and Reading From Files .....	254
Removing Data From Files .....	255
Searching Within Files .....	256
Closing Files .....	258
Using Disk Transactions .....	259
Understanding Transaction Capacity .....	261
File-based and Direct Sector Access Coexistence .....	263
Prolonging Flash Memory Life .....	264
Properties and Methods .....	265
.Availableflashspace R/O Property .....	267
.Buffernum Property .....	267
.Capacity R/O Property .....	268
.Checksum Method .....	268
.Close Method .....	269
.Copyfirmware Method .....	269
.Copyfirmwarelzo Method .....	270
.Cutfrontop Method .....	271
.Create Method .....	271
.Delete Method .....	272
.Filenum Property .....	273
.Fileopened R/O Property .....	273
.Filesize R/O Property .....	274
.Find Method .....	274
.Flush Method .....	275
.Format Method .....	276
.Formatj Method .....	277
.Getattributes Method .....	278
.Getbuffer Method .....	278
.GetData Method .....	279

.Getfreespace Method .....	280
.Getnextdirmember Method.....	280
.Getnumfiles Method .....	281
.Getsector Method .....	281
.Laststatus R/O Property .....	282
.Maxopenedfiles R/O Property.....	282
.Maxstoredfiles R/O Property.....	283
.Mount Method .....	283
.Numservicesectors R/O Property.....	284
.Open Method .....	284
.Pointer R/O Property .....	285
.Ready R/O Property .....	285
.Rename Method .....	285
.Resetdirpointer Method .....	286
.Sector R/O Property .....	287
.Setattributes Method .....	287
.Setbuffer Method .....	288
.Setdata Method .....	289
.Setfilesize Method .....	289
.Setsector Method .....	290
.Setpointer Method .....	291
.Totalsize R/O Property .....	292
.Transactioncapacityremaining R/O Property.....	292
.Transactioncommit Method.....	293
.Transactionstart Method .....	293
.Transactionstarted R/O Property.....	294
<b>IO Object .....</b>	<b>294</b>
Overview .....	294
Line/Port Manipulation With Pre-selection.....	295
Line/Port Manipulation Without Pre-selection.....	295
Controlling Output Buffers .....	296
Working With Interrupts .....	297
Properties, Events, Methods .....	298
.Enabled Property (Selected Platforms Only).....	298
.Intenable Property .....	299
.Intnum Property .....	299
.Invert Method .....	300
.Lineget Method .....	300
.Lineset Method .....	300
.Num Property .....	301
.On_io_int Event .....	301
.Portenable Property (Selected Platforms Only).....	302
.Portget Method .....	302
.Portnum Property .....	302
.Portset Method .....	303
.Portstate property .....	303
.State Property .....	303
<b>Kp Object .....</b>	<b>304</b>
Possible Keypad Configurations .....	304
Key States and Transitions.....	306
Preparing the Keypad for Operation.....	307
Servicing Keypad Events .....	310
Properties, Methods, Events .....	312
.Autodisablecodes Property.....	312
.Enabled Property .....	312
.Longpressdelay Property .....	313
.Longreleasedelay Property.....	313
.On_kp Event .....	314
.On_kp_overflow Event .....	314

.Pressdelay Property .....	315
.Releasedelay Property .....	315
.Repeatdelay Property .....	315
.Returnlinesmapping Property.....	316
.Scanlinesmapping Property.....	317
<b>LCD Object .....</b>	<b>317</b>
Overview .....	318
Understanging Controller Properties.....	318
Preparing the Display for Operation.....	320
Working With Pixels and Colors.....	320
Lines, Rectangles, and Fills.....	321
Working With Text .....	322
Raster Font File Format .....	325
Displaying Images .....	329
Improving Graphical Performance.....	330
Supported Controllers/Panels.....	333
Samsung S6B0108 (Winstar WG12864F).....	333
Solomon SSD1329 (Ritdisplay RGS13128096).....	335
Himax HX8309 (Ampire AM176220).....	336
Properties and Methods .....	338
.Backcolor Property .....	339
.Bitsperpixel R/O Property .....	339
.Bluebits R/O Property .....	340
.Bmp Method .....	340
.Enabled Property .....	341
.Error R/O Property .....	342
.Fill Method .....	342
.Filledrectangle Method .....	343
.Fontheight R/O Property .....	343
.Fontpixelpacking R/O Property .....	344
.Forecolor Property .....	344
.Getprintw idth Method .....	345
.Greenbits R/O Property .....	345
.Height Property .....	346
.Horline Method .....	346
.Inverted Property .....	347
.lomapping Property .....	347
.Line Method .....	348
.Linew idth Property .....	348
.Lock Method .....	348
.Lockcount R/O Property .....	349
.Paneltype R/O Property .....	349
.Pixelpacking R/O Property .....	350
.Print Method .....	351
.Printaligned Method .....	351
.Rectangle Method .....	352
.Redbits R/O Property .....	352
.Rotated Property .....	353
.Setfont Method .....	353
.Setpixel Method .....	354
.Textalignment Property .....	355
.Texthorizontalspacing Property.....	355
.Textorientation Property .....	356
.Textverticalspacing Property.....	356
.Unlock Method .....	356
.Verline Method .....	357
.Width Property .....	357
<b>Net Object .....</b>	<b>358</b>
Overview .....	358

Main Parameters .....	358
Checking Ethernet Status .....	359
Properties, Methods, Events .....	360
.Mac R/O Property .....	360
.Ip Property .....	360
.Netmask Property .....	360
.Gatew ayip Property .....	361
.Failure R/O Property .....	361
.Linkstate R/O Property .....	361
.On_net_link_change Event.....	362
.On_net_overrun Event .....	362
<b>Pat Object .....</b>	<b>363</b>
.Channel Property .....	364
.Greenmap Property .....	364
.On_pat Event .....	365
.Play Method .....	365
.Redmap Property .....	366
<b>Ppp Object .....</b>	<b>366</b>
.Buffrq Method .....	367
.Buffsize R/O Property .....	367
.Enabled Property .....	368
.Ip Property .....	368
.Portnum Property .....	368
<b>Pppoe Object .....</b>	<b>369</b>
.AcmaC Property .....	369
.Ip Property .....	370
.Sessionid Property .....	370
<b>Romfile Object .....</b>	<b>370</b>
.Find Method .....	372
.Find32 Method .....	372
.GetData Method .....	373
.Offset R/O Property .....	373
.Open Method .....	374
.Pointer Property .....	374
.Pointer32 Property .....	374
.Size R/O Property .....	375
<b>RTC Object .....</b>	<b>375</b>
.GetData Method (Previously .Get).....	376
.Running R/O Property .....	377
.Setdata Method (Previously .Set).....	377
<b>Ser Object .....</b>	<b>378</b>
Overview .....	379
Anatomy of a Serial Port .....	379
Three Modes of the Serial Port.....	380
UART Mode .....	380
Wiegand Mode .....	383
Clock/Data Mode .....	386
Port Selection .....	388
Serial Settings .....	390
Sending and Receiving Data (TX and RX buffers).....	393
Allocating Memory for Buffers.....	393
Using Buffers .....	394
Buffer Memory Status .....	394
Receiving Data .....	396
Sending Data .....	397
Handling Buffer Overruns .....	398
Redirecting Buffers .....	399
Sinking Data .....	399
Properties, Methods, Events .....	400

.Autoclose Property	402
.Baudrate Property	402
.Bits Property	403
.Ctsmap property (Selected Platforms Only)	403
.Dircontrol Property	404
.Div9600 R/O Property	404
.Enabled Property	405
.Escchar Property	405
.Esctype Property	405
.Flow control Property	407
.Getdata Method	407
.Interchardelay Property	408
.Interface Property	408
.Mode Property	409
.New txlen R/O Property	410
.Notifysent Method	410
.Num Property	411
.Numofports R/O Property	411
On_ser_data_arrival Event	412
On_ser_data_sent Event	412
On_ser_esc Event	413
On_ser_overrun Event	413
.Parity Property	413
.Redir Method	414
.Rtsmap Property (Selected Platforms Only)	415
.Rxbufirq Method	415
.Rxbufsize R/O Property	416
.Rxclear Method	416
.Rxlen R/O Property	417
.Send Method	417
.Setdata Method	418
.Sinkdata Property	418
.Txbufirq Method	419
.Txbufsize R/O Property	419
.Txclear Method	420
.Txfree R/O Property	420
.Txlen R/O Property	420
<b>Socket Object</b>	<b>421</b>
Overview	422
Anatomy of a Socket	422
Socket Selection	423
Handling Network Connections	424
TCP connection basics	424
UDP "connection" basics	425
Accepting Incoming Connections	426
Accepting UDP broadcasts	428
Understanding TCP Reconnects	428
Understanding UDP Reconnects and Port Switchover	429
Incoming Connections on Multiple Sockets	432
Establishing Outgoing Connections	434
Sending UDP broadcasts	435
Closing Connections	437
Checking Connection Status	439
More On the Socket's Asynchronous Nature	441
Sending and Receiving data	444
Allocating Memory for Buffers	444
Using Buffers in TCP Mode	445
Using Buffers in UDP Mode	446
TX and RX Buffer Memory Status	447

Receiving Data in TCP Mode.....	448
Receiving Data in UDP Mode.....	450
Sending TCP and UDP Data.....	451
"Split Packet" Mode of TCP Data Processing.....	453
Handling Buffer Overruns .....	454
Redirecting Buffers .....	454
Sinking Data .....	456
Working With Inband Commands.....	456
Inband Message Format .....	456
Inband-related Buffers (CMD, RPL, and TX2).....	457
Processing Inband Commands.....	458
Sending Inband Replies .....	460
Using HTTP .....	461
HTTP-related Buffers .....	462
Setting the Socket for HTTP.....	463
Socket Behavior in the HTTP Mode.....	465
Including BASIC Code in HTTP Files.....	466
Generating Dynamic HTML Pages.....	466
URL Substitution .....	468
Working with HTTP Variables.....	469
Simple Case (Small Amount of Variable Data).....	470
Complex Case (Large Amount of Variable Data).....	471
Details on Variable Data .....	473
Properties, Methods, and Events.....	474
.Acceptbcast Property .....	474
.Allow edinterfaces Property.....	474
.Availableinterfaces R/O Property.....	475
.Bcast R/O Property .....	475
.Close Method .....	475
.Cmdbuffrq Method .....	476
.Cmdlen R/O Property .....	477
.Connect Method .....	477
.Connectiontout Property .....	477
.Currentinterface R/O Property.....	478
.Discard Method .....	478
.Endchar Property .....	479
.Escchar Property .....	479
.Event R/O Property (Obsolete).....	480
.Eventsimple R/O Property (Obsolete).....	480
.GetData Method .....	480
.Gethttprqstring Method .....	480
.Getinband Method .....	481
.Httpmode Property .....	481
.Httpnoclose Property .....	482
.Httpportlist Property .....	483
.Httprqstring R/O Property .....	483
.Inbandcommands Property.....	484
.Inconenabledmaster Property.....	484
.Inconmode Property .....	485
.Localport R/O Property .....	485
.Localportlist Property .....	486
.New txlen R/O Property .....	486
.Nextpacket Method .....	487
.Notifysent Method .....	487
.Num Property .....	488
.Numofsock R/O Property .....	488
.Outport Property .....	488
On_sock_data_arrival Event.....	489
On_sock_data_sent Event.....	489

On_sock_event Event .....	490
On_sock_inband Event .....	490
On_sock_overrun Event .....	491
On_sock_postdata .....	491
On_sock_tcp_packet_arrival Event.....	491
.Protocol Property .....	492
.Reconmode Property .....	492
.Redir Method .....	493
.Remoteip R/O Property .....	494
.Remotemac R/O Property .....	495
.Remoteport R/O Property .....	495
.Reset Method .....	495
.Rplbufirq Method .....	496
.Rplfree R/O Property .....	497
.Rpllen R/O Property .....	497
.Rxbufirq Method .....	497
.Rxbufsize R/O Property .....	498
.Rxclear Method .....	498
.Rxpacketlen R/O Property .....	499
.Rxlen R/O Property .....	499
.Send Method .....	500
.Setdata Method .....	500
.Setsendinband Method .....	500
Sinkdata Property .....	501
.Splittcp packets Property .....	501
.State R/O Property .....	502
.Statesimple R/O Property .....	505
.Targetbcast Property .....	505
.Targetinterface Property .....	506
.Targetip Property .....	506
.Targetport Property .....	507
.Toutcounter R/O property .....	507
.Tx2bufirq Method .....	508
.Tx2len R/O Property .....	508
.Txbufirq Method .....	509
.Txbufsize R/O Property .....	509
.Txclear Method .....	510
.Txfree R/O Property .....	510
.Txlen R/O Property .....	510
.Urlsubstitutes .....	511
.Varbufirq Method .....	511
<b>Ssi Object .....</b>	<b>512</b>
Configuring SSI Channel .....	513
CLK, DO, and DI Lines .....	513
Baudrate .....	514
SSI Modes .....	514
Direction .....	515
Sending and Receiving Data.....	515
More on I2C .....	516
Properties, Methods .....	517
.Baudrate Property .....	517
.Channel Property .....	518
.Clkmap Property .....	518
.Dimap Property .....	519
.Direction Property .....	519
.Domap Property .....	519
.Enabled Property .....	520
.Mode Property .....	520
.Str Method .....	520

.Value Method .....	521
.Zmode Property .....	522
<b>Stor Object .....</b>	<b>522</b>
.Base Property .....	523
.Getdata Method (previously .Get).....	523
.Setdata Method (previously .Set).....	524
.Size R/O Property .....	525
<b>Sys Object .....</b>	<b>526</b>
Overview .....	526
On_sys_init Event .....	526
Buffer Management .....	526
System Timer .....	528
PLL Management .....	529
Serial Number .....	530
Miscellaneous .....	530
Properties, Methods, Events .....	530
.Buffalloc Method .....	530
.Currentpll R/O Property (Selected Platforms Only).....	531
.Freebuffpages R/O Property.....	531
.Halt Method .....	532
.New pll Method (Selected Platforms Only).....	532
On_sys_init Event .....	533
On_sys_timer Event .....	533
.Onsystemerperiod Property (Selected Platforms Only).....	533
.Reboot Method .....	534
.Runmode R/O Property .....	534
.Serialnum R/O Property (Selected Platforms Only).....	534
.Setserialnum Method (Selected Platforms Only).....	535
.Resettype R/O Property .....	535
.Timercount R/O Property .....	536
.Totalbuffpages R/O Property.....	536
.Version R/O Property .....	536
<b>Wln Object .....</b>	<b>536</b>
Overview .....	537
Wi-Fi Parlance Primer .....	538
Wln Tasks .....	539
Wln State Transitions .....	542
Brining Up Wi-Fi Interface .....	543
Configuring Interface Lines.....	545
Applying Reset .....	546
Selecting Domain .....	547
Allocating Buffer Memory .....	547
Setting MAC Address (Optional).....	548
Booting Up the Hardw are .....	549
Setting IP, Gatew ay, and Netmask.....	549
Setting TX Pow er (Optional).....	550
Scanning for Wi-Fi Netw orks .....	550
Discovering All Wireless Netw orks .....	551
Collecting Data About Specific Netw ork.....	551
Multiple Access Points With the Same Name.....	552
Setting Wi-Fi Security .....	552
Setting WEP Mode and Key.....	553
Setting WPA Mode and Key.....	553
Associating With Selected Netw ork.....	554
Creating Ow n Ad-hoc Netw ork.....	555
Communicating via Wln Interface.....	555
Disassociating From the Netw ork.....	556
Terminating Ow n Ad-hoc Netw ork.....	556
Detecting Disassociation or Offline State.....	556

Properties, Methods, Events .....	556
.Activescan Method .....	556
.Associate Method .....	557
.Associationstate R/O Property.....	558
.Boot Method .....	558
.Buffrq Method .....	559
.Buffsize R/O Property .....	559
.Clkmap Property .....	560
.Csmap Property .....	560
.Dimap Property .....	560
.Disassociate Method .....	561
.Domain Property .....	561
.Domap Property .....	562
.Enabled R/O Property .....	562
.Gatew ayip Property .....	562
.Ip Property .....	563
.Mac Property .....	563
.Netmask Property .....	564
.Netw orkstart Method .....	564
.Netw orkstop Method .....	564
.On_w In_event Event .....	565
.On_w In_task_complete Event.....	565
.Rssi R/O Property .....	566
.Scan Method .....	567
.Scanresultbssid R/O Property.....	567
.Scanresultbssmode R/O Property.....	568
.Scanresultchannel R/O Property.....	568
.Scanresultrssi R/O Property.....	569
.Scanresultssid R/O Property.....	569
.Scanresultw painfo R/O Property.....	569
.Settxpow er Method .....	570
.Setw ep Method .....	570
.Setw pa Method .....	571
.Task R/O Property .....	572

## Libraries

**572**

<b>Common Library Info .....</b>	<b>575</b>
Library Sets .....	575
Anatomy of Tibbo Libraries .....	576
Libraries and Platforms .....	577
Adding Library Files to Projects .....	577
About _get_info() API Functions .....	577
Library Configurators .....	578
<b>Library Reference .....</b>	<b>580</b>
<b>AGG (AggreGate) Library .....</b>	<b>580</b>
AggreGate Configurator .....	583
The Access Control Demo .....	585
The Steps .....	586
Preparing the AggreGate Server.....	586
Step 1: The Embryo .....	587
Step 2: Adding Setting A-variables .....	588
Define Required Settings .....	590
Define Required A-variables.....	591
Step 3: Adding Table A-variables.....	593
Define the User Table .....	594
Add the Table A-variable .....	595
Step 4: Adding A-functions.....	596

Adding A-function .....	597
Step 5: Firing Instant A-events.....	598
Adding Instant A-event .....	600
Step 6: Handling Stored A-events.....	601
Define the ACE Table .....	603
Define the ACE Stored Event.....	604
Step 7: Gluing it All Together .....	605
Step 8: Adding Bells and Whistles.....	606
En_agg_event_levels .....	606
En_agg_status_codes .....	606
Library Procedures .....	607
Agg_start() .....	607
Agg_stop() .....	608
Agg_get_connection_state().....	609
Agg_record_decode() .....	609
Agg_record_encode() .....	610
Agg_fire_instant_event() .....	610
Agg_stored_event_added().....	611
Agg_proc_stored_events().....	612
Agg_proc_timer() .....	612
Agg_proc_data() .....	612
Agg_proc_sock_event() .....	612
Agg_proc_data_sent() .....	613
Callback_agg_get_firmware_version().....	613
Callback_agg_device_function().....	613
Callback_agg_synchronized().....	614
Callback_agg_pre_buffrq().....	614
Callback_agg_buff_released().....	615
Callback_agg_error() .....	615
Callback_agg_convert_setting().....	616
Callback_agg_convert_event_field().....	617
Callback_agg_rtc_sg() .....	618
<b>DHCP Library .....</b>	<b>618</b>
Step-by-step Usage Instructions .....	619
Operation Details .....	621
Code Examples .....	622
Step 1: Code Example for the Ethernet Interface.....	622
Step 2: Code Example for the Wi-Fi Interface.....	624
Step 3: Adding Bells and Whistles.....	628
Step 4: Adding More Bells and Whistles.....	631
Library Defines (Options) .....	634
En_dhcp_status_codes .....	635
Library Procedures .....	635
Dhcp_get_info() .....	636
Dhcp_start() .....	636
Dhcp_stop() .....	637
Dhcp_proc_timer() .....	637
Dhcp_proc_data() .....	638
Callback_dhcp_ok() .....	638
Callback_dhcp_failure() .....	639
Callback_dhcp_pre_clear_ip().....	639
Callback_dhcp_pre_buffrq().....	640
Callback_dhcp_buff_released().....	640
<b>FILENUM (File Numbers) Library .....</b>	<b>641</b>
Step-by-step Usage Instructions .....	641
Operation Details .....	642
A Code Snippet .....	642
Library Defines (Options) .....	643
Library Procedures .....	644

Filenum_get()	.....	644
Filenum_w ho_uses()	.....	644
Filenum_release()	.....	645
<b>GPRS (PPP) Library</b>	<b>.....</b>	<b>645</b>
Step-by-step Usage Instructions	.....	646
Operation Details	.....	647
Operation Details	.....	647
Code Example	.....	647
Library Defines (Options)	.....	650
En_gprs_status_codes	.....	651
Library Procedures	.....	652
Gprs_get_info()	.....	652
Gprs_start()	.....	652
Gprs_stop()	.....	653
Gprs_proc_timer()	.....	653
Gprs_proc_sock_data()	.....	653
Gprs_proc_ser_data()	.....	654
Callback_gprs_ok()	.....	654
Callback_gprs_failure()	.....	654
Callback_gprs_pre_buffrq()	.....	655
<b>PPPOE Library</b>	<b>.....</b>	<b>655</b>
Step-by-step Usage Instructions	.....	656
Operation Details	.....	657
Code Example	.....	657
Library Defines (Options)	.....	659
En_pppoe_status_codes	.....	660
Library Procedures	.....	660
Pppoe_get_info()	.....	660
Pppoe_start()	.....	661
Pppoe_stop()	.....	661
Pppoe_proc_timer()	.....	662
Pppoe_proc_data()	.....	662
Callback_pppoe_ok()	.....	662
Callback_pppoe_failure()	.....	662
Callback_pppoe_pre_buffrq()	.....	663
<b>SOCK (Socket Numbers) Library</b>	<b>.....</b>	<b>664</b>
Step-by-step Usage Instructions	.....	664
Operation Details	.....	665
A Code Snippet	.....	665
Library Defines (Options)	.....	667
Library Procedures	.....	667
Sock_get()	.....	667
Sock_w ho_uses()	.....	668
Sock_release()	.....	668
<b>STG (Settings) Library</b>	<b>.....</b>	<b>668</b>
Controlling Your Device Through Settings	.....	670
Setting Configurator	.....	670
Library Options	.....	671
Editing Settings	.....	673
Dot-decimal Settings	.....	674
Max Number of Members	.....	675
P1 and P2 Parameters	.....	675
Default Setting Values	.....	675
Step-by-step Usage Instructions	.....	676
Getting Started	.....	676
Verifying and Initializing Settings	.....	677
Writing and Reading Settings	.....	678
Using Stg_sg()	.....	678
Using Stg_get() and Stg_set()	.....	679

Using Setting Numbers .....	680
Working With Multi-value Settings.....	681
Understanding Timestamps.....	681
Using Pre-gets and Post-sets.....	683
Operation Details .....	684
Sample Project .....	686
Step 1: The Embryo .....	686
Step 2: Adding Setting Initialization.....	687
Step 3: Adding Comms .....	688
Step 4: Completing the Project.....	689
Stg_timestamp Global Variable.....	689
En_stg_status_codes .....	690
Library Procedures .....	690
Stg_start() .....	691
Stg_check_all() .....	691
Stg_get_def() .....	692
Stg_restore_multiple() .....	692
Stg_restore_member() .....	693
Stg_get_num_settings() .....	694
Stg_get_num_members() .....	694
Stg_find() .....	695
Stg_stype_get() .....	696
Stg_get() .....	696
Stg_set() .....	697
Stg_sg() .....	698
Stg_set_ts() .....	699
Callback_stg_error() .....	700
Callback_stg_pre_get() .....	700
Callback_stg_post_set() .....	701
Callback_stg_vm_read() .....	702
Callback_stg_vm_write() .....	703
<b>WLN (Wi-Fi Association) Library .....</b>	<b>703</b>
Step-by-step Usage Instructions .....	705
Operation Details .....	706
Code Examples .....	707
Step 1: The Simplest Example.....	708
Step 2: Adding TCP Comms.....	710
Step 3: Trying WPA .....	711
Step 4: Roaming Between Access Points.....	716
Library Defines (Options) .....	721
En_wln_status_codes .....	722
Library Procedures .....	723
Wln_get_info() .....	723
Wln_start() .....	724
Wln_stop() .....	725
Wln_change() .....	725
Wln_rescan() .....	726
Wln_wpa_mkey_get() .....	727
Wln_check_association() .....	728
Wln_proc_timer() .....	728
Wln_proc_data() .....	728
Wln_proc_task_complete().....	729
Wln_proc_event() .....	729
Callback_wln_ok() .....	729
Callback_wln_failure() .....	730
Callback_wln_pre_buffrq().....	730
Callback_wln_mkey_progress_update().....	731
Callback_wln_rescan_result().....	731

**Update History (for this Manual)**

**732**

# Taiko R2

**Last update: 01SEP2012**

[Legal Information](#)<sup>[1]</sup>

[Manual Update History](#)<sup>[732]</sup>

Taiko is a solution which allows you to create programs for Tibbo modules capable of running TiOS (Tibbo Operating System), and products based on these modules.

With Taiko, you write your program in a language called Tibbo Basic (a close relative of any other BASIC you might already know), using a PC software called TIDE - Tibbo Integrated Development Environment. Your program is then compiled into a binary file and uploaded onto a Tibbo module. The Virtual Machine of TiOS then executes this binary.

Taiko allows you to easily create programs for a variety of Tibbo-based products. These may **include**:

- Alarm Panels
- Security Systems (Access control terminals, etc)
- Data Collection terminals, such as time clocks
- Sensor monitors
- Interface converters
- Vending machines
- Industrial process controllers

The solutions created with Taiko are very flexible. They are written using a language similar to BASIC, and are stored on a Tibbo module separately from the core OS of the module (TiOS). This allows for simple modification of your device functionality, even by the end-user (if you so allow).

Tibbo Basic itself is exactly the same for all TiOS-enabled devices. Hardware differences are expressed through so-called *platforms*. Change the platform, and you're programming for a different device.

## Documentation Map

The documentation for Taiko includes:

[Overview](#)<sup>[4]</sup> - The theory and background behind Taiko.

[Getting Started](#)<sup>[9]</sup> - An example starter project.

[Programming with TIDE](#)<sup>[15]</sup> -- An overview of TIDE itself, debug facilities, etc.

[Language Reference](#)<sup>[83]</sup> -- Systematically covers Tibbo Basic statements, keywords and operators.

[Development Environment](#)<sup>[119]</sup> -- Systematically covers TIDE GUI elements.

[Glossary of Terms](#)<sup>[136]</sup> -- Contains some basic terms used in Taiko.

[Platforms](#)<sup>[138]</sup> -- Platform-specific documentation for each target device.

## Legal Information

Tibbo Technology ("TIBBO") is a Taiwan corporation that designs and/or manufactures a number of hardware products, software products, and applications ("PRODUCTS"). In many cases, Tibbo PRODUCTS are combined with each other and/or third-party

products thus creating a PRODUCT COMBINATION.

Whereas you (your Company) wish to purchase any PRODUCT from TIBBO, and/or whereas you (your Company) wish to make use of any documentation or technical information published by TIBBO, and/or make use of any source code published by TIBBO, and/or consult TIBBO and receive technical support from TIBBO or any of its employees acting in an official or unofficial capacity,

**You must acknowledge and accept the following disclaimers:**

1. Tibbo does not have any branch office, affiliated company, or any other form of presence in any other jurisdiction. TIBBO customers, partners and distributors in Taiwan and other countries are independent commercial entities and TIBBO does not indemnify such customers, partners or distributors in any legal proceedings related to, nor accepts any liability for damages resulting from the creation, manufacture, importation, advertisement, resale, or use of any of its PRODUCT or PRODUCT COMBINATION.
2. BASIC-programmable devices ("PROGRAMMABLE DEVICES") manufactured by TIBBO can run a variety of applications written in Tibbo BASIC ("BASIC APPLICATIONS"). Combining a particular PROGRAMMABLE DEVICE with a specific BASIC APPLICATION, either written by TIBBO or any third party, may potentially create a combinatorial end product ("END PRODUCT") that violates local rules, regulations, and/or infringes an existing patent granted in a country where such combination has occurred or where the resulting END PRODUCT is manufactured, exported, advertised, or sold. TIBBO is not capable of monitoring any activities by its customers, partners or distributors aimed at creating any END PRODUCT, does not provide advice on potential legal issues arising from creating such END PRODUCT, nor explicitly recommends the use of any of its PROGRAMMABLE DEVICES in combination with any BASIC APPLICATION, either written by TIBBO or any third party.
3. TIBBO publishes a number of BASIC APPLICATIONS and segments thereof ("CODE SNIPPETS"). The BASIC APPLICATIONS and CODE SNIPPETS are provided "as is" without warranty of any kind, either expressed or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. The entire risk as to the quality and performance of BASIC APPLICATIONS and CODE SNIPPETS resides with you. BASIC APPLICATIONS and CODE SNIPPETS may be used only as a part of a commercial device based on TIBBO hardware. Modified code does not have to be released into the public domain, and does not have to carry a credit for TIBBO. BASIC APPLICATIONS and CODE SNIPPETS are provided solely as coding aids and should not be construed as any indication of the predominant, representative, legal, or best mode of use for any PROGRAMMABLE DEVICE.
4. BASIC-programmable modules ("PROGRAMMABLE MODULES"), such as the EM1000 device, are shipped from TIBBO in either a blank state (without any BASIC APPLICATION loaded), or with a simple test BASIC APPLICATION aimed at verifying correct operation of PROGRAMMABLE MODULE's hardware. All other BASIC-programmable products including boards, external controllers, and developments systems ("NON-MODULE PRODUCTS"), such as the DS1000 and NB1000, are normally shipped with a BASIC APPLICATION pre-loaded. This is done solely for the

convenience of testing by the customer and the nature and function of pre-loaded BASIC APPLICATION shall not be construed as any indication of the predominant, representative, or best mode of use for any such NON-MODULE PRODUCT.

5. All specifications, technical information, and any other data published by TIBBO are subject to change without prior notice. TIBBO assumes no responsibility for any errors and does not make any commitment to update any published information.
6. Any technical advice provided by TIBBO or its personnel is offered on a purely technical basis, does not take into account any potential legal issues arising from the use of such advice, and should not be construed as a suggestion or indication of the possible, predominant, representative, or best mode of use for any Tibbo PRODUCT.
7. Any advance product or business information posted as news or updates of any kind (including Tibbo Blog posts, Tibbo Newsflashes, site news, forum posts and any other timely information posted by Tibbo personnel) shall not be construed as obligatory to TIBBO in any way, shape or form. TIBBO may change or delay any of its plans and product roadmaps without prior notice, and shall not be held liable for such changes to the extent permissible by the applicable law.
8. Neither TIBBO nor its employees shall be held responsible for any damages resulting from the creation, manufacture, or use of any third-party product or system, even if this product or system was inspired, fully or in part, by the advice provided by Tibbo staff (in an official capacity or otherwise) or content published by TIBBO or any other third party.
9. TIBBO may make non-English documentation or other information available at its discretion. Such texts may be the result of work done by third parties, and may not always be reviewed by TIBBO personnel. As such, these are not to be considered official statements by TIBBO. Any apparent inaccuracies, conflicts or differences in meaning between English-language and non-English texts shall always be resolved in favor of the English-language version.
10. TIBBO reserves the right to halt the production or availability of any of its PRODUCTS at any time and without prior notice. The availability of a particular PRODUCT in the past is not an indication of the future availability of this PRODUCT. The sale of the PRODUCT to you is solely at TIBBO's discretion and any such sale can be declined without explanation.
11. TIBBO makes no warranty for the use of its PRODUCTS, other than that expressly contained in the Standard Warranty located on the Company's website. Your use of TIBBO PRODUCTS is at your sole risk. TIBBO PRODUCTS are provided on an "as is" and "as available" basis. TIBBO expressly disclaims the warranties of merchantability, future availability, fitness for a particular purpose and non-infringement. No advice or information, whether oral or written, obtained by you from TIBBO shall create any warranty not expressly stated in the Standard Warranty.
12. LIMITATION OF LIABILITY. BY USING TIBBO PRODUCTS YOU EXPRESSLY AGREE THAT TIBBO SHALL NOT BE LIABLE TO YOU FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, CONSEQUENTIAL OR EXEMPLARY DAMAGES, INCLUDING, BUT

NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, GOODWILL, OR OTHER INTANGIBLE LOSSES (EVEN IF TIBBO HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES) RESULTING FROM THE USE OR THE INABILITY TO USE OF TIBBO PRODUCTS.

13. "Tibbo" is a registered trademark of Tibbo Technology, Inc.
14. Terms and product names mentioned on TIBBO website or in TIBBO documentation may be trademarks of others.

## Overview

Below is a summary of the major fundamentals and theory behind TIDE. This may sound intimidating, but it's actually quite simple. You *should* at least skim over the material herein, because it explains much of what comes next. In here you will find:

- [Our Language Philosophy](#)<sup>[4]</sup>
- [System Components](#)<sup>[7]</sup>
- [Objects](#)<sup>[8]</sup> (a very brief overview)
- [Events](#)<sup>[8]</sup>

## Our Language Philosophy

Several principles have guided us through the development process of Tibbo Basic. Understanding them would help you understand this manual better, and also the language itself. See below:

### A Bit of History

Years ago, programming for the PC was the nearly exclusive domain of engineers. The languages traditionally available, such as C, simply required you to be an engineer to program.

However, one day something interesting happened. Visual Basic\* and Delphi\*\* saw the light of day. And that changed quite a lot on the PC front. Suddenly, people who were not engineers were finding out that they could actually create something cool on their PC. You could say VB\* and Delphi democratized the PC software market.

The situation on the embedded systems market today is quite similar to the situation which existed for the PC market in the pre-VB era. Many embedded systems vendors do offer customizable or programmable solutions -- but to implement those solutions, you would really have to be an engineer and know C/C++ quite well. So, there was clearly a need for an easy-to-use programming system which would democratize this market, as well.

### Principle One: Easy To Write, Easy to Debug

Choosing BASIC as our inspiration was the natural thing to do, for us. It's a language which doesn't require you to be a professional engineer. It is easy to understand. This is why it is embedded into many non-programmer products, such as the Office suite. So we went for BASIC.

Another part of the user experience, and a major one, too, is debugging. Writing your application is just half the job. You also need to debug it and for embedded systems, this is where things typically start getting rough around the edges. Many times you have to buy expensive tools, such as ICE machines (In-Circuit

Emulators), just to figure out what your code is doing. Sometimes you don't even have the luxury of such a machine, and you actually debug by guessing and trying different things in your code.

With our system, one of our major goals was to offer a user experience which is close to debugging on the PC -- without the need for special tools, such as an ICE machine.

While your program is running on the target (embedded device), you actually see how it runs *on your PC*. You can step through it, jump to specific functions, check values of variables etc -- all from the comfort of your own PC.

### **Principle Two: Easy Doesn't Mean Sloppy**

Some modern programming languages use certain techniques to make life 'easier' for programmers. They might not require the programmer to explicitly declare the variables he's going to use ('implicit declaration'), or might do away with the need to specify the type for the variable (i.e, use 'variant variables' which can contain anything).

This has several disadvantages. For one, it is just sloppy. After several days of writing code like that, a programmer might not have a very clear-cut idea of what his program is doing, or where things come from. While this is something which may be subject to debate, the next disadvantage is quite real:

This is simply wasteful programming. These techniques can consume quite a lot of resources, specifically memory. On the PC, a variant used to store just 2 bytes of data might take up to 100 bytes. This isn't a problem, because PCs have so much memory these days that it is barely felt.

However, embedded systems are often low-cost and bare-bones, so physical memory is a truly valuable resource. Waste too much of it -- and you would find that your code can do very little. But manage it prudently, and your code will be capable of quite impressive feats even on your 'low-power' embedded system.

So our systems requires you to be more organized. The effort is worth it.

### **Principle Three: The Purity of Language**

Programming systems on the PC usually make no clear distinction between the 'pure' language constructs which perform calculations and control program flow, and hardware-dependant input/output. For example, many languages contain a print statement which prints something to the screen.

Since all PCs in the world are similar, this works. However, this makes little sense for embedded platform, which have vastly different input/output resources. Depending on the device, it may or may not have a screen, a serial port, networking etc etc.

In our system, we separated the language itself (what we call *the core language*) from the input/output of a particular device. Thus, the language itself remains the same, no matter what device you are programming for. The input/output part is hardware dependant, and changes from platform to platform.

When writing for a specific platform, you are provided with a set of platform-specific *objects*. These provide rich functionality and allow you to do 'real' work, such as printing messages to the serial port, communicating on the Internet or controlling motors and sensors.

Ideally, Tibbo Basic could run on a fridge just as well as it could run on a time and attendance terminal.

### **Principle Four: Thin and Agile**

A lot of embedded systems are built by scaling down larger desktop systems, and it shows. What's the point of using a super-fast processor if you load it with dozens of layers of nested calls?

All the code TiOS includes has been designed from scratch for running on a very simple processor, and optimized for control applications. It has been crafted to have the minimum possible ROM and RAM footprint and to run as fast as possible.

We built TiOS with Pareto's principle in mind. In other words, if a certain functionality is required by only 5% of applications and yet its existence adds 90% overhead, we did not include it. For example, we decided to use a static memory model for procedure variables. Memory is not allocated and deallocated dynamically -- It is assigned on compile-time, which results in great performance improvements.

### **Principle Five: No B.S**

... that is, no babysitting. Development systems intended for rapid application development on the PC will often try to handle every little error or problem the programmer may encounter. If a variable overflows, for example, they will *halt* execution and pop up an error to let him know. This makes sense for a PC-based product, because you are right there to see it halt.

However, when you are creating an embedded system, you expect it to run *at all times*, without halting. Nobody will be there to see any errors and babysit your system. Your device is simply expected *to work*.

This is a major difference also for the development process. In essence, since the whole language is built this way, you will also get much less errors even when doing seemingly 'strange' things, such as putting large values into variables that cannot hold them. The language will deal with it silently, in a very predictable and logical way -- but will not pop up an error.

### **Principle Six: Event-Driven Programming**

Users of VB and Delphi and other Windows-based tools will find this principle familiar. However, if most of your experience with BASIC was under DOS, you might find this slightly odd. Under DOS, you would expect a program to begin from the beginning, then continue and stop. They execute from top to bottom. This may be called *linear execution*.

For Tibbo Basic, this is not the case. The programs you will write will be *event-driven*. Your program will consist of a number of *event handlers* which will be fired (invoked) in response to specific things which happen to your system in real life. If your platform was a fridge, you might want to write a handler for a 'door opening' event. When the door is opened, an event is generated, and an event handler, with your code in it, is fired.


So, you could say that your event-driven application has no beginning and no end. Event handlers are called when events are generated, and in the order in which they were generated.

\* Windows, Visual Basic and VB are registered trademarks of Microsoft Corporation Inc.

\*\* Delphi is a registered trademark of Borland Inc.

## System Components

Taiko is a compound system. It consists of the following components:




**TIDE** is an acronym for Tibbo Integrated Development Environment. This is the PC program in which you will write your applications and compile them, and from which you will upload them to your target and debug them.

The **compiler** is a utility program, used by TIDE. The compiler processes your project files and creates an *executable binary file* (with a .tpc suffix, for Tibbo PCode).

The **target** is a separate hardware device, on which your program actually runs. When debugging code, it is connected to your computer running TIDE (see the link above) and TIDE can monitor and control it. This is called *cross-debugging*.

As covered under [Our Language Philosophy](#)<sup>[4]</sup>, Tibbo Basic is capable of running on various hardware devices. Each type of hardware device on which Tibbo Basic runs is called a *platform*.

And now, the anatomy of the target:



The **target** runs an operating system called TiOS (Tibbo Operating System).

TiOS runs two processes. One is the **Master Process**. This is the process which is in charge of communications (including communications with TIDE) and of generating events. The second process, which is under the control of the Master Process, is called the **VM** (Virtual Machine).

The VM is what actually executes your application. In essence, the VM is a processor implemented in firmware, which executes the compiled form of your application. The instructions it understands are called **P-Code**, which is short for pseudo-code. This is what the compiler produces. It is called pseudo-code because

it is not native binary code which the hardware processor can understand directly; instead, it is interpreted by the VM.

Since the VM is under the complete control of the Master Process, the actual hardware processor will not crash because of an error in your Tibbo Basic application. Your application may operate incorrectly, but you still will be able to debug it. The Master Process can stop or restart the Virtual Machine at will, and can exchange debug information with TIDE, such as report current execution state, variable values, etc.

Simply put, you can think of the VM as a sort of a 'sandbox' within the processor. Your application can play freely, without the possibility of crashing or stalling TiOS due to some error.

The **queue** is used to 'feed' your program with [events](#)<sup>[8]</sup> which it should handle. The Master Process monitors the various interfaces of the platform and generates events, putting them into the queue. The Virtual Machine extracts these events from the other side of the queue and feeds your program with them. Various parts of your program execute in response to events.

## Objects

*Objects* represent the various component part of your platform. For example, a platform with a serial port might have a *ser* object. A platform can be described as a collection of objects.

Under Tibbo Basic, the set of object you get for each platform is fixed. You cannot add new objects or create multiple instances of the same object.

Objects have properties, methods and events. A *property* can be likened to an attribute of the object, and a *method* is an action that the object can perform. [Events](#)<sup>[8]</sup> are described in the next section.

Objects are covered in further detail under [Objects, Events and Platform Functions](#)<sup>[82]</sup>.

## Events

An *event* is something which happens to an object. Plain and simple. A fridge might have door object with an `on_door_open` event, and a paper shredder might have a detector object with an `on_paper_detected` event.

Events are a core concept in Tibbo Basic. They are the primary way in which code gets executed.

The target device maintains an *event queue*. All events registered by the system go into this queue. On the other end of the queue, the Virtual Machine takes out one event at a time and calls an event handler for each event.

*Event handlers* are subroutines in your code which are 'fired' (executed) to handle an event. Often, event handlers contain function calls which run other parts of the program.

While processing an event, other events may happen. These events are then queued for processing, and patiently wait for the first event to complete before beginning execution.

All Tibbo Basic programs are single-threaded, so there is only one event queue. All events are executed in the exact order in which they were queued.

It may sometimes seem that some events should get priority over other events. This functionality is not supported under Tibbo Basic. This is not crucial, as events

tend to execute very quickly, and the queue ensures events are not forgotten.

## Getting Started

Below is a walk-through for a starter project which is written specifically for the EM202-EV and DS202.

Once you are done with this project, you will be able to press the button on the EM202-EV or DS202 and watch the LEDs blink "Hello World!" in Morse code.

- \* This project would actually run also on the EM202, EM200 and EM120 modules. However, these modules cannot work on their own, and you cannot easily test with them.

## Preparing Your Hardware

### Preparing a DS202

Before starting to use TIDE, you should upload the correct firmware to a DS202. Perform the following steps:

- Get `tios_EM202_xxx.bin` firmware file (the latest version) from the Tibbo website. `_100` in this filename stands for version 1.00, for example.
- Connect the DS202 to power (preferably, use adaptor supplied by Tibbo).
- Connect the DS using a network cable (WAS-1499 or similar) to the same hub your computer is connected to, or directly to the computer with a cross network cable (WAS-1498 or similar).
- Make sure your local firewall (such as the XP SP2 firewall) is disabled or does not block broadcast UDP messages. This is essential for communications between TIDE and the DS202 while debugging.
- Run Device Explorer (Start > Programs > Tibbo > Tibbo IDE > Device Explorer).
- You should see your device on the list. Select it.
- Click Upload > Load Firmware Through the Network.
- Select the firmware file, and click OK.
- The firmware will now be uploaded.
- For some firmware versions, you now have to manually reboot the DS (Disconnect and reconnect the power cable). The red Status LED should now blink rapidly. This is OK -- it means the TiOS firmware is loaded and the application program memory is empty.
- Proceed to [Starting a New Project](#)<sup>[10]</sup>.


- Of course, once you upload a device with the TiOS firmware, it is no longer a Device Server! So you cannot see it under DS Manager. You could program it so it would respond to DS Manager -- but by default it is a 'clean slate', and does not respond to DS Manager broadcasts.

If for some reason you cannot perform a network upload, you can perform a serial upload by selecting Upload > Load firmware Through the Serial Port. You

will then be prompted to select a COM port, turn the device off and turn it back on while pressing the SETUP button. Upload will then commence.

## Starting a New Project

To begin a new project, select File > New. You will be presented with the following dialog:



**Platform:** Select EM202 (you can use EM1000 as well)


**Available project types:** Select Empty Project.

**Project name:** Type 'Hello World'.

**Location:** Leave untouched, unless you have a good reason to change it.

**Transport:** leave it as is ("Taiko UDP Broadcast Transport")

**Target Address:** Click Browse. You will be presented with the following dialog:



The number (hopefully) displayed is the MAC address of your target. If you select it and click Buzz, you should see the LED pattern on your target switch off momentarily. This means it is correctly detected.



If you see nothing in this dialog, it means your target isn't in communication with the computer. This is probably a power problem, or a networking problem. Perhaps you have a local firewall on the computer which blocks UDP broadcasts, such as the Windows XP Firewall. To fix this, disable the firewall or configure it to open a specific port.

Once you have located your target, click Select. You will be returned to the previous dialog, and the MAC address for your target will appear under Target Address.

You have now specified all of the required settings for a new project. Click OK and proceed.

## Writing Code

Once you have started your new project, you will be presented with a blank file (main.tbs).

We will now begin writing the actual code in this file. We will construct this project from beginning to end, step by step. For your convenience, the end of this section contains a complete copy of the project without comments. You can copy and paste the whole thing into TIDE, or just copy and paste the commented sections one by one as they appear below.

Here goes:

```
' Comments cannot spill over to the next line. If you see this happening in
this manual, it is a result of the help system -- not an actual feature.

Dim hello_world As String ' define a variable which will hold the whole
pattern we will play.

Dim length, play_position As Integer ' length is a calculated integer which
will contain the whole length of the string we will play, and play_position
```

will contain our current position in this string (how much we have played so far).

```
Const PAT_PLAY_CHUNK_LENGTH = 15 ' define a constant for the size of the
chunk we will play. We will play one chunk of the pattern at a time, and
then move on to the next chunk. Each chunk is 15 'steps' long.
```

```
Declare Sub play_next ' let the compiler know that there is a sub called
play_next. This sub will be used in code before being created so we must
declare it.
```

Notice that we are defining a *chunk* above. The reason for this is that we are going to play quite a long and complex pattern (over 130 steps in length), but the pattern object (*pat.*) used to play the pattern only supports patterns of up to 16 steps. So we have to play our pattern in parts, one after the other, and track our progress through the pattern (this is what the counters are for).

So far, we have prepared the ground. Let us move to the first piece of executable code:

```
sub on_sys_init ' event handler for the init event. Fires whenever the
device powers on.
    hello_world = ' here we define the contents of our string, in morse.

        'R is Red LED, G is Green LED. GGG means a long pulse of the
green LED (line). R means a short pulse of the Red LED (dot). Line (-) means
both off.

        'HELLO .... . .-.. .-.. ---
"R-R-R-R---R---R-GGG-R-R---R-GGG-R-R---GGG-GGG-GGG" +
"-----" + ' A period of silence between words
'WORLD .-.. --- .-.. .-.. ---
"R-GGG-GGG---GGG-GGG-GGG---R-GGG-R---R-GGG-R-R---GGG-R-R" +
"-----" +
'! ..--..
"R-R-GGG-GGG-R-R-"
    length = len(hello_world) ' Calculate total length of string.
    play_position = 1 ' Initialize play_position as we haven't played
anything yet.
end sub
```

We will now write the event handlers for our code.

First, we want the pattern to start playing whenever you press the button. For this, our platform offers a button object, which generates an `on_button_pressed` event. Instead of typing, you can create the event handler for this event by double-clicking on the event name in the [project tree](#)<sup>134</sup>.

```
sub on_button_pressed ' event handler fired whenever the button is pressed
    play_position = 1 ' start playing from the beginning of the pattern
    play_next ' call the routine which plays the next chunk (the first
chunk, in this case)
end sub
```

Notice that the `play_next` routine is not yet defined. In our code, it is first used and then defined. This is why we have to [declare](#)<sup>[84]</sup> it at the beginning.

Now, let us move on to the next event handler:

```
sub on_pat ' this fires whenever a pattern (a chunk, in our case) finishes
playing.
    play_next ' call the routine which plays the next chunk
end sub
```

We have now completed writing our event handlers. Our program now knows what it's supposed to do whenever you press the button, and whenever a chunk of the pattern finishes playing. It just doesn't know *how* to do it yet. This comes next:

```
sub play_next ' plays the next chunk of our large pattern.
    if length < play_position then exit sub ' if we have reached the end of
the pattern, stop.

    dim chunk_len as integer ' internal integer for the length of current
chunk to be played.

    chunk_len = length - play_position + 1 ' calculate how much of the
large string is left.

    if chunk_len > PAT_PLAY_CHUNK_LENGTH then chunk_len =
PAT_PLAY_CHUNK_LENGTH ' if too much is left, we bite off only a chunk we can
process.

    dim chunk as string ' will contain the chunk which will actually play
now.
    chunk = mid(hello_world, play_position, chunk_len) ' chunk is the part
of hello_world which begins at play_position and is as long as chunk_len.

    pat.play(chunk, YES) ' Play this chunk. YES means the pattern may be
interrupted -- you can press the button while the pattern is playing, and it
will start again from the top.

    play_position = play_position + chunk_len ' advance play_position to
account for the chunk we played.

end sub
```

Here is the whole project, without comments:

```
'=====
===
'           HELLO WORLD IN MORSE CODE (for EM202-EV, DS202)
'=====
===

dim hello_world as string
dim length, play_position as integer

const PAT_PLAY_CHUNK_LENGTH = 15
```

```

declare sub play_next

'-----
---
sub on_sys_init
    hello_world =
        "R-R-R-R---R---R-GGG-R-R---R-GGG-R-R---GGG-GGG-GGG" +
        "-----" +
        "R-GGG-GGG---GGG-GGG-GGG---R-GGG-R---R-GGG-R-R---GGG-R-R" +
        "-----" +
        "R-R-GGG-GGG-R-R-"
    length = len(hello_world)
    play_position = 0
end sub

'-----
---
sub on_button_pressed
    play_position = 1
    play_next
end sub

'-----
---
sub on_pat
    play_next
end sub

'-----
---
sub play_next
    if length < play_position then exit sub

    dim chunk_len as integer
    chunk_len = length - play_position + 1
    if chunk_len > PAT_PLAY_CHUNK_LENGTH then chunk_len =
PAT_PLAY_CHUNK_LENGTH

    dim chunk as string
    chunk = mid(hello_world, play_position, chunk_len)
    pat.play(chunk, YES)
    play_position = play_position + chunk_len
end sub

```

## Building, Uploading and Running

Once you are done with writing your project, it is time to build, upload and run it. These three operations can be done by pressing F5.

Press F5 and wait. You will see your project compiling. The [output pane](#)<sup>[133]</sup> will display any errors (if you copied the project as it is, there should be no errors).

The [status bar](#)<sup>[130]</sup> will show you the project building, uploading, and running.

Once the status bar says RUNNING, you may press the button on your device to see it blink "Hello World" in Morse.

For further information about these topics, please see [Making, Uploading and Running an Executable Binary](#)<sup>[26]</sup> and [Debugging Your Project](#)<sup>[28]</sup> below.

## Compiling a Final Binary

The binary executable file you compiled in the previous step is called a [debug binary](#)<sup>[27]</sup>. This type of binary is used while creating your project and debugging it.

When you decide your project is ready to be deployed in the real world, you should compile a [release binary](#)<sup>[27]</sup>. To do this, select Project > Settings and uncheck the Debug version checkbox.

Use Project > Build and Upload to upload the compiled binary into the target. It will automatically start running whenever the device is powered up, and all debug functions will be disabled.

This compiled application binary file will also remain on your hard drive, inside your project folder (see [Starting a New Project](#)<sup>[10]</sup>). You may [upload it](#)<sup>[41]</sup> to any number of devices using the [Device Explorer](#)<sup>[39]</sup>.

You can optionally protect the firmware and application loaded into your device with a [password](#)<sup>[41]</sup> (strongly recommended).

## Programming with TIDE

The topics below attempt to give you a general understanding about working with TIDE. An attempt has been made to lay them out as logically as possible; it would be advised to just read the section from top to bottom and follow the links every time you don't understand a term.

The section called [Managing Projects](#)<sup>[15]</sup> provides an overview of the general structure of a Tibbo Basic project, and also discusses the debugging process.

The next section, [Programming Fundamentals](#)<sup>[43]</sup>, then delves into the specifics of Tibbo Basic programming, including the differences between Tibbo Basic and other languages you may know.

## Managing Projects

Each program you will make with Tibbo Basic is actually a project. Projects include certain files, and have a specific structure. They are compiled into binary files, uploaded onto your target and debugged.

In this section:

- [The Structure of a Project](#)<sup>[16]</sup>
- [Creating, Opening and Saving Projects](#)<sup>[17]</sup>
- [Adding, Removing and Saving Files](#)<sup>[18]</sup>
- [Resource Files](#)<sup>[20]</sup>
- [Built-in Image Editor](#)<sup>[20]</sup>
- [Coding Your Project](#)<sup>[22]</sup>
- [Making, Uploading and Running an Executable Binary](#)<sup>[26]</sup>
- [Debugging Your Project](#)<sup>[28]</sup>
- [Project Settings](#)<sup>[38]</sup>
- [Device Explorer](#)<sup>[39]</sup>

- [Protecting Your Device with Password](#)<sup>[41]</sup>

## The Structure of a Project

A *project* is a collection of related files and resources, which are then compiled into one final binary file, uploaded onto a target and run. Projects include actual source files, HTML files (if any), images (if any), etc.

Your project's files come from two distinctive places: the *project folder* and the *source libraries folder*. Files in the project folder are really "your" project's files. Your project may (and should) make use of [free libraries](#)<sup>[580]</sup> provided by Tibbo. You don't have to copy library files into your project folder -- you can add them directly into you project (see [Adding, Removing, and Saving Files](#)<sup>[18]</sup>, "Adding existing files to your project").

- \* Want to modify a library? Then you really better copied this library's files into your project's folder. It is a very bad practice to modify the files in the library folder.

Here are the files that form a project:



**Project file:** A single file with a **.tpr** extension. Contains project settings, and a list of all files included with the project. You don't have to edit this file manually -- TIDE handles it for you. This file is always kept in the project folder.



**Header files:** Multiple files with a **.tbh** extension. Used for inclusion into other files; usually contain declarations for global variables, constants, etc.



**BASIC files:** Multiple files with a **.tbs** extension. Contain the actual body of your program.



**HTML files:** Multiple files with an **.html** extension (displayed with the currently associated icon). Contain webpages to be displayed by the embedded webserver of your device. These can include blocks of Tibbo Basic code. See [Working with HTML](#)<sup>[79]</sup>.

(Any icon)

**Resource files:** Multiple files without any preset extension. Contain resources (such as images) needed for other files. Some resource files (.cfg, .txt, .ini) can be edited from within TIDE:


- *.cfg*, *.txt*, and *.ini* files are considered to be text files and can be edited using TIDE's built-in text editor.
- *.bmp*, *.jpg*, and *.png* files are graphical files; these will be opened using TIDE's built-in [image editor](#)<sup>[20]</sup>.

- \* Note that the only really *fixed* extension is the one for the project file -- **tpr**. This file contains references to other files within the project. These may use any extension, as long as their type is correctly stated in the project file (this is selected when adding the file, as described [here](#)<sup>[18]</sup>).

The extensions above are the default extensions which are associated with TIDE, and we recommend keeping them.

## Creating, Opening and Saving Projects

To create a new project, select File > New. The following dialog will appear:



**Platform:** The [platform](#)<sup>[138]</sup> on which your project will run.

**Source library set:** Tibbo libraries come in sets. Each set has a version number. Once you choose the library set for your project, it will be used until you change it. Tibbo will keep releasing new library sets. With each new release we will check if backward compatibility has been lost due to new features. If backward compatibility is lost, we will publish the new library set under the new version number. Old library sets will still be distributed and your project will keep compiling without any errors. For new projects, always choose the current library set as defined in the [Library Reference](#)<sup>[580]</sup>.

**Available project types:** Only an Empty Project template is currently offered.

**Project name:** A short name for your project. TIDE will use this name to create a folder for your project, and also to create a project file (.tpr) within this folder.


**Location:** The folder which will contain your project folder.

**Target address:** *Platform-specific.* See [platform](#)<sup>[138]</sup> documentation. The address of the target you will use for debugging and testing this project. This should be a reachable address with a live target. Your project will still be created even if you do not specify this parameter, but you will not be able to upload or debug until you specify the target using the [Project Settings](#)<sup>[38]</sup> dialog.

## Adding, Removing and Saving Files

### Files tab


You can see what files are included in your project at any given time using the Files tab of the [Project pane](#)<sup>[134]</sup>. Notice that the project structure includes a separate branch for [library files](#)<sup>[580]</sup>. These come from the currently selected library set. Library set is defined when [creating new project](#)<sup>[17]</sup> or [editing project settings](#)<sup>[38]</sup>.



### Adding New Files to Your Project

- To add new files to your project, click Project > Add New File or click the Add new file button on the Project Toolbar.

You will be presented with the following dialog:



Specify a name for your file under Filename. If you also specify an extension, the Type listbox will update, too. Automatically recognized file types are:

- *.bas* -- basic files
- *.tbh* -- header files


- *.htm, .html* -- HTML files
  - *.bmp, .jpg, .png, .gif, .ico, .pcx* -- resource graphics files
  - *.txt* -- resource text files
  - all other file extensions are classified as binary resource files by default.
- You can still set the file type regardless of the extension -- just select what you need in the Type listbox.

Adding [image](#)<sup>[20]</sup> files to the project will prompt an additional request for size in pixels, etc.

### Adding Existing Files to Your Project

- To add existing files to your project, click Project > Add Existing File or click the Add existing file button on the Project Toolbar.

You will be presented with the following dialog:



- Under Base location you can select either Project Folder or Source Library Set Folder. In the latter case the file you add is expected to reside in the source libraries folder, inside the currently selected library set. You defined the set to be used when [creating](#)<sup>[17]</sup> the project. You can also change it through the [Project Settings](#)<sup>[38]</sup> dialog.
- Once you selected the location, browse for the filename.
- You may need to make an appropriate selection of file Type and Format.

### Removing Files from Your Project

- To remove a file from your project, first select (single-click) it in the project tree. Then click Project > Remove File or click the Remove button on the Project Toolbar.

You will be presented with a prompt. If you're sure you want to remove the file,

select OK, and the file will be removed from the project. Note that it is not physically deleted -- only removed from the project tree.

### Saving Files

-  To manually save your work, select File > Save, press Ctrl+S, or click the Save button on the Project Toolbar.

Any of these actions would save all open and modified files in your project, including the project file itself.

In addition, every time your project is compiled, all open and modified files are saved.

## Resource Files

Sometimes a project may need access to certain files which are not Tibbo Basic code per se; these may be [image](#)<sup>[20]</sup> files, sound files or any other fixed binary data which is not to be interpreted or modified by the Tibbo Basic compiler but simply used as-is within the project.


These files are not modified or compressed in any way; they are merely included within the final, compiled [binary file](#)<sup>[28]</sup> and may be accessed from within the program or by the built-in HTTP server.

Resource files are included in the [project tree](#)<sup>[134]</sup> under the Resource Files branch.

## Built-in Image Editor

Beginning with release **2.0**, TIDE features a simple image editor that "knows" how to work with *.bmp*, *.jpg*, *.png*, and *.gif* files. The editor is primarily intended for bitmap-level jobs such as preparing "screens" for a device with an LCD display.

All features of the image editor are fairly standard and we see no need in discussing image editor's functionality in details. Image files are [added](#)<sup>[18]</sup> to the project as any other resource files. When adding an image file to the project you will be presented with a choice of selecting RGB or palette color mode for this file. Depending on your choice the [Colors pane](#)<sup>[135]</sup> for this image will display available palette colors...




... or RGB color selector:



Double-clicking on the image file with *.bmp*, *.jpg*, *.png*, or *.gif* extension opens the image editor.

All image-related editing functionality is concentrated within [Image menu](#)<sup>124</sup>...



...and [Image Editor toolbar](#)<sup>127</sup>:




## Coding Your Project

TIDE contains a code editor with the following facilities:

- Syntax highlighting
- [Auto-Completion](#)<sup>[23]</sup>
- [Hinting](#)<sup>[24]</sup>
- [Tooltips](#)<sup>[24]</sup> for properties, events, functions, and even user-configurable tooltips for user-defined functions.

## Project Browser



The Project Browser contains a tree of all objects in the platform (with their methods, properties and events), as well as all procedures and global variables of your project. The tree is updated in real time, using a dynamic background parser which constantly analyzes your source code.

The tree features [icons](#)<sup>[136]</sup> for the various constructs.

An icon next to an event is grayed (inactive) if this event does not have an event handler implemented in the project. The icon becomes "active" when the event handler is created. An icon next to a procedure is grayed if this procedure is merely declared but does not yet have a body. The icon becomes active once the procedure is implemented ("gets" a body). Same applies to global variables -- gray

icon next to variables that are declared but not yet defined, active icon for defined global variables.

Double-clicking on an event which does not yet have an event handler will create an empty event handler procedure for this event at the bottom of the currently active file. Double clicking on an event which already has an event handler will make the cursor jump to this event handler.

Double-clicking on a procedure which does not yet have a body will make the cursor jump to the location where this procedure is defined. Double-clicking on a procedure which already has a body will make the cursor jump to this body.


Double-clicking on a global variable which is not yet defined (using the [dim statement](#)) will make the cursor jump to the location where this variable is declared (using the [declare statement](#)). Double-clicking on a defined global variable will make the cursor jump to the location where this variable is defined.

Hovering the cursor over an item in the displays a [tooltip](#) for this item. Additionally, when in debug mode, hovering the cursor over global variables and object properties displays their current values.

Notice, that currently selected platform is displayed next to the project name in the topmost tree node.

## Code Auto-completion

If you type an object name followed by a dot, the TIDE will pop-up a code-completion box. It looks like this:




This list also supports [tooltips](#) -- they are displayed as you scroll down the list. You can also hover the mouse over an item in the list to see its tooltip.

Code completion box is also displayed for the [structures](#) in your project:



You can also get a list of constants related to your construct. For example, by

typing "ser.enabled=" you will get a list of possible values of this property:



- By pressing Alt+Ctrl+T when the cursor is directly to the right of any meaningful Tibbo Basic construct, you will get a pop-up list with the appropriate contents for the current context. If the cursor isn't immediately to the right of any such construct, you will get a list containing all platform enumeration types, constants, objects and events.

## Code Hinting<sup>3</sup>

*Code hinting* is a feature which helps you see what are the arguments for a function, while writing the code for it. It appears as soon as you type the opening parentheses for a procedure. It looks like this:




You can see the number of arguments required and their types, as well as the return type (if any). The highlighted part shows what syntax element you should type in next.

- You may invoke code hinting manually by pressing Ctrl+Shift+space.

## Tooltips<sup>1.6.4</sup>

When you hover your mouse over event handlers, object properties and methods, constants, procedures, and variables the TIDE displays *tooltips*. These look like this:



The tooltips are displayed when hovering over constructs in the code editor, the [Project Browser](#)<sup>[134]</sup>, [Watch](#)<sup>[33]</sup>, and the [Stack](#)<sup>[133]</sup> pane. They show a formal construct definition and a comment, if available.

- In the code editor, you may also display a tooltip with the keyboard by

pressing **Ctrl+T** when the cursor is within an event handler, a procedure, a constant or a global variable.

Tooltip text for properties, methods, and events comes from the platform file for the [platform](#)<sup>[82]</sup> selected in your project. You can add your own custom comments to the tooltips displayed for procedures and variables of your projects. What's more, you can use HTML formatting to make these comments look more readable! Here is an example:

```
function blink(num as integer) as boolean ' Blinks the lights. Input:
<br><b>num</b>- pattern # to "play". <b><font color=red> Do not set to 0.</font>
font>.

'... your code here ...

End Function
```

This would yield the following tooltip when hovering over the "blink" identifier (notice how HTML formatting improves tooltip readability):

```
sub blink(num as integer)
'Blinks the lights. Input:<br><b>num</b> - pattern # to "play". <b><font color=red>Do not set to 0.</font>
end sub
sub blink(num as short)
Blinks the lights. Input:
num- pattern # to "play". Do not set to 0.
```

[Supported HTML Tags](#)<sup>[26]</sup> section details which tags you can use to beautify your tooltips.

Your comment must be on the same line as the function definition, or immediately following it. The comment can contain multiple lines, if every line begins with a comment character. These lines must be consecutive -- with no blank lines in between. For example:

```
function blink(num as integer) as boolean ' USER-DEFINED. Blinks the lights.
' This is a very important function.

' And must be included in every application.

'... your code here ...

End Function
```

This would yield a tooltip with the text "USER DEFINED. Blinks the lights. This is a very important function." This would be as one paragraph -- line breaks are not displayed within the tooltip, unless you use **<br>** element. The third comment would not be included because it is preceded by a blank line.

As we will explain in the [Introduction to Procedures](#)<sup>[66]</sup>, there is a procedure definition (procedure body) and procedure declaration that merely states that the procedure exists. If both have comments than the comment in the procedure definition wins (takes precedence) over the comment in the procedure declaration.

Variables also have declaration ([declare](#)<sup>[84]</sup> [statement](#)<sup>[84]</sup>) and definition ([dim](#)<sup>[86]</sup> [statement](#)<sup>[86]</sup>). Comment in the definition wins.

Finally, your own comment placed in the event handler definition takes over the comment for this event that comes from the platform file.

## Supported HTML Tags

Here are the tags (HTML elements) that you can use:

- Presentation markup tags: `<b>`, `<i>`, `<big>`, `<small>`, `<s>`, `<u>`, `<font` [color=*color*] [size=*size*] [face=*face*]
- Headings `<h1>`...`<h6>`
- Line break `<br>`
- Comments: `<!-- -->`

All other tags (elements) cannot be used. Most of these tags are simply ignored, but some lead to scrambled text output.

- One peculiarity of the HTML renderer used in the TIDE software is that it often requires you to add an extra space before the closing tag in the tag pair. For example, if you write "`<b>Bold</b> text`" then you will get this output: "**Bold**text". Writing "`<b>Bold </b> text`" or `<b>Bold</b>text` will produce correct result: "**Bold** text".

## Making, Uploading and Running an Executable Binary

An *Executable Binary File* is a file (.tpc type) which contains your project in compiled form, along with any resource files. It is uploaded to the target, where it is actually executed by the TiOS Virtual Machine.

### Making a Binary

- Once you have the code which you wish to try out, you may build it by selecting Project > Build, by pressing the shortcut key F7 or by clicking the Build button on the Debug toolbar.

If this is not the first time you're building this project, the build process will skip any files which were unmodified since the last time the project was built. This optimizes build speed.

To force the build of all files, even those which were not modified since the last time, select Project > Rebuild All.

On build, the [Output pane](#)<sup>[133]</sup> will display any errors. You can double-click on the line describing an error to jump directly to the problematic line in your code.

### Uploading a Binary

Before uploading a binary, you must select the target device. You can do so using the [Device Explorer](#)<sup>[39]</sup>.

- To upload your project, you must select Project > Upload or click the Upload button on the Debug toolbar.

Before uploading, TIDE checks if the project has been changed since it was last built. If so, it builds the project again and attempts to upload the new build.

Also, the current project hosted on the target will be checked. If it is the same (same project and same build number) as the project you are trying to upload, uploading will not occur. Thus, trying to upload a project twice without making any change in the project will not result in a second upload. Also, before uploading, the firmware version is checked and if it is incompatible with the firmware version specified in the platform file, the upload is aborted with an error message.



As of version 2.20.33, TIDE supports *incremental uploads*. It caches the previous build on the computer; when you make a modification, it (1) makes sure the previous build is indeed what's currently running on your device, and then (2) compares the current build with the previous build, block by block. It then attempts to upload only what's changed. This can make rebuild times significantly faster. Your device needs to be running TiOS 3.10.00 or later to be able to take advantage of this feature.

## Running a Binary

For a [debug version](#)<sup>[38]</sup> (the default version type), uploading the binary does not automatically start its execution on the target. Once uploaded, it just sits there, waiting to be executed.

- To begin execution, select Debug > Run, press the shortcut key F5 or click the Run button on the Debug toolbar.

This action optionally builds and uploads your application, if needed. If a new upload was just performed, it also *reboots* the target before running it. This ensures that target starts running the newly uploaded program from a 'fresh' state.

- You may also reboot your device manually at any time by selecting Debug > Restart or clicking the Restart button on the Debug toolbar.
- These actions are *incremental*. This means that when uploading, a build is performed if needed. When running, a build and an upload are performed if needed.

## Two Modes of Target Execution

When you execute a program on the target, it can run in either of two modes (depending on the setting selected under [Project Settings](#))<sup>[38]</sup>:

### Debug Mode

In debug mode, your project runs with the assumption that you are right there, watching the monitor and trying to see what's going on. This means that the Debug menu is active. You can set up [breakpoints](#)<sup>[30]</sup>, or [step](#)<sup>[33]</sup> through your project, watch the variables, etc.

This also means the project might stop if there's an error, such as division by 0. And you can pause execution, stop it, etc.

Also, when uploading a project in debug mode, it does not begin to run by default.

By default, it waits for you to run it.

-  Selecting Debug > Run, pressing F5 or clicking the Run button on the Debug toolbar would send an explicit command to the target, to start running the project.

If the device reboots while a project is running in Debug Mode, the project will not start running automatically after the reboot. You would have to run it explicitly.

### Release Mode

Release mode means business. This is the mode in which you compile the final files, deployed in the field. Under this mode, the working assumption is that you, or anybody else, isn't there. Your box is just supposed to run and run, despite any and all problems and errors.

This means that a release version does not respond to any debug commands. You cannot stop it. It does not stop even when critical errors occur. It also means that when you upload a release version to your target, it starts running immediately.

Even if you reboot your device, when it has a Release Mode binary in memory, it will start running.

## Debugging Your Project

One of the most common operations you will perform during your development process is *debugging*. In essence, this involves controlled execution of your project. While debugging you can step through your program, set breakpoints, watch and change the state of various variables, see how control and decisions statements are executed, etc.

One of the aspects of TIDE is that it employs a technique called *cross-debugging*. Simply put, this means your code runs on a different machine than the one on which you wrote it, and you can debug it from the computer on which you wrote the program.

Thus, code is not debugged using some PC emulator or anything of this sort. It is truly uploaded and run on your target -- just like it would run in real life.

As covered [above](#)<sup>[26]</sup>, the first thing you would have to do to begin debugging a debug binary would be to run it, using F5. Once you press F5 (or Debug > Run), your project will be built (if necessary), uploaded (if necessary) and started.

Once execution has started, there are several ways in which you may control and inspect it. These are listed below.

## Target States

In debug mode, your target may be in one of several states at any given moment.

For this, the [status bar](#)<sup>[130]</sup> displays several different status messages:

-  **Run:** This message means your program is currently running. It doesn't mean any specific code is actually being executed -- perhaps the target device is just sitting idle, waiting for an event to happen. But the program is still running -- not paused. This state is entered by pressing F5 or Debug > Run.
-  **Break:** This message occurs when the Virtual Machine on the target was stopped while executing code. The easiest way to get to this state is by setting and reaching a [breakpoint](#)<sup>[30]</sup> in code. You might also get to this state by selecting Debug > Pause, if you happen to catch the Virtual Machine in the midst of code execution. Once in this

state, the [program pointer](#)<sup>[30]</sup> (a yellow line) is displayed and indicates the next instruction that the Virtual Machine will execute when started. You can now inspect and change various properties and variables (both global and local) using the [watch](#)<sup>[33]</sup>. This is the only state which allows [stepping](#)<sup>[33]</sup>.

PAUSE

**Pause:** This message occurs when the Virtual Machine on the target was stopped while not executing code (in other words, it was caught between events). No program pointer is displayed in this state, because no code is being executed. You can check and modify the state of properties and global variables, etc using the watch. This state is entered by selecting Debug > Pause.

ABORT(DIV0)

**Abort (exception):** This message indicates that an internal error has occurred. The message in parentheses is a short error code. If you hover your mouse over it, you will see a more detailed report of the error. The program pointer will appear at the problematic line. This state is similar to a break, only it is not caused by a breakpoint but by an abnormal condition. All possible causes for exception are listed in [Exceptions](#)<sup>[29]</sup>.

## Communication States

While TIDE is in communication with the target, the status bar displays a moving indicator of the communication state.



**Communication in progress:** The circle is green, and moves from side to side. It advances one step whenever TIDE gets a reply to a debug command.



**Communication problem:** The circle is yellow, and does not move. This state means TIDE did not receive any reply to debug commands for more than 6 seconds. The program may be still running on the target.



**No Communication:** The circle is red, and does not move. Occurs when TIDE did not receive any reply to debug commands for more than 12 seconds. The program may be still running on the target.

## Exceptions

Exceptions are "emergency" halts of program execution. Exceptions are generated when the Virtual Machine encounters something that really prevents it from continuing normal operation. When exception happens you see "ABORT" target state in the status bar, like this:

ABORT(DIV0)

"(DIV0)" is an abbreviated problem description. Hover the mouse over this and you will get a more detailed description.

Listed below are all possible exceptions. When you are in the [debug](#)<sup>[27]</sup> mode any exception from the list below causes the Virtual Machine to abort execution. In the [release](#)<sup>[27]</sup> mode, some "lesser" problems do not cause the halt. The logic here is that there will probably be nobody to restart the problem or check what happened anyway, so the Virtual Machine just tries to continue operation.

Cod e	Description	Halt in debug	Halt in release

		mode?	mode?
<b>DIV O</b>	Division by zero	Yes	No
<b>OO R</b>	Out of range (attempt to access past the highest array member)	Yes	No
<b>FPE RR</b>	Floating point error	Yes	No
<b>IOC</b>	Invalid opcode*	Yes	Yes
<b>OU M</b>	Access outside of user memory*	Yes	Yes
<b>TDL F</b>	Failed to load binary library*	Yes	Yes

\*This exception indicates that either TiOS or Tibbo Basic compiler is not functioning properly. Let us know if you encounter this exception!

## Program Pointer

The *program pointer* is a line, highlighted in yellow, which shows the present location of program execution. It looks like this:

```

> i = 5
  j = i + 5

```

This means that the yellow line is now pending execution. It hasn't been executed yet. The machine is waiting for you to tell it what to do. You can now control it by [stepping](#)<sup>[33]</sup>.

This line is displayed whenever the Virtual Machine has been paused while executing code. This can be achieved by setting a [breakpoint](#)<sup>[30]</sup>, or simply selecting Debug > Pause at the "right" time.

The program pointer will only stop on lines which contain *actual executable code*.

```

dim x as byte ' the program pointer won't stop here, as this isn't
executable code.
x = 1 ' the program pointer will stop here -- this is an actual instruction
to do something.

```

## Breakpoints 3

A *breakpoint* is a point marking a line of code in which you wish to have the debugger pause. It is seen as a little red dot on the left margin of the code. Like this:

```

● dim break as string
  break = "dance"

```

This is what it looks like when the code is not executing.

Once the code begins to execute and the breakpoint is reached, the [program pointer](#)<sup>[30]</sup> is displayed at the line in which the breakpoint is placed:

```
dim break as string  
break = "dance"
```

The yellow arrow over the red dot merely marks the program pointer; a breakpoint is always marked by a red dot.

### Where a Breakpoint May Be Placed

A breakpoint may be placed only on a line which contains executable code; before compiling your project, you could place breakpoints anywhere. However, on compile, these breakpoints will be shifted to the nearest lines following them which contain executable code.

You could add breakpoints to your code at any time -- even while the code is running. However, while the code is running, you may only add breakpoints next to lines which contain executable code. If you click next to a line which does not contain executable code, the closest line following this line which does contain executable code will get a breakpoint.

You may have up to 16 breakpoints in your entire project. Breakpoints are saved when the project is saved.

- Adding breakpoints slows down the performance of the Virtual Machine. Having 16 breakpoints will have a noticeable effect on the speed of execution of your program.

### Toggling Breakpoints

Breakpoints may be toggled (set/cleared) by putting the cursor in the line in which you wish to place (or remove) the breakpoint and pressing F9 or selecting Debug > Toggle Breakpoint. Alternatively, you may also toggle a breakpoint by clicking on the margin of the code at the point in which you wish to have a breakpoint.


You may remove all breakpoints from an entire project (including any files which are not currently open) by selecting Debug > Remove All Breakpoints.

## The Call Stack and Stack Pointer

During the execution of a program, procedures usually call other procedures. The calling procedures are not just left and forgotten; they are placed on the *call stack*.

The call stack can be toggled by View > Call Stack. It lists the sequence of procedure calls which lead to the current procedure (the one in which the [Program Pointer](#)<sup>[30]</sup> is located). The current procedure is listed at the top of the stack. Once it finishes executing, execution returns to the caller (the procedure one line below in the stack). In the caller procedure, execution resumes from the line immediately following the one which called the procedure which has just ended.

So, if the procedure (event handler, actually) **on\_timer** called the procedure **error\_handler**, which in turn called the procedure **write\_logfile**, our call stack would look like this:




When pausing a program in the midst of code execution, the [program pointer](#)<sup>[30]</sup> appears. In the Call Stack pane, the function which currently contains the program pointer is highlighted in yellow. It is the currently executing function, so it is always the first one on the Call Stack list.

- \* Technically speaking, the top function on the call stack isn't actually a part of the *stack* itself, because it is currently executing, and the real stack only contains functions to which execution should later return. It still appears on the same list, for consistency and convenience.

### The Stack Pointer

Double-clicking on any procedure within the call stack which is not the currently executing procedure would display the *stack pointer*. This pointer would be displayed in the source code, within the procedure you double-clicked, and would highlight the line from which execution would resume once control returns to this procedure. The [watch pane](#)<sup>[33]</sup> would also interpret variables as relative to the procedure you've just highlighted.

The stack pointer is light blue in color. On the call stack list, it looks like this:



In the code editing pane, it looks like this:

```


sub error_handler
dim x as integer
x = x + 5
write_logfile
end sub

```

Once again, double-clicking on the functions in the call stack *does not move actual execution* (the program pointer). Any sort of stepping would bring back the yellow program pointer, both in the source code and in the call stack.

## Stepping 1.8.5

The following commands in the Debug menu control stepping into, through and out of various sections of your code:



	Step <u>I</u> nto	F8,F11
	Step <u>O</u> ver	F10
	Step <u>O</u> ut	Shift+F11
	Run to <u>C</u> ursor	Ctrl+F10
	Jump to <u>C</u> ursor	Ctrl+F11

A *step* is an instruction to move the [program pointer](#)<sup>[30]</sup> to another line in source code. Stepping allows you to execute your code in a very controlled way, and work your way along the program in a pace which you can analyze and understand.

- **Step Into:** Steps through your code line by line. When the program pointer reaches a procedure call, you would actually see it step *into* this procedure (hence, the name). You could then see the inner workings of this procedure as it is being executed, line by line.
- **Step Over:** Steps through your code line by line. When the program pointer reaches a procedure call, it executes this entire procedure, but just does it all at once, and stops at the next line after the procedure call. This is useful when you want to debug a body of code which contains a call to a complex or lengthy procedure, which you do not want to debug right now.
- **Step Out:** If you are currently stepping through a function and wish to exit it while you're still in the middle, use Step Out. This would bring you to the line immediately following the line which called the function you were in. This option is disabled when you cannot step out of the current function (i.e, when your other function calls it -- such as in the case of an [event handler](#)<sup>[8]</sup>).
- **Run to Cursor:** The *cursor*, in this case, is the text insertion point. The little blinking black line. You can place the cursor anywhere within the body of your program and have the program execute until it reaches that point. When, and if, that point is reached, the program pointer would display.
- **Jump to Cursor:** This command makes the program pointer unconditionally move to the point where the cursor is. It will just *jump* there, possibly skipping the execution of some code. This is explicit control of program flow.

## The Watch 8.6


The *watch* is a facility which allows you to inspect and change the current value of variables and object properties. You can only use this facility when you are in debug mode and when the program execution is stopped. TIDE is unable to fetch variable values while the Virtual Machine is running. Depending on the scope of the variable, there may be [additional limitations](#)<sup>[37]</sup> as to when you can inspect this variable's value.

The watch updates variable values by reading them from the target every time the Virtual Machine is stopped. If any item on the list changed its value since the previous fetch, this item will be displayed in red.

Watch facility may be accessed by three different ways:

## The Watch Pane

The watch can be toggled by View > Watch. It looks like this:




On the above screenshot we can see the status of a **short**, a **string**, a **property** of an object, a member of an **array**, one user-defined **structure**, and an undefined **variable**. Notice, that the "x(y)" is displayed in red indicating that its value has just changed. Notice also that this line shows an array indexed by another variable (y). This is not the limit of the watch pane's abilities -- try entering more complex expressions, it will work!

There are several ways of adding variables and object properties to the watch list. You can:

- Press Insert while the watch pane has focus -- this will bring up an Add to Watch List dialog. Type the name of a variable or property to watch and press OK.
- Alternatively, double-click on the empty space in the watch pane to obtain the same result.
- You can also select Debug > Add to Watch List from the Menu.
- Additionally, there is an Add to Watch List button on the Debug toolbar.
- You can right-click on the variable or property in the source code and select Add to Watch List from the context-sensitive menu.
- You can also right-click on the property in the Project pane (Browser tab) and select Add to Watch List.


In the Add to Watch List dialog you may type multiple items to be added to the watch by separating their names with commas (i.e. "i, j, k, ser.num"). For objects you will get a drop-down list of available members:



Double-clicking the Name column in the watch pane will allow you to edit the name of the item you want to watch.

The watch pane also allows you to change the value of any variable or object property (provided it is not a read-only property). Double-click on the value field - you will be prompted for a new value.

For numerical variables, you may use hex or binary notation (&h, &b). For strings, you will be presented with the "HEX editor" allowing you to modify the string or the HEX codes of its characters:



Once a new value is entered, it will be actually written to memory on the target, and will be read again before being displayed in the watch. So when you see your new value in the value column, that means it's actually in memory now -- what you


see is what you get.

The watch pane is one of the places where enumeration types become very useful. Look at `sys.runmode` above. Because its possible values are described through an enum, you can see a meaningful state description, rather than just a number. This is one of the main reasons for the existence of enumeration types in Tibbo Basic.

To remove a variable from the watch, select it and press Delete, select `Debug > Remove from Watch List` or click the Remove from Watch List button on the Debug toolbar.

### The Watch Tooltip


This is the watch tooltip:



When you hover the mouse cursor over an identifier in the source while in debug mode you will see a tooltip with the current value for this identifier.

For now, this won't work for arrays. If you want to inspect the values of an array add this array to the watch list.

### The Project Browser



The Project Browser is a tab in the Project pane, which can be toggled by `View > Project`. It displays all objects for your platform, with the properties and methods for each object. It also displays all procedures and global variables in your project.

While debugging, you can see the value of an object property or a global variable by hovering over its identifier in the tree.

## Scopes in Watch

The watch facility is only active when the Virtual Machine is not running, i.e. the execution is stopped. Naturally, the TIDE cannot fetch variable values while the Virtual Machine is executing your program.

You already know that when the Virtual Machine is stopped, the [state of your target](#)<sup>[28]</sup> may be either "BREAK" or "PAUSE". Properties and global variables may be inspected in either state. Local variables only exist in their *context*. Hence, a particular local variable can only be inspected when the state is "BREAK" (the Virtual Machine is in the middle of a code execution -- there is an execution pointer visible) and when this variable exists in the *current context*.

For example:

```
sub sub_one
    dim x as byte
    x = 1
end sub

sub sub_two
    dim x as byte
    x = 2
end sub

sub sub_three
    dim i as integer
    i = 5
end sub
```

Let us say you add x to the watch list.

When the execution pointer highlights the **end sub** keyword for sub\_one, the value of x in the watch would be 1. When the pointer highlights the **end sub** for sub\_two, the value of x in the watch would be 2. Note that these are two *different local variables!*

Similarly, when the execution pointer is at the **end sub** of sub\_three, the x variable in the watch will be undefined -- it will display a question mark.

These same rules apply to the watch tooltip, as well. Even if you hover the mouse over the x of sub\_one when the program pointer is at the end of sub\_two, the value displayed would be the one set in sub\_two -- because this is the current context!

## Code Profiling

*Code Profiling* is the practice of measuring how long it takes for different portions of your program to execute.



This is the timer, located on the Status Bar.


Each time execution begins or resumes in debug mode, the timer is reset and starts counting. Once execution is stopped for whatever reason, the timer displays the time elapsed since execution has begun or resumed.

Remember, as covered [above](#)<sup>[30]</sup>, every additional breakpoint somewhat slows

down the speed of execution of your project.

## Project Settings

The Project Settings dialog is platform specific. It can look like this:



**Platform:** This is the platform selected for the project. In the image above, the [EM1000](#)<sup>[143]</sup> platform is selected.

**Customize:** click to access the list of option available for your platform. These are "global defines" (for a [preprocessor](#))<sup>[76]</sup>, which typically include options such as whether a display is present, display type, etc. For example, on the EM1000 platform you can enable/disable display support ([lcd](#))<sup>[317]</sup> object), flash disk support ([fd](#))<sup>[236]</sup> object), and keypad support ([kp](#))<sup>[304]</sup> object). Additionally, you get to choose the type of the display panel. Disabling objects when they are not in use reduces the size of your compiled application binary.

**Source Libraries Version:** Tibbo libraries come in sets. Each set has a version number. Once you choose the library set for your project, it will be used until you change it. Tibbo will keep releasing new library sets. With each new release we will check if backward compatibility has been lost due to new features. If backward compatibility is lost, we will publish the new library set under the new version number. Old library sets will still be distributed and your project will keep compiling without any errors. For new projects, always choose the current library set as defined in the [Library Reference](#)<sup>[580]</sup>.

**Project name:** A descriptive name for the project.

**Debug version:** If checked, the compiler will build a version of this project which can be debugged using the various debugging facilities within TIDE, such as step, watch, etc. Also, debug versions do not automatically start running after the upload or reboot. Release versions run automatically and can't be debugged. By default, this option is checked. Once you've debugged your project and wish to deploy it, uncheck this and build your final version.


**Output binary file name:** The name for the .bin file of the compiled project.

**Transport:** Selects the way that TIDE will use to communicate with your target. Available selections are platform-specific. See your device's platform documentation for more information on available debugging means. Also, [Debug Communications](#)<sup>[204]</sup> topic lists all currently available debug transports.

**Target address:** Different platforms may use different communication media between TIDE and target. Thus, their target address may be expressed differently. For devices with Ethernet port, the target address is the MAC address of the device.

**Select button:** click it to select the target device's address. For Ethernet devices, clicking the button brings up the [Device Explorer](#)<sup>[39]</sup>.

## Device Explorer



The Device Explorer is actually a standalone program. It can be found in the TIDE installation folder and launched independently. It is also accessible from within TIDE as a dialog (Project > Select/Manage Target).

The Device Explorer shows all Tibbo devices found on the current network segment. These may include serial-over-IP devices and programmable devices running TiOS. Some discovered devices may have two entries -- this happens when you have a TiOS device running serial-over-IP Tibbo BASIC application.

Only TiOS devices can be debug targets.

### Device list columns

**Icon:** The icon to the left of the MAC address shows the status of the device. It can be any of the following:

- Serial-over-IP device, valid IP address.

- Serial-over-IP device, invalid (unreachable) IP address.
- <%TIOS% device, no Tibbo BASIC application in its memory.
- <%TIOS% device, Tibbo BASIC application is loaded and running (executing).
- <%TIOS% device, Tibbo BASIC application is loaded and stopped.
- <%TIOS% device, Tibbo BASIC application is loaded and paused (for debugging).

**MAC:** This is the current MAC address of the device. It can be changed.

**IP:** The current IP address of the device. It can be changed for serial-over-IP devices. On <%TIOS% devices the IP can only be changed via Tibbo BASIC code.

**Version:** The version of the firmware this device is running.

**Comment:** Additional information. For serial-over-IP devices, this is the owner and device names. For <%TIOS% devices, this is the name of the Tibbo BASIC project currently loaded in memory.

You can click on any column header to sort the list by this column.

- Can't see your device in the list? It may not be connected to the same LAN segment (there is a router between your PC and the device), or your PC's firewall may be interfering. To fix this, configure the firewall to allow broadcast UDP datagrams from TIDE.

## Buttons

Button functions apply to the device currently selected (highlighted) in the device list. You can select several devices at once -- **Buzz**, **Upload**, and **Reboot** can be applied to multiple devices simultaneously!

Buttons are...

**Refresh:** repeat the search for devices.

**Buzz:** Make the selected device identify itself by "playing" a pattern on its [status LEDs](#)<sup>[200]</sup>. This is useful for finding out which physical device corresponds to the selected entry in the list. Serial-over-IP devices identify themselves by quickly flickering their red and green LEDs several times. <%TIOS% devices respond by turning their LEDs off for two seconds, but this only happens when Tibbo BASIC application is not executing. <%TIOS% devices that are running an application will not respond to buzz at all.

**Set Password:** you can protect the firmware and compiled Tibbo BASIC application loaded into your device by setting an access [password](#)<sup>[41]</sup> (strongly recommended). This password will then be required for MAC address changing, as well as firmware and/or application uploading.

**Change MAC:** Change the MAC address of the device. Note that you have to reboot the device for the change to become effective.

**Change IP:** Change the IP address of the device. This function is only available for serial-over-IP devices.

**Upload:** see [Upload Function](#)<sup>[41]</sup>.

**Reboot:** reboot the device.

**Abort:** Aborts the current operation. Device Explorer operations never time out --

you must abort them manually.

**Select:** This button is only shown when accessing the Device Explorer from within TIDE. Selecting the device means that TIDE will use the device as its debug target for the currently opened project. You can achieve the same by double-clicking on the device in the list.

**Close:** Close the dialog.

## Upload Function

**Upload** button has a fly-out menu:

- **Load Firmware Through the Network:** Upload new firmware, optionally with compiled Tibbo BASIC application binary attached, through the Ethernet interface. This can be simultaneously applied to a group of devices.
- **Load Application Through the Network:** Upload compiled Tibbo BASIC application through the Ethernet interface. This can be simultaneously applied to a group of devices.
- **Load Firmware Through the Serial Port (X-modem):** Upload firmware, optionally with compiled application binary attached, through the serial port of the device. For this to work, the device must be in the firmware upload mode.
- **Load Firmware Through the Debug Serial Port:** No publicly released Tibbo devices currently support this function.
- **Load Application Through the Debug Serial Port:** No publicly released Tibbo devices currently support this function.

### Loading firmware vs. loading application

"Load firmware" functions allow you to load the following:

- Firmware for "traditional" fixed-function serial-over-IP devices such as DS203.
- Firmware for TiOS devices.
- Firmware for TiOS devices combined with the compiled Tibbo BASIC application binary. This is a single file that in fact contains two parts.

"Load Application" function allows you to load compiled Tibbo BASIC application binary into TiOS devices.

## Protecting Your Device with a Password

Once you have created your Tibbo application, you can start deploying it into multiple devices. At this point, you are recommended to password-protect your device. Since Tibbo devices can be uploaded to and debugged through the network, anyone with the basic understanding of TIDE software can "mess up" with you device in many different ways and without even touching it physically. "They" can simply render the device unusable or, even worse, replace your application with a hacked one one that has additional undesirable "features". All this can be prevented by setting the device password.

### Setting device password

Passwords are set with the [Device Explorer](#)<sup>[39]</sup>. Select the device in the list, click

**Password** button to bring up **Change Device Password** dialog. Enter any password you want. From that point on, firmware and application uploads to the device will require this password. TIDE will prompt you to **Enter Device Password** every time it is needed. Check **Save password for this device** in the **Enter Device Password** dialog and TIDE will memorize the password (it will be stored in an encrypted file). This way, you won't have to input the password over and over again.

Your Tibbo BASIC application can also set the password on its own. This can spare you the trouble of manually protecting each device. You can find a code example in [Special Configuration Section of the EEPROM](#)<sup>[197]</sup>.

### Clearing the password

To remove the password, use the **Password** button of the Device Explorer and set an empty password. This, however, will require you to input the old (current) password as well. And what if you don't remember it? Read on...

### When you forgot the password


Simply press (and keep pressed) the [MD button](#)<sup>[201]</sup> of your device while clicking **OK** button in the **Change Device Password** or **Enter Device Password** dialog. This will make you device accept any password you enter. Pressing the MD button will not erase the password, but rather bypass it. This way you can change the old password (or remove it completely) without knowing what it was.

### How secure is it?

When the password is being set or changed, it is transmitted across the network "in the open". Therefore, set passwords in the secure environment where you can make sure that no one is "eavesdropping". Subsequent transmissions of the password to "login" onto the device (in order to upload firmware, etc.) are "safe". No data is transmitted in the open and eavesdropping on the data transmission will not reveal the password or render any useful data.

### How to remove passwords stored by TIDE

Open the Device Explorer and click on its icon (top left corner of the window). Select **Advanced Settings**. Click on **Clear Password Cache**. You are done.



## Programming Fundamentals

This chapter attempts to provide a very quick run through the fundamentals of creating a program in Tibbo Basic. It was written under the assumption that the reader has some experience in programming for other languages.

There is a marked resemblance between Tibbo Basic and other types of BASIC that you may already know. Thus, we stressed the differences between Tibbo Basic and other BASIC implementations. Some sections begin with a seemingly introductory statement, but the material quickly escalates into more advanced explanations and examples.

**This is not a programming tutorial.** We do not attempt to teach you how to program in general. There are many excellent books which already exist on this subject, and we did not set out to compete with any of them. This is a mere attempt at explaining Tibbo Basic -- no more, no less.

Good luck!

## Program Structure

A typical Tibbo Basic source code file (a [compilation unit](#)<sup>[136]</sup> with the [.tbs](#)<sup>[16]</sup> extension) contains the following sections of code:

### Include Statements

These are used to [include](#)<sup>[95]</sup> other files from the same project (such as header files [[.tbh](#)]<sup>[16]</sup> containing global variable definitions or utility functions). See:

```
include "global.tbh"
```

### Global Variables Definitions

Here you define any variables you wish to be accessible throughout the current compilation unit:

```
dim foo, bar as integer
```

### Subs and Functions

These are procedures which perform specific tasks, and may be called from other places within the project.

```
sub foo
...
end sub

function bar (a as integer) as byte
...
end function
```

### Event Handlers

Tibbo Basic is [event-driven](#). Event handlers are platform-dependent subs, that are executed when something happens. This 'something' depends upon your platform. If your Tibbo Basic program runs on a refrigerator, you would probably have an event handler for the door opening.

```
sub on_door_open
    light = 1 ' turn on the light when someone opens the door to your
    fridge.
end sub
```

Just like any other sub, events can have arguments (input parameters):

```
sub on_door_state(state as byte)
    ' turn the light on and off as the fridge door gets opened and closed
    if state=0 then
        light=0
    else
        light=1
    end if
end sub
```

Event handles are always subs and never functions (i.e. they never return any value as there is nobody to return it to)!

## Code Basics

There are several important things you should know about writing in Tibbo Basic:

### You Can Put Comments in Your Code

The apostrophe character marks the beginning of a comment. Anything following this character until the end of a line is considered to be a comment, and will not be processed by the [compiler](#)<sup>[136]</sup>.

```
x = 1 + 1 ' I am a comment!  
' x = y/0 <--- this line would not cause an error, because it won't even  
execute! It is commented.
```

The only exception to this is that when including an apostrophe within a string (between double quotes) it is not counted as a comment. See:

```
s = "That's a string!" ' Notice that the word that's contains an apostrophe.
```

Comments cannot span multiple lines. A line break terminates a comment. If you want to make a multi-line comment, each line of your comment must begin with an apostrophe.

### Tibbo Basic Doesn't Care About Spaces!

See:

```
y =   x   +           5 ' is just like  
y=x+5 ' and even this is OK:  
  
y =  
x  
+  
5
```

So, spaces, tabs and linefeeds carry no special meaning in Tibbo Basic. Use them or lose them, as you like. The only exceptions are the [If... Then... Else Statement](#)<sup>[94]</sup> and comments.

### Tibbo Basic Is Not Case Sensitive!

See:

```
Z = X + Y ' is just like  
z = x + y  
r = Q + KeWL ' even something like this is legal.  
DiM MooMoo As iNteGER ' this, distatesful as it may be, is still legal. :)
```

Capital letters just don't matter. Really.

### How to Use Double Quote Marks

Double quote marks are used for marking string literals. Simply put, a *string literal* is a constant string value -- like "hello world".

```
s = "I am a string literal!"  
s1 = s
```

### How to Use Single Quote Marks

These are different than the apostrophes which begin a comment. An apostrophe looks like this ' while a single quote mark looks like this ` and is usually located on the tilde (~) key. Single quote marks are used to define a numerical constant which contains the value for an ASCII code. For example:

```
dim b as byte  
dim w as word  
b = `q` ' the variable b now contains the value 113, which is the character  
code for q.  
w = `LM` ' this is also legal, see below.
```

The notation used in the second example above actually places the ASCII value of L into the higher byte of a [word-type](#)<sup>[48]</sup> variable, and the ASCII value of M into the lower byte of that variable. It may seem confusing at first, but it is also legal.



Note that a this isn't the same character as an apostrophe. An apostrophe is ' and a single quote-mark is a `. Usually, the single quote mark is found on the tilde (~) key, and the apostrophe is found on the double-quote (") key.

### How to Define Constants In Different Bases

Tibbo Basic allows you to assign values to constants using decimal, hexadecimal or binary notation. Decimal notation is the default. To assign a hexadecimal value, you must use the prefix **&h** before the first hexadecimal digit of your value. To assign a binary value, you must use the prefix **&b** in the same manner. So:

```
q = 15 ' this is 15, in decimal.  
q = &hF ' this is still 15, just in hex.  
q = &b1111 ' and this is also 15, just in binary notation.
```

These prefixes hold true whenever values are used -- there are no exceptions to this rule. Whenever a numeric value is used, it may be preceded by one of these prefixes and will be interpreted correctly.

## How to Use Colons

Colons are actually not necessary in most parts of Tibbo Basic. They are a traditional part of many BASIC implementations, and are often used to group several statements in one line. However, since Tibbo Basic doesn't really care about spaces anyway, they lose their relevance.

No Tibbo Basic statements require the use of colons.

## Naming Conventions

### Identifiers

An identifier is the 'name' of a constant, a procedure or a variable. It is case insensitive. It may include letters (A-Z, a-z), digits (0-9) and the following special characters: . ~ \$ !. It must start with a letter, and cannot contain spaces.

For example:

```
dim a123 as integer ' A legal example
dim 123a as integer ' An illegal example
dim a.something as integer ' Can contain dots.
sub my_sub (ARG1 as integer, ARG2 as string) ' This is also legal
```

### Platform Objects, their Properties and Methods

The name of an object is used as a prefix, followed by a dot, followed by the name of the property or the method you would like to access. For example:

```
ser.send ' Addressing the 'send' method of a 'ser' object.
x = ser.baudrate ' Assigning variable X with the value of the 'baudrate' of
a 'ser' object
```

### Events

Events are related to specific objects, just like properties and methods. However, events are named differently. The pattern is `on_objectname_eventname`. Such as `on_door_open`.

```
sub on_ser_data_arrival ' event names may contain more than one word after
the object name.
```

## Introduction to Variables, Constants and Scopes

Variables and constants are a major part of any programming language, and Tibbo Basic is no exception; below you will find explanations on the following:

- [Variables And Their Types](#)<sup>[48]</sup>
- [Type Conversion](#)<sup>[50]</sup>

- [Type Conversion in Expressions](#)<sup>[52]</sup>
- [Compile-time Calculations](#)<sup>[53]</sup>
- [Arrays](#)<sup>[54]</sup>
- [Structures](#)<sup>[58]</sup>
- [EnumerationTypes](#)<sup>[59]</sup>
- [Understanding the Scope of Variables](#)<sup>[61]</sup>
- [Declaring variables](#)<sup>[64]</sup>
- [Constants](#)<sup>[65]</sup>

## Variables And Their Types

Variables are used to store values during the execution of an application. Each variable has a *name* (the [identifier](#)<sup>[137]</sup> used to refer to the value the variable contains) and a *type*, which specifies how much data this variable can contain, and also what kind of data it may contain.

Not every variable type is supported on every platform. You will find related information in the "Supported Variable Types" topic in the platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>). If you attempt to use a type which is not supported by your platform you will most probably get "platform does not export XXX function" error during compilation.

Variables are defined using the [Dim Statement](#)<sup>[86]</sup> prior to being used in code. The simplest syntax for defining a variable would be something like:

```
dim x as integer ' x is a variable of type 'integer'.
dim str as string(32) ' str is a variable of type 'string' with a maximum
length of 32 characters (bytes).
```

A variable name must begin with a letter, and must be unique within the same scope, which is the range from which the variable can be referenced.

When you define a variable, some space is reserved for it in memory; later, while the program executes, this memory space can hold a value.

Variables are assigned values like so:

```
x = 15 ' x is now 15.
x = y ' x is now equal to y.
str = "foobar" ' str now contains the string 'foobar' (with no quotes).
```

### Types of Variables

Tibbo Basic supports the following variable types:

Name	Description
<b>byte</b>	Hardware-level. Unsigned. Takes 1 byte in memory. Can hold integer numerical values from 0 to 255 (&hFF).

<b>word</b>	Hardware-level. Unsigned. Takes 2 bytes in memory. Can hold integer numerical values from 0 to 65535 (&hFFFF).
<b>dword (new in V2.0, not available on all platforms)</b>	Hardware-level. Unsigned. Takes 4 bytes in memory. Can hold integer numerical values from 0 to 4294967295 (&hFFFFFFFF).
<b>char</b>	Hardware-level. Signed. Takes 1 byte in memory. Can hold integer numerical values from -128 to 127.
<b>short</b>	Hardware-level. Signed. Takes 2 bytes in memory. Can hold integer numerical values from -32768 to 32767.
<b>integer</b>	Compiler-level. Synonym for <b>short</b> ; substituted for <b>short</b> at compilation. Exists for compatibility with other BASIC implementations.
<b>long (new in V2.0, not available on all platforms)</b>	Hardware-level. Signed. Takes 4 bytes in memory. Can hold integer numerical values from -2147483648 to 2147483647
<b>real (new in V2.0, not available on all platforms)</b>	Hardware-level. Signed, in standard "IEEE" floating-point format. Can hold integer and fractional numerical values from +/- 1.175494E-38 to +/- 3.402823E+38. Real calculations are intrinsically imprecise. Result of floating-point calculations may also differ slightly on different computing platforms. Additionally, floating-point calculations can lead to floating-point errors: #INF, -#INF, #NaN. In the debug mode, any such error causes an <a href="#">FPERR exception</a> <sup>[29]</sup> .
<b>float (new in V2.0, not available on all platforms)</b>	Compiler-level. Synonym for <b>real</b> ; substituted for <b>real</b> at compilation. Exists for compatibility with other BASIC implementations.
<b>string</b>	Hardware-level. Takes up to 257 bytes in memory (max string size can be defined separately for each string variable). Strings can actually be up to 255 bytes long but always begin with a 2-byte header -- 1 byte specifies current length, and 1 byte specifies maximum length. Each character is encoded using an ASCII (single-byte) code.
<b>boolean</b>	Compiler-level. Intended to contain one of two possible values ( <b>true</b> or <b>false</b> ). Substituted for <b>byte</b> at compilation.
<b>user-defined structures (new in V2.0)</b>	Each user-defined structure can include several <i>member variables</i> of different types. More about structures <a href="#">here</a> <sup>[58]</sup> .
<b>user-defined enumeration types</b>	Compiler-level. These are additional, user-defined, data types. More about these under <a href="#">User-Defined Types</a> <sup>[59]</sup> .

\* *Hardware-level* types are actually implemented on the machine which is used to run the final program produced by the compiler.

*Compiler-level* types are substituted by other variable types on compile-time. The actual machine uses other variable types to represent them; they are implemented for convenience while programming.

## Type Conversion

Variables can derive their value from other variables; in other words, you can assign a variable to another variable. A simple example of this would be:

```
dim x, y as byte
x = 5 ' x is now 5
y = x ' y is now 5 as well
```

However, as covered above, there are several types of variables, and not all of them can handle the same data. For example, what would happen if you assigned a variable of type **byte** the value intended for a variable of type **word**?

Table below details all possible conversion situations.

		Convert into								
		Byte	Word	Dword	Char	Short	Long	Real	String	
C o n v e r t  f r o m	Byte	---	OK	OK	Reinterpret	OK	OK	OK	OK <a href="#">str</a> <small>[225]</small>	
	Word	Truncate	---	OK	Reinterpret Truncate	Reinterpret	OK	OK	OK <a href="#">str</a> <small>[225]</small>	
	Dword	Truncate	Truncate	---	Truncate	Truncate	Reinterpret	OK	OK <a href="#">lstr</a> <small>[216]</small>	
	Char	Reinterpret	Reinterpret	Reinterpret	---	OK	OK	OK	OK <a href="#">stri</a> <small>[226]</small>	
	Short	Reinterpret Truncate	Reinterpret	Reinterpret	Truncate	---	OK	OK	OK <a href="#">stri</a> <small>[226]</small>	
	Long	Reinterpret Truncate	Reinterpret	Truncate	Truncate	Truncate	---	OK	OK <a href="#">lstri</a> <small>[217]</small>	
	Real	Fraction ???	Fracti- on ???	Fractio- n ???	Fractio- n ???	Fractio- n ???	Fractio- n ???	Fracti- on ????	---	OK fstr*
	String	OK <a href="#">val</a> <small>[229]</small>	OK <a href="#">val</a> <small>[229]</small>	OK <a href="#">lval</a> <small>[218]</small>	OK <a href="#">val</a> <small>[229]</small>	OK <a href="#">val</a> <small>[229]</small>	OK <a href="#">val</a> <small>[229]</small>	OK <a href="#">lval</a> <small>[218]</small>	OK <a href="#">str</a> <a href="#">tof</a> <small>[228]</small>	---

\*fstr is a functional equivalent of [fstr](#)[211], but without mode and rnd parameters.

### Conversions without loss

Conversions marked as "**OK**" incur no loss -- the value being passed from variable of one type to variable of another type remains unchanged. For example, conversion from **word** into **dword** is done without any loss, because 32-bit **word** variable can hold any value that the 16-bit **word** variable can hold.

### Conversions that cause reinterpretation

Conversions marked with "**Reinterpret**" mean that although binary data held by the receiving variable may be the same this binary variable *may* be interpreted differently on the destination "side". As an example, see this conversion from **byte** into **char**:

```
dim x as byte
dim c as char
x = 254
c = x ' c now contains the binary value of 254, which is interpreted as -2
```

In the above example, both x and c will contain the same binary data. However, c is a signed 8-bit value, so binary contents of 254 mean -2. Strictly speaking, this reinterpretation will only happen if the value of x exceeds maximum positive number that c can hold -- 127. If x<=127 conversion will not cause reinterpretation. For example, if x=15 then doing c=x will result in c=15 as well.

In fact, in some cases, conversion from unsigned type to a signed time will never result in the reinterpretation. This is when the maximum value that the source unsigned variable can hold can always fit in the range of positive values that the signed destination variable can hold. Example: conversion from byte (value range 0-255) to short (value range -32768 to 32767) will never result in the reinterpretation.

Conversion from signed type into unsigned type will always cause reinterpretation if the source variable contained a negative value.

### Conversions that cause truncation

Conversions marked with "**Truncate**" mean that part of the binary data (on the most significant side) *may* be lost during the conversion. For example, converting from **word** type into **byte** type will only leave 8 bits of the original 16-bit value:

```
dim x as byte
dim w as word
w = 12345 'hex representation of 12345 is 3039
x = w ' now x contains 57. Why? Because only '39' of '3039' could fit in,
and decimal of &h39 is 57.
```

Notice, that some conversions will cause reinterpretation and truncation at the same time!

### Conversions that round the number (remove fractions)

Conversions from real type into any other numerical type will cut off the fraction, as real is the only type that can hold fractions. Such conversions are marked as "**Fraction**" in the table above.

## Conversions that implicitly invoke functions available to the user

Some conversions automatically invoke functions (syscalls) available for use in your program. In such cases the table above lists the name of the function invoked. For example, conversion from byte into string relies on the [str](#)<sup>[225]</sup> function. Two ways of conversion below produce identical result:

```
dim x as byte
dim s as string
s = str(x) ' explicit invocation
s = x ' implicit invocation. Compiler is smart enough to use str for this
conversion
```

## Conversion of Boolean Variables

**Boolean** variables are actually stored as **byte** type variables; thus, all notes above for **byte** type variables hold true for **boolean** variables as well.

## Conversion of Enumeration Types

User-defined enumeration types are held in various variable types, depending on the values associated with the constants within the enumeration type. This is described in detail under [User-Defined Types](#)<sup>[59]</sup>. Thus, they are converted according to the variable type used to store them (described above).

## Type conversion in expressions

In the [Type Conversion](#)<sup>[50]</sup> we already explained what happens when you assign the value of a variable of one type to a variable of another type. This section deals the cases where variables of different types are used in expression. For example, if **x** is **byte** and **i** is **integer**, what will happen when you do "x+i"?

### The Virtual Machine operates on 16-bit values by default

Native data width for the Virtual Machine is 16 bits. When you are performing calculations on 8-bit and/or 16-bit variables, result is always truncated to 16 bits. Also, all intermediary calculations are done using 16-bit arithmetic. Consider the following example first:

```
dim x,y,z as byte
x=150
y=200
z=(x+y)/10 ' result of 35 is within byte variable's range, but intermediary
calculations require 16-bit arithmetic.
```

The above example will give correct result. Even though all three variables are of **byte** type, internal calculations are 16-bit, so when **x+y** produces 350, which is beyond the range of the **byte** variable, the Virtual Machine handles this in the right way. Now, let's see another example:

```
dim i,j,k as word
i=50000
j=60000
k=(i+j)/10 ' result will be 4446, which is incorrect. 32-bit arithmetic was
not automatically used!
```

This example requires 32-bit calculations because  $i+j$  will produce a number which is outside the scope of 16-bit calculations. However, our compiler will not invoke 32-bit calculations automatically. Read on, this is not all...

### Mixing in a 32-variable will cause the compiler to use 32-bit calculations

For the example above, turn  $i$  or  $j$  into a `dword`. Now, your calculations will be correct. Mixing in any 32-bit variable will automatically upgrade calculations to 32 bits!

```
dim i,k as word
dim d as dword
i=50000
d=60000
k=(i+d)/10 ' result will be 11000. This is correct!
```

### String and non-string variables cannot be mixed!

Yes, sorry, but you cannot do the following (compiler will generate [type mismatch](#) error):

```
'Wrong!!!
dim x as byte
x=5+"6"
```

In case you are wondering why  $x="6"$  would work but  $x=5+"6"$  doesn't: the latter is a mixed expression in which the compiler cannot decide what is implied: conversion of string to value and then addition, or conversion of value to string and then string concatenation!

## Compile-time Calculations

Tibbo Basic always tries to pre-calculate everything that can be pre-calculated during compilation. For example, if you write the following code:

```
dim x,y as byte
y=5
x=5+10+y 'compiler will precalculate 5+10 and then the Virtual Machine will
only have to do 15+y
```

Pre-calculation reduces program size and speeds up execution.

When processing a string like "x=50000" compiler first determines the variable of what type would be necessary to hold the fixed value and chooses the smallest sufficient variable type. For example, for 50000 it is, obviously, **word**. Next, compiler applies the same rules of [type conversion](#)<sup>50</sup> as between two actual variables. Hence, in our example this will be like performing **byte= word**.

One additional detail. Large fixed values assigned to variables of real type must be written with fractional part, even if this fractional part is 0. Consider the following example:

```
dim r as real
r=12345678901 'try to compile this and you will get "constant too big"
error.
```

Compiler will notice that this constant does not fit even into **dword** and will generate an error. Now, try this:

```
dim r as real
r=12345678901.0 'that will work!
```

On seeing ".0" at the end of the value compiler will realize that the value must be treated as a **real** one (floating-point format) and process the value correctly.

So, why is it possible for compiler to automatically process values that fit into 8, 16, and 32 bits, but at the same time requires your conscious effort to specify that the value needs to be treated as a floating-point one?

This is because floating-point calculations are imprecise. The value "12345678901", when converted into a floating-point format, will not be exactly the same! The floating-point value will only *approximate* the value we intended to have!

For this reason we require you, the programmer, to make a conscious choice when specifying such values. By adding ".0" you acknowledge that you understand potential imprecision of the result.

## Arrays 4.2.4.5

An *array* is a single variable which contains several elements of the same type. Each element has a value and an index number, and may be accessed using this number.

An example of a simple array would be:

Index:	0	1	2	3	4
Value:	15	32	4	100	-30

The code to produce such an array in Tibbo Basic would look like this:

```
dim x(5) as char
x(0) = 15
x(1) = 32
x(2) = 4
```

```
x(3) = 100
x(4) = -30
```

The first index in an array is **0**. Thus, the array above contains 5 values, with indices from 0 to 4.

This is different from some BASIC implementations that understand x(5) as "array x with the maximum element number of 5" (that is, with 6 elements). In Tibbo Basic declaring x(5) means "array of 5 elements, with indices from 0 to 4".

### Variable Types For Arrays

In the example above, the array was assigned the type **char**. This means that each element within this array will be stored in a variable of type **char**<sup>[48]</sup>. Starting from Tibbo Basic **V2.0** you can have arrays of variables of any type.

### Accessing a Value Within an Array

To access a specific value within an array, include its index immediately after the name of the array, in parentheses. The index may also be expressed through a variable.

```
y = x(4) ' y would get a value of -30, according to the previous array
y = x(z) ' y would get the value of index z within array x.
```

As an example, you could iterate through an array with a loop (such as a [For... Next Statement](#)<sup>[90]</sup>) and execute code on each element in the array, by using a variable to refer to the index of an element. Let's see how to calculate the sum of the first three elements in the array we previously defined:

```
dim x(5) as char
x(0) = 15
x(1) = 32
x(2) = 4
x(3) = 100
x(4) = -30

dim sum as integer
sum = 0

for i = 0 to 4 ' note that you do not necessarily have to iterate through
all elements in the array.
    sum = sum + x(i)
next i
' now, at the end of this loop, sum contains the sum for the first three
elements (51)
```

The TIDE and Tibbo Basic **V2.0** introduced correct handling of array indices. It is no longer possible for your program to point to an array element that does not exist. For example, if your array only has 5 elements and you try to access element number 5 the Virtual Machine will:

- Generate an [OOR \(Out Of Range\) exception](#)<sup>[29]</sup> and halt if your program is in the [debug](#)<sup>[27]</sup> mode. If you attempt to continue the Virtual Machine will access `x(4)` -- the element with maximum available index.
- When in the [release](#)<sup>[27]</sup> mode, the OOR exception will not be generated but "index limiting" will still occur.

Example:

```
dim x(5) as char
dim f as byte

f=5
x(f)=3 'index limiting will happen here (preceded by the OOR exception if
you are in the debug mode)
```

Compiler is smart enough to notice out-of-range situations even at compile time. For example, the following code will generate an error during compilation:

```
dim x(5) as char

x(5)=3 'compiler will determine that this operation will be ecessing an
array element which does not exist!
```

### Multi-Dimensional Arrays

The array in the example above is called a *one-dimensional* array. This is because every element in the array has just a single index number. However, we could also have an array which looks like this:

Index:	0	1	2	3	4
0	15	32	4	100	-30
1	78	15	-3	0	55
2	32	48	97	5	22
3	13	18	9	87	54
4	32	35	79	124	3
5	7	-9	48	8	99

This is called a *two-dimensional array*. Each element in the array is now identified by an index consisting of two numbers (two coordinates). For example, the element **2, 0** contains the value **32**. To create such an array, you would use the following code:

```
dim x(5,6) as char
x(0,0) = 15
x(0,1) = 32
x(0,2) = 4
```

```
.....  
x(5,2) = 48  
x(5,3) = 8  
x(5,4) = 99
```

Iterating through such an array would be done using a nested loop for each dimension in the array. The array above contains only two dimensions, so we would nest one loop within another. For an array containing six dimensions, we would have to use six such nested loops. See:

```
dim x(5,6) as char  
x(0,0) = 15  
x(0,1) = 32  
x(0,2) = 4  
.....  
x(5,2) = 48  
x(5,3) = 8  
x(5,4) = 99  
  
dim i, j, sum as integer  
sum = 0  
for i = 0 to 5  
    for j = 0 to 4  
        sum = sum + x(i,j)  
    next j  
next i  
' here, sum would be equal to the sum of the whole array. How much is that?  
Try and see.
```

In Tibbo Basic, you may define up to 8 dimensions in an array.

### Alternative way of defining arrays

We have already explained that the following string means "an array x containing 10 elements of type byte":

```
dim x(10) as byte
```

In Tibbo Basic, the same can be expressed in a different way:

```
dim x as byte(10) 'you can think of it as '10 times of byte type' :-)
```

Both ways of defining arrays are completely identical and you can even mix them together, as we can see on the following examples of 2-dimensional arrays:

```
dim i(20,10) as byte 'two-dimensional array, 20x10 elements
dim i2(20) as byte(10) 'same! that is, 20 groups of byte x 10 -- exactly same
meaning
dim i3 as byte(20,10) 'yet another way -- same result!
```

Now, Tibbo Basic strings can be defined with an optional parameter specifying maximum string length, for example:

```
dim s as byte(30) 'this string will have maximum length of 30 characters
(bytes)
```

So, how do we declare an array of string variables? Here are some examples:

```
dim s(20,10) as string(30) 'two-dimensional array of 30-byte strings, 20x10
elements
dim s2(20) as string(30)(10) 'same!
dim s2 as string(30)(20,10) 'same!
```

### Arrays introduce slight overhead

Each array occupies more space than the sum total of space needed by all elements of an array. This is because each array also includes housekeeping data that, for instance, defines how many elements are there in an array, array of what type that is, etc.

## Structures 4.6

Beginning with **V2**, Tibbo Basic supports structures. Structure is a combinatorial user-defined data type that includes one or several *member* variables. Structures are declared using **type ... end type** statements, as shown in the example below:

```
'this is a structure with three members
type my_struct
  x as byte
  y as Long
  s as string
end type
```

In the above example, we declared a structure `my_struct` that has three member variables: `x`, `y`, and `s`. This is just a declaration -- you still have to define a variable

with the new type you have created if you want to use the structure of this type in your program:

```
dim var1 as my_struct 'this is how you define a variable with type
'my_struct'
```

After that, you can address individual elements of the structure as follows:

```
var1.x=5
var1.y=12345678
var1.s="Test"
```

Structures you define may include members that are arrays or other structures. Structure variables like `var1` above can be arrays as well, of course. In total, Tibbo Basic supports up to eight nesting levels (as in "array within a structure within a structure within and array" -- each structure or array is one level and up to 8 levels are possible). Here is a complex example:

```
type foo_struct 'structure with two members, and both are arrays
  x(10) as byte
  s(10) as string(4)
end type

type bar_struct 'structure with two members, one if which is another
structure
  foo as foo_struct 'so, this member is a structure
  w as word
end type

dim bar(20) as bar_struct 'we define an array of type 'bar_struct'

bar(1).foo.s(2)="test" 'oh-ho! we address element 2 of member s of member
foo of element 1 of bar!
```

### Structures introduce slight overhead

Each structure occupies more space than the sum total of space needed by all of its members. This is because each structure also includes housekeeping data that, for instance, defines how many members are there, what type they have, etc.

## Enumeration Types

At times, it may be useful for a programmer to define his own enumeration data types; for example, when working with the days of the week, it may be useful to refer to them by name in code, rather than by number:

```
dim i as integer
i = 2 ' i is an integer, and can only be assigned a numerical value. you
would have to remember that 2 is Monday.
```

```
dim d as dayofweek
d = monday ' now d is a user-defined type, dayofweek, and can be assigned a
value using the symbol Monday.
```

Enumeration definitions are made like this:

```
enum dayofweek
    sunday = 1, ' if 1 is not specified, the default value associated with
the first constant is 0.
    monday, ' by default, increments the previous value by 1. can also
be explicitly specified.
    tuesday,
    wednesday,
    thursday,
    friday,
    saturday,
    holiday = 99, ' as described above, values can be explicitly associated
with any constant in the list.
    holiday2 'this will have the value of 100
end enum
```

An enumeration type would then be used within the code as shown above (d = Monday). Note that even though Monday is an [identifier](#)<sup>[137]</sup> (i.e., an actual word, and not just some number) it does not have to be surrounded by quote marks (because it's not a string).

The value associated with each identifier within the enumeration type doesn't necessarily have to be unique; however, when you associate the same value with several constants, the distinction between these constants will be lost on compile time.

```
enum dayofweek
    Sunday = 1,
    Monday,
    Tuesday,
    Wednesday,
    Thursday,
    Friday,
    Saturday,
    holiday = 99
    bestdayofweek = 7 ' bestdayofweek and Saturday are actually the same!
    fridaythethirteenth = -666 ' a negative constant.
end enum
```

Note that above, `saturday` was implicitly (automatically) associated with the value 7, and `bestdayofweek` was explicitly associated with the same value. Now, on compile-time, they would both be considered to be just the same.

### Type Mapping for Enum Types

When the project is being compiled, all enumeration types are substituted with plain numerical values. the platform on which the code is running doesn't have to know anything about Saturday or about the best day of the week; for the platform, the number 7 is informative enough.

Hence, enumeration types are converted to various built-in numerical variable types. The actual numerical type used to store the enumeration type depends on the values associated with the constants within this enumeration type:

Values associated with constants do not exceed range	Actual variable type used to store enum type
-128 to 127	<b>char</b>
0 to 255	<b>byte</b>
-32768 to 32767	<b>short</b>
0 to 65535	<b>word</b>
-2147483648 to 2147483647	<b>long</b>
0 to 4294967295	<b>dword</b>

Notice, that enumeration types cannot be converted into real values, so you cannot use fractional numbers in you enums.

Some examples:

```
enum tiny
  tinyfoo,
  tinybar
end enum ' this enum will be associated with a char type

enum medium
  mediumfoo = 254
  mediumbar
end enum ' this enum will be associated with a byte type

enum impossible
  baddy = -1
  cruise = 4294967295
end enum ' this enum will raise a compile error, as no single variable type
can hold its values

enum nofractions
  thisisok = 4294967295
  thisisnot = 125.25
end enum ' compiler won't accept this! Integer values only, please!
```

### Enumeration types are helpful when debugging your code

For each enumeration type variable, the [watch facility](#)<sup>[33]</sup> of the TIDE shows this variable's current numerical value with a correct identifier associated with this value. This usually proves to be very useful during debugging! After all, seeing "dayofweek= 2- Monday" is much less cryptic than just "dayofweek= 2"!

## Understanding the Scope of Variables

A *scope* is a section of code, from which you can 'see' a variable (i.e, assign it a value, or read its value). For example:

```

sub foobar(x as byte)
  dim i, y as byte
  y = x * 30
  for i = 1 to y
    dim r as short
    r = x + 5
  next i
  r = x + 5 ' this would produce a compiler error
end sub

```

So, in the example above, **x** and **y** could be seen from anywhere within the **sub** procedure called **foobar**. However, **r** could be seen only from within the **for... next** statement. Thus, trying to assign **r** a value from outside the **for... next** statement would result in a compiler error, because it actually doesn't exist outside of that loop.

One identifier can refer to several different variables, depending on the scope in this identifier is used:

```

dim x as byte ' this creates the variable x in the global scope.

sub foobar(x as byte) ' here we create x once more, in the scope of the
  local sub (x as an argument).
  dim f, y as byte
  x = 5 ' right now, only the locally-created x (foobar agrument) equals
5; global x remains unchanged.
  y = x * 30
  for f = 1 to y
    dim x as byte
    x = 30 ' the argument x outside the for... next statement still
equals 5. only this local x equals 30.
  next f
end sub

```

Tibbo Basic supports several scopes:

### Global Scope

Every compilation unit has, in itself, one global scope. Variables declared in this scope are accessible from within any **sub** or **function** in this compilation unit.

```

dim s as string

sub foo
  s = "foo" ' assigning a value to the global string variable s.
end sub

sub bar
  dim i as short
  i = 0
  s = "" ' initialize s, in case it contains anything already (such as
'foo').
  for i = 1 to 5

```

```

        s = s + "bar" ' note
    next i
end sub ' at this point, s contains 'barbarbarbarbar'.

```

## Local Scope

This is the scope which is between the beginning and the end of each of the following statements:

Beginning	End	Notes
<b>sub</b>	<b>end sub</b>	Cannot be nested.
<b>function</b>	<b>end function</b>	Cannot be nested.
<b>for</b>	<b>next</b>	
<b>while</b>	<b>wend</b>	
<b>if... then... else</b>	<b>end if</b>	No <b>exit</b> statement for <b>if... then... else</b> .
<b>do</b>	<b>loop</b>	

Variables declared in this scope are accessible from within the construct in which they were declared. Local scopes may be nested, for example, **for...next** scope inside **sub...end** sub scope.

A locally defined variable with the same name as a global variable takes precedence in its context over any variable with the same name which is defined in a 'wider' scope.

Local variable names also take precedence over procedure names. For example:

```

sub prc1(x as byte)
    'some code here
end sub

sub prc2
    dim prc1 as byte 'define a local variable with the same name as one
    procedure we have
    prc1=0 'this will generate no error -- in the current scope prc1 is a
    variable
    prc1(2) 'here, we try to invoke sub prc1 and this will cause a compiler
    error.
end sub

```

## HTML Scope

 This section applies only to platforms which include an HTTP server.

This is a special scope, implemented in Tibbo Basic. HTML files included within a project may contain embedded Tibbo Basic code. This code is executed when the HTTP server processes an HTTP GET (or POST) request. Statements within an HTML file are considered to be within one scope -- similarly to a **function** or **sub** scope, with the exceptions that **include**<sup>[95]</sup> and **declare**<sup>[84]</sup> statements are allowed.

```

<!DOCTYPE HTML PUBLIC "-//W3C//DTD W3 HTML//EN">
<HTML>
<BODY>

    BEGINNING OF OUTPUT<br>

<?
include "global.tbh"
declare i as integer ' i is defined somewhere else
for i = 1 to 10
?>

    <i> Foo </i>

<?
next i
?>

    <br>END OF OUTPUT<br>

</BODY>
</HTML>

```

Designing dynamic HTML pages always presents you with a choice: what to do- include the BASIC code right into the HTML file or create a set of subs and functions and just call them from the HTML file? In the first place you put a lot of BASIC code into the HTML file itself, in the second case you just call subs and functions from the HTML file. So, which way is better?

Generally, we recommend to use the second way. First of all, this style of programming is cleaner- a mixture of BASIC code and static HTML text usually looks messy. Second, the second method *consumes less variable memory*.

Although the HTML scope is similar to a local scope of a function or a sub, its variables get exclusive memory allocation as if they were global. When you avoid writing a lot of BASIC code in the HTML file itself you usually avoid having to create a lot of variables in the HTML scope and this saves you memory!

## Declaring Variables

Usually, a variable is first defined by the `dim` [statement](#) and then used in code; however, at times, a single global variable must be accessible from several compilation units. In such cases, you must use the `public` modifier when defining this variable, and use the `declare` [statement](#) in each compilation unit from which this variable needs to be accessed.

For example, let us say this is the file **foo.tbs**:

```

public dim i as integer ' the integer i is defined in this file, and made
into a public variable. It can now be used from other compilation units.

```

And this is the file **bar.tbs**:

```


```

```
i = i + 5 ' this would cause a compiler error. What is i?

' the correct way:
declare i as integer ' lets the compiler know that i is defined elsewhere.
i = i + 5
```

Also, if for some reason you would attempt to use a variable in a single compilation unit before defining it using the **dim** statement, you will have to use a **declare** statement before using it to let the compiler know that it exists. For example:

```
declare i as integer
i = 7 ' i has not been defined yet, but we let the compiler know that it is
defined elsewhere.

...

dim i as integer ' we now define i. Note that here it doesn't have to be
public, because it is used in the same compilation unit.

' this example is rather pointless, but just illustrates this single
principle.
```

## Constants.4.10

*Constants* are used to represent values which do not change throughout the program; these values may be strings or numbers. They may either be stated explicitly, or be derived as the result of an expression.

Some examples:

```
const universal_answer = 42
const copyright = "(c) 2005 Widget Systems Inc." ' this is a string constant
const escape_char = `@` ' this constant will contain a numerical value --
the ASCII code for the char @.

const hexi = &hFB ' would create a constant with a value of 251 (&hFB in
hex)
const bini = &b00110101 ' would create a constant with a value of 53
(&b00110101 in binary)

const width = 10
const height = 15
const area = width * height ' constants may contain expressions which
include other constants

dim x as byte
const foo = x + 10 ' this will produce a compiler error. Constant
expressions may contain only constants.
```

Constants can be useful when you have some values which are used throughout the code; with constants, you can define them just once and then refer to them by their meaningful name. This has the added benefit of allowing you to easily change the value for the constant any time during the development process -- you will just have to change the definition of the constant, which is a single line of code.

- \* When defining a list of related constants, it is often convenient to use the [Enum Statement](#)<sup>[88]</sup> and create one data type which contains this list of constants. See also [User-Defined Types](#)<sup>[59]</sup> above.

When defining a constant within a [scope](#)<sup>[61]</sup>, this constant is visible only from within this scope. It is a good idea to define all constants within header files, and [include](#)<sup>[95]</sup> these files into each compilation unit.

### String constants

String constants can include escape sequences to define unprintable characters. This functionality is borrowed from C. Adding unprintable characters to the string has always been rather inconvenient in BASIC language. The only way to do so was like this:

```
s = "abc"+chr(10)+chr(13) 'add LF/CR in the end
```

In Tibbo Basic you can achieve the same by using escape sequences -- C style:

```
s = "abc\n\f" '\n' means LF, '\f' -- CR
const STR1 = "abc\x10\x13" 'same result can be achieved using HEX codes of
the characters
```

The following standard escape sequences are recognized:

- "\0" for ASCII code 0
- "\a" for ASCII code 7 (&h7)
- "\b" for ASCII code 8 (&h8, BS character)
- "\t" for ASCII code 9 (&h9)
- "\n" for ASCII code 10 (&hA, LF character)
- "\v" for ASCII code 11 (&hB)
- "\f" for ASCII code 12 (&hC)
- "\r" for ASCII code 13 (&hD, CR character)
- "\e" for ASCII code 27 (&h1B, ESC character)

Any ASCII character, printable or unprintable, can be defined using its HEX code. The following format should be used: "\x00" where "00" is the HEX code of the character. Notice, that two digits should be present on the code, for example: "\x0A" -- leading zero must not be omitted.

\

## Introduction to Procedures

A *procedure* is a named piece of code, which performs a designated task, and can be called (used) by other parts of the program. In Tibbo Basic, there are two types of procedures:

## Function Procedures

A function is defined using the [Function Statement](#)<sup>[91]</sup>. Functions can optionally have one or several arguments. Functions always return a single value. They can, however, change the value of the arguments passed to them using [ByRef](#)<sup>[68]</sup> and thus indirectly return more than one value. This would be an example of a function:

```
function multiply(a as integer, b as integer) as integer
    multiply = a * b
end function
```

Note how the function above returns a value: via a local variable with the same name as the function itself. Such a variable is automatically created by the compiler for each function.

## Sub Procedures

*Sub* is short for *subroutine*; just like a function, a sub procedure can optionally accept one or more arguments. However, unlike functions, sub procedures do not return a value. It is defined using the [Sub Statement](#)<sup>[99]</sup>. This would be an example of a sub:

```
dim a(10) as byte ' a is a global variable -- outside the scope of the
function.

sub init_array
    dim i as integer
    for i = 0 to 9
        a(i) = 0 ' the global variable gets changed.
    next i
end sub
```

Subs change the value of the arguments passed to them using [ByRef](#)<sup>[68]</sup> and thus indirectly return a value, or even several values. Of course, they may also change the value of global variables.

## Event handlers are like subs

Event handlers defined in the platform work exactly like sub procedures. Event handler subs can accept arguments. Event handlers can never be function procedures as each function has to return a value and the event handler has nobody to return this value to.

## Declaring Procedures

Usually, a procedure is first defined by the [function](#)<sup>[91]</sup> or [sub](#)<sup>[99]</sup> statements and then used in code; however, at times, functions can reside in a different compilation unit. In such a case, you must use the [public](#)<sup>[104]</sup> modifier when defining this function, and use the [declare statement](#)<sup>[84]</sup> to let the compiler know that the function exists.

For example, let us say this is the file **utility\_functions.tbs**:

```
public function multiply(a as integer, b as integer) as integer ' the value
returns by this function is an integer
    multiply = a * b
end function
```

And this is the file **program.tbs**:

```
declare function multiply(a as integer, b as integer) as integer ' declaring
just the name isn't enough. Include also the arguments and the types.
dim i as integer
i = multiply(3, 7)
```

**Declare** statements are usually used within header files which are then included into compilation units. Also, if for some reason you would attempt to use a procedure in a single compilation unit before defining it, you will have to use a **declare** statement to let the compiler know that it exists. For example:

```
declare function multiply(a as integer, b as integer) as integer
dim i as integer
i = multiply(3, 7)

...

function multiply(a as integer, b as integer) as integer ' now this function
doesn't have to be public.
    multiply = a * b
end function
```

Event handler subs require no declaration as they are already declared in your device's platform.

### No Recursion

One thing you have to know is that procedures cannot call themselves. Also, two procedures cannot call each other. This is due to TiOS not using dynamic memory allocation. Such allocation would create a serious overhead for the system, and would drastically slow everything down -- not just recursive procedures. For more information, see [Memory Allocation for Procedures](#)<sup>[70]</sup>.

## Passing Arguments to Procedures

When calling subroutines or functions, it is often necessary to pass a certain value for processing within the procedure. An example of this would be a function which calculates the sum of two values; naturally, such a function would need to get two arguments -- the values which are to be added up.

There are two different ways to pass arguments to such a procedure:

### The Default: Passing By Value

When passing an argument to a procedure *by value*, this argument is *copied* to a location in memory which was reserved for the local variables of this function. Processing is then done on this local copy -- the original remains untouched. For

example:

```
sub foo(x as byte)
...
x = 1
...
end sub

sub bar
  dim y as byte
  y = 2
  foo(y)
  ' at this point in code, y is still 2.
end sub
```

This way of passing variables is the default used in Tibbo Basic.

### Passing By Reference

In certain cases, copying is not the preferred solution; for example, when a procedure has to modify several arguments passed to it and these later have to be accessible. Another example would be when processing large strings -- copying them would cause significant overhead.

In such cases, arguments are passed *by reference*. When passing by reference, the actual values are not copied. Instead, the procedure receives a reference to the location of the original values in memory -- hence, the name. For example:

```
sub foo(byref x as byte)
...
x = 1
...
end sub

sub bar
  dim y as byte
  y = 2
  foo(y)
  ' at this point in code, y is 1!
end sub
```

When passing arguments by reference, the code within the procedure will access these arguments using indirect addressing. This may cause possible overhead. The only case where it does not cause overhead (relative to passing by value) is when working with large strings; in this case, passing them by reference saves the need to copy the whole string to another location in memory.



Here is our advice: when dealing with strings it is usually better (in terms of performance) to pass them by reference. For all other types, passing by value yields better performance.

### Strict byref argument match is now required!

Beginning with Tibbo Basic release **2.0**, strict match is required between the type of byref argument and the type of variable being passed. For example, trying to pass a string for a byte will now cause a compiler error:

```
sub bar(byref x as byte)
  ...
end sub

sub foo
  bar("123") 'attempt to pass a string will generate a compiler error
  bar(val("123")) 'this will work!
end sub
```

In the above example, sub bar takes a byte argument and we are trying to pass a string. Wrong! Compiler understands that byref arguments can be manipulated by the procedure that takes them. Therefore, it is important that actual variables being passed match the type of argument that procedure expects. Automatic [type conversion](#)<sup>[50]</sup> won't apply here.


## Memory Allocation for Procedures

Variable memory (RAM) allocation in TiOS is [not dynamic](#)<sup>[48]</sup>. Memory is allocated for variables at compile-time.

The compiler builds a "tree" reflecting procedure calls within your project. When two different procedures never call each other, it is safe to allocate the same memory space for the variables of each of them. They will never get mixed.


Let us say we have two event handlers in our project: on\_event\_1, which needs 7 bytes of memory, on\_event\_2, which needs 5 bytes of memory. They do not call each other. In this case, the total memory required for our project will be 7 bytes -- they will share the same memory space because only one will be executing at any given time.

However, sometimes procedures call other procedures. This affects memory allocation.



As seen above, the event handler `on_event_1` calls procedure A, which in turn calls procedure B. The memory required for each procedure is listed in brackets. Since `on_event_1`, procedure A and procedure B call each other, they may not share the same memory space. If procedure A keeps a variable in memory, then obviously procedure B cannot use the same space in memory to store its own variables, because procedure A may need its variable once control returns to it after procedure B has completed. Thus, the total memory required for this tree is 11 bytes.

Now, let us say we also have `on_event_2` in our project, which calls procedure C, which in turn calls procedure D. This is a completely separate chain:



As can be seen, this chain takes up 7 bytes of memory. However, this memory can be the same memory used for the `on_event_1` chain, because these two chains will never execute at the same time. Thus, the total memory required for our project remains at 11 bytes.

A typical project usually includes a number of [global variables](#)<sup>[67]</sup>. Naturally, these variables are allocated their exclusive space that is not shared with local variables of procedures. Variables of HTML scope, which are local by nature, are allocated exclusive memory space as if they were global (this is an unfortunate byproduct of

the way compiler handles HTML pages). Hence, it is more economical to implement necessary functionality in procedures invoked from HTML pages rather than include BASIC code directly into the body of HTML files.

## Introduction to Control Structures

*Control Structures* are used to choose what parts of your program to execute, when to execute them, and whether to repeat certain blocks of code or not (and for how many iterations).

The two main types of control structures are [decision structures](#)<sup>[72]</sup> and [loop structures](#)<sup>[72]</sup>.

## Decision Structures

*Decision Structures* are used to conditionally execute code, according to the existence or absence of certain conditions.

Common uses for decision structures are to verify the validity of arguments, to handle errors in execution, to branch to different sections of code, etc.

An example of a simple decision structure would be:

```
dim x, y as byte
dim s as string

if x < y then
    s = "x is less than y"
else
    s = "x is greater than, or equal to, y"
end if
```

The following decision structures are implemented in Tibbo Basic:

- [If... Then... Else Statement](#)<sup>[94]</sup>
- [Select-Case Statement](#)<sup>[97]</sup>

## Loop Structures

*Loop structures* are used to iterate through a certain piece of code more than once. This is useful in many scenarios, such as processing arrays, processing request queues, performing string operations (such as parsing), etc.

An example of a simple loop structure would be:

```
dim f, i as integer

f = 1

for i = 1 to 6
    f = f * i
next i
' f is now equal to 1*2*3*4*5*6 (720).
```

The following loop structures are implemented in Tibbo Basic:

- [Do... Loop Statement](#)<sup>[87]</sup>
- [For... Next Statement](#)<sup>[90]</sup>
- [While-Wend Statement](#)<sup>[101]</sup>

## Doevents<sup>[6.3]</sup>

Although under Tibbo Basic, event-driven programming is the norm, there may be special cases in which you just have to linger an overly long time in one event handler. This will block execution of other events. They will just keep accumulating in the queue (see [System Components](#)<sup>[71]</sup>).

To resolve this, a [doevents](#)<sup>[87]</sup> statement has been provided. When this statement is invoked within a procedure, the execution of this procedure is interrupted. The VM then handles events which were present in the queue as of the moment of `doevents` invocation. Once these events are handled, control is returned to the procedure which invoked `doevents`.

If new events are added to the queue while `doevents` is executing, they will not be processed on the same `doevents` 'round'. `doevents` only processes those events present in the queue at the moment it was invoked.


To summarize, `doevents` provides a way for a procedure to let other events execute while the procedure is doing something lengthy.

```
'calculate sum of all array elements -- this will surely take time!
dim sum, f as word
sum = 0
for f = 0 to 49999
    sum = sum + arr(f)
    doevents 'don't want to stall other events so allow their execution
while we are crunching numbers
next f
```

### Multiple Doevents Calls

Let us say we are in event handler `on_event_1`. This event handler executes a `doevents` call. The VM begins processing other events in the queue, and starts executing an event handler `on_event_3`, which also contains a `doevents` statement.

In this case, a new `doevents` round will begin. Only when it completes, control will be returned to event handler `on_event_3`, which will complete, and then return control to the previous `doevents` (the one from event handler `on_event_1`).




The point here is that control will not be returned to `on_event_1` until `on_event_3` fully completes execution, since `on_event_3` contains a `doevents` statement in itself.

### Memory Allocation When Using Doevents

When a procedure utilizes `doevents`, it means its execution gets interrupted, while other procedures get control. We have no way to know which other procedures will get control, as this depends on the events which will wait in the queue.

As a result, a procedure which utilizes `doevents`, and any procedures calling it (directly or through other procedures) cannot share any memory space with any other procedure in the project. This would lead to variable corruption -- procedures newly executed will use the shared memory and corrupt variables which are still needed for the procedures previously interrupted by `doevents`.



Above we have the same two chains of procedures which appear under [Memory Allocation for Procedures](#)<sup>[70]</sup>, with one noticeable difference: Procedure C includes a `doevents` statement. The `on_event_1` chain takes up 11 bytes. But `on_event_2` and procedure C (which together take up 5 bytes) cannot share the same space with the `on_event_1` chain, because when the `doevents` statement is invoked, the state of variables for `on_event_2` and procedure C must be preserved. So these two get their own exclusive memory space.

Procedure D, which is also a part of the `on_event_2` chain, does not get its own exclusive memory space. This is because it comes later on the chain than the procedure which contains the `doevents` statement. There will never be a situation

where the variables of procedure D must be preserved while other chains are executing.


Thus, the total memory requirements of the project depicted above would be 16 bytes -- 11 shared bytes plus 5 exclusive bytes. This is more than would have been required had we not used `doevents`.

### Sharing Procedures Which Utilize `Doevents`

Procedures which contain `doevents` statements, as well as all procedures which call them (directly or through other procedures) cannot be shared between chains.

Let us say event handler `on_event_1` calls procedure A. Procedure A calls procedure B. Procedure B contains a `doevents` statement, and also calls procedure C.

Next, we have event handler `on_event_2`. It cannot call procedure A or B, because procedure B contains a `doevents` statement (and A calls B). If it *could* call procedure A, we might get a situation whereby event handler `on_event_1` fires, calls procedure A. In it, procedure B is called, and `doevents` is executed. During `doevents`, an event handler `on_event_2` fires, and calls procedure A *again* -- while the previous instance of A still holds variables in memory, waiting for control to return to it. This would corrupt the values of variables used by the first A (if you try to do something like this, the compiler will raise an error).



However, note that in the example above we also have procedure C (which is called by procedure B). This procedure can be shared by everyone -- because it is later on the chain than the procedure which contains the `doevents` statement.

### `Doevents` for Events of The Same Type

For some events, only one instance of the event may be present in the queue at any given time. The next event of the same kind may only be generated after the current one has completed processing. For other events, multiple instances in the queue are allowed.

Let us say that for `event_1`, multiple instances are allowed, and that this event's handler contains a `doevents` statement. When this statement executes, it may happen that another instance of `event_1` will be found on the queue, waiting to be processed. If this happens, this new instance will just be skipped -- execution will move on to the next event on the queue. Otherwise, we would once again get recursion (execution of an event handler while a previous instance of this event handler is already executing), which is not allowed under Tibbo Basic.

## Using Preprocessor

Tibbo Basic compiler includes a preprocessor that understands several directives.

### **#define and #undef**

The **#define** directive assigns a replacement token for an identifier. Before compilation, each occurrence of this identifier will be replaced with the token, for example:

```
#define ABC x(5) 'now ABC will imply 'x(5)'  
ABC=20 'now it is the same as writing x(5)=20
```

The **#undef** directive "destroys" the definition made earlier with **#define** :

```
#define ABC x(5) 'define  
...  
#undef ABC 'destroy  
...  
ABC=20 'you will get a compilation error on this line (compiler will try to  
process this as "=20")
```

### **#if - #else - #elif -- #endif**

These directives are used to conditionally include certain portions of the source code into the compilation process (or exclude from it). Here is an example:

```
#define OPTION 0 'set to 0, 1, or 2 to select different blocks of code for  
compilation  
...  
#If OPTION=0  
    s="ABC" 'will be compiled when OPTION=0  
#elif OPTION=1  
    s="DEF" 'will be compiled when OPTION=1  
#Else  
    s="123" 'will be compiled when OPTION=2, 3, etc.  
#endif
```

You can improve on this example and add meaning to 0, 1, and 2:

```
#define RED 0  
#define GREEN 1  
#define BLUE 2  
...  
#define OPTION BLUE  
...  
#If OPTION=RED  
    s="ABC" 'will be compiled when OPTION=RED (0)
```

```
#elif OPTION=GREEN
    s="DEF" 'will be compiled when OPTION=GREEN (1)
#else
    s="123" 'will be compiled when neither RED, nor GREEN
#endif
```

You can also write like this:

```
#If OPTION
    x=33 'will be compiled in if OPTION evaluates to any value except 0. Will
not be compiled in if OPTION evaluates to 0.
#endif
```

Preprocessor directives are not "strict". You don't have to define something before using it. During #if evaluation, all undefined identifiers will be replaced with 0:

```
#If WEIRDNESS 'undefined identifier
    x=33 'will not be compiled in
#endif
```

Do not confuse compile-time definitions such as "#define OPTION 2" and actual application code like "const COLOR=2" or "x=3". They are from two different worlds and you can't use the latter as part of #if directives. For example, the following will not work:

```
#define OPTION 0 'preprocessor directive
Const COLOR=2 'constant used by your application

#If OPTION=COLOR 'to a confused programmer, this looks like 0=2, but COLOR
is not #defined, hence, it will be evaluated to 0
    'hence, this code will be compiled in!
#endif
```

The #if directive also understands expressions, for example:

```
#define RED 0
#define GREEN 1
#define BLUE 2
...
#define OPTION 2
...
#If OPTION=GREEN+1
    'will be compiled in, because GREEN=1, hence the entire expression
evaluates to 2, and OPTION=2
#endif
```

### **#ifdef - #else - #endif**

`#ifdef` and `#ifndef` are like `#if`, but instead of evaluating an expression they simply checks if specified definition exists:

```
#ifdef OPTION
    s="X" 'will be compiled if OPTION is defined
#else
    s="1" 'will be compiled if OPTION is not defined
#endif
```


`#ifndef` is like `#ifdef`, but in reverse:

```
#ifndef OPTION
    s="X" 'will be compiled if OPTION is not defined
#else
    s="1" 'will be compiled if OPTION is defined
#endif
```

## **Scope of Preprocessor Directives**

Each preprocessor directive applies only to its own [compilation unit](#)<sup>[43]</sup>, not the entire project. So, a `#define` directive in *main.h* will not be "visible" in *main.tbs* unless the latter includes the *main.h*.

The only exception to the above are platform defines. These are globally visible throughout your entire project. Platform defines determine options such as the presence or absence of a display, display type, etc. These options are selected through the Customize Platform dialog, accessible through the [Project Settings](#)<sup>[137]</sup> dialog.



## Working with HTML

One of the strengths of Tibbo programmable devices is that they feature a built-in webserver (of course, this is only true for devices that have a network interface and support TCP communications). You can use this webserver as an engine for server-side scripting; simply put, you can output dynamic HTML content by including Tibbo Basic instructions within HTML pages.

Here is a simple example:

```
<!DOCTYPE HTML PUBLIC "-//W3C//DTD W3 HTML//EN">  
<HTML>  
<BODY>  
  
    BEGINNING OF OUTPUT<br>  
  
<?  
dim i as integer  
for i = 1 to 10  
?>  
  
    <i> Foo </i> <br>  
  
<?  
next i  
?>  
  
    <br>END OF OUTPUT<br>  
  
</BODY>  
</HTML>
```

In effect, this file would cause the following to appear in the browser window of the user accessing this page:

```
BEGINNING OF OUTPUT
foo
END OF OUTPUT
```

### When to Use HTML Pages In Your Project

For an embedded device, built-in webserver can provide a convenient interface to this device; in fact, it is one of the best ways to allow your users to access your device remotely. They would just have to enter an address in a web browser, and voila, up comes your interface.

HTML support, as implemented in the Tibbo Basic, allows you complete control over page structure. You can use client-side technologies such as JavaScript, CSS etc., while still being able to dynamically generate HTML content within Tibbo device.

Further information about creating HTML files with dynamic content can be found in the [next topic](#)<sup>[80]</sup> as well as [Using HTTP](#)<sup>[461]</sup> topic (part of the [sock](#)<sup>[421]</sup> object documentation).

## Embedding Code Within an HTML File

As covered in [Understanding the Scope of Variables](#)<sup>[61]</sup>, each HTML file has a special scope, and all code within the file resides within this scope.

To begin a block of Tibbo Basic code within an HTML file, you must use an escape sequence -- `<?` . To close the section of code, use the reverse escape sequence -- `?>` .

When the embedded HTTP server receives a GET (or POST) request, it begins to output the requested HTML file. It simply reads the HTML file from top to bottom, and transmits its contents with no alteration. However, the moment it encounters a block of Tibbo Basic code, it begins executing it.

Tibbo Basic code inside HTML files does not differ from the code in "basic" files, but it may not contain procedures. This is because the Tibbo Basic code in the HTML file is considered to constitute a procedure in itself. Notice, that all code in one HTML file is considered to be a single procedure, even if there are several fragments of code in this HTML file. Consider this example:

```

<!DOCTYPE HTML public "-//W3C//DTD W3 HTML//EN">
<HTML>
<BODY>

    BEGINNING OF OUTPUT<br>

<?
'<----- BASIC procedure starts here
dim i as integer
for i = 1 to 10
?>

    <i> Foo </i> <br>

<?
next i
'<----- procedure ends here
?>

    <br>end OF OUTPUT<br>

</BODY>
</HTML>

```

There two code fragments, yet they both form one procedure. For example, variable *i* declared in the first fragment is still visible in the second fragment.

The fact that entire code within each HTML file is considered to be a part of a single procedure has implications in the way events are handled (reminder: there is a [single queue](#)<sup>[71]</sup> for all events). The next event waiting in the event queue won't be executed until the end of the HTML procedure is reached. Just because the HTML procedure consists of two or more fragments does not mean that other events will somehow be able to get executed while the HTTP server outputs the static data between those fragments ("*<i> Foo </i> <br>*" in our example). Use [doevents](#)<sup>[73]</sup> if you want other event handlers to squeeze in!

Tibbo Basic code in the code fragments may include [decision structures](#)<sup>[72]</sup> or [loop structures](#)<sup>[72]</sup> that may cause various segments of HTML code to be output more than once, to be skipped altogether, or to be output only when certain conditions are true or false. In the above example the line "*<i> Foo </i> <br>*" will be output 10 times because this line resides between two code fragments that implement a cycle!

The same result could be achieved in a different manner:

```

<!DOCTYPE HTML public "-//W3C//DTD W3 HTML//EN">
<HTML>
<BODY>

    BEGINNING OF OUTPUT<br>

<?
dim i as integer
dim s as string

s="<i> Foo </i> <br>"

```

```

for i = 1 to 10
  while sock.txfree<len(s) 'these free lines can be omitted for simple
    doevents              'tests but are actually essential for
  wend                    'reliable output of large data chunks

  sock.setdata(s)        'this prepares data for output
  sock.send              'and this commits it for sending (see sock
object)
next i
?>

<br>end OF OUTPUT<br>

</BODY>
</HTML>

```

Here we have a single code block and "printing" the same line several times is achieved by using [sock.setdata](#)<sup>[500]</sup> and [sock.send](#)<sup>[500]</sup> methods of the [sock](#)<sup>[421]</sup> object.

So, which of the two examples shows a better way of coding? Actually, both ways are correct and equally efficient. The first way will have an advantage in case you have large static blocks that may be harder to deal with when you need to print them using `sock.setdata` method.

Further information about creating HTML files with dynamic content can be found in [Using HTTP](#)<sup>[461]</sup> (part of the [sock](#)<sup>[421]</sup> object documentation).

## Understanding Platforms

As an embedded language, Tibbo Basic may find itself within many various hardware devices; each such device may have different capabilities in terms of storage, physical interfaces, processing power, and other such parameters.

Thus, Tibbo Basic is not a one-size-fits-all affair; it is customized specifically for every type of physical device on which TiOS runs. A function which initializes a WiFi interface would make very little sense on a device which does not support WiFi. The same would go for a function which clears the screen -- what if you have no screen? This holds true even for string functions -- some platforms are so tiny, they do not even need to support string processing!

Because of this, the 'core' of the Tibbo Basic language is actually very minimalistic -- we call it "pure" -- it contains only the statements listed under [Statements](#)<sup>[83]</sup> below. Any other functionality is implemented specifically for each platform, and is documented in detail for your platform under [Platforms](#)<sup>[138]</sup>.

## Objects, Events and Platform Functions

Each [platform](#)<sup>[138]</sup> provides the following types of custom language constructs:

### Objects

These provide a way to access the various facilities and subsystems of the host platform. For example, in a platform which supports networking, we would have a *socket* object that handles TCP/IP communication.

Each object has *properties*, *methods* and *events*:

A *property* of an object allows you to read or change an internal variable for this object. For example, a *serial port* object may have a *baudrate* property. Change

the value of this property, and the actual physical baudrate changes. There are also read-only properties which only provide information.

```
ser.baudrate = 3 ' set the baudrate
x = ser.numofports ' find out how many serial ports the device has.
```

A *method* of an object is a way to make the object perform a certain action. It is basically a procedure. It can optionally take arguments or return values. Our *ser* object could have *getdata* and *setdata* methods, for instance.

```
s = ser.getdata(50) ' gets up to 50 bytes of data into variable s.
ser.setdata(s) ' prepares up to 50 bytes of data for sending.
ser.send ' no arguments, returns nothing. Sends data.
```

An *event*<sup>[87]</sup> of an object is something that 'happens' to this object in reality. When TiOS registers an event, an *event handler* for it is automatically called, if it exists in your source code. *Event handlers* are simply subs with no arguments.

```
sub on ser_data_arrival
' ... do something! ... <-- will be called when data arrives into the serial
port.
end sub
```

### Platform Functions

Many functions commonly available in other BASIC versions are implemented in Tibbo Basic on the platform level and not on the "pure" language level; these include also seemingly universal functions, such as string processing, or various date and time functions. This is done so because not every platform would actually need these functions, universal as they may seem. Some platforms may have very limited resources, and not every platform needs to know what the time is, or how to parse strings.

## Language Reference

The text below provides a complete rundown of all built-in language [statements](#)<sup>[83]</sup>, [keywords](#)<sup>[102]</sup> and [operators](#)<sup>[105]</sup>. If you can't find something here, that means it is platform-specific, and you would find it in your [platform](#)<sup>[138]</sup> documentation.

The examples provided herein may not work on your platform -- they are given for reference only.

### Statements

*Statements* are used for directing the machine to perform a specific operation. A *statement* is the smallest possible unit of code which would compile by itself. You could say they are the programming-language equivalent of a sentence in human speech.

Statements are built into Tibbo Basic itself, and are not platform-specific.

## Const Statement

<b>Function:</b>	Declares constants for use in place of literal values.
<b>Syntax:</b>	<b>const</b> name = value
<b>Scope:</b>	Global, HTML and local
<b>See Also:</b>	<a href="#">Enum Statement</a> <sup>[88]</sup>

Part	Description
name	The name of the constant, later used to refer to this constant in code.
value	The value for the constant; this can be an expression.

### Details

This statement defines an identifier, and binds a constant value to it. During compilation, when the compiler finds an identifier, it substitutes the identifier with the value given for the constant.

When defining a constant, you can use any valid constant expression; this can be another constant, a string, or a mathematical expression. Of course, constant expressions cannot include variables, functions, or other elements of code which are not constant (and, hence, cannot be resolved during compilation).

Global constants are usually declared in the [header file](#)<sup>[16]</sup>.

### Examples

```
const foo = "abc" + "fddf"
const bar = 123 + 56 * 56
const foobar = "dfdfgfg"
```

## Declare Statement

<b>Function:</b>	Declares a function or a subroutine or a variable for later use.
<b>Syntax:</b>	<p><b>declare function</b> name [ ( [ <b>byref</b> ] argument1 <b>as</b> type1, [ <b>byref</b> ] argument2 <b>as</b> type2,...) ] <b>as</b> ret_type</p> <p><i>or:</i></p> <p><b>declare sub</b> name [ ( [ <b>byref</b> ] argument1 <b>as</b> type1, [ <b>byref</b> ] argument2 <b>as</b> type2,...) ]</p> <p><i>or:</i></p> <p><b>declare</b> name [ ( bounds1) ] [ , name2 [ ( bounds2 ) ] ] <b>as</b> type [ ( max_string_size ) ]</p>

**Scope:** Global and HTML

**See Also:** [Function Statement](#)<sup>[91]</sup>, [Sub Statement](#)<sup>[99]</sup>, [Dim Statement](#)<sup>[86]</sup>

Part	Description
<b>function</b>	Optional. Used to specify that you are declaring a <a href="#">function procedure</a> <sup>[66]</sup> .
<b>sub</b>	Optional. Used to specify that you are declaring a <a href="#">sub procedure</a> <sup>[66]</sup> . If neither <b>sub</b> nor <b>function</b> appear, it is assumed that the <b>declare</b> is used to declare a variable.
name	Required. Used to specify the name of the function, sub or variable you are declaring.
<b>byref</b>	Optional. If present, arguments are passed <a href="#">by reference</a> <sup>[68]</sup> . If not, arguments are passed <a href="#">By Value</a> <sup>[68]</sup> .
argument1[1, 2...]	Optional. The name of the argument to be passed to the procedure. Only used if <b>sub</b> or <b>function</b> appear.
<b>as</b>	Required. Precedes the type definition.
type[1, 2...]	Optional (required if arguments are present). Specifies the <a href="#">type</a> <sup>[48]</sup> of the argument to be passed to the procedure.
ret_type	Optional (required for functions, cannot be used for subs). Used to specify the type of the return value from the procedure.
bounds[1, 2...]	Optional (used only when declaring variables). Specifies the boundary (finite size) of a dimension in an array.

## Details

In large projects, you often define a function or variable in one compilation unit, and use it from other units, so it is external to those units.

The unit which uses this external variable or function should refer to it in a way which lets the compiler know that it does indeed exist externally.

The **declare** statement is used to refer to a variable or function in this manner, but doesn't actually allocate any memory or produce any code; rather, it tells the compiler about this external entity, so that the compiler knows about it and can deal with it (see [Dim Statement](#)<sup>[86]</sup>).

Usually, variables and functions which are shared between compilation units are declared in a header file, and this header is then included in the units (see [Include Statement](#)<sup>[95]</sup>).

## Example

```
declare function hittest(x as integer, y as integer) as boolean
declare sub dosomething (s as byref string)
declare devicestate as integer
```

## Dim Statement

<b>Function:</b>	Defines a variable and allocates memory for it.
<b>Syntax:</b>	[ <b>public</b> ] <b>dim</b> name1 [ (bounds1) ] [ , name2 [ (bounds2) ] ] <b>as</b> type [ (max_string_size) ]
<b>Scope:</b>	Global, HTML and local
<b>See Also:</b>	<a href="#">Declare Statement</a> <sup>[84]</sup>

Part	Description
<b>public</b>	Optional; may only be used in a global scope. If present, makes the variable(s) <a href="#">public</a> <sup>[61]</sup> .
name[1, 2...]	Required. Specifies the name for the variable.
bounds[1, 2...]	Optional. Specifies the boundary (finite size) of a dimension in an array. Several comma-delimited boundary values make a multi-dimensional array.
<b>as</b>	Required. Precedes the type definition.
type	Required. Specifies the <a href="#">type</a> <sup>[48]</sup> of the variable.
max_string_size	Optional (can be used only when <i>type</i> is string). Sets the maximum size for a string (default size is 255 bytes).

### Details

The **dim** statement creates a variable in the current scope. It reserves memory space for this variable. Hence, as part of a **dim** statement, you have to specify the *type* of the variable; specifying the type also defines how much memory will be allocated for this variable.

When creating strings, you can explicitly define their maximum size by including it in parentheses immediately following the **string** keyword. The default maximum size of strings is 255 bytes, but if you're sure a string will contain less than 255 bytes of data, it is better to constrain it to a lower size (and thus reduce the memory footprint of your program).

The **dim** statement can also be used to create [arrays](#)<sup>[54]</sup>. This is done by specifying the number of elements in the array in parentheses immediately following the name of the variable. Multi-dimensional arrays are created by specifying the number of elements in each dimension, separated by commas.

Note that creating a variable using **dim** does not assign any value (i.e, 0) to this variable.

There are alternative ways of specifying the number and size of each array dimension in an array. Please, examine the examples below.

### Examples

```
dim x, y(5) as integer ' x is an integer; y is a one-dimensional array of 5
integers.
dim z(2, 3) as byte ' a two-dimensional array, 2x3 bytes.
```

```
dim z2(2) as byte(3) ' same -- a two-dimensional array, 2x3 bytes
dim z2 as byte(2,3) ' same again -- a two-dimensional array, 2x3 bytes

dim s as string(32) ' s is a string which can contain up to 32 bytes
dim s(10) as string(32) 'array of 10 strings with 32-byte capacity
dim s as string(32)(10) 'alternative way to make the same definition
```

## Doevents Statement

<b>Function:</b>	Interrupts the current event handler and processes all events in the queue at the moment of invocation.
<b>Syntax:</b>	<b>doevents</b>
<b>Scope:</b>	Global, HTML and local
<b>See Also:</b>	<a href="#">Declare Statement</a> <sup>[84]</sup>

---

### Details

Executes events pending in the queue, then returns execution to current event handler. See [doevents](#)<sup>[73]</sup> above.

### Examples

```
'calculate sum of all array elements -- this will surely take time!
dim sum, f as word
sum = 0
for f = 0 to 49999
    sum = sum + arr(f)
    doevents 'don't want to stall other events so allow their execution
while we are crunching numbers
next f
```

## Do... Loop Statement

<b>Function:</b>	Repeats a block of statements while a condition is <b>True</b> or until a condition becomes <b>True</b> .
<b>Syntax:</b>	<b>do</b> [ <b>while</b>   <b>until</b> ] expression statement1 statement2 ... <b>[exit do]</b> ... statementN <b>loop</b>  <i>or:</i>  <b>do</b> statement1

```

statement2
...
[exit do]
...
statementN
loop [ while | until ] expression

```

**Scope:** Local and HTML

**See Also:** [For... Next Statement](#)<sup>[90]</sup>, [While-Wend Statement](#)<sup>[101]</sup>, [Exit Statement](#)<sup>[89]</sup>

Part	Description
expression	A logical expression which is evaluated either before or after the first time the statements are executed.
statement[1, 2...]	Lines of code to be executed.

### Details

The **do-loop** statement repeats a block of code. If the condition (**while** or **until**) is included at the end of the loop (after the **loop** keyword), the block of code is executed at least once; If the condition is included at the beginning of the loop (after the **do** keyword), the condition must evaluate to **true** for the code to execute even once.

Any number of [exit do](#)<sup>[89]</sup> statements may be placed anywhere in the **do... loop** as an alternate way to exit the loop. These can be used as an alternate way to exit the loop, such as after evaluating a condition mid-loop using an [if... then](#)<sup>[94]</sup> statement. **Exit do** statements used within nested **do-loop** statements will transfer control to the loop which is one nested level above the loop in which the **exit do** occurs.

### Examples

```

= = ~ =
D= ñ~ = = = = ó ~ñW
=Z=M

=Z= =H=N
= = =Z=NM

D= ñ~ = = = = ó ~ñW
=Z=M
= = =Z=NM
=Z= =H=N
=

```

## Enum Statement

**Function:** Declares a type for an enumeration.

**Syntax:** **enum** name

```
const1 [= value1],
const2 [= value2],
```

```
...
```

```
end enum
```

**Scope:** Global and HTML

**See Also:** [Const Statement](#)<sup>[84]</sup>

Part	Description
name	Required. The name of the <b>enum</b> type. The name must be a valid Tibbo Basic identifier, and is specified as the type when declaring variables or parameters of the <b>enum</b> type.
const[1, 2...]	Required. The name for the constant in the enum.
value1	Optional. A value associated with the constant.

### Details

Enum types can be useful for debugging purposes. When you add an enum type to a watch, you will see the constant name within the enum, and not a meaningless number.

By default, constants get incremental values, starting from 0 for the first item. You can think of this as a counter, enumerating the items in the list. Explicit values may be specified for any constant on the list. This also sets the counter to this explicit value. The counter will continue to increment from this new value.

### Examples

```
enum my_enum
  my_const1, ' implicit value -- 0 is assumed
  my_const2 = 5, ' explicit value of 5, counter is set to 5 too.
  my_const3 ' Counter increments to 6, implicit value of 6.
end enum
```

## Exit Statement

**Function:** Immediately terminates execution of function or a loop.

**Syntax:**

```
exit do
exit for
exit function
exit sub
exit while
```

**Scope:** Local and HTML

**See Also:** [Do-Loop Statement](#)<sup>[87]</sup>, [For... Next Statement](#)<sup>[90]</sup>, [Function Statement](#)<sup>[91]</sup>, [Sub Statement](#)<sup>[99]</sup>, [While-Wend Statement](#)<sup>[101]</sup>

Part	Description
<b>exit do</b>	Provides an alternative way to leave a <b>do... loop</b> statement. Can be used only from within such a loop. <b>exit do</b> transfers the control to the statement following the <b>loop</b> statement. When used within nested <b>do... loop</b> statements, <b>exit do</b> transfers control to the loop which is one nested level above the loop in which <b>exit do</b> occurs.
<b>exit for</b>	Provides a way to exit a <b>for</b> loop. Can be used only within <b>for... next</b> or <b>for each... next</b> loops. When using <b>exit for</b> , control is passed to the statement which is immediately after the <b>next</b> statement. When used within nested <b>for</b> loops, <b>exit for</b> transfers control to the loop which is one nested level above the loop in which <b>exit for</b> occurs.
<b>exit function</b>	Exits the current function. Execution resumes from the point where the function was originally called.
<b>exit sub</b>	The same as <b>exit function</b> , only used for subroutine procedures.
<b>exit while</b>	Exists a <b>while</b> loop before the condition it is dependant upon evaluates as <b>false</b> .

### Details

Do not confuse **exit** (which just quits) with **end** (which defines the end of a section of code).

### Examples

```
function send_data as integer
  ' before sending data, we want to make sure Ethernet interface is OK
  if net.failure <> 0 then
    send_data = 1 ' this way we notify the caller of an error
    exit function
  end if
  ' Ethernet interface is OK, proceed with sending data
end function
```

## For... Next Statement

**Function:** Repeats a block of statements while a counter increments until it reaches a set value.

**Syntax:**

```
for name = start_expression to end_expression [ step
step_number ]
  statement1
  statement2
  ...
  [exit for]
  ...
  statementN
next name
```

<b>Scope:</b>	Local and HTML
<b>See Also:</b>	<a href="#">Do-Loop Statement</a> <sup>[87]</sup> , <a href="#">Exit Statement</a> <sup>[89]</sup> , <a href="#">While-Wend Statement</a> <sup>[101]</sup>

Part	Description
name	Required. The name of the counter. This has to be a numeric variable, which was previously explicitly defined using a <a href="#">Dim Statement</a> <sup>[86]</sup> .
start_expression	Required. The initial value of the counter. This actually sets the value of the <i>name</i> counter to the result of this expression. Can be a numerical constant, or a more complex expression.
end_expression	Required. The end value for the counter; once the counter reaches it, execution of the <b>for... next</b> loop stops. Can be a numerical constant, or a more complex expression.
step_number	Optional. Defines the intervals in which the <i>name</i> counter is incremented on every pass of the loop. This must be a numerical constant, and can be either positive or negative.
statement[1, 2...]	Required. Lines of code to be executed as long as the counter is 'in range' -- between the <i>start_expression</i> and the <i>end_expression</i> .

### Details

It is not advised to change the value of the counter while within a **for... next** loop. You might get unexpected results, such as infinite loops.

**For... next** loops may be nested, using different counter variables (*name* above). There is also an [exit](#)<sup>[89]</sup> statement which can be used to terminate them abruptly.

Under Tibbo Basic, you are required to explicitly state the name of the cycle variable to be incremented immediately following the **next** keyword.

### Examples

```
dim a(10) as integer
dim f as byte

for f = 0 to 9 ' in a 10-member array, element indices are 0 to 9
    sum = sum + a(f)
next f
```

## Function Statement

<b>Function:</b>	Used to define <a href="#">functions</a> <sup>[66]</sup> -- distinct units in code which perform specific tasks and always return a value.
<b>Syntax:</b>	[ <b>public</b> ] <b>function</b> name [ ( [ <b>byref</b> ] argument1 <b>as</b> type1, [ <b>byref</b> ] argument2 <b>as</b> type2...) ] <b>as</b> ret_type

```

statement1
statement2
...
[exit function]
...
statementN
end function

```

**Scope:** Global

**See Also:** [Declare Statement](#)<sup>[84]</sup>, [Exit Statement](#)<sup>[89]</sup>, [Sub Statement](#)<sup>[99]</sup>

Part	Description
<b>public</b>	Optional. If set, allows other compilation units (files in a project) to access the function.
name	Required. Specifies the name for the function (used to call it, etc).
<b>byref</b>	Optional. If present, the argument immediately following this modifier will be passed <a href="#">by reference</a> <sup>[68]</sup> .
argument[1, 2...]	Optional. The name of the argument(s) passed to the function; arguments must have a name which is a valid identifier. This is a local identifier, used to refer to these arguments within the body of the function.
<b>as</b>	Optional (required if arguments are specified). Precedes the type definition.
type[1, 2...]	Optional (required if arguments are specified). Specifies the <a href="#">data type</a> <sup>[48]</sup> for the argument. Each argument name must be followed with a type definition, even when specifying several arguments of the same type.
ret_type	Required. Specifies the type of the value the function will return. In effect, this is the data type of the function.
statement[1, 2...]	Required. The body of code executed within the function; specifies the actual 'work' done by the function.

### Details

Functions cannot be nested (which is why their scope is defined as global or HTML) . Function always return a single value. Functions can call other functions and subroutines.

The return value of a function must be explicitly set from within the body of the function, by referring to the name of the function as a variable (of type *ret\_type*) which is then assigned a value.

### Examples

```

'this is just an example to show how functions call each other. It's not
actually useful.
declare subtract (x as byte, y as byte) as integer ' have to declare,
because it's invoked before its body.

```

```
function distance(x as byte, y as byte) as integer
    if x>y then
        distance = subtract(x,y)
    else
        distance = subtract(y,x)
    end if
end function
...
function subtract (x as byte, y as byte) as integer
    subtract = x - y
end function
```

## Goto Statement

<b>Function:</b>	Jumps to a specific point in code, marked by a label.
<b>Syntax:</b>	<b>goto</b> label ... label:
<b>Scope:</b>	Local and HTML
<b>See Also:</b>	---

---

Part	Description
label	Required. Marks a specific point in code.

### Details

Unconditionally jumps to label in code. Notice that all goto labels are local -- you cannot use goto statement to jump from within one procedure into another procedure!

### Examples

```
dim arr1(5),arr2(5),f as byte

sub on_sys_init

arr1(0) = 1
arr1(1) = 2
arr1(2) = 3
arr1(3) = 4
arr1(4) = 5

arr2(0) = 1
arr2(1) = 2
arr2(2) = 2
arr2(3) = 4
arr2(4) = 5

'compare arrays and jump if not exactly the same
for f=0 to 4
```

```

    if arr1(f)<>arr2(f) then goto not_the_same
next f
'here when both arrays contain the same data
exit sub

'here when arrays are not the same
not_the_same:
'... place code here ...

```

## If... Then... Else Statement

<b>Function:</b>	A way to conditionally execute code.
<b>Syntax:</b>	<pre> <b>if</b> expression <b>then</b>     statement1     statement2     ...   [ <b>else</b>     statement1     statement2     ...   ] <b>end if</b> </pre> <p><i>or:</i></p> <pre> <b>if</b> expression <b>then</b> true_statement1 : true_statement2 ... </pre>
<b>Scope:</b>	Local and HTML
<b>See Also:</b>	<a href="#">Select-Case Statement</a> <sup>[97]</sup>

Part	Description
expression	Required. The result of this expression ( <b>true</b> or <b>false</b> ) is then used to determine what code will execute.
statement[1, 2...]	Required. Statements to execute.
:	Optional. Separator for multiple statements on a single line. Covered under <a href="#">Programming Fundamentals</a> <sup>[43]</sup> .

### Details

When the expression evaluates to **true**, the block of code immediately following the **then** keyword is executed. If it evaluates to **false**, the code immediately following the **else** keyword is executed; if there is no **else** keyword, program flow resumes from the line immediately following the **end if** keyword.

When using the single-line syntax (as in the lower example above), an **if** statement must not be terminated using an **end if**. This is the only construct under Tibbo Basic where line end matters. So, if you want to have several statements in such a construct, you need to place them all in the same line, and separate them with colons.

**If... then... else** statements may be nested.

- \* Currently, single-line **if... then** statements cannot contain an **else** clause. The **elseif** syntax is not currently supported at all (even on multi-line **if... then** statements).

### Examples

```
if net.failure=1 then
    if sys.runmode=0 then ser.setdata("Ethernet failure!"):ser.send
    'message when in debug mode
    sys.halt
else
    if net.linkstate=0 then
        ser.setdata("No Ethernet link!")
    else
        if net.linkstate=1 then
            ser.setdata("Linked at 10Mbit/s.")
        else
            ser.setdata("Linked at 100Mbit/s.")
        end if
    end if
    ser.send
end if
```

## Include Statement

<b>Function:</b>	Includes a file (such as a header file) at the point of the statement.
<b>Syntax:</b>	<b>include</b> "filename"
<b>Scope:</b>	Global and HTML
<b>See Also:</b>	<a href="#">Includepp Statement</a> <sup>[96]</sup>

Part	Description
"filename"	Contains the filename to be included. The path can be a relative path to the <a href="#">project path</a> <sup>[76]</sup> , an absolute path (such as c:\myfolder\myfile.tbs) or even a UNC path (such as \\MY-SERVER\Main\myfile.tbs).

### Details

Makes compiler include the contents of a file at the point of the include statement. Usually used to include header files with [declarations](#)<sup>[84]</sup>, definitions for [constants](#)<sup>[84]</sup>, [enum types](#)<sup>[88]</sup>, etc.

### Examples

File: global.tbh (a header file)

```
Declare Function multiply(x As Byte, y As Byte) As Integer
Const k=3 'a crucially vital global constant.
```

File: main.tbs (a source code file)

```
Include "global.tbh" ' now we have access to multiply and to K.

Sub on_sys_init
'
'   ...
'   Dim result As Integer
'   result = multiply(k, 3)
'   ...
'
End Sub
```

File: library.tbs (a source code file)

```
Include "global.tbh"

Public Function multiply(x As Byte, y As Byte) As Integer

    multiply = x * y

End Function
```

## Includepp Statement

<b>Function:</b>	Includes <a href="#">preprocessor directives</a> <sup>[76]</sup> found in a specified file at the point of the statement.
<b>Syntax:</b>	<b>includepp</b> "filename"
<b>Scope:</b>	Global and HTML
<b>See Also:</b>	<a href="#">Include Statement</a> <sup>[95]</sup>

Part	Description
"filename"	Contains the filename to be parsed for preprocessor directives. The path can be a relative path to the <a href="#">project path</a> <sup>[16]</sup> , an absolute path (such as c:\myfolder\myfile.tbs) or even a UNC path (such as \\MY-SERVER\Main\myfile.tbs).

### Details

Makes compiler parse the specified file and include all lines that start with "#". This is mainly intended to facilitate inclusion of preprocessor directives from library configuration files.

### Examples

As an example, consider the [setting configuration file](#)<sup>[670]</sup>, which defines the list of settings to be maintained by the [STG library](#)<sup>[668]</sup>. The file is supposed to provide a

list of [#define](#)<sup>[76]</sup> statements to override default #define statements of the STG library.

File: global.tbh (a header file)

```
includepp "settings.txt"
include "settings\trunk\settings.tbh"
```

File: settings.txt (setting descriptor file) -- actual contents

```
>>BT E    B    1    0    255    A    0    This is a Byte setting
>>WD E    W    1    0    65535  A    0    This is a word setting
>>ST E    S    1    0    16     A    ^    This is a String
setting
>>DD E    D    1    0    4      A    ^    This is a dot-decimal
String setting
#define STG_DESCRIPTOR_FILE "settings.txt"
#define STG_MAX_NUM_SETTINGS 4
#define STG_RAM_ARRAY_SIZE 0
#define STG_MAX_SETTING_NAME_LEN 2
#define STG_MAX_SETTING_VALUE_LEN 16
```

As a result, all #define statements from settings.txt will be included. Lines that do not start with "#" will be ignored.

## Select-Case Statement

**Function:** A way to conditionally execute code.

**Syntax:**

```
select select_expression
    case expression1_1 [ , expression1_2, ... ] [ : ]
        statement1_1
        statement1_2
    ...
    case expression2_1 [ , expression2_2, ... ] [ : ]
        statement2_1
        statement2_2
    ...
    [ case else [ : ]
        statementN_1
        statementN_2
    ...
    ]
end select
```

**Scope:** Local and HTML

**See Also:** [If... Then... Else Statement](#)<sup>[94]</sup>

Part	Description
------	-------------

<code>select_expression</code>	Required. The expression which is evaluated first; subsequent expressions are tested to match this expression. If a match is found, the statements contained within this <b>case</b> clause are executed, and execution then resumes from the line immediately following <b>end select</b> .
<code>expression[1_1...N_1]</code>	Required. An expression to evaluate; If it matches the <code>select_expression</code> , the statements included in this <b>case</b> clause are executed.
<code>statement[1_1...N_1]</code>	Required. Statements to execute when <code>expression[1_1...N_1]</code> matches <code>select_expression</code> .
<code>:</code>	Optional. Maintained for backwards compatibility -- some versions of BASIC in the past required a colon following every <b>case</b> expression.
<b>case else</b>	Optional. Precedes a block statements which is executed if neither of the earlier <b>case</b> clause match the <code>select_expression</code> . If present, must be the last <b>case</b> clause.

### Details

It is of note that once a matching **case** clause is found, no other **case** clauses are tested; the code within the matching clause is simply executed, and execution resumes from the line following **end select**.

Also, remember that writing two `select_expressions` at the same time does not mean that there will be a shared code for both of them. Rather, it means that the first expression will have no code associated with it!

```
...
case 1 : 'this expression has no code associated with it
case 2 : 'code 'x=5' belongs to this expression
      x=5
...
```

Correct way to have a single block of code for two expressions is as follows:

```
...
case 1,2 : 'x=5 will be done both for 1 and 2
      x=5
...
```

### Examples

```
sub print_weekday (weekday as byte)
  select case weekday
    case 1 : ser.setdata("Monday")
    case 2 : ser.setdata("Tuesday")
    case 3 : ser.setdata("Wednesday")
    case 4 : ser.setdata("Thursday")
    case 5 : ser.setdata("Friday")
    case 6 : ser.setdata("Saturday")
```

```

    case 7 : ser.setdata("Sunday")
    case else : ser.setdata("Did you just invent a new day?")
end select
ser.send
end sub

```

## Sub Statement

<b>Function:</b>	Used to define <a href="#">subs</a> <sup>[66]</sup> -- distinct units in code which perform specific tasks. These never return any value.
<b>Syntax:</b>	<pre> [ <b>public</b> ] <b>sub</b> name [ ( [ <b>byref</b> ] argument1 <b>as</b> type1, [ <b>byref</b> ] argument2 <b>as</b> type2... ) ]     statement1     statement2     ...     <b>[exit sub]</b>     ...     statementN <b>end sub</b> </pre>
<b>Scope:</b>	Global
<b>See Also:</b>	<a href="#">Declare Statement</a> <sup>[84]</sup> , <a href="#">Exit Statement</a> <sup>[89]</sup> , <a href="#">Function Statement</a> <sup>[91]</sup>

Part	Description
<b>public</b>	Optional. If set, allows other compilation units (files in a project) to access the function.
name	Required. Specifies the name for the function (used to call it, etc).
<b>byref</b>	Optional. If present, the argument immediately following this modifier will be passed <a href="#">by reference</a> <sup>[68]</sup> .
argument[1, 2...]	Optional. The name of the argument(s) passed to the function; arguments must have a name which is a valid identifier. This is a local identifier, used to refer to these arguments within the body of the function.
<b>as</b>	Optional (required if arguments are specified). Precedes the type definition.
type[1, 2...]	Optional (required if arguments are specified). Specifies the <a href="#">data type</a> <sup>[48]</sup> for the argument. Each argument name must be followed with a type definition, even when specifying several arguments of the same type.
statement[1, 2...]	Required. The body of code executed within the function; specifies the actual 'work' done by the function.

### Details

Subroutines cannot be nested (which is why their scope is defined as global or HTML). Subroutines do not return values. Subroutines can call other subroutines

and functions.

### Examples

```
sub print_to_serial(s as byref string)
  ser.setdata(s)
  ser.send
  s = "OK" ' This sub actually returns something, if indirectly.
end sub
```

## Type Statement

<b>Function:</b>	Used to declare <a href="#">structures</a> <sup>[58]</sup> -- combinatorial data types that includes one or several <i>member</i> variables.
<b>Syntax:</b>	<b>type</b> type_name name1 [ (bounds1) ] <b>as</b> type [ (max_string_size) ] ... nameN [ (boundsN) ] <b>as</b> type [ (max_string_size) ] <b>end type</b>
<b>Scope:</b>	Global, HTML and local
<b>See Also:</b>	<a href="#">Dim Statement</a> <sup>[86]</sup>

Part	Description
type_name	Required. Specifies the name for this structure <i>type</i> (not a particular variable).
name[1, 2...]	Required. Specifies the name for the member variable.
bounds[1, 2...]	Optional. Specifies the boundary (finite size) of a dimension in an array. Several comma-delimited boundary values make a multi-dimensional array.
<b>as</b>	Required. Precedes the type definition.
type	Required. Specifies the <a href="#">type</a> <sup>[48]</sup> of the variable.
max_string_size	Optional (can be used only when <i>type</i> is string). Sets the maximum size for a string (default size is 255 bytes).
<b>end type</b>	Required. Closes type declaration.

### Details

Structures can include any number of members, and each member can be of any type. Any member can also be an array or another structure. Nesting of up to 8 levels is allowed (i.e. "array within a structure within a structure within and array" -- each structure or array is one level and up to 8 levels are possible).

**Type...end type** is only a declaration, not a variable definition! You still need to use a regular [dim](#)<sup>[86]</sup> statement to define a variable of the type you have declared.

### Examples

```
'declare new type
```

```

type my_struct
  x as byte
  y as Long
  s as string(10)
end type

'define a variable of this type
dim my as my_struct

```

## While-Wend Statement

<b>Function:</b>	Executes a block of code as long as an expression evaluates to <b>true</b> .
<b>Syntax:</b>	<pre> while expression   statement1   statement2   ...   [exit sub]   ...   statementN wend </pre>
<b>Scope:</b>	Local and HTML
<b>See Also:</b>	<a href="#">Do-Loop Statement</a> <sup>[87]</sup> , <a href="#">For... Next Statement</a> <sup>[90]</sup> , <a href="#">Exit Statement</a> <sup>[89]</sup>

Part	Description
expression	Required. The expression which is to be evaluated.
statement[1, 2...]	Required. The code to run when the expression is <b>true</b> .

### Details

Makes a pre-conditional loop. First, the expression is evaluated and then if it is **true** statement1, statement2, etc are executed. Then expression is evaluated again and so on until expression becomes **false**.

### Examples

```

function wait_char(ch as byte) as byte
  ' waits for specific character with ASCII code ch to arrive into the serial
  port.
  ' returns 0 if char was encountered or 1 if this character was encountered

  dim s as string(1)

  ' input data byte by byte for as long as there is some data left to
  process
  s = ser.getdata(255) ' will input byte by byte as s only can contain a
  single char!
  while len(s) <> 0

```

```
        if s = chr(ch) then
            wait_char = 0 ' character encountered!
            exit function
        end if
        s = ser.getdata(255)
    wend

    wait_char = 1 ' did not encounter ch character and there is no more
data to input (for now)!

End Function
```

## Keywords

This chapter contains links from single keywords to the statements in which you may find them. It is meant to be used as a resource for context-sensitive help.

### As

A keyword designating data type. Appears as part of the following statements:

[Declare Statement](#)<sup>[84]</sup>

[Dim Statement](#)<sup>[86]</sup>

[Function Statement](#)<sup>[91]</sup>

[Sub Statement](#)<sup>[99]</sup>

### Boolean

A data type. Please see [Variables And Their Types](#)<sup>[48]</sup>.

### ByRef

A keyword designating a way of passing arguments. Appears as part of the following statements:

[Function Statement](#)<sup>[91]</sup>

[Sub Statement](#)<sup>[99]</sup>

For further details, see [Passing Arguments to Procedures](#)<sup>[68]</sup>.

### Byte

A data type. Please see [Variables And Their Types](#)<sup>[48]</sup>.

### ByVal

A keyword designating a way of passing arguments. Appears as part of the following statements:

[Function Statement](#)<sup>[91]</sup>

[Sub Statement](#)<sup>[99]</sup>

For further details, see [Passing Arguments to Procedures](#)<sup>[68]</sup>.

## Char

A data type. Please see [Variables And Their Types](#)<sup>[48]</sup>.

## Else

A keyword used to denote conditions. Appears as part of the following statements:

[If... Then... Else Statement](#)<sup>[94]</sup>

[Select-Case Statement](#)<sup>[97]</sup>

## End

This keyword is used in the following statements:

[Enum Statement](#)<sup>[88]</sup>

[Function Statement](#)<sup>[97]</sup>

[Select Statement](#)<sup>[97]</sup>

[Sub Statement](#)<sup>[99]</sup>

[Type Statement](#)<sup>[100]</sup>

## False

A byte constant with a value of 0, associated with [boolean](#)<sup>[48]</sup> variables.

## For

Appears as part of the following statement:

[For... Next Statement](#)<sup>[90]</sup>

## Integer

A data type. Please see [Variables And Their Types](#)<sup>[48]</sup>.

## Next

Appears as part of the following statement:

[For... Next Statement](#)<sup>[90]</sup>

## Public

A keyword used to denote visibility. Appears as part of the following statements:

[Dim Statement](#)<sup>[86]</sup>

[Function Statement](#)<sup>[97]</sup>

[Sub Statement](#)<sup>[99]</sup>

For further details, see [Understanding the Scope of Variables](#)<sup>[67]</sup>.

## Short

A data type. Please see [Variables And Their Types](#)<sup>[48]</sup>.

## Step

Appears as part of the following statement:

[For... Next Statement](#)<sup>[90]</sup>

## String

A data type. Please see [Variables And Their Types](#)<sup>[48]</sup>.

## Then

A keyword used to denote conditional execution. Appears as part of the following statement:

[If... Then... Else Statement](#)<sup>[94]</sup>

## Type

Appears as part of the following statement:

[Type Statement](#)<sup>[100]</sup>

## To

Appears as part of the following statement:

[For... Next Statement](#)<sup>[90]</sup>

## True

A byte constant with a value of 1, associated with [boolean](#)<sup>[48]</sup> variables.

## Word

A data type. Please see [Variables And Their Types](#)<sup>[48]</sup>.

## Operators

Tibbo Basic supports the following operators:

### + Operator

Addition operator (applies to strings as well).

```
i = 1 + 2 ' this would be 3
s = "foo" + "bar" ' this would be "foobar"
```

### \* Operator

Multiplication operator.

```
i = 5 * 2 ' 10.
```

### - Operator

Subtraction Operator.

```
i = 20 - 5 ' 15
```

### / Operator

Division operator.

```
i = 30 / 10 ' 3
i = 10 / 3 ' also 3 -- only integers are supported, decimal part is removed.
```

### MOD Operator

Used to divide two numbers and return the remainder.

```
i = 10 mod 3 ' this would be 1
```

### = Operator

**(1)** Equality operator. **(2)** Assignment operator.

```
if i = 5 then .... ' as an equality operator

i = 5 ' as an assignment operator
```

## AND Operator

**(1)** Logical AND. **(2)** Bitwise AND.

```
if i = 5 AND j = 10 then.... ' as a logical AND

x =
&b01011001 AND
&b10101011 ' this would be
&b00001001
```

## NOT Operator

**(1)** Logical NOT. **(2)** Bitwise NOT.

```
if NOT b then.... ' as a logical NOT -- b is a boolean value

x = NOT &b01011001 ' this would be &b10100110
```

## OR Operator

**(1)** Logical OR. **(2)** Bitwise OR.

```
if i = 5 OR j = 10 then.... ' as a logical OR

x =
&b10110101 OR
&b01011001 ' this would be
&b11111101
```

## XOR Operator

**(1)** Logical XOR. **(2)** Bitwise XOR.

```
if i = 5 XOR j = 10 then.... ' as a logical XOR

&b10110101 XOR
&b01011001 ' this would be
&b11101100
```

## Error Messages

Below is a listing of all error messages which may appear when trying to build and upload your Tibbo BASIC program onto a target.

## C1001

### Description:

This error occurs when a source file contains an “illegal” character (like a special character, a non-English letter, etc) outside of a string literal or a comment.

### Example:

```
%dim x as byte ' error C1001: invalid char '%' (25)
```

### See Also

- [Naming Conventions](#)<sup>[47]</sup>

## C1002

### Description:

This error occurs when source code contains a line break inside a string literal or a character constant.

### Example:

```
S = "I am a string  
literal " ' error C1002: newline in constant
```

### See Also

- [Variables And Their Types](#)<sup>[48]</sup>

## C1003

### Description:

Unlike string literals, character constants may not be empty.

### Example:

```
x = `` ' error C1003: empty char constant
```

### See Also

- [Constants](#)<sup>[65]</sup>

## C1004

### Description:

Character constants may contain two characters at most (in which case, the constant type will be 'word').

### Example:

```
x = `abc` ' error C1004: too many chars in constant
```

### See Also

- [Constants](#) <sup>[65]</sup>
- [\\*\\*\\*](#) <sup>[7]</sup>

## C1005

### Description:

The compiler detected an attempt to specify a numerical constant using an incorrect format.

### Example:

```
x = &G12 ' error C1005: invalid numeric constant: unknown base 'G'  
x = &b102 ' error C1005: invalid numeric constant  
x = 10a ' error C1005: invalid numeric constant
```

### See Also

- [Type Conversion](#) <sup>[50]</sup>

## C1006

### Description:

This error occurs when Tibbo BASIC syntax is violated. Refer to the documentation of a particular statement to see its syntax.

### Example:

```
select x \ error C1006: 'Case' expected  
case 1: case 2:  
    b = true  
case 3:  
    b = false
```

```
    case else:
        sys.halt
    end select

sub on_init
    ...
end function ' error C1006: 'End Sub' expected
```

### See Also

- [Language Reference](#)<sup>[83]</sup>

## C1007

### Description:

A numerical constant does not fit in any supported numerical type.

### Example:

```
x = 65536 ' error C1007: Constant too big
x = -32769 ' error C1007: Constant too big

enum my_enum
    my_val1 = -32768,
    my_val2 = 32768
end enum ' error C1007: enum range is too wide
```

### See Also

- [Variables And Their Types](#)<sup>[48]</sup>
- [Constants](#)<sup>[65]</sup>

## C1008

### Description:

This error occurs when an expression which should be constant is not actually constant.

### Example:

```
dim x as integer
const a = 5 * x ' error C1008: constant expression expected
```

**See Also**

- [Constants](#)<sup>[65]</sup>

## C1009

**Description:**

This error occurs when the requested operation cannot be performed using the data types provided.

**Example:**

```
dim s as string
s = "abc" + 5 ' error C1009: type mismatch
```

**See Also**

- [Variables And Their Types](#)<sup>[48]</sup>

## C1010

**Description:**

This error occurs when attempting to re-use an identifier that is already used (and thus, cannot be reused in the current scope) in a definition or a declaration (of an enumeration type, a constant, a variable or a function).

**Example:**

```
dim x as string
sub x ' error C1010: redefinition of identifier 'x'
...
end sub
```

**See Also**

- [Identifier](#)<sup>[137]</sup>

[\\*\\*\\*](#)<sup>[7]</sup>

## C1011

### Description:

This error occurs when attempting to define a procedure twice.

### Example:

```
sub x
end sub

sub x ' error C1011: 'x' already has body
end sub
```

### See Also

- [Sub Statement](#)<sup>[99]</sup>
- [Function Statement](#)<sup>[91]</sup>

## C1012

### Description:

The definition for a procedure does not match a previous declaration for that procedure (a different number or type of arguments and/or a return value)

### Example:

```
declare sub x

sub x(i as integer) ' error C1012: argument count mismatch (see previous
declaration of 'x')
end sub
```

### See Also

- [Declare Statement](#)<sup>[84]</sup>
- [Sub Statement](#)<sup>[99]</sup>
- [Function Statement](#)<sup>[91]</sup>

## C1013

### Description:

This error occurs when a statement references an identifier which has not previously been defined.

**Example:**

```
dim x as integer
x = 15 * y ' error C1013: undeclared identifier 'y'
```

**See Also**

- [Dim Statement](#)<sup>[86]</sup>

## C1014

**Description:**

Identifiers can refer to entities of different types: labels, variables, procedures, enumeration types, constants. This error occurs when you cannot use identifier of a certain type in the current statement.

**Example:**

```
dim x as integer
goto x ' error C1014: 'x' is not a label
```

**See Also**

- [Identifier](#)<sup>[137]</sup>

## C1015

**Description:**

The **next** clause of a **for/next** statement must use the same index variable as the **for** clause.

**Example:**

```
dim i,j as integer
for i = 1 to 10
next j ' error C1015: 'For'/'Next' arguments mismatch
```

**See Also**

- [For... Next Statement](#)<sup>[90]</sup>

## C1016

### Description:

The **exit** statement may be used only from within certain statements (**for**, **while**, **do-loop**, **sub**, **function**). This error occurs when the compiler encounters an **exit** statement which is used not from within one of these statements.

### Example:

```
for i = 1 to 10
    exit while ' error C1016: 'Exit' is of scope
next i
```

### See Also

- [Exit Statement](#)<sup>[89]</sup>
- [\\*\\*\\*](#)<sup>[7]</sup>

## C1017

### Description:

Assignment statements must contain a value on left side of the equal sign (called an l-value). This can be a variable, an array element or a read-write property, and may not be a constant.

### Example:

```
1 = x ' error C1017: l-value expected on the left of '='
```

## C1018

### Description:

Assignment statements must contain a value on right side of the equal sign (called an r-value). This error occurs when an expression on the right side of such a statement does not return a value.

### Example:

```
sub sub1
...
end sub
```

```
...  
x = sub1 ' error C1018: subroutine cannot be on the right of '='
```

## C1019

### Description:

This error occurs when attempting to access a variable which is not an array as if it were an array (by using an index number).

### Example:

```
dim i,j as integer  
i = j(3) ' error C1019: j is not array
```

### See Also

- [Introduction to Variables, Constants and Scopes](#)<sup>[47]</sup>
- [Arrays](#)<sup>[54]</sup>

## C1020

### Description:

This error occurs when trying to define an array with more than 8 dimensions (a maximum of 8 dimensions are allowed).

### Example:

```
dim i(2,2,2,2,2,2,2,2,2) as integer ' error C1020: Too many array dimensions  
(8 max)
```

### See Also

- [Arrays](#)<sup>[54]</sup>

## C1021

### Description:

This error occurs when a property was defined for read-only or for write-only, but the program tries to access this property in a different way.

**Example:**

```
sys.runmode = PL_SYS_MODE_DEBUG ' error C1021: write access to property is denied
```

**See Also**

- [Understanding Platforms](#)<sup>[82]</sup>

## C1022

**Description:**

There are several system calls which the compiler uses directly, and are invoked implicitly in code (string comparison, string copy, conversion from string to number, etc). This error occurs when a platform does not export these functions, but source code requires them.

**Example:**

```
doevents ' error C1022: platform does not export 'doevents' syscall
```

**See Also**

- [Type Conversion](#)<sup>[50]</sup>
- [\\*\\*\\*](#)<sup>[7]</sup>

## C1023

**Description:**

The global scope may contain only declarations/definitions of procedures, variables, enumeration types and constants. This error occurs when some other statement is encountered at the global scope.

**Example:**

```
for i = 1 to 10 ' error C1023: Unexpected at global scope  
next i
```

**See Also**

- [Understanding the Scope of Variables](#)<sup>[61]</sup>

[\\*\\*\\*](#) 

## C1024

### Description:

This error occurs when an **include** statement references a file which cannot be read. Most commonly, it means the filename was misspelled.

### Example:

```
include "utileties.tbh" ' error C1024: unable to read file 'utileties.tbh'
```

### See Also

- [Include Statement](#) 

## L1001

### Description:

This error is occurs when the linker tries to link two object files which have different data base addresses.

Lower addresses are reserved for passing arguments and returning values from platform syscalls. The data base address for program variables is calculated according to how much memory platform syscalls require for arguments and return values.

Most commonly, this error means that you are trying to link object files built for different platforms.

### See Also

- [System Components](#) 

## L1002

### Description:

This error occurs when the linker attempts to link two object files with different counts of platform event handlers. Most commonly this error means that you are trying to link object files built for two different platforms.

### See Also

- [System Components](#) 

## L1003

### Description:

During linking, one or more addresses remained unresolved. That means that these addresses are referenced from one or more compilation units but are never defined.

### See Also

- [Declare Statement](#)<sup>[84]</sup>

## L1004

### Description:

This error means that when linking two object files, the linker encountered a situation where the import is a data address and the export is a code address or vice versa.

## L1005

### Description:

Since all memory allocation is static, recursion is not supported. This error occurs whenever the linker encounters recursion (direct or indirect).

### See Also

- [Introduction to Procedures](#)<sup>[66]</sup>
- [Our Language Philosophy](#)<sup>[4]</sup>

## L1006

### Description:

The TiOS Virtual Machine may hold up to 255 stack locations. This error occurs when the linker needs to reserve more stack locations. That does not necessarily mean that the direct call chain in program is 255 calls long. Each independent **doevents** statement approximately doubles the required needed stack locations.

**See Also**

- [Doevents](#)<sup>[73]</sup>
- [System Components](#)<sup>[7]</sup>

**L1007****Description:**

A function which contains a **doevents** statement may not be called from more than one independent call chain.

**See Also**

- [Doevents](#)<sup>[73]</sup>
- [\\*\\*\\*](#)<sup>[7]</sup>

**L1008****Description:**

The amount of RAM needed to store variables for your project exceeds the maximum possible size for this platform. In simple terms, your variables take up too much space.

**See Also**

- [Platform Specifications](#)<sup>[138]</sup>
- [\\*\\*\\*](#)<sup>[7]</sup>

**L1009****Description:**

The amount of FLASH (program memory) needed to store your project exceeds the maximum possible size for this platform. I.e, your program is too large.

**See Also**

- [Platform Specifications](#)<sup>[138]</sup>

---

## Objects, Properties, Methods, Events

Under Tibbo Basic, these are all platform-specific constructs.

Please refer to your [Platform](#)<sup>138</sup> documentation for details about the objects, properties, methods and events for your platform.

## Development Environment

Below is an overview of the TIDE GUI.

As a general rule, those things which you know from common Windows programs (such as Window > Tile) will work just as you would expect them to work. We will concentrate on the more unique parts of the TIDE GUI.

## Installation Requirements

The recommended system requirements for TIDE are:


- 800 MHz Intel Pentium III processor (or equivalent) and later
- Windows 98, ME, 2000, XP, 2003
- 256 MB RAM
- 20MB of available disk space
- A communication medium with your target (platform-specific)
- At least one target device to work with (required for debugging)
- 1024 x 768, 24-bit display recommended

## User Interface

The following is a systematic overview of the TIDE graphical user interface.

## Main Window

The main window for TIDE looks like this:



The parts in the screenshot above are:

- (1) The [Menu Bar](#)<sup>[121]</sup>
- (2) The [Project Toolbar](#)<sup>[126]</sup>
- (3) The [Debug Toolbar](#)<sup>[126]</sup>
- (4) The [Code Editor](#)<sup>[120]</sup>
- (5) The [Project Pane](#)<sup>[134]</sup>
- (6) The [Watch Pane](#)<sup>[135]</sup>
- (7) The [Output Pane](#)<sup>[133]</sup>
- (8) The [Call Stack Pane](#)<sup>[133]</sup>
- (9) The [Status Bar](#)<sup>[130]</sup>

## Operation Modes

Essentially, the TIDE GUI has two primary modes: The Edit Mode, in which you write the code for your application, and the Debug Mode, which is used while your code is running on the target and you are debugging it.

In each of these modes you may show, hide or resize various interface elements. The changes you make in one mode do not affect the other state. I.e, you could display the [Debug Toolbar](#)<sup>[126]</sup> while in Debug Mode and hide it while in Edit Mode. Every time you will go into Debug Mode, the toolbar would appear. When you switch back to the Edit Mode, the toolbar will disappear. Thus, you may customize your

workspace so it would serve you best both while editing code and while debugging.

Another key difference is that while in Debug Mode you cannot enter any new code. Whenever you try to type code while in this mode, you will be prompted to stop program execution on the target and switch back to Edit Mode.

You can easily tell the two modes apart by the background color of the code editor pane: When the background is white, you are in Edit Mode. When it's grey, you are in Debug Mode.

## Menu Bar


A standard bar, modeled after the classic Windows menu bar.



See below:

- [File Menu](#)<sup>[121]</sup>
- [Edit Menu](#)<sup>[122]</sup>
- [View Menu](#)<sup>[122]</sup>
- [Project Menu](#)<sup>[123]</sup>
- [Debug Menu](#)<sup>[124]</sup>
- [Image Menu](#)<sup>[124]</sup> (visible only when graphical resource is selected for editing)
- [Window Menu](#)<sup>[125]</sup>
- [Help Menu](#)<sup>[125]</sup>

## File Menu .3.1



**New Project:** Displays the [New Project](#)<sup>[132]</sup> dialog.

**Open Project:** Opens an existing project

**Save Project:** Saves all modified files on this project. Happens automatically on build.

**Close Project:** Closes current project.

**Save File:** Saves the current file.

**Close File:** Closes the current file.

**Print:** Prints the current file.


**Print Preview:** Check output before printing.

**Print Setup:** Configure printing.

**1... 4:** Recent files.

**Exit:** Quits TIDE.

## Edit Menu.3.2



**Undo:** Cancels last action.


**Redo:** Cancels last undo.

**Cut, Copy, Paste:** Standard edit actions.

**Select All:** Select all text.

**Find, Find Next, Find Prev, Find in Files, Replace:** Standard find & replace actions.

## View Menu.3.3



**Project Toolbar:** Toggles (shows/hides) the [Project](#) toolbar.

**Debug Toolbar:** Toggles the [Debug](#) toolbar.

**Status Bar:** Toggles the [Status Bar](#).

**Project:** Toggles the [Project](#) pane.

**Output:** Toggles the [Output](#) pane.

**Clear Output:** Clears the contents of the Output pane.


**Watch:** Toggles the [Watch](#) pane.

**Call Stack:** Toggles the [Call Stack](#) pane.

**Auto-complete List:** Show an appropriate [auto-complete list](#) for the current context.

**Argument List:** Show a list of arguments for the current procedure call.

## Project Menu



**Settings:** Displays the [Project Settings](#) dialog.

**Select/Manage Target:** Shows the platform-specific dialog used to select a target for your project and upload firmware.

**Add File:** Displays the [Add file to project](#) dialog.

**Remove File:** Removes the file currently selected in the Project Tree from the project. Does not delete file from disk.

**Rename File:** Renames the file currently selected in the Project Tree.

**Build:** Builds project without uploading. Builds only files modified since last build.


**Rebuild All:** Rebuilds project including all files -- even those not modified since last build.

**Build and Upload:** Builds if necessary, and uploads project to target without running it.

**Rebuild All and Upload:** Rebuilds project including all files, uploads and does not run.

**Stop Build/Upload/Debug:** Stops building, uploading or debugging. Exits debug mode. If the target was running, it will continue running.

## Debug Menu5



**Restart:** Reboots the target device. Rebooting the device will not resume execution. Once the device has finished the reboot process, execution will be paused, pending further debug instructions.

**Run:** Begins or resumes program execution on target. If switching from Edit mode, this optionally compiles and uploads the project (when needed).

**Pause:** Pauses program execution. Covered under [Target States](#)<sup>[28]</sup> above.

**Step Into:** Covered under [Stepping](#)<sup>[33]</sup> above.

**Step Over:** Covered under [Stepping](#)<sup>[33]</sup> above.

**Step Out:** Covered under [Stepping](#)<sup>[33]</sup> above.

**Run to Cursor:** Covered under [Stepping](#)<sup>[33]</sup> above.

**Jump to Cursor:** Covered under [Stepping](#)<sup>[33]</sup> above.


**Toggle Breakpoint:** Covered under [Breakpoints](#)<sup>[30]</sup> above.

**Remove All Breakpoints:** Covered under [Breakpoints](#)<sup>[30]</sup> above.

**Add to Watch List:** Covered under [The Watch](#)<sup>[33]</sup> above.

**Remove from Watch List:** Covered under [The Watch](#)<sup>[33]</sup> above.

## Image Menu6



This menu is visible only when a graphical resource is selected for editing. TIDE

"knows" how to work with *.bmp*, *.jpg*, *.gif*, and *.png* files.

**Resize:** Changes the size of the image's "canvas". This is not re-sampling of the image: existing image elements won't shrink or get larger, just the total image size in pixels will change. If the new image size is smaller than portions of the image at the right and on the bottom will be lost.

**Zoom In:** Selects higher magnification. x1, x2, x4, x8, x16 magnification levels are available.

**Zoom Out:** Selects lower magnification. x1, x2, x4, x8, x16 magnification levels are available.

**Grid:** Toggles image grid visible/invisible.


**Flip H:** Mirrors entire image or selected rectangular area (if selection is made) horizontally.

**Flip V:** Mirrors entire image or selected rectangular area (if selection is made) vertically.

**Rotate Right 90:** Rotates entire image or selected rectangular area (if selection is made) 90 degrees clockwise.

**Rotate Left 90:** Rotates entire image or selected rectangular area (if selection is made) 90 degrees counter-clockwise.

## Window Menu




**Close:** Closes current window. Can also be done with Ctrl+W.

**Close All:** Closes all open documents without closing projects.

**Cascade, Tile:** Standard window actions.

## Help Menu3.8



**Contents:** Opens the help file at the contents.

**Index:** Opens the help file at the index.

**Search:** Opens the help file in search mode.

**Context-Sensitive Help:** Opens the help file at the topic for the currently selected keyword in the code editor.

**Online Support:** Open <http://www.tibbo.com/taiko.php> using the default browser.

**About TIDE:** Displays version information, etc.

## Toolbars

The TIDE has the following toolbars:

- [Project Toolbar](#)<sup>[126]</sup>
- [Debug Toolbar](#)<sup>[126]</sup>
- [Image Editor Toolbar](#)<sup>[127]</sup> (visible only when graphical resource is selected for editing)
- [Tool Properties Toolbar](#)<sup>[128]</sup> (visible only when graphical resource is selected for editing, contents depend on the selected tool)

### Project Toolbar



- **New Project:** Displays the [New Project](#)<sup>[132]</sup> dialog.
- **Open Project:** Opens an existing project
- **Save Project:** Saves all modified files on this project. Happens automatically on build.
- **Add File:** Displays the [Add file to project](#)<sup>[132]</sup> dialog.
- **Remove File:** Removes current file from project. Does not delete file from disk.
- **Settings:** Displays the [Project Settings](#)<sup>[131]</sup> dialog.
- **Copy:** Self-explanatory.
- **Cut:** Self-explanatory.
- **Paste:** Self-explanatory.
- **Undo:** Cancels last action.
- **Redo:** Cancels last undo.
- **Find:** Self-explanatory.
- **Find Next:** Self-explanatory.
- **Find Prev:** Self-explanatory.
- **Replace:** Self-explanatory.

### Debug Toolbar



**Select/Manage Target:** Shows the platform-specific dialog used to select a target for your project and upload firmware.

**Build:** Builds project without uploading. Builds only files modified since last build.

**Build and Upload:** Uploads project to target without running it. Builds prior to upload, if required.

**Restart:** Reboots the target device. Rebooting the device will not resume execution. Once the device has finished the reboot process, execution will be paused, pending further debug instructions.

**Run:** Begins or resumes program execution on target. If switching from Edit mode, this optionally compiles and uploads the project (when needed).

**Pause:** Pauses program execution. Covered under [Target States](#)<sup>[28]</sup> above.

**Stop Build/Upload/Debug:** Stops building, uploading or debugging. Exits debug mode. If the target was running, it will continue running.

**Step Into:** Covered under [Stepping](#)<sup>[33]</sup> above.

**Step Over:** Covered under [Stepping](#)<sup>[33]</sup> above.

**Step Out:** Covered under [Stepping](#)<sup>[33]</sup> above.

**Run to Cursor:** Covered under [Stepping](#)<sup>[33]</sup> above.

**Jump to Cursor:** Covered under [Stepping](#)<sup>[33]</sup> above.

**Toggle Breakpoint:** Covered under [Breakpoints](#)<sup>[30]</sup> above.

**Add to Watch List:** Covered under [The Watch](#)<sup>[33]</sup> above.

**Remove from Watch List:** Covered under [The Watch](#)<sup>[33]</sup> above.

## Image Editor Toolbar



This toolbar is visible only when graphical resource is selected for editing. When you select a certain tool an additional [Tool Properties Toolbar](#)<sup>[128]</sup> specifically for this tool is displayed. This toolbar provides all options for the selected tool.

**Selection Tool:** Selects rectangular image area to move, copy, or transform.

**Hand Tool:** Allows you to scroll the image using "hand grip" (position the tool over the image, click and hold left mouse button, then drag the image).

**Paint Tool:** Use this tool to do "freehand" painting over the image.

**Eraser Tool:** Erases portions of the image (paints with background color).

**Text Tool:** Adds text to the image.

**Line Tool:** Draws straight lines.

**Rectangle Tool:** Draws rectangles.

**Ellipse Tool:** Draws ellipses.

**Eyedropper Tool:** "Picks" the color off the image (left-click over the image to pick the fore-color; right click to pick the background color).

**Zoom Tool:** Changes the zoom level (magnification). x1, x2, x4, x8, x16 zoom levels are available.

## Tool Properties Toolbar

When you select a certain [image edit tool](#)<sup>[127]</sup> an additional properties toolbar specifically for this tool is displayed. This toolbar provides all options for the selected tool. The following toolbars are available:

- [Selection Tool Properties Toolbar](#)<sup>[128]</sup>
- [Paint Tool Properties Toolbar](#)<sup>[128]</sup>
- [Eraser Tool Properties Toolbar](#)<sup>[128]</sup>
- [Text Tool Properties Toolbar](#)<sup>[129]</sup>
- [Line Tool Properties Toolbar](#)<sup>[129]</sup>
- [Rectangle Tool Properties Toolbar](#)<sup>[129]</sup>
- [Ellipse Tool Properties Toolbar](#)<sup>[130]</sup>
- [Zoom Tool Properties Toolbar](#)<sup>[130]</sup>

### Selection Tool Properties



**Transparency Mode:** For drag/drop and copy/paste operations selects whether pixels of background color will be copied to the destination as well. When the transparency mode is OFF the rectangular image fragment being copied or moved will overlay original image underneath completely. When the transparency mode is ON the original image will still be visible through the copied data.


**Flip Horizontally:** Mirrors entire image or selected rectangular area (if selection is made) horizontally.

**Flip Vertically:** Mirrors entire image or selected rectangular area (if selection is made) vertically.

**Rotate Left 90:** Rotates entire image or selected rectangular area (if selection is made) 90 degrees counter-clockwise.

**Rotate Right 90:** Rotates entire image or selected rectangular area (if selection is made) 90 degrees clockwise.

### Paint Tool Properties



**Inversion Mode:** Toggles paint tool's inversion mode on/off. When inversion is OFF, left-clicking on an image pixel changes this pixel's color to fore-ground color; right-clicking changes the color to background color. With inversion ON, left-clicking causes the pixel to alternate between fore-ground and background colors.


**Size:** "Pencil tip" width in pixels.

### Eraser Tool Properties



**Size:** "Eraser width" in pixels.

## Text Tool Properties



**Transparency Mode:** selects whether original image will still be visible underneath the text. When the transparency mode is OFF, original image will not be visible. When the transparency mode is ON, original image will be visible.

**Inversion Mode:** Toggles text tool's inversion mode on/off. When inversion is OFF, the text will always be printed in the fore-ground color. When inversion is ON, the text will appear in fore-ground color over the areas originally painted in background color and in background color over the areas originally painted with non-background color.

**Font Selector:** Selects the font to print the text with.

**Font Size:** Selects the size of the font.

**Bold:** Toggles bold attribute for the font on/off.

**Italic:** Toggles italic attribute for the font on/off.

**Underline:** Toggles underline attribute for the font on/off.

**Left:** Selects left alignment for the text (result is visible with multi-line text only).

**Center:** Selects center alignment for the text (result is visible with multi-line text only).

**Right:** Selects right alignment for the text (result is visible with multi-line text only).

## Line Tool Properties



**Inversion Mode:** Toggles line tool's inversion mode on/off. When inversion is OFF, the line will always be drawn in the fore-ground color. When inversion is ON, the line will appear in fore-ground color over the areas originally painted in background color and in background color over the areas originally painted with non-background color.

**Size:** Line width in pixels.

## Rectangle Tool Properties



**Inversion Mode:** Toggles rectangle tool's inversion mode on/off. When inversion is OFF, the rectangle's border will always be drawn in the fore-ground color and filling (for filled rectangles) will always be done with background color. When inversion is ON, the rectangle's border will appear in fore-ground color over the areas originally painted in background color and in background color over the areas originally painted with non-background color. The color for the "filling" (when enabled) will be exactly opposite.

**Solid Rectangle:** Creates a rectangle filled with fore-ground color (+ inversion mode effect is applied with enabled).

**Filled Rectangle:** Creates a rectangle with the border of fore-ground color and filled with the background color (+ inversion mode effect is applied with enabled).

**Unfilled Rectangle:** Creates a rectangle with the border of fore-ground color and no filling (+ inversion mode effect is applied with enabled).

**Size:** Border width (irrelevant for solid rectangles).

**Corner rounding:** Defines the radius of rectangle corners.

## Ellipse Tool Properties



**Inversion Mode:** Toggles ellipse tool's inversion mode on/off. When inversion is OFF, the ellipse's border will always be drawn in the fore-ground color and filling (for filled ellipses) will always be done with background color. When inversion is ON, the ellipse's border will appear in fore-ground color over the areas originally painted in background color and in background color over the areas originally painted with non-background color. The color for the "filling" (when enabled) will be exactly opposite.

**Solid Ellipse:** Creates an ellipse filled with fore-ground color (+ inversion mode effect is applied with enabled).

**Filled Ellipse:** Creates an ellipse with the border of fore-ground color and filled with the background color (+ inversion mode effect is applied with enabled).

**Unfilled Ellipse:** Creates an ellipse with the border of fore-ground color and no filling (+ inversion mode effect is applied with enabled).

**Size:** Border width (irrelevant for solid ellipses).

## Zoom Tool Properties



**Zoom Level:** Selects one of available zoom (magnification) levels.

## Status Bar

Below is a screenshot of the status bar:



**Target:** Shows selected debug transport and target address (in this case, MAC address).

**Progress Bar:** Shows progress during long operations (uploading binary, etc).

**Communication State indicator:** Covered under [Target States](#)<sup>[28]</sup> above.

-  **Target State indicator:** Covered under [Target States](#)<sup>[28]</sup> above.
-  **Timer:** Covered under [Code Profiling](#)<sup>[37]</sup> above.
-  **Cursor location:** Lines and columns.
-  **CAP, NUM, SCRL:** Status indicators for Caps Lock, Num Lock and Scroll Lock.

## Dialogs

Not all dialogs are reviewed -- only the ones which are not self-explanatory.

In this section:


- [Project Settings](#)<sup>[131]</sup>
- [New Project](#)<sup>[132]</sup>
- [Add file to Project](#)<sup>[132]</sup>
- [Graphic File Properties Dialog](#)<sup>[133]</sup>

## Project Settings




This dialog has been covered under [Project Settings](#)<sup>[38]</sup> above.

## New Project.2




This dialog has been covered under [Starting a New Project](#)<sup>[10]</sup> above.

## Add File to Project



This dialog has been covered under [Adding, Removing and Saving Files](#)<sup>[18]</sup> above.

## Graphic File Properties Dialog



This dialog has been covered under [Adding, Removing and Saving Files](#)<sup>[18]</sup> above.


## Panes

Some panes may be toggled using shortcut keys or the [View Menu](#)<sup>[122]</sup>. [Colors pane](#)<sup>[135]</sup> is displayed automatically when an image resource file is opened for editing.

In this section:

- [Call Stack](#)<sup>[133]</sup>
- [Output](#)<sup>[133]</sup>
- [Project](#)<sup>[134]</sup>
- [Watch](#)<sup>[135]</sup>
- [Colors](#)<sup>[135]</sup>

### Call Stack.7.1



The Call Stack pane is covered under [The Call Stack](#)<sup>[31]</sup> above.

### Output6.2.7.2




Displays status messages while compiling, linking, uploading and debugging. Double clicking on an error message would move the cursor to the line of code which

caused the error.

## Project 2.7.3


The Project pane contains two tabs: [Browser](#)<sup>[134]</sup> and [Files](#)<sup>[134]</sup>.

### Browser




The Browser tab has been covered under [Using the Project Browser](#)<sup>[22]</sup> and under [The Watch](#)<sup>[33]</sup> above.

### Files



The Files tab has been covered under [Adding, Removing and Saving Files](#)<sup>[18]</sup> above.


## Watch 6.2.7.4




The Watch pane has been covered under [The Watch](#) <sup>[33]</sup> above.

## Colors 6.2.7.5

Colors pane is displayed whenever a graphical resource is opened for editing in TIDE. Depending on the color mode selection you've made when adding an image file to the project, the pane will either show available palette colors...



... or RGB color selector:



## Language Element Icons

Throughout TIDE, many icons are used for various Tibbo Basic constructs. Below is a complete listing:

- **Constants** (see [Constants](#)<sup>[65]</sup>)
- **Enumeration Types** (see [User-Defined Types](#)<sup>[59]</sup>)
- **System Calls** (see [Function Reference](#)<sup>[205]</sup>)
- **Objects** (see [Object Reference](#)<sup>[231]</sup>)
- **Properties** (see [Object Reference](#)<sup>[231]</sup>)
- **Methods** (see [Object Reference](#)<sup>[231]</sup>)
- **Event Handlers** (Implemented in current project -- see [Object Reference](#)<sup>[231]</sup>). Grayed if no event handler exists for an event.
- **Procedures** (see [Introduction to Procedures](#)<sup>[66]</sup>). Grayed if a procedure is not implemented (i.e. doesn't have a body).
- **Variables** (see [Introduction to Variables, Constants and Scopes](#)<sup>[47]</sup>). Grayed if the variable is not defined.

## Glossary of Terms

Below are several key definitions for terms used throughout the text.

### Compilation Unit

A single file containing source code, to be processed by the [compiler](#)<sup>[136]</sup>. Projects may contain many compilation units. Under Tibbo Basic, BASIC source files (.tbs) and HTML files (.html) are compilation units.

### Compiler

For Tibbo Basic, a software program which takes compilation units and converts each of them, individually, to executable [P-Code](#)<sup>[137]</sup>. The Tibbo Basic compiler is a single-pass compiler, which means it goes over each compilation unit from beginning to end, and does it just one time.

### Construct

A meaningful combination of language elements, including keywords, identifiers, constants, etc. An example of a construct would be  $A = B + 5$ .

### Cross-Debugging

This is the practice of using one device to observe and control the state of a program running on another device, in order to find bugs in it. Under Tibbo Basic, your computer displays various status messages and information about variables etc, but the actual code is executed on the [target](#)<sup>[137]</sup>. The target state is periodically polled and displayed on your computer. Hence, cross-debugging.

## Identifier

Any 'name' for a variable, a function, a subroutine, a constant, or any other 'thing' you may call or refer to within a program. In the statement `x = 5`, `x` is an identifier. An existing [keyword](#)<sup>[137]</sup> cannot be used as an identifier, since it already has a fixed meaning as part of Tibbo Basic syntax.

## Keyword

A single word which carries a specific meaning within Tibbo Basic. Keywords are listed under [Keywords](#)<sup>[102]</sup> above.

## Label

An [identifier](#)<sup>[137]</sup> marking the beginning of a block of code which will then be called using a [Goto Statement](#)<sup>[93]</sup>. Labels are declared in code by writing their name, followed by a colon, on a single line.

## Linker

A software program processing the output of the [compiler](#)<sup>[136]</sup>, to look for any cross-references between the units. If compilation unit A calls a procedure which is in compilation unit B, the linker associates between the two, and provides compilation unit A with the proper memory addresses so that it could actually reach the procedure it needs in unit B.

## P-Code

Pseudo-Code. This is code which is not executed directly by a processor, but by a 'virtual processor' (called a Virtual Machine) which is a part of TiOS that emulates a processor, interprets the P-Code and executes it.

The Tibbo Basic compiler produces P-Code.

## Syscall

A system *call*. This is an internal platform function -- not to be used explicitly. It is expressed as a numeric value. Syscalls are automatically invoked when you perform certain operations in code, such as variable type conversion.

You do not have to invoke syscalls directly within your code -- it is not recommended.

## Target

The hardware device with which you are working. This is the device connected to the computer while debugging. The code you are writing actually runs on this device, and the debug messages originate from the device -- not from anywhere within your computer.

## Virtual Machine

This a part of TiOS. In essence, it is a processor implemented in software. It executes the [P-Code](#)<sup>[137]</sup> of your application (produced by the compiler).

Using a Virtual Machine, we can achieve full control over its code execution. You can think of your application as if it runs in a designated 'sandbox' -- you can do

anything, but the Operating System will stay unharmed. So no code executed in the Virtual Machine can crash TiOS itself.

This approach also greatly enhances your control over your program execution during debugging.

## Platforms

This section contains specifications for all platforms included into the current documentation.

Each platform supports a number of functions (syscalls) and objects. Actual functions and object description is not included into each platform's spec. Instead, they are documented in the [Function Reference](#)<sup>[205]</sup> and [Object Reference](#)<sup>[231]</sup> sections, while [Platform Specifications](#)<sup>[138]</sup> section only contains the lists of functions and objects supported. This is because most functions and objects are shared by different platforms.

## Platform Specifications

The following platforms are included into this documentation:

Platform	Devices
<a href="#">EM500W</a> <sup>[138]</sup>	EM500 + GA1000
<a href="#">EM1000</a> <sup>[143]</sup>	EM1000, DS1000
<a href="#">EM1000W</a> <sup>[143]</sup>	EM1000 + GA1000
<a href="#">EM1202</a> <sup>[151]</sup>	EM1202, EM1202EV*, DS1202*
<a href="#">EM1202W</a> <sup>[151]</sup>	EM1202 + GA1000
<a href="#">DS1100</a> <sup>[164]</sup>	DS1100
<a href="#">DS1101W</a> <sup>[168]</sup>	DS1101 + GA1000
<a href="#">DS1102W</a> <sup>[174]</sup>	DS1102 + GA1000
<a href="#">DS1202</a> <sup>[181]</sup>	EM1202EV*, DS1202*
<a href="#">EM1206</a> <sup>[158]</sup>	EM1206
<a href="#">EM1206W</a> <sup>[158]</sup>	EM1206 + GA1000
<a href="#">DS1206</a> <sup>[186]</sup>	DS1206, DS1206N

\* These devices can be used with the EM1202 or DS1202 platform. Notice, however, that the EM1202EV and DS1202 interconnect certain pins of the EM1202. See Programmable Hardware Manual for details.

## EM500W

### Memory space

RAM	<b>EM500W: 17,920*</b> bytes for application variables and data
Flash	<b>327,680</b> bytes for application storage, data cannot be stored in this memory
EEPROM	<b>200</b> bytes for application data

\* RAM available in the debug mode is smaller by 257 bytes. All memory is available in the release mode.

### Supported Objects, variable types, and functions

- [Sock](#)<sup>[421]</sup> — socket communications (up to 16 UDP, TCP, and HTTP sessions);
- [Net](#)<sup>[358]</sup> — controls the Ethernet port;
- [Wln](#)<sup>[536]</sup> — handles the Wi-Fi interface (requires [GA1000](#)<sup>[201]</sup> add-on module);
- [Ser](#)<sup>[378]</sup> — in charge of the serial port (UART, Wiegand, and clock/data modes);
- [Io](#)<sup>[294]</sup> — handles I/O lines, ports, and interrupts;
- [Fd](#)<sup>[236]</sup>\* — manages flash memory file system and direct sector access (requires an [externally connected flash IC](#)<sup>[143]</sup>);
- [Stor](#)<sup>[522]</sup> — provides access to the EEPROM;
- [Romfile](#)<sup>[370]</sup> — facilitates access to resource files (fixed data);
- [Pppoe](#)<sup>[369]</sup> — provides access to the Internet over an ADSL modem;
- [Ppp](#)<sup>[366]</sup> — provides access to the Internet over a serial modem (GPRS, POTS, etc.);
- [Pat](#)<sup>[363]</sup> — "plays" patterns on a pair of LEDs;
- [Button](#)<sup>[234]</sup> — monitors the MD line ([setup button](#)<sup>[201]</sup>);
- [Sys](#)<sup>[526]</sup> — in charge of general device functionality.

\* Fully supported with the exception of [fd.copyfirmware](#)<sup>[269]</sup>. Disabled by default -- enable it in [Project Settings](#)<sup>[38]</sup> -> Customize.

This platform supports the standard set of [variable types](#)<sup>[192]</sup> and [functions](#)<sup>[192]</sup> (a.k.a. "syscalls") **except** [aes128enc](#)<sup>[206]</sup> and [aes128dec](#)<sup>[205]</sup>. These AES128 functions are **not present** on the EM500W platform.

### Platform-specific constants

You can find them [here](#)<sup>[140]</sup>.

### Miscellaneous information

Available network interfaces	<b>Ethernet (net.)</b> <sup>(1)</sup>
<a href="#">GPIO type</a> <sup>[194]</sup>	<b>Bidirectional</b>
<a href="#">RTS/CTS remapping</a> <sup>[195]</sup>	<b>Not supported</b> <sup>(2)</sup>
<a href="#">GA1000 lines remapping</a> <sup>[201]</sup>	<b>Not supported</b> <sup>(3)</sup>
<a href="#">Serial port FIFOs</a> <sup>[196]</sup>	<b>16 byte for TX, 16 bytes for RX</b>
<a href="#">Clock frequency (PLL) control</a> <sup>[196]</sup>	<b>Not supported, frequency is fixed at 80MHz</b>
<a href="#">Special configuration section of the EEPROM</a> <sup>[197]</sup>	<b>8 bytes for MAC storage</b>
<a href="#">Device serial number</a> <sup>[199]</sup>	<b>4 bytes, the number can't be changed</b>
<a href="#">Flash memory configuration</a> <sup>[200]</sup>	<b>Dedicated memory for firmware/</b>

	<b>application</b> <b>Data cannot be stored in this memory</b>
<a href="#">LEDs</a> <sup>[200]</sup>	<b>Green (SG) and red (SR) Status LED lines</b> <b>(their brightness indicates Ethernet link status)</b> <b>One additional dedicated link status LED line</b>
<a href="#">Debug communications</a> <sup>[204]</sup>	<b>Ethernet / UDP Broadcast transport</b> <b>Ethernet / WinPCap transport</b>

Comments:

1. The [sock.allowedinterfaces](#) <sup>[474]</sup> property refers to the Ethernet interface as "NET". [Sock.targetinterface](#) <sup>[506]</sup> and [sock.currentinterface](#) <sup>[478]</sup> properties rely on the [pl\\_sock\\_interfaces](#) <sup>[150]</sup> enum, whose members differ depending on the platform.
2. CTS is permanently mapped to [0- PL\\_INT\\_NUM\\_0](#) <sup>[142]</sup> ([0- PL\\_IO\\_NUM\\_0 INTO](#) <sup>[141]</sup>).  
RTS is permanently mapped to [2- PL\\_IO\\_NUM\\_2](#) <sup>[141]</sup>.
3. Connect the GA1000 add-on module as follows (also see schematic diagram C in [Connecting GA1000](#) <sup>[201]</sup>):

<b>CS</b>	<a href="#">7- PL_IO_NUM_7</a> <sup>[141]</sup>
<b>CLK</b>	<a href="#">6- PL_IO_NUM_6</a> <sup>[141]</sup>
<b>DI</b>	<a href="#">5- PL_IO_NUM_5</a> <sup>[141]</sup> (yes, DI and DO lines are on the same GPIO line)
<b>DO</b>	
<b>RST</b>	Choose any suitable GPIO or <a href="#">use NAND gates</a> <sup>[201]</sup> to generate reset

## Platform-specific Constants

The following constant lists are platform-specific:

- [Enum pl\\_redir](#) <sup>[140]</sup>- the list of constants that define buffer redirection (shorting) for this platform.
- [Enum pl\\_io\\_num](#) <sup>[141]</sup>- the list of constants that define available I/O lines.
- [Enum pl\\_io\\_port\\_num](#) <sup>[142]</sup>- the list of constants that define available 8-bit I/O ports.
- [Enum pl\\_int\\_num](#) <sup>[142]</sup>- the list of constants that define available *interrupt* lines.
- [Enum pl\\_sock\\_interfaces](#) <sup>[142]</sup>- the list of available network interfaces.

### Enum pl\_redir

Enum `pl_redir` contains the list of constants that define buffer redirection (shorting). The following objects support buffers and buffer redirection:

- [Ser](#) <sup>[378]</sup> object (see [ser.redir](#) <sup>[414]</sup> method)
- [Sock](#) <sup>[421]</sup> object (see [sock.redir](#) <sup>[493]</sup> method)

Enum `pl_redir` for this platform includes the following constants:

- 0- `PL_REDIR_NONE`: Cancels redirection for the serial port or socket.  
1- `PL_REDIR_SER`: Redirects RX data of the serial port or socket to the TX

buffer of the serial port.

6- PL_REDIR_SOCKET0:	Redirects RX data of the serial port or socket to the TX buffer of socket 0. This constant can be used as a "base" for all other sockets i.e. in expressions like <code>sock.redir= PL_REDIR_SOCKET0+f</code> .
7- PL_REDIR_SOCKET1:	Redirects RX data of the serial port or socket to the TX buffer of socket 1.
8- PL_REDIR_SOCKET2:	Redirects RX data of the serial port or socket to the TX buffer of socket 2.
9- PL_REDIR_SOCKET3:	Redirects RX data of the serial port or socket to the TX buffer of socket 3.
10- PL_REDIR_SOCKET4:	Redirects RX data of the serial port or socket to the TX buffer of socket 4.
11- PL_REDIR_SOCKET5:	Redirects RX data of the serial port or socket to the TX buffer of socket 5.
12- PL_REDIR_SOCKET6:	Redirects RX data of the serial port or socket to the TX buffer of socket 6.
13- PL_REDIR_SOCKET7:	Redirects RX data of the serial port or socket to the TX buffer of socket 7.
14- PL_REDIR_SOCKET8:	Redirects RX data of the serial port or socket to the TX buffer of socket 8.
15- PL_REDIR_SOCKET9:	Redirects RX data of the serial port or socket to the TX buffer of socket 9.
16- PL_REDIR_SOCKET10:	Redirects RX data of the serial port or socket to the TX buffer of socket 10.
17- PL_REDIR_SOCKET11:	Redirects RX data of the serial port or socket to the TX buffer of socket 11.
18- PL_REDIR_SOCKET12:	Redirects RX data of the serial port or socket to the TX buffer of socket 12.
19- PL_REDIR_SOCKET13:	Redirects RX data of the serial port or socket to the TX buffer of socket 13.
20- PL_REDIR_SOCKET14:	Redirects RX data of the serial port or socket to the TX buffer of socket 14.
21- PL_REDIR_SOCKET15:	Redirects RX data of the serial port or socket to the TX buffer of socket 15.

## Enum `pl_io_num`

Enum `pl_io_num` contains the list of constants that refer to available GPIO lines. Use these constants when selecting the line with the `io.[294]` object (see the `io.num[301]` property).

Note that GPIO lines are of *bidirectional* `type[194]` and do not require explicit configuration as outputs or inputs.

Enum `pl_io_num` includes the following constants:

0- PL_IO_NUM_0_INT0:	General-purpose I/O line 0 (P0.0). This is also the interrupt line 0.
1- PL_IO_NUM_1_INT1:	General-purpose I/O line 1 (P0.1). This is also the interrupt line 1.

2- PL_IO_NUM_2:	General-purpose I/O line 2 (P0.2).
3- PL_IO_NUM_3:	General-purpose I/O line 3 (P0.3).
4- PL_IO_NUM_4:	General-purpose I/O line 4 (P0.4).
5- PL_IO_NUM_5:	General-purpose I/O line 5 (P0.5).
6- PL_IO_NUM_6:	General-purpose I/O line 6 (P0.6).
7- PL_IO_NUM_7:	General-purpose I/O line 7 (P0.7).
8- PL_IO_NULL:	This is a NULL line that does not physically exist. The state of this line is always detected as LOW. Setting this line has no effect.

## Enum pl\_io\_port\_num

Enum `pl_io_port_num` contains the list of available 8-bit GPIO ports. Use these constants when selecting the port with the `io.`<sup>[294]</sup> object (see the `io.portnum`<sup>[302]</sup> property).

Note that GPIO lines are of *bidirectional type*<sup>[194]</sup> and do not require explicit configuration as outputs or inputs.

Enum `pl_io_port_num` includes the following constants:

0- PL_IO_PORT_NUM_0:	8-bit port 0 (P0). Contains I/O lines 0-7.
----------------------	--

## Enum pl\_int\_num

Enum `pl_int_num` contains the list of constants that refer to available *interrupt* lines. Interrupt lines are mapped to [GPIO lines](#)<sup>[147]</sup> (this mapping can't be altered).

Enum `pl_int_num` includes the following constants:

0- PL_INT_NUM_0:	Interrupt line 0 (mapped onto I/O line 0).
1- PL_INT_NUM_1:	Interrupt line 1 (mapped onto I/O line 1).
2- PL_INT_NULL:	This is a NULL interrupt line that does not physically exist.

## Enum pl\_sock\_interfaces

Enum `pl_sock_interfaces` contains the list of network interfaces supported by the platform:


0- PL_SOCK_INTERFACE_NULL:	Null (empty) interface.
1- PL_SOCK_INTERFACE_NET ( <b>default</b> ):	<a href="#">Ethernet interface</a> <sup>[358]</sup> .
2- PL_SOCK_INTERFACE_WLN:	<a href="#">Wi-Fi interface</a> <sup>[536]</sup> .
3- PL_SOCK_INTERFACE_PPP:	<a href="#">PPP interface</a> <sup>[366]</sup> .
4- PL_SOCK_INTERFACE_PPPOE:	<a href="#">PPPoE interface</a> <sup>[369]</sup> .

## Connecting External Flash IC

The EM500W platform includes [fd.](#)<sup>[236]</sup> object (with the exception of the [fd.copyfirmware](#)<sup>[269]</sup> method). For this to work, an external flash IC must be connected to the EM500.

As shown on the schematic diagram below, this flash IC is ATMEL AT45DB041. Since the EM500 has a *dedicated* [flash memory configuration](#)<sup>[200]</sup>, the flash IC will be used exclusively by the fd. object and provide 1MB of storage.

The 5.1K pull-up resistor is needed to "sharpen" SPI clock signal. EM500's [bidirectional GPIOs](#)<sup>[194]</sup> allow interconnecting SI and SO lines (this saves one GPIO line!).



For the [fd.](#)<sup>[236]</sup> object to work, it must be enabled first. Do this through [Project Settings](#)<sup>[38]</sup> -> Customize dialog.

- **DO NOT** enable fd. object unless you actually have the flash IC attached. When the fd. object is enabled, the EM500 will attempt to detect the flash IC presence. That is, the EM500 will try to access the flash through the SPI interface. This means that there will be signals on GPIO4 (CS), GPIO3 (CLK), and GPIO1 (DI/DO). Flash IC detection may interfere with the operation of your device (if you have something else connected to these GPIOs).

## EM1000 and EM1000W Platforms

The difference between the EM1000 and EM1000W platforms is that the EM1000W additionally includes the Wi-Fi ([wln.](#)<sup>[536]</sup>) object (requires an external GA1000 add-on module). All other features of these two platforms are exactly the same.

### Memory space

RAM	<b>22,528*</b> bytes for application variables and data
Flash	<b>983,040</b> bytes for application and data storage ( <a href="#">shared</a> <sup>[200]</sup> flash memory)**
EEPROM	<b>2040</b> bytes for application data

\*RAM available in the debug mode is smaller by 257 bytes. All memory is available

in the release mode.

\*\*Some earlier devices had only 458,752 bytes of flash memory available

### Supported Objects, variable types, and functions

- [Sock](#)<sup>[421]</sup> — socket communications (up to 16 UDP, TCP, and HTTP sessions);
- [Net](#)<sup>[358]</sup> — controls the Ethernet interface;
- [Wln](#)<sup>[536]</sup> — handles the Wi-Fi interface (only available on the **EM1000W platform**, requires [GA1000](#)<sup>[201]</sup> add-on module);
- [Ser](#)<sup>[378]</sup> — in charge of serial ports (UART, Wiegand, and clock/data modes);
- [Ssi](#)<sup>[512]</sup> — implements up to four serial synchronous interface (SSI) channels, supports SPI, I2C, clock/data, etc.;
- [Io](#)<sup>[294]</sup> — handles I/O lines, ports, and interrupts;
- [Lcd](#)<sup>[317]</sup> — controls graphical display panels (several types supported);
- [Kp](#)<sup>[304]</sup> — scans keypads of matrix and "binary" types;
- [Rtc](#)<sup>[375]</sup> — keeps track of date and time;
- [Fd](#)<sup>[236]</sup> — manages flash memory file system and direct sector access;
- [Stor](#)<sup>[522]</sup> — provides access to the EEPROM;
- [Romfile](#)<sup>[370]</sup> — facilitates access to resource files (fixed data);
- [Pppoe](#)<sup>[369]</sup> — provides access to the Internet over an ADSL modem;
- [Ppp](#)<sup>[366]</sup> — provides access to the Internet over a serial modem (GPRS, POTS, etc.);
- [Pat](#)<sup>[363]</sup> — "plays" patterns on up to five LED pairs;
- [Beep](#)<sup>[232]</sup> — generates buzzer patterns;
- [Button](#)<sup>[234]</sup> — monitors the MD line ([setup button](#)<sup>[201]</sup>);
- [Sys](#)<sup>[526]</sup> — in charge of general device functionality.

These platforms support the standard set of [variable types](#)<sup>[192]</sup> and [functions](#)<sup>[192]</sup> (a.k.a. "syscalls").

### Platform-specific constants

You can find them [here](#)<sup>[146]</sup>.

### Miscellaneous information

Available network interfaces	<b>EM1000: Ethernet (net.)</b> <b>EM1000W: Ethernet (<a href="#">net.</a><sup>[358]</sup>), Wi-Fi (<a href="#">wln.</a><sup>[536]</sup>)<sup>(1)</sup></b>
<a href="#">GPIO type</a> <sup>[194]</sup>	<b>Unidirectional</b>
<a href="#">RTS/CTS remapping</a> <sup>[195]</sup>	<b>Supported<sup>(2)</sup></b>
<a href="#">GA1000 lines remapping</a> <sup>[201]</sup>	<b>Supported<sup>(3)</sup></b>
<a href="#">Serial port FIFOs</a> <sup>[196]</sup>	<b>16 byte for TX, 16 bytes for RX</b>

<a href="#">Clock frequency (PLL) control</a> <sup>[196]</sup>	<b>PLL on: 88.4736Mhz, PLL off: 11.0592Mhz</b> <sup>(4)</sup>
<a href="#">Special configuration section of the EEPROM</a> <sup>[197]</sup>	<b>8 bytes for MAC storage</b>
<a href="#">Device serial number</a> <sup>[199]</sup>	<b>128 bytes: 64 OTP bytes + 64 fixed bytes</b> <sup>(5)</sup>
<a href="#">Flash memory configuration</a> <sup>[200]</sup>	<b>Shared</b>
<a href="#">LEDs</a> <sup>[200]</sup>	<b>Green (SG) and red (SR) Status LED lines Green (EG) and yellow (EY) Ethernet LED lines</b>
<a href="#">Debug communications</a> <sup>[204]</sup>	<b>Ethernet / UDP Broadcast transport Ethernet / WinPCap transport</b>

Comments:

- The [sock.allowedinterfaces](#)<sup>[474]</sup> property refers to the Ethernet interface as "NET", Wi-Fi -- as "WLN". [Sock.targetinterface](#)<sup>[506]</sup> and [sock.currentinterface](#)<sup>[478]</sup> properties rely on the [pl\\_sock\\_interfaces](#)<sup>[150]</sup> enum, whose members differ depending on the platform.
- Default CTS/RTS mapping is different for each serial port:

	<b>RTS</b>	<b>CTS</b>
<b>Port 1</b>	<a href="#">0- PL IO NUM 0</a> <sup>[147]</sup>	<a href="#">0- PL INT NUM 0</a> <sup>[147]</sup> ( <a href="#">16- PL IO NUM 16 INT0</a> <sup>[150]</sup> )
<b>Port 2</b>	<a href="#">1- PL IO NUM 1</a> <sup>[147]</sup>	<a href="#">1- PL INT NUM 1</a> <sup>[147]</sup> ( <a href="#">17- PL IO NUM 17 INT1</a> <sup>[150]</sup> )
<b>Port 3</b>	<a href="#">2- PL IO NUM 2</a> <sup>[147]</sup>	<a href="#">2- PL INT NUM 2</a> <sup>[147]</sup> ( <a href="#">18- PL IO NUM 18 INT2</a> <sup>[150]</sup> )
<b>Port 4</b>	<a href="#">3- PL IO NUM 3</a> <sup>[147]</sup>	<a href="#">3- PL INT NUM 3</a> <sup>[147]</sup> ( <a href="#">19- PL IO NUM 19 INT3</a> <sup>[150]</sup> )

- Mapping of [GA1000](#)<sup>[201]</sup> control lines is fully flexible on the EM1000W. However, if the GA1000 module is installed *on top* of the EM1000 (so called EM1000G module combination), then the following mapping *must* be applied:

<b>CS</b>	<a href="#">49- PL IO NUM 49</a> <sup>[147]</sup>
<b>CLK</b>	<a href="#">53- PL IO NUM 53</a> <sup>[147]</sup>
<b>DI</b>	<a href="#">52- PL IO NUM 52</a> <sup>[147]</sup>
<b>DO</b>	<a href="#">50- PL IO NUM 50</a> <sup>[147]</sup>
<b>RST</b>	<a href="#">51- PL IO NUM 51</a> <sup>[147]</sup>

- Default PLL state after the external reset depends on the PM pin of the EM1000 (W).
- Older EM1000 and EM1000W devices did not contain the serial number. To find out if your EM1000(W) has the serial number onboard, try to read this serial number with the [sys.serialnum](#)<sup>[534]</sup> R/O property. If this property returns an empty string, then the serial number is not present. Sys.serialnum returns all 128 bytes of the serial number. First 64 bytes are one-time-programmable (OTP) with the [sys.setserialnum](#)<sup>[535]</sup> method.

## Platform-specific Constants

The following constant lists are platform-specific:

- [Enum pl\\_redir](#)<sup>[146]</sup> the list of constants that define buffer redirection (shorting) for this platform.
- [Enum pl\\_io\\_num](#)<sup>[147]</sup> the list of constants that define available I/O lines.
- [Enum pl\\_io\\_port\\_num](#)<sup>[148]</sup> the list of constants that define available 8-bit I/O ports.
- [Enum pl\\_int\\_num](#)<sup>[150]</sup> the list of constants that define available *interrupt* lines.
- [Enum pl\\_sock\\_interfaces](#)<sup>[150]</sup> the list of available network interfaces.

### Enum pl\_redir

Enum pl\_redir contains the list of constants that define buffer redirection (shorting). The following objects support buffers and buffer redirection:

- [Ser.](#)<sup>[376]</sup> object (see [ser.redir](#)<sup>[414]</sup> method)
- [Sock.](#)<sup>[421]</sup> object (see [sock.redir](#)<sup>[493]</sup> method)

Enum pl\_redir for this platform includes the following constants:

0-	PL_REDIR_NONE:	Cancels redirection for the serial port or socket.
1-	PL_REDIR_SER:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 0. This constant can be used as a "base" for all other serial ports, i.e. in expressions like <code>ser.redir= PL_REDIR_SER+f</code> .
1-	PL_REDIR_SER0:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 0.
2-	PL_REDIR_SER1:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 1.
3-	PL_REDIR_SER2:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 2.
4-	PL_REDIR_SER3:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 3.
6-	PL_REDIR SOCK0:	Redirects RX data of the serial port or socket to the TX buffer of socket 0. This constant can be used as a "base" for all other sockets i.e. in expressions like <code>sock.redir= PL_REDIR SOCK0+f</code> .
7-	PL_REDIR SOCK1:	Redirects RX data of the serial port or socket to the TX buffer of socket 1.
8-	PL_REDIR SOCK2:	Redirects RX data of the serial port or socket to the TX buffer of socket 2.
9-	PL_REDIR SOCK3:	Redirects RX data of the serial port or socket to the TX buffer of socket 3.
10-	PL_REDIR SOCK4:	Redirects RX data of the serial port or socket to the TX buffer of socket 4.
11-	PL_REDIR SOCK5:	Redirects RX data of the serial port or socket to the TX buffer of socket 5.
12-	PL_REDIR SOCK6:	Redirects RX data of the serial port or socket to the TX buffer of socket 6.
13-	PL_REDIR SOCK7:	Redirects RX data of the serial port or socket to the TX

	buffer of socket 7.
14- PL_REDIR_SOCKET8:	Redirects RX data of the serial port or socket to the TX buffer of socket 8.
15- PL_REDIR_SOCKET9:	Redirects RX data of the serial port or socket to the TX buffer of socket 9.
16- PL_REDIR_SOCKET10:	Redirects RX data of the serial port or socket to the TX buffer of socket 10.
17- PL_REDIR_SOCKET11:	Redirects RX data of the serial port or socket to the TX buffer of socket 11.
18- PL_REDIR_SOCKET12:	Redirects RX data of the serial port or socket to the TX buffer of socket 12.
19- PL_REDIR_SOCKET13:	Redirects RX data of the serial port or socket to the TX buffer of socket 13.
20- PL_REDIR_SOCKET14:	Redirects RX data of the serial port or socket to the TX buffer of socket 14.
21- PL_REDIR_SOCKET15:	Redirects RX data of the serial port or socket to the TX buffer of socket 15.

## Enum pl\_io\_num

Enum `pl_io_num` contains the list of constants that refer to available GPIO lines. Use these constants when selecting the line with the `io.[294]` object (see the `io.num[301]` property).

Note that GPIO lines are of *unidirectional* `type[194]` and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see the notes at the bottom of the page.

Enum `pl_io_num` includes the following constants:

0- PL_IO_NUM_0:	General-purpose I/O line 0 (P0.0).
1- PL_IO_NUM_1:	General-purpose I/O line 1 (P0.1).
2- PL_IO_NUM_2:	General-purpose I/O line 2 (P0.2).
3- PL_IO_NUM_3:	General-purpose I/O line 3 (P0.3).
4- PL_IO_NUM_4:	General-purpose I/O line 4 (P0.4).
5- PL_IO_NUM_5:	General-purpose I/O line 5 (P0.5).
6- PL_IO_NUM_6:	General-purpose I/O line 6 (P0.6).
7- PL_IO_NUM_7:	General-purpose I/O line 7 (P0.7).
8- PL_IO_NUM_8_RX0 <sup>(1)</sup> :	General-purpose I/O line 8 (P1.0). This line is also the <code>RX/W1in/din<sup>[379]</sup></code> input of the serial port 0.
9- PL_IO_NUM_9_TX0 <sup>(2)</sup> :	General-purpose I/O line 9 (P1.1). This line is also the <code>TX/W1out/dout<sup>[379]</sup></code> output of the serial port 0.
10- PL_IO_NUM_10_RX1 <sup>(1)</sup> :	General-purpose I/O line 10 (P1.2). This line is also the <code>RX/W0&amp;1in/din</code> input of the serial port 1.
11- PL_IO_NUM_11_TX1 <sup>(2)</sup> :	General-purpose I/O line 11 (P1.3). This line is also the <code>TX/W1out/dout</code> output of the serial port 1.
12- PL_IO_NUM_12_RX2 <sup>(1)</sup> :	General-purpose I/O line 12 (P1.4). This line is also the <code>RX/W0&amp;1in/din</code> input of the serial port 2.
13- PL_IO_NUM_13_TX2 <sup>(2)</sup> :	General-purpose I/O line 13 (P1.5). This line is also

	the TX/W1out/dout output of the serial port 2.
14- PL_IO_NUM_14_RX3 <sup>(1)</sup> :	General-purpose I/O line 14 (P1.6). This line is also the RX/W0&1in/din input of the serial port 3.
15- PL_IO_NUM_15_TX3 <sup>(2)</sup> :	General-purpose I/O line 15 (P1.7). This line is also the TX/W1out/dout output of the serial port 3.
16- PL_IO_NUM_16_INT0:	General-purpose I/O line 16 (P2.0). This is also the interrupt line 0.
17- PL_IO_NUM_17_INT1:	General-purpose I/O line 17 (P2.1). This is also the interrupt line 1.
18- PL_IO_NUM_18_INT2:	General-purpose I/O line 18 (P2.2). This is also the interrupt line 2.
19- PL_IO_NUM_19_INT3:	General-purpose I/O line 19 (P2.3). This is also the interrupt line 3.
20- PL_IO_NUM_20_INT4:	General-purpose I/O line 20 (P2.4). This is also the interrupt line 4.
21- PL_IO_NUM_21_INT5:	General-purpose I/O line 21 (P2.5). This is also the interrupt line 5.
22- PL_IO_NUM_22_INT6:	General-purpose I/O line 22 (P2.6). This is also the interrupt line 6.
23- PL_IO_NUM_23_INT7:	General-purpose I/O line 23 (P2.7). This is also the interrupt line 7.
24- PL_IO_NUM_24:	General-purpose I/O line 24 (P3.0).
25- PL_IO_NUM_25:	General-purpose I/O line 25 (P3.1).
26- PL_IO_NUM_26:	General-purpose I/O line 26 (P3.2).
27- PL_IO_NUM_27:	General-purpose I/O line 27 (P3.3).
28- PL_IO_NUM_28:	General-purpose I/O line 28 (P3.4).
29- PL_IO_NUM_29:	General-purpose I/O line 29 (P3.5).
30- PL_IO_NUM_30:	General-purpose I/O line 30 (P3.6).
31- PL_IO_NUM_31:	General-purpose I/O line 31 (P3.7).
32- PL_IO_NUM_32:	General-purpose I/O line 32 (P4.0).
33- PL_IO_NUM_33:	General-purpose I/O line 33 (P4.1).
34- PL_IO_NUM_34:	General-purpose I/O line 34 (P4.2).
35- PL_IO_NUM_35:	General-purpose I/O line 35 (P4.3).
36- PL_IO_NUM_36:	General-purpose I/O line 36 (P4.4).
37- PL_IO_NUM_37:	General-purpose I/O line 37 (P4.5).
38- PL_IO_NUM_38:	General-purpose I/O line 38 (P4.6).
39- PL_IO_NUM_39:	General-purpose I/O line 39 (P4.7).
40- PL_IO_NUM_40:	General-purpose I/O line 40 (does not belong to any 8-bit port).
41- PL_IO_NUM_41:	General-purpose I/O line 41 (does not belong to any 8-bit port).
42- PL_IO_NUM_42:	General-purpose I/O line 42 (does not belong to any 8-bit port).
43- PL_IO_NUM_43:	General-purpose I/O line 43 (does not belong to any 8-bit port).

44- PL_IO_NUM_44:	General-purpose I/O line 44 (does not belong to any 8-bit port).
45- PL_IO_NUM_45_CO <sup>(3)</sup> :	General-purpose I/O line 45 (does not belong to any 8-bit port). This line is also used by the <a href="#">beep</a> <sup>[232]</sup> object to generate square wave output that is primarily intended for driving beeper (buzzer).
46- PL_IO_NUM_46:	General-purpose I/O line 46 (does not belong to any 8-bit port).
47- PL_IO_NUM_47:	General-purpose I/O line 47 (does not belong to any 8-bit port).
48- PL_IO_NUM_48:	General-purpose I/O line 48 (does not belong to any 8-bit port).
49- PL_IO_NUM_49:	General-purpose I/O line 49 (does not belong to any 8-bit port).
50- PL_IO_NUM_50:	General-purpose I/O line 50 (does not belong to any 8-bit port).
51- PL_IO_NUM_51:	General-purpose I/O line 51 (does not belong to any 8-bit port).
52- PL_IO_NUM_52:	General-purpose I/O line 52 (does not belong to any 8-bit port).
53- PL_IO_NUM_53:	General-purpose I/O line 53 (does not belong to any 8-bit port).
54- PL_IO_NULL:	This is a NULL line that does not physically exist. The state of this line is always detected as LOW. Setting this line has no effect.

#### Notes:

1. When a serial port is in the [UART](#)<sup>[380]</sup> mode ([ser.mode](#)<sup>[409]</sup>= 0- PL\_SER\_MODE\_UART) this line is automatically configured to be an input when this serial port is enabled ([ser.enabled](#)<sup>[405]</sup>= 1- YES) and returns to the previous input/output and high/low state when this serial port is closed ([ser.enabled](#)= 0- NO). When a serial port is in the [Wiegand](#)<sup>[383]</sup> or [clock/data](#)<sup>[386]</sup> mode ([ser.mode](#)= 1- PL\_SER\_MODE\_WIEGAND or [ser.mode](#)= 2- PL\_SER\_MODE\_CLOCKDATA), the line has to be configured as input by the application- this will not happen automatically.
2. When a serial port is in the UART mode ([ser.mode](#)= 0- PL\_SER\_MODE\_UART) this line is automatically configured to be an output when the serial port is enabled ([ser.enabled](#)= 1- YES) and returns to the previous input/output and high/low state when the serial port is closed ([ser.enabled](#)= 0- NO). When a serial port is in the Wiegand or clock/data mode ([ser.mode](#)= 1- PL\_SER\_MODE\_WIEGAND or [ser.mode](#)= 2- PL\_SER\_MODE\_CLOCKDATA), the line has to be configured as output by the application- this will not happen automatically.
3. When the beeper pattern starts playing, this line is configured as output automatically. When the beeper pattern stops playing, the output returns to the input/output and high/low state that it had before the pattern started playing.

## Enum `pl_io_port_num`

Enum `pl_io_port_num` contains the list of available 8-bit GPIO ports. Use these constants when selecting the port with the [io](#)<sup>[294]</sup> object (see the [io.portnum](#)<sup>[302]</sup> property).

Note that GPIO lines are of *unidirectional type*<sup>[194]</sup> and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see [Enum pl\\_io\\_num](#)<sup>[147]</sup> for details.

Enum `pl_io_port_num` includes the following constants:

0- <code>PL_IO_PORT_NUM_0</code> :	8-bit port 0 (P0). Contains I/O lines 0-7.
1- <code>PL_IO_PORT_NUM_1</code> :	8-bit port 1 (P1). Contains I/O lines 8-15.
2- <code>PL_IO_PORT_NUM_2</code> :	8-bit port 2 (P2). Contains I/O lines 16-23.
3- <code>PL_IO_PORT_NUM_3</code> :	8-bit port 3 (P3). Contains I/O lines 24-31.
4- <code>PL_IO_PORT_NUM_4</code> :	8-bit port 4 (P4). Contains I/O lines 32-39.

## Enum `pl_int_num`

Enum `pl_int_num` contains the list of constants that refer to available *interrupt* lines. Interrupt lines are mapped to [GPIO lines](#)<sup>[147]</sup> (this mapping can't be altered). For example, interrupt line 0 corresponds to GPIO line 16, interrupt line 1- to GPIO line 17, and so on. Keep in mind that for an interrupt line to work you need to [configure](#)<sup>[194]</sup> the corresponding GPIO line as input.

Enum `pl_int_num` includes the following constants:

0- <code>PL_INT_NUM_0</code> :	Interrupt line 0 (mapped onto I/O line 16).
1- <code>PL_INT_NUM_1</code> :	Interrupt line 1 (mapped onto I/O line 17).
2- <code>PL_INT_NUM_2</code> :	Interrupt line 2 (mapped onto I/O line 18).
3- <code>PL_INT_NUM_3</code> :	Interrupt line 3 (mapped onto I/O line 19).
4- <code>PL_INT_NUM_4</code> :	Interrupt line 4 (mapped onto I/O line 20).
5- <code>PL_INT_NUM_5</code> :	Interrupt line 5 (mapped onto I/O line 21).
6- <code>PL_INT_NUM_6</code> :	Interrupt line 6 (mapped onto I/O line 22).
7- <code>PL_INT_NUM_7</code> :	Interrupt line 7 (mapped onto I/O line 23).
8- <code>PL_INT_NULL</code> :	This is a NULL interrupt line that does not physically exist.

## Enum `pl_sock_interfaces`

Enum `pl_sock_interfaces` contains the list of available network interfaces. The EM1000 and EM1000W platforms differ in that the EM1000W has the W-Fi interface (requires an external GA1000 add-on module), while the EM1000 does not, and the `pl_sock_interfaces` reflects this.

### EM1000 platform

0- <code>PL_SOCK_INTERFACE_NULL</code> :	Null (empty) interface.
1- <code>PL_SOCK_INTERFACE_NET</code> ( <b>default</b> ):	<a href="#">Ethernet interface</a> <sup>[358]</sup> .
3- <code>PL_SOCK_INTERFACE_PPP</code> :	<a href="#">PPP interface</a> <sup>[366]</sup> .

4- PL\_SOCK\_INTERFACE\_PPPOE: [PPPoE interface](#)<sup>[369]</sup>.

### EM1000W platform

0- PL\_SOCK\_INTERFACE\_NULL: Null (empty) interface.

1- PL\_SOCK\_INTERFACE\_NET (**default**): [Ethernet interface](#)<sup>[358]</sup>.

2- PL\_SOCK\_INTERFACE\_WLN: [Wi-Fi interface](#)<sup>[536]</sup>.

3- PL\_SOCK\_INTERFACE\_PPP: [PPP interface](#)<sup>[366]</sup>.

4- PL\_SOCK\_INTERFACE\_PPPOE: [PPPoE interface](#)<sup>[369]</sup>.

## EM1202 and EM1202W Platforms

The difference between the EM1202 and EM202W platforms is that the EM1202W additionally includes the Wi-Fi ([wln](#)<sup>[536]</sup>) object (requires an external GA1000 add-on module). All other features of these two platforms are exactly the same.

### Memory space

RAM	<b>22,528*</b> bytes for application variables and data
Flash	<b>983,040</b> bytes for application and data storage ( <a href="#">shared</a> <sup>[200]</sup> flash memory)**
EEPROM	<b>2040</b> bytes for application data

\* RAM available in the debug mode is smaller by 257 bytes. All memory is available in the release mode.

\*\* Some earlier devices had only 458,752 bytes of flash memory available

### Supported Objects, variable types, and functions

- [Sock](#)<sup>[421]</sup> — socket communications (up to 16 UDP, TCP, and HTTP sessions);
- [Net](#)<sup>[358]</sup> — controls the Ethernet port;
- [Wln](#)<sup>[536]</sup> — handles the Wi-Fi interface (only available on the **EM1202W platform**, requires [GA1000](#)<sup>[201]</sup> add-on module);
- [Ser](#)<sup>[378]</sup> — in charge of serial ports (UART, Wiegand, and clock/data modes);
- [Ssi](#)<sup>[512]</sup> — implements up to four serial synchronous interface (SSI) channels, supports SPI, I2C, clock/data, etc.;
- [Io](#)<sup>[294]</sup> — handles I/O lines, ports, and interrupts;
- [Lcd](#)<sup>[317]</sup> — controls graphical display panels (several types supported);
- [Kp](#)<sup>[304]</sup> — scans keypads of matrix and "binary" types;
- [Fd](#)<sup>[236]</sup> — manages flash memory file system and direct sector access;
- [Stor](#)<sup>[522]</sup> — provides access to the EEPROM;
- [Romfile](#)<sup>[370]</sup> — facilitates access to resource files (fixed data);
- [Pppoe](#)<sup>[369]</sup> — provides access to the Internet over an ADSL modem;

- [Ppp](#)<sup>[366]</sup> — provides access to the Internet over a serial modem (GPRS, POTS, etc.);
- [Pat](#)<sup>[363]</sup> — "plays" patterns on up to five LED pairs;
- [Beep](#)<sup>[232]</sup> — generates buzzer patterns;
- [Button](#)<sup>[234]</sup> — monitors the MD line ([setup button](#)<sup>[201]</sup>);
- [Sys](#)<sup>[526]</sup> — in charge of general device functionality.

These platforms support the standard set of [variable types](#)<sup>[192]</sup> and [functions](#)<sup>[192]</sup> (a.k.a. "syscalls").

### Platform-specific constants

You can find them [here](#)<sup>[153]</sup>.

### Miscellaneous information

Available network interfaces	<b>EM1202: Ethernet (net.)</b> <b>EM1202W: Ethernet (net.<sup>[358]</sup>), Wi-Fi (wln.<sup>[536]</sup>)<sup>(1)</sup></b>
<a href="#">GPIO type</a> <sup>[194]</sup>	<b>Unidirectional</b>
<a href="#">RTS/CTS remapping</a> <sup>[195]</sup>	<b>Supported<sup>(2)</sup></b>
<a href="#">GA1000 lines remapping</a> <sup>[201]</sup>	<b>Supported</b>
<a href="#">Serial port FIFOs</a> <sup>[196]</sup>	<b>16 byte for TX, 16 bytes for RX</b>
<a href="#">Clock frequency (PLL) control</a> <sup>[196]</sup>	<b>PLL on (def): 88.4736Mhz, PLL off: 11.0592Mhz<sup>(3)</sup></b>
<a href="#">Special configuration section of the EEPROM</a> <sup>[197]</sup>	<b>8 bytes for MAC storage</b>
<a href="#">Device serial number</a> <sup>[199]</sup>	<b>128 bytes: 64 OTP bytes + 64 fixed bytes<sup>(4)</sup></b>
<a href="#">Flash memory configuration</a> <sup>[200]</sup>	<b>Shared</b>
<a href="#">LEDs</a> <sup>[200]</sup>	<b>Green (SG) and red (SR) Status LED lines</b> <b>Green (EG) and yellow (EY) Ethernet LED lines</b>
<a href="#">Debug communications</a> <sup>[204]</sup>	<b>Ethernet / UDP Broadcast transport</b> <b>Ethernet / WinPCap transport</b>

#### Comments:

1. The [sock.allowedinterfaces](#)<sup>[474]</sup> property refers to the Ethernet interface as "NET", Wi-Fi -- as "WLN". [Sock.targetinterface](#)<sup>[506]</sup> and [sock.currentinterface](#)<sup>[478]</sup> properties rely on the [pl\\_sock\\_interfaces](#)<sup>[150]</sup> enum, whose members differ depending on the platform.
2. Default CTS/RTS mapping is different for each serial port:

	RTS	CTS

<b>Port 1</b>	<a href="#">0- PL IO NUM 0</a> <small>(154)</small>	<a href="#">0- PL INT NUM 0</a> <small>(157)</small> ( <a href="#">16- PL IO NUM 16 INT0</a> <small>(154)</small> )
<b>Port 2</b>	<a href="#">1- PL IO NUM 1</a> <small>(154)</small>	<a href="#">1- PL INT NUM 1</a> <small>(157)</small> ( <a href="#">17- PL IO NUM 17 INT1</a> <small>(154)</small> )
<b>Port 3</b>	<a href="#">2- PL IO NUM 2</a> <small>(154)</small>	<a href="#">2- PL INT NUM 2</a> <small>(157)</small> ( <a href="#">18- PL IO NUM 18 INT2</a> <small>(154)</small> )
<b>Port 4</b>	<a href="#">3- PL IO NUM 3</a> <small>(154)</small>	<a href="#">3- PL INT NUM 3</a> <small>(157)</small> ( <a href="#">19- PL IO NUM 19 INT3</a> <small>(154)</small> )

3. Default PLL state after the external reset is ON.
4. Older EM1202 and EM1202W devices did not contain the serial number. To find out if your EM1202(W) has the serial number onboard, try to read this serial number with the [sys.serialnum](#)(534) R/O property. If this property returns an empty string, then the serial number is not present. Sys.serialnum returns all 128 bytes of the serial number. First 64 bytes are one-time-programmable (OTP) with the [sys.setserialnum](#)(535) method.

## Platform-specific Constants

The following constant lists are platform-specific:

- [Enum pl\\_redir](#)(146) - the list of constants that define buffer redirection (shorting) for this platform.
- [Enum pl\\_io\\_num](#)(147) - the list of constants that define available I/O lines.
- [Enum pl\\_io\\_port\\_num](#)(156) - the list of constants that define available 8-bit I/O ports.
- [Enum pl\\_int\\_num](#)(150) - the list of constants that define available *interrupt* lines.
- [Enum pl\\_sock\\_interfaces](#)(157) - the list of available network interfaces.

### Enum pl\_redir

Enum pl\_redir contains the list of constants that define buffer redirection (shorting) for these platforms. The following objects support buffers and buffer redirection:

- [Ser.](#)(378) object (see [ser.redir](#)(414) method)
- [Sock.](#)(421) object (see [sock.redir](#)(493) method)

Enum pl\_redir for this platform includes the following constants:

- 0- PL\_REDIR\_NONE: Cancels redirection for the serial port or socket.
- 1- PL\_REDIR\_SER: Redirects RX data of the serial port or socket to the TX buffer of the serial port 0. This constant can be used as a "base" for all other serial ports, i.e. in expressions like ser.redir= PL\_REDIR\_SER+f.
- 1- PL\_REDIR\_SER0: Redirects RX data of the serial port or socket to the TX buffer of the serial port 0.
- 2- PL\_REDIR\_SER1: Redirects RX data of the serial port or socket to the TX buffer of the serial port 1.
- 3- PL\_REDIR\_SER2: Redirects RX data of the serial port or socket to the TX buffer of the serial port 2.
- 4- PL\_REDIR\_SER3: Redirects RX data of the serial port or socket to the TX buffer of the serial port 3.

6- PL_REDIR_SOCKET0:	Redirects RX data of the serial port or socket to the TX buffer of socket 0. This constant can be used as a "base" for all other sockets i.e. in expressions like sock.redir= PL_REDIR_SOCKET0+f.
7- PL_REDIR_SOCKET1:	Redirects RX data of the serial port or socket to the TX buffer of socket 1.
8- PL_REDIR_SOCKET2:	Redirects RX data of the serial port or socket to the TX buffer of socket 2.
9- PL_REDIR_SOCKET3:	Redirects RX data of the serial port or socket to the TX buffer of socket 3.
10- PL_REDIR_SOCKET4:	Redirects RX data of the serial port or socket to the TX buffer of socket 4.
11- PL_REDIR_SOCKET5:	Redirects RX data of the serial port or socket to the TX buffer of socket 5.
12- PL_REDIR_SOCKET6:	Redirects RX data of the serial port or socket to the TX buffer of socket 6.
13- PL_REDIR_SOCKET7:	Redirects RX data of the serial port or socket to the TX buffer of socket 7.
14- PL_REDIR_SOCKET8:	Redirects RX data of the serial port or socket to the TX buffer of socket 8.
15- PL_REDIR_SOCKET9:	Redirects RX data of the serial port or socket to the TX buffer of socket 9.
16- PL_REDIR_SOCKET10:	Redirects RX data of the serial port or socket to the TX buffer of socket 10.
17- PL_REDIR_SOCKET11:	Redirects RX data of the serial port or socket to the TX buffer of socket 11.
18- PL_REDIR_SOCKET12:	Redirects RX data of the serial port or socket to the TX buffer of socket 12.
19- PL_REDIR_SOCKET13:	Redirects RX data of the serial port or socket to the TX buffer of socket 13.
20- PL_REDIR_SOCKET14:	Redirects RX data of the serial port or socket to the TX buffer of socket 14.
21- PL_REDIR_SOCKET15:	Redirects RX data of the serial port or socket to the TX buffer of socket 15.

## Enum pl\_io\_num

Enum pl\_io\_num contains the list of constants that refer to available GPIO lines. Use these constants when selecting the line with the [io.<sup>\[294\]</sup>](#) object (see the [io.num<sup>\[301\]</sup>](#) property).

Note that GPIO lines are of *unidirectional type<sup>[194]</sup>* and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see the notes at the bottom of the page.

Enum pl\_io\_num includes the following constants:

0- PL_IO_NUM_0:	Selects general-purpose I/O line 0 (P0.0).
1- PL_IO_NUM_1:	Selects general-purpose I/O line 1 (P0.1).
2- PL_IO_NUM_2:	Selects general-purpose I/O line 2 (P0.2).
3- PL_IO_NUM_3:	Selects general-purpose I/O line 3 (P0.3).

4- PL_IO_NUM_4:	Selects general-purpose I/O line 4 (P0.4).
5- PL_IO_NUM_5:	Selects general-purpose I/O line 5 (P0.5).
6- PL_IO_NUM_6:	Selects general-purpose I/O line 6 (P0.6).
7- PL_IO_NUM_7:	Selects general-purpose I/O line 7 (P0.7).
8- PL_IO_NUM_8_RX0 <sup>(1)</sup> :	Selects general-purpose I/O line 8 (P1.0). This line is also the <a href="#">RX/W1in/din</a> <sup>[379]</sup> input of the serial port 0.
9- PL_IO_NUM_9_TX0 <sup>(2)</sup> :	Selects general-purpose I/O line 9 (P1.1). This line is also the <a href="#">TX/W1out/dout</a> <sup>[379]</sup> output of the serial port 0.
10- PL_IO_NUM_10_RX1 <sup>(1)</sup> :	Selects general-purpose I/O line 10 (P1.2). This line is also the RX/W0&1in/din input of the serial port 1.
11- PL_IO_NUM_11_TX1 <sup>(2)</sup> :	Selects general-purpose I/O line 11 (P1.3). This line is also the TX/W1out/dout output of the serial port 1.
12- PL_IO_NUM_12_RX2 <sup>(1)</sup> :	Selects general-purpose I/O line 12 (P1.4). This line is also the RX/W0&1in/din input of the serial port 2.
13- PL_IO_NUM_13_TX2 <sup>(2)</sup> :	Selects general-purpose I/O line 13 (P1.5). This line is also the TX/W1out/dout output of the serial port 2.
14- PL_IO_NUM_14_RX3 <sup>(1)</sup> :	Selects general-purpose I/O line 14 (P1.6). This line is also the RX/W0&1in/din input of the serial port 3.
15- PL_IO_NUM_15_TX3 <sup>(2)</sup> :	Selects general-purpose I/O line 15 (P1.7). This line is also the TX/W1out/dout output of the serial port 3.
16- PL_IO_NUM_16_INT0:	Selects general-purpose I/O line 16 (P2.0). This is also the interrupt line 0.
17- PL_IO_NUM_17_INT1:	Selects general-purpose I/O line 17 (P2.1). This is also the interrupt line 1.
18- PL_IO_NUM_18_INT2:	Selects general-purpose I/O line 18 (P2.2). This is also the interrupt line 2.
19- PL_IO_NUM_19_INT3:	Selects general-purpose I/O line 19 (P2.3). This is also the interrupt line 3.
20- PL_IO_NUM_20_INT4:	Selects general-purpose I/O line 20 (P2.4). This is also the interrupt line 4.
21- PL_IO_NUM_21_INT5:	Selects general-purpose I/O line 21 (P2.5). This is also the interrupt line 5.
22- PL_IO_NUM_22_INT6:	Selects general-purpose I/O line 22 (P2.6). This is also the interrupt line 6.
23- PL_IO_NUM_23_INT7:	Selects general-purpose I/O line 23 (P2.7). This is also the interrupt line 7.
24- PL_IO_NUM_24:	Selects general-purpose I/O line 24 (does not belong to any 8-bit port).
25- PL_IO_NUM_25:	Selects general-purpose I/O line 25 (does not belong to any 8-bit port).
26- PL_IO_NUM_26:	Selects general-purpose I/O line 26 (does not belong to any 8-bit port).
27- PL_IO_NUM_27:	Selects general-purpose I/O line 27 (does not belong to any 8-bit port).

28- PL_IO_NUM_28:	Selects general-purpose I/O line 28 (does not belong to any 8-bit port).
29- PL_IO_NUM_29_CO <sup>(3)</sup> :	Selects general-purpose I/O line 29 (does not belong to any 8-bit port). This line is also used by the <a href="#">beep</a> <sup>[232]</sup> object to generate square wave output that is primarily intended for driving beeper (buzzer).
30- PL_IO_NUM_30:	Selects general-purpose I/O line 30 (does not belong to any 8-bit port).
31- PL_IO_NUM_31:	Selects general-purpose I/O line 31 (does not belong to any 8-bit port).
32- PL_IO_NULL:	This is a NULL line that does not physically exist. The state of this line is always detected as LOW. Setting this line has no effect.

#### Notes:

1. When a serial port is in the [UART](#) <sup>[380]</sup> mode ([ser.mode](#) <sup>[409]</sup>= 0- PL\_SER\_MODE\_UART) this line is automatically configured to be an input when this serial port is enabled ([ser.enabled](#) <sup>[405]</sup>= 1- YES) and returns to the previous input/output and high/low state when this serial port is closed ([ser.enabled](#)= 0- NO). When a serial port is in the [Wiegand](#) <sup>[383]</sup> or [clock/data](#) <sup>[386]</sup> mode ([ser.mode](#)= 1- PL\_SER\_MODE\_WIEGAND or [ser.mode](#)= 2- PL\_SER\_MODE\_CLOCKDATA), the line has to be configured as input by the application- this will not happen automatically.
2. When a serial port is in the UART mode ([ser.mode](#)= 0- PL\_SER\_MODE\_UART) this line is automatically configured to be an output when the serial port is enabled ([ser.enabled](#)= 1- YES) and returns to the previous input/output and high/low state when the serial port is closed ([ser.enabled](#)= 0- NO). When a serial port is in the Wiegand or clock/data mode ([ser.mode](#)= 1- PL\_SER\_MODE\_WIEGAND or [ser.mode](#)= 2- PL\_SER\_MODE\_CLOCKDATA), the line has to be configured as output by the application- this will not happen automatically.
3. When the beeper pattern starts playing, this line is configured as output automatically. When the beeper pattern stops playing, the output returns to the input/output and high/low state that it had before the pattern started playing.

## Enum pl\_io\_port\_num

Enum `pl_io_port_num` contains the list of available 8-bit GPIO ports. Use these constants when selecting the port with the [io.](#) <sup>[294]</sup> object (see the [io.portnum](#) <sup>[302]</sup> property).

Note that GPIO lines are of *unidirectional* [type](#) <sup>[194]</sup> and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see [Enum pl\\_io\\_num](#) <sup>[154]</sup> for details.

Enum `pl_io_port_num` includes the following constants:

0- PL_IO_PORT_NUM_0:	8-bit port 0 (P0). Contains I/O lines 0-7.
1- PL_IO_PORT_NUM_1:	8-bit port 1 (P1). Contains I/O lines 8-15.
2- PL_IO_PORT_NUM_2:	8-bit port 2 (P2). Contains I/O lines 16-23.

## Enum pl\_int\_num

Enum `pl_int_num` contains the list of constants that refer to available *interrupt* lines. Interrupt lines are mapped to [GPIO lines](#)<sup>[154]</sup> (this mapping can't be altered). For example, interrupt line 0 corresponds to GPIO line 16, interrupt line 1- to GPIO line 17, and so on. Keep in mind that for an interrupt line to work you need to [configure](#)<sup>[194]</sup> the corresponding GPIO line as input.

Enum `pl_int_num` for this platform includes the following constants:

0- <code>PL_INT_NUM_0</code> :	Interrupt line 0 (mapped onto I/O line 16).
1- <code>PL_INT_NUM_1</code> :	Interrupt line 1 (mapped onto I/O line 17).
2- <code>PL_INT_NUM_2</code> :	Interrupt line 2 (mapped onto I/O line 18).
3- <code>PL_INT_NUM_3</code> :	Interrupt line 3 (mapped onto I/O line 19).
4- <code>PL_INT_NUM_4</code> :	Interrupt line 4 (mapped onto I/O line 20).
5- <code>PL_INT_NUM_5</code> :	Interrupt line 5 (mapped onto I/O line 21).
6- <code>PL_INT_NUM_6</code> :	Interrupt line 6 (mapped onto I/O line 22).
7- <code>PL_INT_NUM_7</code> :	Interrupt line 7 (mapped onto I/O line 23).
8- <code>PL_INT_NULL</code> :	This is a NULL interrupt line that does not physically exist.

## Enum pl\_sock\_interfaces

Enum `pl_sock_interfaces` contains the list of available network interfaces. The EM1202 and EM1202W platforms differ in that the EM1202W has the W-Fi interface (requires an external GA1000 add-on module), while the EM1202 does not, and the `pl_sock_interfaces` reflects this.

### EM1202 platform

0- <code>PL_SOCKET_INTERFACE_NULL</code> :	Null (empty) interface.
1- <code>PL_SOCKET_INTERFACE_NET (default)</code> :	<a href="#">Ethernet interface</a> <sup>[358]</sup> .
3- <code>PL_SOCKET_INTERFACE_PPP</code> :	<a href="#">PPP interface</a> <sup>[366]</sup> .
4- <code>PL_SOCKET_INTERFACE_PPPOE</code> :	<a href="#">PPPoE interface</a> <sup>[369]</sup> .

### EM1202W platform

0- <code>PL_SOCKET_INTERFACE_NULL</code> :	Null (empty) interface.
1- <code>PL_SOCKET_INTERFACE_NET (default)</code> :	<a href="#">Ethernet interface</a> <sup>[358]</sup> .
2- <code>PL_SOCKET_INTERFACE_WLN</code> :	<a href="#">Wi-Fi interface</a> <sup>[536]</sup> .
3- <code>PL_SOCKET_INTERFACE_PPP</code> :	<a href="#">PPP interface</a> <sup>[366]</sup> .
4- <code>PL_SOCKET_INTERFACE_PPPOE</code> :	<a href="#">PPPoE interface</a> <sup>[369]</sup> .

## EM1206 and EM1206W Platforms

The difference between the EM1206 and EM1206W platforms is that the EM1206W additionally includes the Wi-Fi ([wln.](#)<sup>[536]</sup>) object (requires an external GA1000 add-on module). All other features of these two platforms are exactly the same.

### Memory space

RAM	<b>22,528*</b> bytes for application variables and data
Flash	<b>983,040</b> bytes for application and data storage ( <a href="#">shared</a> <sup>[200]</sup> flash memory)**
EEPROM	<b>2040</b> bytes for application data

\* RAM available in the debug mode is smaller by 257 bytes. All memory is available in the release mode.

\*\*Some earlier devices had only 458,752 bytes of flash memory available

### Supported Objects, variable types, and functions

- [Sock](#)<sup>[421]</sup> — socket communications (up to 16 UDP, TCP, and HTTP sessions);
- [Net](#)<sup>[358]</sup> — controls the Ethernet port;
- [Wln](#)<sup>[536]</sup> — handles the Wi-Fi interface (only available on the **EM1206W platform**, requires [GA1000](#)<sup>[201]</sup> add-on module);
- [Ser](#)<sup>[378]</sup> — in charge of serial ports (UART, Wiegand, and clock/data modes);
- [Ssi](#)<sup>[512]</sup> — implements up to four serial synchronous interface (SSI) channels, supports SPI, I2C, clock/data, etc.;
- [Io](#)<sup>[294]</sup> — handles I/O lines, ports, and interrupts;
- [Kp](#)<sup>[304]</sup> — scans keypads of matrix and "binary" types;
- [Rtc](#)<sup>[375]</sup> — keeps track of date and time;
- [Fd](#)<sup>[236]</sup> — manages flash memory file system and direct sector access;
- [Stor](#)<sup>[522]</sup> — provides access to the EEPROM;
- [Romfile](#)<sup>[370]</sup> — facilitates access to resource files (fixed data);
- [Pppoe](#)<sup>[369]</sup> — provides access to the Internet over an ADSL modem;
- [Ppp](#)<sup>[366]</sup> — provides access to the Internet over a serial modem (GPRS, POTS, etc.);
- [Pat](#)<sup>[363]</sup> — "plays" patterns on up to five LED pairs;
- [Beep](#)<sup>[232]</sup> — generates buzzer patterns;
- [Button](#)<sup>[234]</sup> — monitors the MD line ([setup button](#)<sup>[201]</sup>);
- [Sys](#)<sup>[526]</sup> — in charge of general device functionality.

These platforms support the standard set of [variable types](#)<sup>[192]</sup> and [functions](#)<sup>[192]</sup> (a.k.a. "syscalls").

### Platform-specific constants

You can find them [here](#).

**Miscellaneous information**

Available network interfaces	<b>EM1206: Ethernet (net.)</b> <b>EM1206W: Ethernet (net.), Wi-Fi (wln.)</b> <sup>(1)</sup>
<a href="#">GPIO type</a>	<b>Unidirectional</b>
<a href="#">RTS/CTS remapping</a>	<b>Supported</b> <sup>(2)</sup>
<a href="#">GA1000 lines remapping</a>	<b>Supported</b> <sup>(3)</sup>
<a href="#">Serial port FIFOs</a>	<b>16 byte for TX, 16 bytes for RX</b>
<a href="#">Clock frequency (PLL) control</a>	<b>PLL on (def): 88.4736Mhz, PLL off: 11.0592Mhz</b> <sup>(4)</sup>
<a href="#">Special configuration section of the EEPROM</a>	<b>8 bytes for MAC storage</b>
<a href="#">Device serial number</a>	<b>128 bytes: 64 OTP bytes + 64 fixed bytes</b> <sup>(5)</sup>
<a href="#">Flash memory configuration</a>	<b>Shared</b>
<a href="#">LEDs</a>	<b>Green (SG) and red (SR) Status LED lines</b> <b>Green (EG) and yellow (EY) Ethernet LED lines</b>
<a href="#">Debug communications</a>	<b>Ethernet / UDP Broadcast transport</b> <b>Ethernet / WinPCap transport</b>

1. The [sock.allowedinterfaces](#) property refers to the Ethernet interface as "NET", Wi-Fi -- as "WLN". [Sock.targetinterface](#) and [sock.currentinterface](#) properties rely on the [pl\\_sock\\_interfaces](#) enum, whose members differ depending on the platform.
2. Default CTS/RTS mapping is different for each serial port. Notice that CTS and RTS lines in default mapping interfere with each other. Do remember to select meaningful mapping for these lines!

	<b>RTS</b>	<b>CTS</b>
<b>Port 1</b>	<a href="#">0- PL_IO_NUM_0_RX0_INT0</a>	<a href="#">0- PL_INT_NUM_0</a> ( <a href="#">0- PL_IO_NUM_0_RX0_INT0</a> )
<b>Port 2</b>	<a href="#">1- PL_IO_NUM_1_TX0_INT1</a>	<a href="#">1- PL_INT_NUM_1</a> ( <a href="#">1- PL_IO_NUM_1_TX0_INT1</a> )
<b>Port 3</b>	<a href="#">2- PL_IO_NUM_2_RX1_INT2</a>	<a href="#">2- PL_INT_NUM_2</a> ( <a href="#">2- PL_IO_NUM_2_RX1_INT2</a> )
<b>Port 4</b>	<a href="#">3- PL_IO_NUM_3_TX1_INT3</a>	<a href="#">3- PL_INT_NUM_3</a> ( <a href="#">3- PL_IO_NUM_3_TX1_INT3</a> )

3. Mapping of [GA1000](#) control lines is fully flexible on the EM1206W. However, if

the EM1206EV board is used, then the following mapping *must* be applied:

<b>CS</b>	<a href="#">15- PL_IO_NUM_15</a> <sup>[161]</sup>
<b>CLK</b>	<a href="#">14- PL_IO_NUM_14</a> <sup>[161]</sup>
<b>DI</b>	<a href="#">12- PL_IO_NUM_12</a> <sup>[161]</sup>
<b>DO</b>	<a href="#">13- PL_IO_NUM_13</a> <sup>[161]</sup>
<b>RST</b>	<a href="#">11- PL_IO_NUM_11</a> <sup>[161]</sup>

- Default PLL state after the external reset is ON.
- Older EM1206 and EM1206W devices did not contain the serial number. To find out if your EM1206(W) has the serial number onboard, try to read this serial number with the [sys.serialnum](#)<sup>[534]</sup> R/O property. If this property returns an empty string, then the serial number is not present. Sys.serialnum returns all 128 bytes of the serial number. First 64 bytes are one-time-programmable (OTP) with the [sys.setserialnum](#)<sup>[535]</sup> method.

## Platform-specific Constants

The following constant lists are platform-specific:

- [Enum pl\\_redir](#)<sup>[160]</sup> the list of constants that define buffer redirection (shorting) for this platform.
- [Enum pl\\_io\\_num](#)<sup>[161]</sup> the list of constants that define available I/O lines.
- [Enum pl\\_io\\_port\\_num](#)<sup>[163]</sup> the list of constants that define available 8-bit I/O ports.
- [Enum pl\\_int\\_num](#)<sup>[163]</sup> the list of constants that define available *interrupt* lines.
- [Enum pl\\_sock\\_interfaces](#)<sup>[163]</sup> the list of available network interfaces.

### Enum pl\_redir

Enum pl\_redir contains the list of constants that define buffer redirection (shorting) for these platforms. The following objects support buffers and buffer redirection:

- [Ser](#)<sup>[378]</sup> object (see [ser.redir](#)<sup>[414]</sup> method)
- [Sock](#)<sup>[421]</sup> object (see [sock.redir](#)<sup>[493]</sup> method)

Enum pl\_redir for this platform includes the following constants:

- 0- PL\_REDIR\_NONE: Cancels redirection for the serial port or socket.
- 1- PL\_REDIR\_SER: Redirects RX data of the serial port or socket to the TX buffer of the serial port 0. This constant can be used as a "base" for all other serial ports, i.e. in expressions like `ser.redir= PL_REDIR_SER+f`.
- 1- PL\_REDIR\_SER0: Redirects RX data of the serial port or socket to the TX buffer of the serial port 0.
- 2- PL\_REDIR\_SER1: Redirects RX data of the serial port or socket to the TX buffer of the serial port 1.
- 3- PL\_REDIR\_SER2: Redirects RX data of the serial port or socket to the TX buffer of the serial port 2.
- 4- PL\_REDIR\_SER3: Redirects RX data of the serial port or socket to the TX buffer of the serial port 3.

6- PL_REDIR_SOCKET0:	Redirects RX data of the serial port or socket to the TX buffer of socket 0. This constant can be used as a "base" for all other sockets i.e. in expressions like sock.redir= PL_REDIR_SOCKET0+f.
7- PL_REDIR_SOCKET1:	Redirects RX data of the serial port or socket to the TX buffer of socket 1.
8- PL_REDIR_SOCKET2:	Redirects RX data of the serial port or socket to the TX buffer of socket 2.
9- PL_REDIR_SOCKET3:	Redirects RX data of the serial port or socket to the TX buffer of socket 3.
10- PL_REDIR_SOCKET4:	Redirects RX data of the serial port or socket to the TX buffer of socket 4.
11- PL_REDIR_SOCKET5:	Redirects RX data of the serial port or socket to the TX buffer of socket 5.
12- PL_REDIR_SOCKET6:	Redirects RX data of the serial port or socket to the TX buffer of socket 6.
13- PL_REDIR_SOCKET7:	Redirects RX data of the serial port or socket to the TX buffer of socket 7.
14- PL_REDIR_SOCKET8:	Redirects RX data of the serial port or socket to the TX buffer of socket 8.
15- PL_REDIR_SOCKET9:	Redirects RX data of the serial port or socket to the TX buffer of socket 9.
16- PL_REDIR_SOCKET10:	Redirects RX data of the serial port or socket to the TX buffer of socket 10.
17- PL_REDIR_SOCKET11:	Redirects RX data of the serial port or socket to the TX buffer of socket 11.
18- PL_REDIR_SOCKET12:	Redirects RX data of the serial port or socket to the TX buffer of socket 12.
19- PL_REDIR_SOCKET13:	Redirects RX data of the serial port or socket to the TX buffer of socket 13.
20- PL_REDIR_SOCKET14:	Redirects RX data of the serial port or socket to the TX buffer of socket 14.
21- PL_REDIR_SOCKET15:	Redirects RX data of the serial port or socket to the TX buffer of socket 15.

## Enum pl\_io\_num

Enum `pl_io_num` contains the list of constants that refer to available GPIO lines. Use these constants when selecting the line with the `io.[294]` object (see the `io.num[301]` property).

Note that GPIO lines are of *unidirectional type<sup>[194]</sup>* and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see the notes at the bottom of the page.

Enum `pl_io_num` includes the following constants:

- 0- PL\_IO\_NUM\_0\_RX0\_INT0<sup>(1)</sup>: General-purpose I/O line 0 (P0.0). This line is also the `RX/W1in/din[379]` input of the serial port 0 and the interrupt line 0.
- 1- PL\_IO\_NUM\_1\_TX0\_INT1<sup>(2)</sup>: General-purpose I/O line 1 (P0.1). This line is also

- the [TX/W1out/dout](#)<sup>[379]</sup> output of the serial port 0 and the interrupt line 1.
- 2- PL\_IO\_NUM\_2\_RX1\_INT2<sup>(1)</sup>: General-purpose I/O line 2 (P0.2). This line is also the RX/W0&1in/din input of the serial port 1 and the interrupt line 2.
- 3- PL\_IO\_NUM\_3\_TX1\_INT3<sup>(2)</sup>: General-purpose I/O line 3 (P0.3). This line is also the TX/W1out/dout output of the serial port 1 and the interrupt line 3.
- 4- PL\_IO\_NUM\_4\_RX2\_INT4<sup>(1)</sup>: General-purpose I/O line 4 (P0.4). This line is also the RX/W0&1in/din input of the serial port 2 and the interrupt line 4.
- 5- PL\_IO\_NUM\_5\_TX2\_INT5<sup>(2)</sup>: General-purpose I/O line 5 (P0.5). This line is also the TX/W1out/dout output of the serial port 2 and the interrupt line 5.
- 6- PL\_IO\_NUM\_6\_RX3\_INT6<sup>(1)</sup>: General-purpose I/O line 6 (P0.6). This line is also the RX/W0&1in/din input of the serial port 3 and the interrupt line 6.
- 7- PL\_IO\_NUM\_7\_TX3\_INT7<sup>(2)</sup>: General-purpose I/O line 7 (P0.7). This line is also the TX/W1out/dout output of the serial port 3 and the interrupt line 7.
- 8- PL\_IO\_NUM\_8: General-purpose I/O line 8 (P1.0).
- 9- PL\_IO\_NUM\_9: General-purpose I/O line 9 (P1.1).
- 10- PL\_IO\_NUM\_10: General-purpose I/O line 10 (P1.2).
- 11- PL\_IO\_NUM\_11: General-purpose I/O line 11 (P1.3).
- 12- PL\_IO\_NUM\_12: General-purpose I/O line 12 (P1.4).
- 13- PL\_IO\_NUM\_13: General-purpose I/O line 13 (P1.5).
- 14- PL\_IO\_NUM\_14: General-purpose I/O line 14 (P1.6).
- 15- PL\_IO\_NUM\_15: General-purpose I/O line 15 (P1.7).
- 16- PL\_IO\_NUM\_16\_CO<sup>(3)</sup>: General-purpose I/O line 16 (does not belong to any 8-bit port). This line is also used by the [beep](#)<sup>[232]</sup> object to generate square wave output that is primarily intended for driving beeper (buzzer).
- 17- PL\_IO\_NULL: This is a NULL line that does not physically exist. The state of this line is always detected as LOW. Setting this line has no effect.

#### Notes:

- When a serial port is in the [UART](#)<sup>[380]</sup> mode ([ser.mode](#)<sup>[409]</sup>= 0- PL\_SER\_MODE\_UART) this line is automatically configured to be an input when this serial port is enabled ([ser.enabled](#)<sup>[405]</sup>= 1- YES) and returns to the previous input/output and high/low state when this serial port is closed ([ser.enabled](#)= 0- NO). When a serial port is in the [Wiegand](#)<sup>[383]</sup> or [clock/data](#)<sup>[386]</sup> mode ([ser.mode](#)= 1- PL\_SER\_MODE\_WIEGAND or [ser.mode](#)= 2- PL\_SER\_MODE\_CLOCKDATA), the line has to be configured as input by the application- this will not happen automatically.
- When a serial port is in the UART mode ([ser.mode](#)= 0- PL\_SER\_MODE\_UART) this line is automatically configured to be an output when the serial port is enabled ([ser.enabled](#)= 1- YES) and returns to the previous input/output and high/low state when the serial port is closed ([ser.enabled](#)= 0- NO). When a serial port is in

the Wiegand or clock/data mode (ser.mode= 1- PL\_SER\_MODE\_WIEGAND or ser.mode= 2- PL\_SER\_MODE\_CLOCKDATA), the line has to be configured as output by the application- this will not happen automatically.

3. When the beeper pattern starts playing, this line is configured as output automatically. When the beeper pattern stops playing, the output returns to the input/output and high/low state that it had before the pattern started playing.

## Enum pl\_io\_port\_num

Enum pl\_io\_port\_num contains the list of available 8-bit GPIO ports. Use these constants when selecting the port with the [io](#) object (see the [io.portnum](#) property).

Note that GPIO lines are of *unidirectional* [type](#) and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see [Enum pl\\_io\\_num](#) for details.

Enum pl\_io\_port\_num includes the following constants:

- 0- PL\_IO\_PORT\_NUM\_0: 8-bit port 0 (P0). Contains I/O lines 0-7.
- 1- PL\_IO\_PORT\_NUM\_1: 8-bit port 1 (P1). Contains I/O lines 8-15.

## Enum pl\_int\_num

Enum pl\_int\_num contains the list of constants that refer to available *interrupt* lines. Interrupt lines are mapped to [GPIO lines](#) (this mapping can't be altered). Keep in mind that for an interrupt line to work you need to [configure](#) the corresponding GPIO line as input.

Enum pl\_int\_num for this platform includes the following constants:

- 0- PL\_INT\_NUM\_0: Interrupt line 0 (mapped onto I/O line 0).
- 1- PL\_INT\_NUM\_1: Interrupt line 1 (mapped onto I/O line 1).
- 2- PL\_INT\_NUM\_2: Interrupt line 2 (mapped onto I/O line 2).
- 3- PL\_INT\_NUM\_3: Interrupt line 3 (mapped onto I/O line 3).
- 4- PL\_INT\_NUM\_4: Interrupt line 4 (mapped onto I/O line 4).
- 5- PL\_INT\_NUM\_5: Interrupt line 5 (mapped onto I/O line 5).
- 6- PL\_INT\_NUM\_6: Interrupt line 6 (mapped onto I/O line 6).
- 7- PL\_INT\_NUM\_7: Interrupt line 7 (mapped onto I/O line 7).
- 8- PL\_INT\_NULL: This is a NULL interrupt line that does not physically exist.

## Enum pl\_sock\_interfaces

Enum pl\_sock\_interfaces contains the list of available network interfaces. The EM1206 and EM1206W platforms differ in that the EM1206W has the W-Fi interface (requires an external GA1000 add-on module), while the EM1206 does not, and the pl\_sock\_interfaces reflects this.

### EM1206 platform

0- PL_SOCKET_INTERFACE_NULL:	Null (empty) interface.
1- PL_SOCKET_INTERFACE_NET <b>(default)</b> :	<a href="#">Ethernet interface</a> <sup>[358]</sup> .
3- PL_SOCKET_INTERFACE_PPP:	<a href="#">PPP interface</a> <sup>[366]</sup> .
4- PL_SOCKET_INTERFACE_PPPOE:	<a href="#">PPPoE interface</a> <sup>[369]</sup> .

### EM1206W platform

0- PL_SOCKET_INTERFACE_NULL:	Null (empty) interface.
1- PL_SOCKET_INTERFACE_NET <b>(default)</b> :	<a href="#">Ethernet interface</a> <sup>[358]</sup> .
2- PL_SOCKET_INTERFACE_WLN:	<a href="#">Wi-Fi interface</a> <sup>[536]</sup> .
3- PL_SOCKET_INTERFACE_PPP:	<a href="#">PPP interface</a> <sup>[366]</sup> .
4- PL_SOCKET_INTERFACE_PPPOE:	<a href="#">PPPoE interface</a> <sup>[369]</sup> .

## DS1100 Platform

### Memory space

RAM	<b>17,920*</b> bytes for application variables and data
Flash	<b>327,680</b> bytes for application storage, data cannot be stored in this memory
EEPROM	<b>200</b> bytes for application data

\* RAM available in the debug mode is smaller by 257 bytes. All memory is available in the release mode.

### Supported Objects, variable types, and functions

- [Sock](#)<sup>[421]</sup> — socket communications (up to 16 UDP, TCP, and HTTP sessions);
- [Net](#)<sup>[358]</sup> — controls the Ethernet port;
- [Ser](#)<sup>[378]</sup> — in charge of the RS232 port;
- [Io](#)<sup>[294]</sup> — handles I/O lines, ports, and interrupts;
- [Stor](#)<sup>[522]</sup> — provides access to the EEPROM;
- [Romfile](#)<sup>[370]</sup> — facilitates access to resource files (fixed data);
- [Pppoe](#)<sup>[369]</sup> — provides access to the Internet over an ADSL modem;
- [Ppp](#)<sup>[366]</sup> — provides access to the Internet over a serial modem (GPRS, POTS, etc.);
- [Pat](#)<sup>[363]</sup> — "plays" patterns on a pair of LEDs;
- [Button](#)<sup>[234]</sup> — monitors the MD line ([setup button](#)<sup>[201]</sup>);
- [Sys](#)<sup>[526]</sup> — in charge of general device functionality.

\* Fully supported with the exception of [fd.copyfirmware](#)<sup>[269]</sup>. Disabled by default --

enable it in [Project Settings](#)<sup>[38]</sup> -> *Customize*.

This platform supports the standard set of [variable types](#)<sup>[192]</sup> and [functions](#)<sup>[192]</sup> (a.k.a. "syscalls") **except** [aes128enc](#)<sup>[206]</sup> and [aes128dec](#)<sup>[205]</sup>. These AES128 functions are **not present** on the DS1100 platform.

### Platform-specific constants

You can find them [here](#)<sup>[165]</sup>.

### Miscellaneous information

<a href="#">Available network interfaces</a>	<b>Ethernet (<a href="#">net</a>,<sup>[358]</sup>)<sup>(1)</sup></b>
<a href="#">GPIO type</a> <sup>[194]</sup>	<b>Bidirectional</b>
<a href="#">RTS/CTS remapping</a> <sup>[195]</sup>	<b>Not supported</b> <sup>(2)</sup>
<a href="#">Serial port FIFOs</a> <sup>[196]</sup>	<b>16 byte for TX, 16 bytes for RX</b>
<a href="#">Clock frequency (PLL) control</a> <sup>[196]</sup>	<b>Not supported, frequency is fixed at 80MHz</b>
<a href="#">Special configuration section of the EEPROM</a> <sup>[197]</sup>	<b>8 bytes for MAC storage</b>
<a href="#">Device serial number</a> <sup>[199]</sup>	<b>4 bytes, the number can't be changed</b>
<a href="#">Flash memory configuration</a> <sup>[200]</sup>	<b>Dedicated memory for firmware/ application Data cannot be stored in this memory</b>
<a href="#">LEDs</a> <sup>[200]</sup>	<b>Green (SG) and red (SR) Status LEDs A dedicated Ethernet link status LED (yellow)</b>
<a href="#">Debug communications</a> <sup>[204]</sup>	<b>Ethernet / UDP Broadcast transport Ethernet / WinPCap transport</b>

#### Comments:

1. The [sock.allowedinterfaces](#)<sup>[474]</sup> property refers to the Ethernet interface as "NET". [Sock.targetinterface](#)<sup>[506]</sup> and [sock.currentinterface](#)<sup>[478]</sup> properties rely on the [pl\\_sock\\_interfaces](#)<sup>[150]</sup> enum, whose members differ depending on the platform.
2. CTS is permanently mapped to [0- PL\\_INT\\_NUM\\_0](#)<sup>[167]</sup> ([0- PL\\_IO\\_NUM\\_0 INTO](#)<sup>[167]</sup>).  
RTS is permanently mapped to [2- PL\\_IO\\_NUM\\_2](#)<sup>[167]</sup>.

## Platform-specific Constants

The following constant lists are platform-specific:

- [Enum\\_pl\\_redir](#)<sup>[166]</sup>- the list of constants that define buffer redirection (shorting) for this platform.
- [Enum\\_pl\\_io\\_num](#)<sup>[167]</sup>- the list of constants that define available I/O lines.
- [Enum\\_pl\\_io\\_port\\_num](#)<sup>[167]</sup>- the list of constants that define available 8-bit I/O ports.

- [Enum pl\\_int\\_num](#)<sup>[167]</sup> the list of constants that define available *interrupt* lines.
- [Enum pl\\_sock\\_interfaces](#)<sup>[168]</sup> the list of available network interfaces.

## Enum pl\_redir

Enum pl\_redir contains the list of constants that define buffer redirection (shorting). The following objects support buffers and buffer redirection:

- [Ser.](#)<sup>[378]</sup> object (see [ser.redir](#)<sup>[414]</sup> method)
- [Sock.](#)<sup>[421]</sup> object (see [sock.redir](#)<sup>[493]</sup> method)

Enum pl\_redir for this platform includes the following constants:

0-	PL_REDIR_NONE:	Cancels redirection for the serial port or socket.
1-	PL_REDIR_SER:	Redirects RX data of the serial port or socket to the TX buffer of the serial port.
6-	PL_REDIR_SOCKET0:	Redirects RX data of the serial port or socket to the TX buffer of socket 0. This constant can be used as a "base" for all other sockets i.e. in expressions like sock.redir= PL_REDIR_SOCKET0+f.
7-	PL_REDIR_SOCKET1:	Redirects RX data of the serial port or socket to the TX buffer of socket 1.
8-	PL_REDIR_SOCKET2:	Redirects RX data of the serial port or socket to the TX buffer of socket 2.
9-	PL_REDIR_SOCKET3:	Redirects RX data of the serial port or socket to the TX buffer of socket 3.
10-	PL_REDIR_SOCKET4:	Redirects RX data of the serial port or socket to the TX buffer of socket 4.
11-	PL_REDIR_SOCKET5:	Redirects RX data of the serial port or socket to the TX buffer of socket 5.
12-	PL_REDIR_SOCKET6:	Redirects RX data of the serial port or socket to the TX buffer of socket 6.
13-	PL_REDIR_SOCKET7:	Redirects RX data of the serial port or socket to the TX buffer of socket 7.
14-	PL_REDIR_SOCKET8:	Redirects RX data of the serial port or socket to the TX buffer of socket 8.
15-	PL_REDIR_SOCKET9:	Redirects RX data of the serial port or socket to the TX buffer of socket 9.
16-	PL_REDIR_SOCKET10:	Redirects RX data of the serial port or socket to the TX buffer of socket 10.
17-	PL_REDIR_SOCKET11:	Redirects RX data of the serial port or socket to the TX buffer of socket 11.
18-	PL_REDIR_SOCKET12:	Redirects RX data of the serial port or socket to the TX buffer of socket 12.
19-	PL_REDIR_SOCKET13:	Redirects RX data of the serial port or socket to the TX buffer of socket 13.
20-	PL_REDIR_SOCKET14:	Redirects RX data of the serial port or socket to the TX buffer of socket 14.
21-	PL_REDIR_SOCKET15:	Redirects RX data of the serial port or socket to the TX buffer of socket 15.

## Enum pl\_io\_num

Enum `pl_io_num` contains the list of constants that refer to available GPIO lines. Use these constants when selecting the line with the `io` object (see the `io.num` property).

Note that GPIO lines are of *bidirectional* type and do not require explicit configuration as outputs or inputs.

Enum `pl_io_num` includes the following constants:

- 0- `PL_IO_NUM_0_CTS_INT0`: General-purpose I/O line 0 (P0.0), also the CTS input of the serial port and the interrupt line 0.
- 1- `PL_IO_NUM_1_DSR_INT1`: General-purpose I/O line 1 (P0.1), also the DSR input of the serial port and the interrupt line 1.
- 2- `PL_IO_NUM_2_RTS`: General-purpose I/O line 2 (P0.2), also the RTS output of the serial port.
- 3- `PL_IO_NUM_3_DTR`: General-purpose I/O line 3 (P0.3), also the DTR output of the serial port.
- 4- `PL_IO_NUM_4_DCD`: General-purpose I/O line 4 (P0.4), also the DCD input of the serial port.
- 5- `PL_IO_NUM_5`: Not implemented.
- 6- `PL_IO_NUM_6`: Not implemented.
- 7- `PL_IO_NUM_7`: Not implemented.
- 8- `PL_IO_NULL`: This is a NULL line that does not physically exist. The state of this line is always detected as LOW. Setting this line has no effect.

## Enum pl\_io\_port\_num

Enum `pl_io_port_num` contains the list of available 8-bit GPIO ports. Use these constants when selecting the port with the `io` object (see the `io.portnum` property).

Note that GPIO lines are of *bidirectional* type and do not require explicit configuration as outputs or inputs.

Enum `pl_io_port_num` includes the following constants:

- 0- `PL_IO_PORT_NUM_0`: 8-bit port 0 (P0). Contains I/O lines 0-7. Lines 5-7 are not implemented on this platform.

## Enum pl\_int\_num

Enum `pl_int_num` contains the list of constants that refer to available *interrupt* lines. Interrupt lines are mapped to [GPIO lines](#) (this mapping can't be altered).

Enum `pl_int_num` includes the following constants:

- 0- `PL_INT_NUM_0`: Interrupt line 0 (mapped to I/O line 0, which serves as the CTS input of the serial port).
- 1- `PL_INT_NUM_1`: Interrupt line 1 (mapped to I/O line 1, which serves as

- the DSR input of the serial port).
- 2- PL\_INT\_NULL: This is a NULL interrupt line that does not physically exist.

## Enum pl\_sock\_interfaces

Enum pl\_sock\_interfaces contains the list of network interfaces supported by the platform:

- 0- PL\_SOCKET\_INTERFACE\_NULL: Null (empty) interface.
- 1- PL\_SOCKET\_INTERFACE\_NET (**default**): [Ethernet interface](#)<sup>[358]</sup>.
- 3- PL\_SOCKET\_INTERFACE\_PPP: [PPP interface](#)<sup>[366]</sup>.
- 4- PL\_SOCKET\_INTERFACE\_PPPOE: [PPPoE interface](#)<sup>[369]</sup>.

## DS1101W Platform

### • Memory space

RAM	<b>22,528*</b> bytes for application variables and data
Flash	<b>983,040</b> bytes for application and data storage ( <a href="#">shared</a> <sup>[200]</sup> flash memory)**
EEPROM	<b>2040</b> bytes for application data

\* RAM available in the debug mode is smaller by 257 bytes. All memory is available in the release mode.

\*\* Some earlier devices had only 458,752 bytes of flash memory available

### Supported Objects, variable types, and functions

- [Sock](#)<sup>[421]</sup> — socket communications (up to 16 UDP, TCP, and HTTP sessions);
- [Net](#)<sup>[358]</sup> — controls the Ethernet port;
- [Win](#)<sup>[536]</sup> — handles the Wi-Fi interface (requires [GA1000](#)<sup>[201]</sup> add-on module, i.e. "G" device option);
- [Ser](#)<sup>[378]</sup> — in charge of the serial ports (on this device, [serial channels](#)<sup>[205]</sup> of the RS232 port);
- [Io](#)<sup>[294]</sup> — handles I/O lines, ports, and interrupts;
- [Lcd](#)<sup>[317]</sup> — controls the 96x32 monochrome OLED display (therefore, requires the "D" device option);
- [Fd](#)<sup>[236]</sup> — manages flash memory file system and direct sector access;
- [Stor](#)<sup>[522]</sup> — provides access to the EEPROM;
- [Romfile](#)<sup>[370]</sup> — facilitates access to resource files (fixed data);
- [Pppoe](#)<sup>[369]</sup> — provides access to the Internet over an ADSL modem;

- [Ppp](#)<sup>[366]</sup> — provides access to the Internet over a serial modem (GPRS, POTS, etc.);
- [Pat](#)<sup>[363]</sup> — "plays" patterns on a pair of LEDs;
- [Beep](#)<sup>[232]</sup> — generates buzzer patterns;
- [Button](#)<sup>[234]</sup> — monitors the MD line ([setup button](#)<sup>[201]</sup>);
- [Sys](#)<sup>[526]</sup> — in charge of general device functionality.



As all displays of this type, the DS1101's OLED display has a limited life span. There will be a decrease in the display brightness after ~10000 hours of operation. To prolong display life, use the [lcd.lock](#)<sup>[348]</sup> method to turn the display off whenever possible. Display image is preserved when the display is "locked".

These platforms support the standard set of [variable types](#)<sup>[192]</sup> and [functions](#)<sup>[192]</sup> (a.k.a. "syscalls").

### Platform-specific constants

You can find them [here](#)<sup>[170]</sup>.

### Miscellaneous information

<a href="#">Available network interfaces</a>	<b>Ethernet (<a href="#">net.</a><sup>[358]</sup>), Wi-Fi (<a href="#">wln.</a><sup>[538]</sup>)<sup>(1)</sup></b>
<a href="#">GPIO type</a> <sup>[194]</sup>	<b>Unidirectional</b>
<a href="#">RTS/CTS remapping</a> <sup>[195]</sup>	<b>Supported<sup>(2)</sup></b>
<a href="#">GA1000 lines remapping</a> <sup>[201]</sup>	<b>Supported<sup>(3)</sup></b>
<a href="#">Serial port FIFOs</a> <sup>[196]</sup>	<b>16 byte for TX, 16 bytes for RX</b>
<a href="#">Clock frequency (PLL) control</a> <sup>[196]</sup>	<b>PLL on (def): 88.4736Mhz, PLL off: 11.0592Mhz<sup>(4)</sup></b>
<a href="#">Special configuration section of the EEPROM</a> <sup>[197]</sup>	<b>8 bytes for MAC storage</b>
<a href="#">Device serial number</a> <sup>[199]</sup>	<b>128 bytes: 64 OTP bytes + 64 fixed bytes</b>
<a href="#">Flash memory configuration</a> <sup>[200]</sup>	<b>Shared</b>
<a href="#">LEDs</a> <sup>[200]</sup>	<b>Green (SG) and red (SR) Status LEDs A dedicated Ethernet link status LED (yellow) An LED bar consisting of five blue LEDs<sup>(5)</sup></b>
<a href="#">Debug communications</a> <sup>[204]</sup>	<b>Ethernet / UDP Broadcast transport Ethernet / WinPCap transport</b>

#### Comments:

1. The [sock.allowedinterfaces](#)<sup>[474]</sup> property refers to the Ethernet interface as "NET", Wi-Fi -- as "WLN". [Sock.targetinterface](#)<sup>[506]</sup> and [sock.currentinterface](#)<sup>[478]</sup>

properties rely on the [pl\\_sock\\_interfaces](#)<sup>[174]</sup> enum, whose members differ depending on the platform.

- The hardware of this platform supports [serial\\_channels](#)<sup>[205]</sup>, which means that CTS/RTS and DTR/DSR pairs of the DB9 connector can also be used as RX/TX pairs of additional serial channels. Therefore, it is up to you to decide which lines are used as RTS and CTS, and which channels they will belong to. Proper mapping will be required to implement each particular arrangement.
- Although the platform itself supports remapping, actual "wires" connecting the system to the GA1000 are fixed and your mapping should reflect this:

<b>CS</b>	<a href="#">15- PL IO NUM 15</a> <sup>[171]</sup>
<b>CLK</b>	<a href="#">14- PL IO NUM 14</a> <sup>[171]</sup>
<b>DI</b>	<a href="#">12- PL IO NUM 12</a> <sup>[171]</sup>
<b>DO</b>	<a href="#">13- PL IO NUM 13</a> <sup>[171]</sup>
<b>RST</b>	<a href="#">11- PL IO NUM 11</a> <sup>[171]</sup>

- Default PLL state after the external reset is ON.
- The LEDs of the LED bar are mapped to [GPIO lines](#)<sup>[171]</sup>. The LEDs are primarily intended for the Wi-Fi signal strength indication but can also be used for other purposes.

## Platform-specific Constants

The following constant lists are platform-specific:

- [Enum pl\\_redir](#)<sup>[170]</sup> the list of constants that define buffer redirection (shorting) for this platform.
- [Enum pl\\_io\\_num](#)<sup>[171]</sup> the list of constants that define available I/O lines.
- [Enum pl\\_io\\_port\\_num](#)<sup>[173]</sup> the list of constants that define available 8-bit I/O ports.
- [Enum pl\\_int\\_num](#)<sup>[174]</sup> the list of constants that define available *interrupt* lines.
- [Enum pl\\_sock\\_interfaces](#)<sup>[174]</sup> the list of available network interfaces.

### Enum pl\_redir

Enum `pl_redir` contains the list of constants that define buffer redirection (shorting) for these platforms. The following objects support buffers and buffer redirection:

- [Ser](#)<sup>[376]</sup> object (see [ser.redir](#)<sup>[414]</sup> method)
- [Sock](#)<sup>[421]</sup> object (see [sock.redir](#)<sup>[493]</sup> method)

Enum `pl_redir` for this platform includes the following constants:

- |                   |   |
|-------------------|---|
| 0- PL_REDIR_NONE: | Cancels redirection for the serial port* or socket.   |
| 1- PL_REDIR_SER:  | Redirects RX data of the serial port or socket to the TX buffer of the serial port 0. This constant can be used as a "base" for all other serial ports, i.e. in expressions like <code>ser.redir= PL_REDIR_SER+f</code> . |
| 1- PL_REDIR_SER0: | Redirects RX data of the serial port or socket to the TX buffer of the serial port 0.   |
| 2- PL_REDIR_SER1: | Redirects RX data of the serial port or socket to the TX  |

	buffer of the serial port 1.
3- PL_REDIRE_SER2:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 2.
4- PL_REDIRE_SER3:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 3.
6- PL_REDIRE_SOCKET0:	Redirects RX data of the serial port or socket to the TX buffer of socket 0. This constant can be used as a "base" for all other sockets i.e. in expressions like sock.redir= PL_REDIRE_SOCKET0+f.
7- PL_REDIRE_SOCKET1:	Redirects RX data of the serial port or socket to the TX buffer of socket 1.
8- PL_REDIRE_SOCKET2:	Redirects RX data of the serial port or socket to the TX buffer of socket 2.
9- PL_REDIRE_SOCKET3:	Redirects RX data of the serial port or socket to the TX buffer of socket 3.
10- PL_REDIRE_SOCKET4:	Redirects RX data of the serial port or socket to the TX buffer of socket 4.
11- PL_REDIRE_SOCKET5:	Redirects RX data of the serial port or socket to the TX buffer of socket 5.
12- PL_REDIRE_SOCKET6:	Redirects RX data of the serial port or socket to the TX buffer of socket 6.
13- PL_REDIRE_SOCKET7:	Redirects RX data of the serial port or socket to the TX buffer of socket 7.
14- PL_REDIRE_SOCKET8:	Redirects RX data of the serial port or socket to the TX buffer of socket 8.
15- PL_REDIRE_SOCKET9:	Redirects RX data of the serial port or socket to the TX buffer of socket 9.
16- PL_REDIRE_SOCKET10:	Redirects RX data of the serial port or socket to the TX buffer of socket 10.
17- PL_REDIRE_SOCKET11:	Redirects RX data of the serial port or socket to the TX buffer of socket 11.
18- PL_REDIRE_SOCKET12:	Redirects RX data of the serial port or socket to the TX buffer of socket 12.
19- PL_REDIRE_SOCKET13:	Redirects RX data of the serial port or socket to the TX buffer of socket 13.
20- PL_REDIRE_SOCKET14:	Redirects RX data of the serial port or socket to the TX buffer of socket 14.
21- PL_REDIRE_SOCKET15:	Redirects RX data of the serial port or socket to the TX buffer of socket 15.

*\*In this list, the term "serial port" actually refers to "serial channel".*

## Enum pl\_io\_num

Enum pl\_io\_num contains the list of constants that refer to available GPIO lines. Use these constants when selecting the line with the [io](#) object (see the [io.num](#) property).

Note that GPIO lines are of *unidirectional type* and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically

-- see the notes at the bottom of the page.

- The DS1101 device has the RS232 transceiver IC onboard. This IC "dictates" the GPIO line direction for certain lines. Do not try to use GPIO lines 0, 2, 4, and 6 as outputs -- this can permanently damage the hardware.

Enum `pl_io_num` includes the following constants:

- 0- `PL_IO_NUM_0_RX0_INT0`<sup>(1)</sup>: General-purpose I/O line 0 (P0.0). This line is also the `RX/W1in/din`<sub>[379]</sub> input of the serial port<sup>(3)</sup> 0 and the interrupt line 0.
- 1- `PL_IO_NUM_1_TX0_INT1`<sup>(2)</sup>: General-purpose I/O line 1 (P0.1). This line is also the `TX/W1out/dout`<sub>[379]</sub> output of the serial port 0 and the interrupt line 1.
- 2- `PL_IO_NUM_2_RX1_INT2`<sup>(1)</sup>: General-purpose I/O line 2 (P0.2). This line is also the `RX/W0&1in/din` input of the serial port 1 and the interrupt line 2.
- 3- `PL_IO_NUM_3_TX1_INT3`<sup>(2)</sup>: General-purpose I/O line 3 (P0.3). This line is also the `TX/W1out/dout` output of the serial port 1 and the interrupt line 3.
- 4- `PL_IO_NUM_4_RX2_INT4`<sup>(1)</sup>: General-purpose I/O line 4 (P0.4). This line is also the `RX/W0&1in/din` input of the serial port 2 and the interrupt line 4.
- 5- `PL_IO_NUM_5_TX2_INT5`<sup>(2)</sup>: General-purpose I/O line 5 (P0.5). This line is also the `TX/W1out/dout` output of the serial port 2 and the interrupt line 5.
- 6- `PL_IO_NUM_6_RX3_INT6`<sup>(1)</sup>: General-purpose I/O line 6 (P0.6). This line is also the `RX/W0&1in/din` input of the serial port 3 and the interrupt line 6.
- 7- `PL_IO_NUM_7_EMPTY`: Not implemented.
- 8- `PL_IO_NUM_8_PWROUT`: Controls the power output on pin 9 of the DB9M connector. Power will be ON when this output is enabled (`io.enabled= 1- YES`) and set to LOW (`io.state= 0- LOW`).
- `PL_IO_NUM_9`: Pin 8 on the wireless interface connector.
- `PL_IO_NUM_10`: Pin 6 on the wireless interface connector.
- `PL_IO_NUM_11`: The RST line of the wireless interface.
- `PL_IO_NUM_12`: The DI line of the wireless interface.
- `PL_IO_NUM_13`: The DO line of the wireless interface.
- `PL_IO_NUM_14`: The CLK line of the wireless interface.
- `PL_IO_NUM_15`: The CS line of the wireless interface.
- `PL_IO_NUM_16`: Pin 9 on the wireless interface connector.
- `PL_IO_NUM_17_EMPTY`: Not implemented.
- `PL_IO_NUM_18_EMPTY`: Not implemented.
- `PL_IO_NUM_19_SB1`: LED bar, LED#1 (the "weakest signal" LED).
- `PL_IO_NUM_20_SB2`: LED bar, LED#2.

PL_IO_NUM_21_SB3:	LED bar, LED#3.
PL_IO_NUM_22_SB4:	LED bar, LED#4.
PL_IO_NUM_23_SB5:	LED bar, LED#5 (the "strongest signal" LED).
PL_IO_NUM_24_OLED_D0:	OLED display data bus, line 0 (P0.0).
PL_IO_NUM_25_OLED_D1:	OLED display data bus, line 1 (P0.0).
PL_IO_NUM_26_OLED_D2:	OLED display data bus, line 2 (P0.1).
PL_IO_NUM_27_OLED_D3:	OLED display data bus, line 3 (P0.2).
PL_IO_NUM_28_OLED_D4:	OLED display data bus, line 4 (P0.3).
PL_IO_NUM_29_OLED_D5:	OLED display data bus, line 5 (P0.4).
PL_IO_NUM_30_OLED_D6:	OLED display data bus, line 6 (P0.5).
PL_IO_NUM_31_OLED_D7:	OLED display data bus, line 7 (P0.6).
PL_IO_NUM_32_OLED_CS:	OLED display, CS control line.
PL_IO_NUM_33_OLED_RD:	OLED display, RD control line.
PL_IO_NUM_34_OLED_WR:	OLED display, WR control line.
PL_IO_NUM_35_OLED_DC:	OLED display, DC control line.
PL_IO_NUM_36_OLED_RST:	OLED display, RST control line.
PL_IO_NUM_37_CO:	General-purpose I/O line 37 (does not belong to any 8-bit port), also a square wave output controlled by the beep object. This output is driving a buzzer.
PL_IO_NULL:	This is a NULL line that does not physically exist. The state of this line is always detected as LOW. Setting this line has no effect.

#### Notes:

1. When a serial port is in the [UART](#) <sup>[380]</sup> mode ([ser.mode](#) <sup>[409]</sup>= 0- PL\_SER\_MODE\_UART) this line is automatically configured to be an input when this serial port is enabled ([ser.enabled](#) <sup>[405]</sup>= 1- YES) and returns to the previous input/output and high/low state when this serial port is closed ([ser.enabled](#)= 0- NO).
2. When a serial port is in the UART mode ([ser.mode](#)= 0- PL\_SER\_MODE\_UART) this line is automatically configured to be an output when the serial port is enabled ([ser.enabled](#)= 1- YES) and returns to the previous input/output and high/low state when the serial port is closed ([ser.enabled](#)= 0- NO).
3. In this list, the term "serial port" actually refers to "serial channel".

## Enum pl\_io\_port\_num

Enum `pl_io_port_num` contains the list of available 8-bit GPIO ports. Use these constants when selecting the port with the [io](#) <sup>[294]</sup> object (see the [io.portnum](#) <sup>[302]</sup> property).

Note that GPIO lines are of *unidirectional* [type](#) <sup>[194]</sup> and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see [Enum pl\\_io\\_num](#) <sup>[171]</sup> for details.

- The DS1101 device has the RS232 transceiver IC onboard. This IC "dictates" the GPIO line direction for certain lines. Do not try to use GPIO lines 0, 2, 4, and 6 as outputs -- this can permanently damage the hardware.

Enum `pl_io_port_num` includes only one constant:

`PL_IO_PORT_NUM_0`: 8-bit port 0, contains I/O lines 24-31 (the data bus of the OLED display).

## Enum `pl_int_num`

Enum `pl_int_num` contains the list of constants that refer to available *interrupt* lines. Interrupt lines are mapped to [GPIO lines](#)<sup>[171]</sup> (this mapping can't be altered). Keep in mind that for an interrupt line to work you need to [configure](#)<sup>[194]</sup> the corresponding GPIO line as input.

Enum `pl_int_num` for this platform includes the following constants:

`PL_INT_NUM_0`: Interrupt line 0 (mapped onto I/O line 0).  
`PL_INT_NUM_1`: Interrupt line 1 (mapped onto I/O line 1).  
`PL_INT_NUM_2`: Interrupt line 2 (mapped onto I/O line 2).  
`PL_INT_NUM_3`: Interrupt line 3 (mapped onto I/O line 3).  
`PL_INT_NUM_4`: Interrupt line 4 (mapped onto I/O line 4).  
`PL_INT_NUM_5`: Interrupt line 5 (mapped onto I/O line 5).  
`PL_INT_NUM_6`: Interrupt line 6 (mapped onto I/O line 6).  
`PL_INT_NUM_7`: Interrupt line 7 (mapped onto I/O line 7).  
`PL_INT_NULL`: This is a NULL interrupt line that does not physically exist.

## Enum `pl_sock_interfaces`

Enum `pl_sock_interfaces` contains the list of network interfaces supported by the platform:

0- `PL_SOCK_INTERFACE_NULL`: Null (empty) interface.  
 1- `PL_SOCK_INTERFACE_NET (default)`: [Ethernet interface](#)<sup>[358]</sup>.  
 2- `PL_SOCK_INTERFACE_WLN`: [Wi-Fi interface](#)<sup>[536]</sup>.  
 3- `PL_SOCK_INTERFACE_PPP`: [PPP interface](#)<sup>[366]</sup>.  
 4- `PL_SOCK_INTERFACE_PPPOE`: [PPPoE interface](#)<sup>[369]</sup>.

## DS1102W Platform

- **Memory space**

RAM	<b>22,528*</b> bytes for application variables and data
Flash	<b>983,040</b> bytes for application and data storage ( <a href="#">shared</a> <sup>[200]</sup> flash)

	memory)**
EEPROM	<b>2040</b> bytes for application data

\* RAM available in the debug mode is smaller by 257 bytes. All memory is available in the release mode.

\*\* Some earlier devices had only 458,752 bytes of flash memory available

**Supported Objects, variable types, and functions**

- [Sock](#)<sup>[421]</sup> — socket communications (up to 16 UDP, TCP, and HTTP sessions);
- [Net](#)<sup>[358]</sup> — controls the Ethernet port;
- [Wln](#)<sup>[536]</sup> — handles the Wi-Fi interface (requires [GA1000](#)<sup>[201]</sup> add-on module, i.e. "G" device option);
- [Ser](#)<sup>[378]</sup> — in charge of the serial ports (on this device, [serial channels](#)<sup>[205]</sup> of the RS232 port);
- [Io](#)<sup>[294]</sup> — handles I/O lines, ports, and interrupts;
- [Lcd](#)<sup>[317]</sup> — controls the 96x32 monochrome OLED display (therefore, requires the "D" device option);
- [Fd](#)<sup>[236]</sup> — manages flash memory file system and direct sector access;
- [Stor](#)<sup>[522]</sup> — provides access to the EEPROM;
- [Romfile](#)<sup>[370]</sup> — facilitates access to resource files (fixed data);
- [Pppoe](#)<sup>[369]</sup> — provides access to the Internet over an ADSL modem;
- [Ppp](#)<sup>[366]</sup> — provides access to the Internet over a serial modem (GPRS, POTS, etc.);
- [Pat](#)<sup>[363]</sup> — "plays" patterns on a pair of LEDs;
- [Beep](#)<sup>[232]</sup> — generates buzzer patterns;
- [Button](#)<sup>[234]</sup> — monitors the MD line ([setup button](#)<sup>[201]</sup>);
- [Sys](#)<sup>[526]</sup> — in charge of general device functionality.

These platforms support the standard set of [variable types](#)<sup>[192]</sup> and [functions](#)<sup>[192]</sup> (a.k.a. "syscalls").

**Platform-specific constants**

You can find them [here](#)<sup>[176]</sup>.

**Miscellaneous information**

Available network interfaces	<b>Ethernet (<a href="#">net.</a><sup>[358]</sup>), Wi-Fi (<a href="#">wln.</a><sup>[536]</sup>)<sup>(1)</sup></b>
<a href="#">GPIO type</a> <sup>[194]</sup>	<b>Unidirectional</b>
<a href="#">RTS/CTS remapping</a> <sup>[195]</sup>	<b>Supported<sup>(2)</sup></b>
<a href="#">GA1000 lines remapping</a> <sup>[201]</sup>	<b>Supported<sup>(3)</sup></b>
<a href="#">Serial port FIFOs</a> <sup>[196]</sup>	<b>16 byte for TX, 16 bytes for RX</b>

<a href="#">Clock frequency (PLL) control</a> <sup>[196]</sup>	<b>PLL on (def): 88.4736Mhz, PLL off: 11.0592Mhz<sup>(4)</sup></b>
<a href="#">Special configuration section of the EEPROM</a> <sup>[197]</sup>	<b>8 bytes for MAC storage</b>
<a href="#">Device serial number</a> <sup>[199]</sup>	<b>128 bytes: 64 OTP bytes + 64 fixed bytes</b>
<a href="#">Flash memory configuration</a> <sup>[200]</sup>	<b>Shared</b>
<a href="#">LEDs</a> <sup>[200]</sup>	<b>Green (SG) and red (SR) Status LEDs A dedicated Ethernet link status LED (yellow) An LED bar consisting of five blue LEDs<sup>(5)</sup></b>
<a href="#">Debug communications</a> <sup>[204]</sup>	<b>Ethernet / UDP Broadcast transport Ethernet / WinPCap transport</b>

#### Comments:

1. The [sock.allowedinterfaces](#)<sup>[474]</sup> property refers to the Ethernet interface as "NET", Wi-Fi -- as "WLN". [Sock.targetinterface](#)<sup>[506]</sup> and [sock.currentinterface](#)<sup>[478]</sup> properties rely on the [pl\\_sock\\_interfaces](#)<sup>[180]</sup> enum, whose members differ depending on the platform.
2. The hardware of this platform supports [serial channels](#)<sup>[205]</sup>, which means that CTS/RTS and DTR/DSR pairs of the DB9 connector can also be used as RX/TX pairs of additional serial channels. Therefore, it is up to you to decide which lines are used as RTS and CTS, and which channels they will belong to. Proper mapping will be required to implement each particular arrangement.
3. Although the platform itself supports remapping, actual "wires" connecting the system to the GA1000 are fixed and your mapping should reflect this:

<b>CS</b>	<a href="#">15- PL IO NUM 15</a> <sup>[178]</sup>
<b>CLK</b>	<a href="#">14- PL IO NUM 14</a> <sup>[178]</sup>
<b>DI</b>	<a href="#">12- PL IO NUM 12</a> <sup>[178]</sup>
<b>DO</b>	<a href="#">13- PL IO NUM 13</a> <sup>[178]</sup>
<b>RST</b>	<a href="#">11- PL IO NUM 11</a> <sup>[178]</sup>

4. Default PLL state after the external reset is ON.
5. The LEDs of the LED bar are mapped to [GPIO lines](#)<sup>[178]</sup>. The LEDs are primarily intended for the Wi-Fi signal strength indication but can also be used for other purposes.

## Platform-specific Constants

The following constant lists are platform-specific:

- [Enum pl\\_redir](#)<sup>[177]</sup> - the list of constants that define buffer redirection (shorting) for this platform.
- [Enum pl\\_io\\_num](#)<sup>[178]</sup> - the list of constants that define available I/O lines.
- [Enum pl\\_io\\_port\\_num](#)<sup>[180]</sup> - the list of constants that define available 8-bit I/O ports.

- [Enum pl\\_int\\_num](#)<sup>[180]</sup> the list of constants that define available *interrupt* lines.
- [Enum pl\\_sock\\_interfaces](#)<sup>[180]</sup> the list of available network interfaces.

## Enum pl\_redir

Enum pl\_redir contains the list of constants that define buffer redirection (shorting) for these platforms. The following objects support buffers and buffer redirection:

- [Ser](#)<sup>[378]</sup> object (see [ser.redir](#)<sup>[414]</sup> method)
- [Sock](#)<sup>[421]</sup> object (see [sock.redir](#)<sup>[493]</sup> method)

Enum pl\_redir for this platform includes the following constants:

0- PL_REDIR_NONE:	Cancels redirection for the serial port* or socket.
1- PL_REDIR_SER:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 0. This constant can be used as a "base" for all other serial ports, i.e. in expressions like ser.redir= PL_REDIR_SER+f.
1- PL_REDIR_SER0:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 0.
2- PL_REDIR_SER1:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 1.
3- PL_REDIR_SER2:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 2.
4- PL_REDIR_SER3:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 3.
6- PL_REDIR SOCK0:	Redirects RX data of the serial port or socket to the TX buffer of socket 0. This constant can be used as a "base" for all other sockets i.e. in expressions like sock.redir= PL_REDIR SOCK0+f.
7- PL_REDIR SOCK1:	Redirects RX data of the serial port or socket to the TX buffer of socket 1.
8- PL_REDIR SOCK2:	Redirects RX data of the serial port or socket to the TX buffer of socket 2.
9- PL_REDIR SOCK3:	Redirects RX data of the serial port or socket to the TX buffer of socket 3.
10- PL_REDIR SOCK4:	Redirects RX data of the serial port or socket to the TX buffer of socket 4.
11- PL_REDIR SOCK5:	Redirects RX data of the serial port or socket to the TX buffer of socket 5.
12- PL_REDIR SOCK6:	Redirects RX data of the serial port or socket to the TX buffer of socket 6.
13- PL_REDIR SOCK7:	Redirects RX data of the serial port or socket to the TX buffer of socket 7.
14- PL_REDIR SOCK8:	Redirects RX data of the serial port or socket to the TX buffer of socket 8.
15- PL_REDIR SOCK9:	Redirects RX data of the serial port or socket to the TX buffer of socket 9.
16- PL_REDIR SOCK10:	Redirects RX data of the serial port or socket to the TX buffer of socket 10.

- 17- PL\_REDIR\_SOCKET11: Redirects RX data of the serial port or socket to the TX buffer of socket 11.
- 18- PL\_REDIR\_SOCKET12: Redirects RX data of the serial port or socket to the TX buffer of socket 12.
- 19- PL\_REDIR\_SOCKET13: Redirects RX data of the serial port or socket to the TX buffer of socket 13.
- 20- PL\_REDIR\_SOCKET14: Redirects RX data of the serial port or socket to the TX buffer of socket 14.
- 21- PL\_REDIR\_SOCKET15: Redirects RX data of the serial port or socket to the TX buffer of socket 15.

*\*In this list, the term "serial port" actually refers to "serial channel".*

## Enum pl\_io\_num

Enum `pl_io_num` contains the list of constants that refer to available GPIO lines. Use these constants when selecting the line with the `io.`<sup>[294]</sup> object (see the `io.num`<sup>[301]</sup> property).

Note that GPIO lines are of *unidirectional* `type`<sup>[194]</sup> and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see the notes at the bottom of the page.

- The DS1102 device has the RS232 transceiver IC onboard. This IC "dictates" the GPIO line direction for certain lines. Do not try to use GPIO lines 0, 2, 4, and 6 as outputs -- this can permanently damage the hardware.

Enum `pl_io_num` includes the following constants:

- 0- `PL_IO_NUM_0_RX0_INT0`<sup>(1)</sup>: General-purpose I/O line 0 (P0.0). This line is also the `RX/W1in/din`<sup>[379]</sup> input of the serial port<sup>(3)</sup> 0 and the interrupt line 0.
- 1- `PL_IO_NUM_1_TX0_INT1`<sup>(2)</sup>: General-purpose I/O line 1 (P0.1). This line is also the `TX/W1out/dout`<sup>[379]</sup> output of the serial port 0 and the interrupt line 1.
- 2- `PL_IO_NUM_2_RX1_INT2`<sup>(1)</sup>: General-purpose I/O line 2 (P0.2). This line is also the `RX/W0&1in/din` input of the serial port 1 and the interrupt line 2.
- 3- `PL_IO_NUM_3_TX1_INT3`<sup>(2)</sup>: General-purpose I/O line 3 (P0.3). This line is also the `TX/W1out/dout` output of the serial port 1 and the interrupt line 3.
- 4- `PL_IO_NUM_4_RX2_INT4`<sup>(1)</sup>: General-purpose I/O line 4 (P0.4). This line is also the `RX/W0&1in/din` input of the serial port 2 and the interrupt line 4.
- 5- `PL_IO_NUM_5_TX2_INT5`<sup>(2)</sup>: General-purpose I/O line 5 (P0.5). This line is also the `TX/W1out/dout` output of the serial port 2 and the interrupt line 5.
- 6- `PL_IO_NUM_6_RX3_INT6`<sup>(1)</sup>: Not implemented.
- 7- `PL_IO_NUM_7_EMPTY`: Not implemented.
- 8- `PL_IO_NUM_8_PWROUT`: Not implemented.
- `PL_IO_NUM_9`: Pin 8 on the wireless interface connector.

PL_IO_NUM_10:	Pin 6 on the wireless interface connector.
PL_IO_NUM_11:	The RST line of the wireless interface.
PL_IO_NUM_12:	The DI line of the wireless interface.
PL_IO_NUM_13:	The DO line of the wireless interface.
PL_IO_NUM_14:	The CLK line of the wireless interface.
PL_IO_NUM_15:	The CS line of the wireless interface.
PL_IO_NUM_16:	Pin 9 on the wireless interface connector.
PL_IO_NUM_17_RSMD:	Serial port mode: HIGH for RS422/485, LOW for RS232.
PL_IO_NUM_18_HDFD:	Serial port mode: HIGH for full-duplex, LOW for half-duplex.
PL_IO_NUM_19_SB1:	LED bar, LED#1 (the "weakest signal" LED).
PL_IO_NUM_20_SB2:	LED bar, LED#2.
PL_IO_NUM_21_SB3:	LED bar, LED#3.
PL_IO_NUM_22_SB4:	LED bar, LED#4.
PL_IO_NUM_23_SB5:	LED bar, LED#5 (the "strongest signal" LED).
PL_IO_NUM_24_OLED_D0:	OLED display data bus, line 0 (P0.0).
PL_IO_NUM_25_OLED_D1:	OLED display data bus, line 1 (P0.0).
PL_IO_NUM_26_OLED_D2:	OLED display data bus, line 2 (P0.1).
PL_IO_NUM_27_OLED_D3:	OLED display data bus, line 3 (P0.2).
PL_IO_NUM_28_OLED_D4:	OLED display data bus, line 4 (P0.3).
PL_IO_NUM_29_OLED_D5:	OLED display data bus, line 5 (P0.4).
PL_IO_NUM_30_OLED_D6:	OLED display data bus, line 6 (P0.5).
PL_IO_NUM_31_OLED_D7:	OLED display data bus, line 7 (P0.6).
PL_IO_NUM_32_OLED_CS:	OLED display, CS control line.
PL_IO_NUM_33_OLED_RD:	OLED display, RD control line.
PL_IO_NUM_34_OLED_WR:	OLED display, WR control line.
PL_IO_NUM_35_OLED_DC:	OLED display, DC control line.
PL_IO_NUM_36_OLED_RST:	OLED display, RST control line.
PL_IO_NUM_37_CO:	General-purpose I/O line 37 (does not belong to any 8-bit port), also a square wave output controlled by the beep object. This output is driving a buzzer.
PL_IO_NULL:	This is a NULL line that does not physically exist. The state of this line is always detected as LOW. Setting this line has no effect.

#### Notes:

1. When a serial port is in the [UART](#) mode (`ser.mode` = 0- `PL_SER_MODE_UART`) this line is automatically configured to be an input when this serial port is enabled (`ser.enabled` = 1- YES) and returns to the previous input/output and high/low state when this serial port is closed (`ser.enabled` = 0- NO).
2. When a serial port is in the UART mode (`ser.mode` = 0- `PL_SER_MODE_UART`) this line is automatically configured to be an output when the serial port is enabled (`ser.enabled` = 1- YES) and returns to the previous input/output and high/low

state when the serial port is closed (ser.enabled= 0- NO).

3. In this list, the term "serial port" actually refers to "serial channel".

## Enum pl\_io\_port\_num

Enum pl\_io\_port\_num contains the list of available 8-bit GPIO ports. Use these constants when selecting the port with the [io.](#)<sup>[294]</sup> object (see the [io.portnum](#)<sup>[302]</sup> property).

Note that GPIO lines are of *unidirectional* [type](#)<sup>[194]</sup> and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see [Enum pl\\_io\\_num](#)<sup>[178]</sup> for details.

- The DS1102 device has the RS232 transceiver IC onboard. This IC "dictates" the GPIO line direction for certain lines. Do not try to use GPIO lines 0, 2, 4, and 6 as outputs -- this can permanently damage the hardware.

Enum pl\_io\_port\_num includes only one constant:

PL\_IO\_PORT\_NUM\_0:                   8-bit port 0, contains I/O lines 24-31 (the data bus of the OLED display).

## Enum pl\_int\_num

Enum pl\_int\_num contains the list of constants that refer to available *interrupt* lines. Interrupt lines are mapped to [GPIO lines](#)<sup>[178]</sup> (this mapping can't be altered). Keep in mind that for an interrupt line to work you need to [configure](#)<sup>[194]</sup> the corresponding GPIO line as input.

Enum pl\_int\_num for this platform includes the following constants:

PL_INT_NUM_0:	Interrupt line 0 (mapped onto I/O line 0).
PL_INT_NUM_1:	Interrupt line 1 (mapped onto I/O line 1).
PL_INT_NUM_2:	Interrupt line 2 (mapped onto I/O line 2).
PL_INT_NUM_3:	Interrupt line 3 (mapped onto I/O line 3).
PL_INT_NUM_4:	Interrupt line 4 (mapped onto I/O line 4).
PL_INT_NUM_5:	Interrupt line 5 (mapped onto I/O line 5).
PL_INT_NUM_6:	Interrupt line 6 (mapped onto I/O line 6).
PL_INT_NUM_7:	Interrupt line 7 (mapped onto I/O line 7).
PL_INT_NULL:	This is a NULL interrupt line that does not physically exist.

## Enum pl\_sock\_interfaces

Enum pl\_sock\_interfaces contains the list of network interfaces supported by the platform:

0- PL_SOCK_INTERFACE_NULL:	Null (empty) interface.
1- PL_SOCK_INTERFACE_NET ( <b>default</b> ):	<a href="#">Ethernet interface</a> <sup>[358]</sup> .
2- PL_SOCK_INTERFACE_WLN:	<a href="#">Wi-Fi interface</a> <sup>[536]</sup> .
3- PL_SOCK_INTERFACE_PPP:	<a href="#">PPP interface</a> <sup>[366]</sup> .
4- PL_SOCK_INTERFACE_PPPOE:	<a href="#">PPPoE interface</a> <sup>[369]</sup> .

## DS1202 Platform

### Memory space

RAM	<b>22,528*</b> bytes for application variables and data
Flash	<b>983,040</b> bytes for application and data storage ( <a href="#">shared</a> <sup>[200]</sup> flash memory)**
EEPROM	<b>2040</b> bytes for application data

\* RAM available in the debug mode is smaller by 257 bytes. All memory is available in the release mode.

\*\* Some earlier devices had only 458,752 bytes of flash memory available

### Supported Objects, variable types, and functions

- [Sock](#)<sup>[421]</sup> — socket communications (up to 16 UDP, TCP, and HTTP sessions);
- [Net](#)<sup>[358]</sup> — controls the Ethernet port;
- [Ser](#)<sup>[378]</sup> — in charge of the serial ports (on this device, [serial channels](#)<sup>[205]</sup> of the RS232 port);
- [Ssi](#)<sup>[512]</sup> — implements up to four serial synchronous interface (SSI) channels, supports SPI, I2C, clock/data, etc.;
- [Io](#)<sup>[294]</sup> — handles I/O lines, ports, and interrupts;
- [Fd](#)<sup>[236]</sup> — manages flash memory file system and direct sector access;
- [Stor](#)<sup>[522]</sup> — provides access to the EEPROM;
- [Romfile](#)<sup>[370]</sup> — facilitates access to resource files (fixed data);
- [Pppoe](#)<sup>[369]</sup> — provides access to the Internet over an ADSL modem;
- [Ppp](#)<sup>[366]</sup> — provides access to the Internet over a serial modem (GPRS, POTS, etc.);
- [Pat](#)<sup>[363]</sup> — "plays" patterns on a pair of LEDs;
- [Button](#)<sup>[234]</sup> — monitors the MD line ([setup button](#)<sup>[201]</sup>);
- [Sys](#)<sup>[526]</sup> — in charge of general device functionality.

These platforms support the standard set of [variable types](#)<sup>[192]</sup> and [functions](#)<sup>[192]</sup> (a.k.a. "syscalls").

### Platform-specific constants

You can find them [here](#).

### Miscellaneous information

Available network interfaces	<b>Ethernet (net.)<sup>(1)</sup></b>
<a href="#">GPIO type</a> <sup>194</sup>	<b>Unidirectional</b>
<a href="#">RTS/CTS remapping</a> <sup>195</sup>	<b>Supported<sup>(2)</sup></b>
<a href="#">GA1000 lines remapping</a> <sup>201</sup>	<b>This platform does not support Wi-Fi at all</b>
<a href="#">Serial port FIFOs</a> <sup>196</sup>	<b>16 byte for TX, 16 bytes for RX</b>
<a href="#">Clock frequency (PLL) control</a> <sup>196</sup>	<b>PLL on (def): 88.4736Mhz, PLL off: 11.0592Mhz<sup>(3)</sup></b>
<a href="#">Special configuration section of the EEPROM</a> <sup>197</sup>	<b>8 bytes for MAC storage</b>
<a href="#">Device serial number</a> <sup>199</sup>	<b>128 bytes: 64 OTP bytes + 64 fixed bytes<sup>(4)</sup></b>
<a href="#">Flash memory configuration</a> <sup>200</sup>	<b>Shared</b>
<a href="#">LEDs</a> <sup>200</sup>	<b>Green (SG) and red (SR) Status LEDs Green (EG) and yellow (EY) Ethernet LEDs</b>
<a href="#">Debug communications</a> <sup>204</sup>	<b>Ethernet / UDP Broadcast transport Ethernet / WinPCap transport</b>

#### Comments:

1. The [sock.allowedinterfaces](#)<sup>474</sup> property refers to the Ethernet interface as "NET". [Sock.targetinterface](#)<sup>506</sup> and [sock.currentinterface](#)<sup>478</sup> properties rely on the [pl\\_sock\\_interfaces](#)<sup>186</sup> enum, whose members differ depending on the platform.
2. The hardware of this platform supports [serial\\_channels](#)<sup>205</sup>, which means that CTS/RTS and DTR/DSR pairs of the DB9 connector can also be used as RX/TX pairs of additional serial channels. Therefore, it is up to you to decide which lines are used as RTS and CTS, and which channels they will belong to. Proper mapping will be required to implement each particular arrangement.
3. Default PLL state after the external reset is ON.
4. Older DS1202 and DS1202W devices did not contain the serial number. To find out if your DS1202(W) has the serial number onboard, try to read this serial number with the [sys.serialnum](#)<sup>534</sup> R/O property. If this property returns an empty string, then the serial number is not present. Sys.serialnum returns all 128 bytes of the serial number. First 64 bytes are one-time-programmable (OTP) with the [sys.setserialnum](#)<sup>535</sup> method.

## Platform-specific Constants

The following constant lists are platform-specific:

- [Enum\\_pl\\_redir](#)<sup>183</sup> - the list of constants that define buffer redirection (shorting) for this platform.
- [Enum\\_pl\\_io\\_num](#)<sup>184</sup> - the list of constants that define available I/O lines.

- [Enum pl\\_io\\_port\\_num](#)<sup>[185]</sup> the list of constants that define available 8-bit I/O ports.
- [Enum pl\\_int\\_num](#)<sup>[185]</sup> the list of constants that define available *interrupt* lines.
- [Enum pl\\_sock\\_interfaces](#)<sup>[186]</sup> the list of available network interfaces.

## Enum pl\_redir

Enum pl\_redir contains the list of constants that define buffer redirection (shorting) for these platforms. The following objects support buffers and buffer redirection:

- [Ser.](#)<sup>[376]</sup> object (see [ser.redir](#)<sup>[414]</sup> method)
- [Sock.](#)<sup>[421]</sup> object (see [sock.redir](#)<sup>[493]</sup> method)

Enum pl\_redir for this platform includes the following constants:

0- PL_REDIR_NONE:	Cancels redirection for the serial port* or socket.
1- PL_REDIR_SER:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 0. This constant can be used as a "base" for all other serial ports, i.e. in expressions like ser.redir= PL_REDIR_SER+f.
1- PL_REDIR_SER0:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 0.
2- PL_REDIR_SER1:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 1.
3- PL_REDIR_SER2:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 2.
4- PL_REDIR_SER3:	Redirects RX data of the serial port or socket to the TX buffer of the serial port 3.
6- PL_REDIR SOCK0:	Redirects RX data of the serial port or socket to the TX buffer of socket 0. This constant can be used as a "base" for all other sockets i.e. in expressions like sock.redir= PL_REDIR SOCK0+f.
7- PL_REDIR SOCK1:	Redirects RX data of the serial port or socket to the TX buffer of socket 1.
8- PL_REDIR SOCK2:	Redirects RX data of the serial port or socket to the TX buffer of socket 2.
9- PL_REDIR SOCK3:	Redirects RX data of the serial port or socket to the TX buffer of socket 3.
10- PL_REDIR SOCK4:	Redirects RX data of the serial port or socket to the TX buffer of socket 4.
11- PL_REDIR SOCK5:	Redirects RX data of the serial port or socket to the TX buffer of socket 5.
12- PL_REDIR SOCK6:	Redirects RX data of the serial port or socket to the TX buffer of socket 6.
13- PL_REDIR SOCK7:	Redirects RX data of the serial port or socket to the TX buffer of socket 7.
14- PL_REDIR SOCK8:	Redirects RX data of the serial port or socket to the TX buffer of socket 8.
15- PL_REDIR SOCK9:	Redirects RX data of the serial port or socket to the TX buffer of socket 9.

- 16- PL\_REDIR\_SOCKET10: Redirects RX data of the serial port or socket to the TX buffer of socket 10.
- 17- PL\_REDIR\_SOCKET11: Redirects RX data of the serial port or socket to the TX buffer of socket 11.
- 18- PL\_REDIR\_SOCKET12: Redirects RX data of the serial port or socket to the TX buffer of socket 12.
- 19- PL\_REDIR\_SOCKET13: Redirects RX data of the serial port or socket to the TX buffer of socket 13.
- 20- PL\_REDIR\_SOCKET14: Redirects RX data of the serial port or socket to the TX buffer of socket 14.
- 21- PL\_REDIR\_SOCKET15: Redirects RX data of the serial port or socket to the TX buffer of socket 15.

*\*In this list, the term "serial port" actually refers to "serial channel".*

## Enum pl\_io\_num

Enum pl\_io\_num contains the list of constants that refer to available GPIO lines. Use these constants when selecting the line with the [io.](#)<sup>[294]</sup> object (see the [io.num](#)<sup>[301]</sup> property).

Note that GPIO lines are of *unidirectional* [type](#)<sup>[194]</sup> and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see the notes at the bottom of the page.

- The EM1202EV-RS board and the DS1202 controller have the RS232 transceiver IC onboard. This IC "dictates" the GPIO line direction for certain lines. Do not try to use GPIO lines 0, 2, 4, and 6 as outputs -- this can permanently damage the hardware.

Enum pl\_io\_num includes the following constants:

- 0- PL\_IO\_NUM\_0\_RX0\_INT0<sup>(1)</sup>: General-purpose I/O line 0 (P0.0). This line is also the [RX/W1in/din](#)<sup>[379]</sup> input of the serial port<sup>(3)</sup> 0 and the interrupt line 0.
- 1- PL\_IO\_NUM\_1\_TX0\_INT4<sup>(2)</sup>: General-purpose I/O line 1 (P0.1). This line is also the [TX/W1out/dout](#)<sup>[379]</sup> output of the serial port 0 and the interrupt line 4.
- 2- PL\_IO\_NUM\_2\_RX1\_INT1<sup>(1)</sup>: General-purpose I/O line 2 (P0.2). This line is also the RX/W0&1in/din input of the serial port 1 and the interrupt line 1.
- 3- PL\_IO\_NUM\_3\_TX1\_INT5<sup>(2)</sup>: General-purpose I/O line 3 (P0.3). This line is also the TX/W1out/dout output of the serial port 1 and the interrupt line 5.
- 4- PL\_IO\_NUM\_4\_RX2\_INT2<sup>(1)</sup>: General-purpose I/O line 4 (P0.4). This line is also the RX/W0&1in/din input of the serial port 2 and the interrupt line 2.
- 5- PL\_IO\_NUM\_5\_TX2\_INT6<sup>(2)</sup>: General-purpose I/O line 5 (P0.5). This line is also the TX/W1out/dout output of the serial port 2 and the interrupt line 6.
- 6- PL\_IO\_NUM\_6\_RX3\_INT3<sup>(1)</sup>: General-purpose I/O line 6 (P0.6). This line is also

- the RX/W0&1in/din input of the serial port 3 and the interrupt line 3.
- 7- PL\_IO\_NUM\_7\_INT7<sup>(2)</sup>: General-purpose I/O line 7 (P0.7). This line is also the interrupt line 7.
- PL\_IO\_NULL: This is a NULL line that does not physically exist. The state of this line is always detected as LOW. Setting this line has no effect.

Notes:

1. When a serial port is in the [UART](#)<sup>[380]</sup> mode ([ser.mode](#)<sup>[409]</sup>= 0- PL\_SER\_MODE\_UART) this line is automatically configured to be an input when this serial port is enabled ([ser.enabled](#)<sup>[405]</sup>= 1- YES) and returns to the previous input/output and high/low state when this serial port is closed ([ser.enabled](#)= 0- NO).
2. When a serial port is in the UART mode ([ser.mode](#)= 0- PL\_SER\_MODE\_UART) this line is automatically configured to be an output when the serial port is enabled ([ser.enabled](#)= 1- YES) and returns to the previous input/output and high/low state when the serial port is closed ([ser.enabled](#)= 0- NO).
3. In this list, the term "serial port" actually refers to "serial channel".

### Enum pl\_io\_port\_num

Enum `pl_io_port_num` contains the list of available 8-bit GPIO ports. Use these constants when selecting the port with the [io](#)<sup>[294]</sup> object (see the [io.portnum](#)<sup>[302]</sup> property).

Note that GPIO lines are of *unidirectional* [type](#)<sup>[194]</sup> and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see [Enum pl\\_io\\_num](#)<sup>[184]</sup> for details.

- The EM1202EV-RS board and the DS1202 controller have RS232 transceiver IC onboard. This IC defines which I/O lines of the device should be configured as inputs, and which- as outputs. Specifically, do not try to use I/I lines 0, 2, 4, 6, and 7 as outputs -- this can permanently damage the hardware.

Enum `pl_io_port_num` includes only one constant:

- 0- PL\_IO\_PORT\_NUM\_0: 8-bit port 0 (P0). Contains I/O lines 0-7.

### Enum pl\_int\_num

Enum `pl_int_num` contains the list of constants that refer to available *interrupt* lines. Interrupt lines are mapped to [GPIO lines](#)<sup>[184]</sup> (this mapping can't be altered). Keep in mind that for an interrupt line to work you need to [configure](#)<sup>[194]</sup> the corresponding GPIO line as input.

Enum `pl_int_num` for this platform includes the following constants:

- PL\_INT\_NUM\_0: Interrupt line 0 (mapped onto I/O line 0).
- PL\_INT\_NUM\_1: Interrupt line 1 (mapped onto I/O line 2).
- PL\_INT\_NUM\_2: Interrupt line 2 (mapped onto I/O line 4).
- PL\_INT\_NUM\_3: Interrupt line 3 (mapped onto I/O line 6).

PL_INT_NUM_4:	Interrupt line 4 (mapped onto I/O line 1).
PL_INT_NUM_5:	Interrupt line 5 (mapped onto I/O line 3).
PL_INT_NUM_6:	Interrupt line 6 (mapped onto I/O line 5).
PL_INT_NUM_7:	Interrupt line 7 (mapped onto I/O line 7).
PL_INT_NULL:	This is a NULL interrupt line that does not physically exist.

## Enum pl\_sock\_interfaces

Enum pl\_sock\_interfaces contains the list of network interfaces supported by the platform:

0- PL_SOCK_INTERFACE_NULL:	Null (empty) interface.
1- PL_SOCK_INTERFACE_NET ( <b>default</b> ):	<a href="#">Ethernet interface</a> <sup>[358]</sup> .
3- PL_SOCK_INTERFACE_PPP:	<a href="#">PPP interface</a> <sup>[366]</sup> .
4- PL_SOCK_INTERFACE_PPPOE:	<a href="#">PPPoE interface</a> <sup>[369]</sup> .

## DS1206 Platform

### • Memory space

RAM	<b>22,528*</b> bytes for application variables and data
Flash	<b>983,040</b> bytes for application and data storage ( <a href="#">shared</a> <sup>[200]</sup> flash memory)**
EEPROM	<b>2040</b> bytes for application data

\* RAM available in the debug mode is smaller by 257 bytes. All memory is available in the release mode.

\*\* Some earlier devices had only 458,752 bytes of flash memory available

### Supported Objects, variable types, and functions

- [Sock](#)<sup>[421]</sup> — socket communications (up to 16 UDP, TCP, and HTTP sessions);
- [Net](#)<sup>[358]</sup> — controls the Ethernet port;
- [Ser](#)<sup>[378]</sup> — in charge of the serial ports (on this device, [serial channels](#)<sup>[205]</sup> of the RS232 port);
- [Ssi](#)<sup>[512]</sup> — implements up to four serial synchronous interface (SSI) channels, supports SPI, I2C, clock/data, etc.;
- [Io](#)<sup>[294]</sup> — handles I/O lines, ports, and interrupts;
- [Fd](#)<sup>[236]</sup> — manages flash memory file system and direct sector access;

- [Stor](#)<sup>[522]</sup> — provides access to the EEPROM;
- [Romfile](#)<sup>[370]</sup> — facilitates access to resource files (fixed data);
- [Pppoe](#)<sup>[369]</sup> — provides access to the Internet over an ADSL modem;
- [Ppp](#)<sup>[366]</sup> — provides access to the Internet over a serial modem (GPRS, POTS, etc.);
- [Pat](#)<sup>[363]</sup> — "plays" patterns on a pair of LEDs;
- [Button](#)<sup>[234]</sup> — monitors the MD line ([setup button](#)<sup>[201]</sup>);
- [Sys](#)<sup>[526]</sup> — in charge of general device functionality.

These platforms support the standard set of [variable types](#)<sup>[192]</sup> and [functions](#)<sup>[192]</sup> (a.k.a. "syscalls").

### Platform-specific constants

You can find them [here](#)<sup>[188]</sup>.

### Miscellaneous information

Available network interfaces	<b>Ethernet (net.)</b> <sup>(1)</sup>
<a href="#">GPIO type</a> <sup>[194]</sup>	<b>Unidirectional</b>
<a href="#">RTS/CTS remapping</a> <sup>[195]</sup>	<b>Supported</b> <sup>(2)</sup>
<a href="#">GA1000 lines remapping</a> <sup>[201]</sup>	<b>This platform does not support Wi-Fi at all</b>
<a href="#">Serial port FIFOs</a> <sup>[196]</sup>	<b>16 byte for TX, 16 bytes for RX</b>
<a href="#">Clock frequency (PLL) control</a> <sup>[196]</sup>	<b>PLL on (def): 88.4736Mhz, PLL off: 11.0592Mhz</b> <sup>(3)</sup>
<a href="#">Special configuration section of the EEPROM</a> <sup>[197]</sup>	<b>8 bytes for MAC storage</b>
<a href="#">Device serial number</a> <sup>[199]</sup>	<b>128 bytes: 64 OTP bytes + 64 fixed bytes</b> <sup>(4)</sup>
<a href="#">Flash memory configuration</a> <sup>[200]</sup>	<b>Shared</b>
<a href="#">LEDs</a> <sup>[200]</sup>	<b>Green (SG) and red (SR) Status LEDs Green (EG) and yellow (EY) Ethernet LEDs</b>
<a href="#">Debug communications</a> <sup>[204]</sup>	<b>Ethernet / UDP Broadcast transport Ethernet / WinPCap transport</b>

#### Comments:

1. The [sock.allowedinterfaces](#)<sup>[474]</sup> property refers to the Ethernet interface as "NET". [Sock.targetinterface](#)<sup>[506]</sup> and [sock.currentinterface](#)<sup>[478]</sup> properties rely on the [pl\\_sock\\_interfaces](#)<sup>[191]</sup> enum, whose members differ depending on the platform.
2. The hardware of this platform supports [serial channels](#)<sup>[205]</sup>, which means that CTS/RTS and DTR/DSR pairs of the DB9 connector can also be used as RX/TX pairs of additional serial channels. Therefore, it is up to you to decide which lines

are used as RTS and CTS, and which channels they will belong to. Proper mapping will be required to implement each particular arrangement.

3. Default PLL state after the external reset is ON.
4. Older DS1206 and DS1206W devices did not contain the serial number. To find out if your DS1206(W) has the serial number onboard, try to read this serial number with the [sys.serialnum](#)<sup>[534]</sup> R/O property. If this property returns an empty string, then the serial number is not present. Sys.serialnum returns all 128 bytes of the serial number. First 64 bytes are one-time-programmable (OTP) with the [sys.setserialnum](#)<sup>[535]</sup> method.

## Platform-specific Constants

The following constant lists are platform-specific:

- [Enum pl\\_redir](#)<sup>[188]</sup> the list of constants that define buffer redirection (shorting) for this platform.
- [Enum pl\\_io\\_num](#)<sup>[189]</sup> the list of constants that define available I/O lines.
- [Enum pl\\_io\\_port\\_num](#)<sup>[190]</sup> the list of constants that define available 8-bit I/O ports.
- [Enum pl\\_int\\_num](#)<sup>[191]</sup> the list of constants that define available *interrupt* lines.
- [Enum pl\\_sock\\_interfaces](#)<sup>[191]</sup> the list of available network interfaces.

### Enum pl\_redir

Enum pl\_redir contains the list of constants that define buffer redirection (shorting) for these platforms. The following objects support buffers and buffer redirection:

- [Ser](#)<sup>[378]</sup> object (see [ser.redir](#)<sup>[414]</sup> method)
- [Sock](#)<sup>[421]</sup> object (see [sock.redir](#)<sup>[493]</sup> method)

Enum pl\_redir for this platform includes the following constants:

- |    |                 |   |
|----|-----------------|---|
| 0- | PL_REDIR_NONE:  | Cancels redirection for the serial port* or socket.   |
| 1- | PL_REDIR_SER:   | Redirects RX data of the serial port or socket to the TX buffer of the serial port 0. This constant can be used as a "base" for all other serial ports, i.e. in expressions like <code>ser.redir= PL_REDIR_SER+f</code> . |
| 1- | PL_REDIR_SER0:  | Redirects RX data of the serial port or socket to the TX buffer of the serial port 0.   |
| 2- | PL_REDIR_SER1:  | Redirects RX data of the serial port or socket to the TX buffer of the serial port 1.   |
| 3- | PL_REDIR_SER2:  | Redirects RX data of the serial port or socket to the TX buffer of the serial port 2.   |
| 4- | PL_REDIR_SER3:  | Redirects RX data of the serial port or socket to the TX buffer of the serial port 3.   |
| 6- | PL_REDIR SOCK0: | Redirects RX data of the serial port or socket to the TX buffer of socket 0. This constant can be used as a "base" for all other sockets i.e. in expressions like <code>sock.redir= PL_REDIR SOCK0+f</code> .             |
| 7- | PL_REDIR SOCK1: | Redirects RX data of the serial port or socket to the TX buffer of socket 1.  |
| 8- | PL_REDIR SOCK2: | Redirects RX data of the serial port or socket to the TX  |

	buffer of socket 2.
9- PL_REDIR SOCK3:	Redirects RX data of the serial port or socket to the TX buffer of socket 3.
10- PL_REDIR SOCK4:	Redirects RX data of the serial port or socket to the TX buffer of socket 4.
11- PL_REDIR SOCK5:	Redirects RX data of the serial port or socket to the TX buffer of socket 5.
12- PL_REDIR SOCK6:	Redirects RX data of the serial port or socket to the TX buffer of socket 6.
13- PL_REDIR SOCK7:	Redirects RX data of the serial port or socket to the TX buffer of socket 7.
14- PL_REDIR SOCK8:	Redirects RX data of the serial port or socket to the TX buffer of socket 8.
15- PL_REDIR SOCK9:	Redirects RX data of the serial port or socket to the TX buffer of socket 9.
16- PL_REDIR SOCK10:	Redirects RX data of the serial port or socket to the TX buffer of socket 10.
17- PL_REDIR SOCK11:	Redirects RX data of the serial port or socket to the TX buffer of socket 11.
18- PL_REDIR SOCK12:	Redirects RX data of the serial port or socket to the TX buffer of socket 12.
19- PL_REDIR SOCK13:	Redirects RX data of the serial port or socket to the TX buffer of socket 13.
20- PL_REDIR SOCK14:	Redirects RX data of the serial port or socket to the TX buffer of socket 14.
21- PL_REDIR SOCK15:	Redirects RX data of the serial port or socket to the TX buffer of socket 15.

*\*In this list, the term "serial port" actually refers to "serial channel".*

## Enum pl\_io\_num

Enum `pl_io_num` contains the list of constants that refer to available GPIO lines. Use these constants when selecting the line with the `io.[294]` object (see the `io.num[301]` property).

Note that GPIO lines are of *unidirectional type<sup>[194]</sup>* and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see the notes at the bottom of the page.

- The DS1206N-RS board and the DS1206 controller have the RS232 transceiver IC onboard. This IC "dictates" the GPIO line direction for certain lines. Do not try to use GPIO lines 0, 2, 4, and 6 as outputs -- this can permanently damage the hardware.

Enum `pl_io_num` includes the following constants:

- 0- `PL_IO_NUM_0_RX0_INT0(1)`: General-purpose I/O line 0 (P0.0). This line is also the `RX/W1in/din[379]` input of the serial port<sup>(3)</sup> 0 and the interrupt line 0.

- 1- `PL_IO_NUM_1_TX0_INT1`<sup>(2)</sup>: General-purpose I/O line 1 (P0.1). This line is also the `TX/W1out/dout`<sup>[379]</sup> output of the serial port 0 and the interrupt line 1.
- 2- `PL_IO_NUM_2_RX1_INT2`<sup>(1)</sup>: General-purpose I/O line 2 (P0.2). This line is also the `RX/W0&1in/din` input of the serial port 1 and the interrupt line 2.
- 3- `PL_IO_NUM_3_TX1_INT3`<sup>(2)</sup>: General-purpose I/O line 3 (P0.3). This line is also the `TX/W1out/dout` output of the serial port 1 and the interrupt line 3.
- 4- `PL_IO_NUM_4_RX2_INT4`<sup>(1)</sup>: General-purpose I/O line 4 (P0.4). This line is also the `RX/W0&1in/din` input of the serial port 2 and the interrupt line 4.
- 5- `PL_IO_NUM_5_TX2_INT5`<sup>(2)</sup>: General-purpose I/O line 5 (P0.5). This line is also the `TX/W1out/dout` output of the serial port 2 and the interrupt line 5.
- 6- `PL_IO_NUM_6_RX3_INT6`<sup>(1)</sup>: General-purpose I/O line 6 (P0.6). This line is also the `RX/W0&1in/din` input of the serial port 3 and the interrupt line 6.
- 7- `PL_IO_NUM_7_EMPTY`: Not implemented.
- 8- `PL_IO_NUM_8_PWROUT`: Controls the power output on pin 9 of the DB9M connector (this applies only to DS1206N-RS and DS1206 devices). Power will be ON when this output is enabled (`io.enabled= 1- YES`) and set to HIGH (`io.state= 1- HIGH`).
- `PL_IO_NULL`: This is a NULL line that does not physically exist. The state of this line is always detected as LOW. Setting this line has no effect.

#### Notes:

- When a serial port is in the `UART`<sup>[380]</sup> mode (`ser.mode`<sup>[409]</sup>= 0- `PL_SER_MODE_UART`) this line is automatically configured to be an input when this serial port is enabled (`ser.enabled`<sup>[405]</sup>= 1- YES) and returns to the previous input/output and high/low state when this serial port is closed (`ser.enabled= 0- NO`).
- When a serial port is in the `UART` mode (`ser.mode= 0- PL_SER_MODE_UART`) this line is automatically configured to be an output when the serial port is enabled (`ser.enabled= 1- YES`) and returns to the previous input/output and high/low state when the serial port is closed (`ser.enabled= 0- NO`).
- In this list, the term "serial port" actually refers to "serial channel".

## Enum `pl_io_port_num`

Enum `pl_io_port_num` contains the list of available 8-bit GPIO ports. Use these constants when selecting the port with the `io`<sup>[294]</sup> object (see the `io.portnum`<sup>[302]</sup> property).

Note that GPIO lines are of *unidirectional* `type`<sup>[194]</sup> and require explicit configuration as outputs or inputs. Some lines are configured as inputs or outputs automatically -- see `Enum_pl_io_num`<sup>[189]</sup> for details.

- The DS1206N-RS board and the DS1206 controller have RS232 transceiver IC onboard. This IC defines which I/O lines of the device should be configured as

inputs, and which- as outputs. Specifically, do not try to use I/O lines 0, 2, 4, and 6 as outputs -- this can permanently damage the hardware.

Enum `pl_io_port_num` includes only one constant:

0- `PL_IO_PORT_NUM_0`: 8-bit port 0 (P0). Contains I/O lines 0-7.

## Enum `pl_int_num`

Enum `pl_int_num` contains the list of constants that refer to available *interrupt* lines. Interrupt lines are mapped to [GPIO lines](#)<sup>[189]</sup> (this mapping can't be altered). Keep in mind that for an interrupt line to work you need to [configure](#)<sup>[194]</sup> the corresponding GPIO line as input.

Enum `pl_int_num` for this platform includes the following constants:

<code>PL_INT_NUM_0</code> :	Interrupt line 0 (mapped onto I/O line 0).
<code>PL_INT_NUM_1</code> :	Interrupt line 1 (mapped onto I/O line 1).
<code>PL_INT_NUM_2</code> :	Interrupt line 2 (mapped onto I/O line 2).
<code>PL_INT_NUM_3</code> :	Interrupt line 3 (mapped onto I/O line 3).
<code>PL_INT_NUM_4</code> :	Interrupt line 4 (mapped onto I/O line 4).
<code>PL_INT_NUM_5</code> :	Interrupt line 5 (mapped onto I/O line 5).
<code>PL_INT_NUM_6</code> :	Interrupt line 6 (mapped onto I/O line 6).
<code>PL_INT_NUM_7</code> :	Interrupt line 7 (mapped onto I/O line 7).
<code>PL_INT_NULL</code> :	This is a NULL interrupt line that does not physically exist.

## Enum `pl_sock_interfaces`

Enum `pl_sock_interfaces` contains the list of network interfaces supported by the platform:

0- <code>PL_SOCK_INTERFACE_NULL</code> :	Null (empty) interface.
1- <code>PL_SOCK_INTERFACE_NET</code> ( <b>default</b> ):	<a href="#">Ethernet interface</a> <sup>[358]</sup> .
3- <code>PL_SOCK_INTERFACE_PPP</code> :	<a href="#">PPP interface</a> <sup>[366]</sup> .
4- <code>PL_SOCK_INTERFACE_PPPOE</code> :	<a href="#">PPPoE interface</a> <sup>[369]</sup> .

## Common Information

- [Supported Variable Types](#)<sup>[192]</sup>
- [Supported Functions](#)<sup>[192]</sup>
- [GPIO Type](#)<sup>[194]</sup>
- [RTS/CTS Remapping](#)<sup>[195]</sup>

- [Serial port FIFOs](#)<sup>[196]</sup>
- [Clock Frequency \(PLL\) Control](#)<sup>[196]</sup>
- [Special Configuration Section of the EEPROM](#)<sup>[197]</sup>
- [Device Serial Number](#)<sup>[199]</sup>
- [Flash Memory Configuration](#)<sup>[200]</sup>
- [LEDs](#)<sup>[200]</sup>
- [Setup \(MD\) Button \(Line\)](#)<sup>[201]</sup>
- [Connecting GA1000](#)<sup>[201]</sup>
- [Debug Communications](#)<sup>[204]</sup>

## Supported Variable Types

The following variable types are supported by all devices:

- Byte
- Word
- Dword
- Char
- Short (integer)
- Long
- Real (float)
- Boolean
- User-defined structures
- User-defined enumeration types

For general type description see [Variables and Their Types](#)<sup>[48]</sup>.

## Supported Functions

The following syscalls (platform functions) are supported by all:

- String-related:
  - [Asc](#)<sup>[206]</sup> string character --> ASCII code;
  - [Chr](#)<sup>[208]</sup> ASCII code --> string character;
  - [Val](#)<sup>[229]</sup> numerical string--> 16-bit value (word or short);
  - [Lval](#)<sup>[218]</sup> numerical string --> 32-bit value (dword or long);
  - [Strtof](#)<sup>[228]</sup> numerical string --> real value;
  - [Bin](#)<sup>[207]</sup> unsigned 16-bit numeric value (word) --> binary numerical string;
  - [Lbin](#)<sup>[214]</sup> unsigned 32-bit numeric value (dword) --> binary numerical string;
  - [Str](#)<sup>[225]</sup> unsigned 16-bit numeric value (word) --> decimal numerical string;
  - [Stri](#)<sup>[226]</sup> signed 16-bit numeric value (short) --> decimal numerical string;
  - [Lstr](#)<sup>[216]</sup> unsigned 32-bit numeric value (dword) --> decimal numerical string;

- [Lstrl](#)<sup>[217]</sup> signed 32-bit numeric value (long) --> decimal numerical string;
  - [Hex](#)<sup>[212]</sup> unsigned 16-bit numeric value (word) --> hexadecimal numerical string;
  - [Lhex](#)<sup>[216]</sup> unsigned 32-bit numeric value (dword) --> hexadecimal numerical string;
  - [Ftostr](#)<sup>[211]</sup> real value --> numerical string;
  - [Len](#)<sup>[215]</sup> gets the string length;
  - [Left](#)<sup>[215]</sup> gets a left portion of a string;
  - [Mid](#)<sup>[219]</sup> gets a middle portion of a string;
  - [Right](#)<sup>[223]</sup> gets a right portion of a string;
  - [Insert](#)<sup>[213]</sup> inserts a string into another string;
  - [Instr](#)<sup>[214]</sup> finds a substring in a string;
  - [Strgen](#)<sup>[226]</sup> generates a string using repeating substring;
  - [Strsum](#)<sup>[227]</sup> calculates 16-bit (word) sum of string characters' ASCII codes;
  - [Ddstr](#)<sup>[210]</sup> dot-decimal value --> dot-decimal string;
  - [Ddval](#)<sup>[210]</sup> dot-decimal string --> dot-decimal value;
  - [Strand](#)<sup>[225]</sup> logical AND on corresponding data bytes from two strings;
  - [Stror](#)<sup>[227]</sup> logical OR on corresponding data bytes from two strings;
  - [Strxor](#)<sup>[228]</sup> logical XOR on corresponding data bytes from two strings.
- Date and time serialization and de-serialization:
    - [Daycount](#)<sup>[209]</sup> given year, month, and date --> day number;
    - [Mincount](#)<sup>[220]</sup> given hours and minutes --> minute number;
    - [Year](#)<sup>[230]</sup> given day number --> year;
    - [Month](#)<sup>[221]</sup> given day number --> month;
    - [Date](#)<sup>[208]</sup> given day number --> date;
    - [Weekday](#)<sup>[230]</sup> given day number --> day of the week;
    - [Hours](#)<sup>[213]</sup> given minutes number --> hours;
    - [Minutes](#)<sup>[221]</sup> given minutes number --> minutes.
  - Hash calculation, encryption, and related functions:
    - [Aes128enc](#)<sup>[206]</sup> encrypts data according to the AES128 algorithm (**not supported** on the [EM500W](#)<sup>[138]</sup> and [DS1100](#)<sup>[164]</sup> platforms);
    - [Aes128dec](#)<sup>[205]</sup> decrypts data according to the AES128 algorithm (**not supported** on the [EM500W](#)<sup>[138]</sup> and [DS1100](#)<sup>[164]</sup> platforms);
    - [Rc4](#)<sup>[222]</sup> encrypts/decrypts data according to the RC4 algorithm;
    - [Md5](#)<sup>[218]</sup> calculates MD5 hash of a string;
    - [Sha1](#)<sup>[223]</sup> calculates SHA-1 hash of a string;
    - [Random](#)<sup>[222]</sup> generates a random string;
  - Miscellaneous
    - [Cfloat](#)<sup>[207]</sup> checks the validity of a real value.

## GPIO Type 10.3

As for as GPIO lines go, Tibbo devices fall into two categories:

- Devices with unidirectional GPIO lines: such devices require explicit configuration of each GPIO line as input or output; and
- Devices with bidirectional GPIO lines: GPIO lines of these devices work as outputs and inputs at the same time.

To find out the type of GPIO lines on your device, refer to its platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

### Devices with unidirectional GPIO lines

On such devices you need to explicitly enable or disable the output driver of each I/O line (controlled by the [io](#)<sup>[294]</sup> object). When the device boots up all pins are configured as inputs. If you want to use any particular I/O pin as the output, enable this pin's output driver first (set [io.enabled](#)<sup>[298]</sup>= 1-YES):

```
...
io.num= PL_IO_NUM_5      'select the line
io.enabled= YES          'enable output driver (you need to do this only
once)
io.state= LOW            'set the state
...
```

- Make sure that your external circuitry does not attempt to drive the I/O lines that have their output drivers enabled. Severe damage to the device and/or your circuitry may occur if this happens!

When the driver is enabled ([io.enabled](#)= 1-YES) and you read the state of the pin, you get back the state of your own output driver. To turn the line into an input, switch the output driver off ([ser.enabled](#)= 0- NO). This will allow you to sense the state of the external signal applied to the I/O line:

```
...
io.num= PL_IO_NUM_4      'just to select some line as an example
io.enabled= NO           'now the output driver is off
x=io.state               'read line state into x
...
```

There is the [io.portenabled](#)<sup>[302]</sup> property as well. It allows simultaneous configuration of all GPIO lines in the 8-bit I/O port.

[Serial port](#)<sup>[378]</sup> lines also require proper configuration. Depending on the mode of the serial port (see [ser.mode](#)<sup>[409]</sup>) you need to set the following:

<b>ser.mode</b>	<b>TX/ W1out/</b>	<b>RX/W1in/ din input</b>	<b>RTS/ W0out/</b>	<b>CTS/ W0&amp;1in/</b>
-----------------	-----------------------	-------------------------------	------------------------	-----------------------------

	dout output		cout output	cin input
0- <a href="#">PL_SER_MODE_UAR</a> T <sup>[380]</sup>	Will auto-configure as output <sup>(1)</sup>	Will auto-configure as input <sup>(1)</sup>	Requires configuration as output <sup>(2)</sup>	Requires configuration as input <sup>(2)</sup>
1- <a href="#">PL_SER_MODE_WIE</a> GAND <sup>[383]</sup>	Requires configuration as output	Requires configuration as input		
2- <a href="#">PL_SER_MODE_CLO</a> CKDATA <sup>[386]</sup>				

Notes:

1. When This line does not require configuration, it will be configured automatically as input or output when the port is opened. When the port is closed the line will return to the input/output and high/low state it had before the port was opened.
2. If [RTS/CTS remapping](#)<sup>[195]</sup> is supported, you need to configure the I/O pin to which this line of the serial port is *currently* mapped.

### Devices with bidirectional GPIO lines

I/O lines of these devices do not require explicit configuration as inputs or outputs. All lines are "quasi-bidirectional" and can be viewed as open collector outputs with weak pull-up resistors. To "measure" an external signal applied to an I/O line, set this line to HIGH first, then read the state of the line. It is OK to drive the line LOW externally when the same line outputs HIGH internally. [Io.enabled](#)<sup>[298]</sup> and [io.portenabled](#)<sup>[302]</sup> properties exist, but only for compatibility with other platforms. Writing to these properties has no effect and reading them always returns 1- YES and 255 (all lines enabled) correspondingly.

To sense the state of the external signal applied to the I/O line, set the line to HIGH first:

```

...
io.num= PL_IO_NUM    'just to select some line as an example
io.state= HIGH       'now we can read the line
x=io.state           'read line state into x
...

```

Serial port lines of devices with bidirectional GPIO do not require configuration as well.

## RTS/CTS Remapping

Remapping feature allows you to select which GPIO line of your device will function as the RTS line of a [serial port](#)<sup>[378]</sup>. This is done through the [ser.rtsmap](#)<sup>[415]</sup> property. In the same manner, the CTS line of a serial port can be mapped to the interrupt line of your choice (see [ser.ctsmap](#)<sup>[403]</sup>).

Not all devices support this feature. To find out if your device allows RTS/CTS

remapping, refer to its platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>). This topic will also present the default mapping for CTS and RTS lines of your device.

Note that on some devices you need to [explicitly configure](#)<sup>[194]</sup> CTS lines as inputs and RTS lines as outputs.

## Serial Port FIFOs

FIFO (first-in-first-out) is a type of hardware memory that stores the data in a queue fashion. FIFOs are characterized by "depth". For example, 16-byte FIFO can queue up to 16 bytes of data, so it has the depth of 16.

Serial ports usually have two independent FIFOs -- one for the outgoing (TX) data, and one for the incoming (RX) data. The TX FIFO allows the system to place a number of bytes into the queue, and then the serial port's hardware will take care of their orderly transmission. The RX FIFO temporarily stores the incoming data until the system gets a chance to process it.

To find out if your device's serial port(s) have FIFOs and what are the depths of these FIFOs, refer to the device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

When the [serial port](#)<sup>[378]</sup> is in the [UART/full-duplex/flow control](#)<sup>[380]</sup> mode ([ser.mode](#)<sup>[409]</sup>= 0- PL\_SER\_MODE\_UART, [ser.interface](#)<sup>[408]</sup>= 0- PL\_SER\_SI\_FULLDUPLEX, and [ser.flowcontrol](#)<sup>[407]</sup>= 1- ENABLED) the device is monitoring its CTS input to see if attached serial device is ready to receive more data. If the CTS state changes to "cannot transmit" the device will stop sending out data immediately. However, the data that has already entered the FIFO will still be sent out. Therefore, after the CTS state becomes "cannot transmit" the device can still send out a number of characters that already went into the transmit FIFO.

## Clock Frequency (PLL) Control

Some devices support clock frequency (PLL) control. When the PLL is on, the system is running at the highest possible frequency. When the PLL is off, the system is running at a reduced frequency. For example, the [EM1000](#)<sup>[143]</sup> can run at 88.4736MHz (PLL on) or 11.0592MHz (PLL off).

To find out if your device allows frequency control and what particular frequencies it can operate on, refer to this device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

The clock frequency affects all aspects of device operation that rely on this clock. Naturally, program execution speed, too, depends on the clock frequency. [Serial port](#)<sup>[378]</sup> baudrates (see [ser.baudrate](#)<sup>[402]</sup>) in the [UART](#)<sup>[380]</sup> mode ([ser.mode](#)<sup>[409]</sup>= 0- PL\_SER\_MODE\_UART) also depend on the main clock. Finally, the frequency of the square wave generated by the [beep](#)<sup>[232]</sup> object depends on the main clock as well. The period of the [on sys timer](#)<sup>[533]</sup> event of the [sys](#)<sup>[526]</sup> is not affected by the PLL mode.



There is a way to set the baudrate in the clock-independent (and, actually, platform-independent) way -- see [ser.div9600](#)<sup>[404]</sup> property for details (example of use can be found in the [Serial Settings](#)<sup>[390]</sup> topic). For the beep object, you just have to set the [beep.divider](#)<sup>[232]</sup> correctly depending on the current PLL mode.

For PLL control, the [sys](#)<sup>[526]</sup> object has a [sys.currentpll](#)<sup>[531]</sup> read-only property and

[sys.newpll](#)<sup>[532]</sup> method. See [PLL Management](#)<sup>[529]</sup> topic- it explains how to switch the PLL on and off.

After the external reset (see [sys.resettype](#)<sup>[535]</sup>), devices with PLL control may boot with the PLL on or off. Refer to the "Platform-dependent Programming Information" topic inside your device's platform specifications section for more information.

## Special Configuration Section of the EEPROM

All Tibbo devices have an EEPROM memory (accessible through the [stor.](#)<sup>[522]</sup> object). Bottom 28 bytes of the EEPROM form a so-called "special configuration section". This section includes:

- 8 bytes for storing the MAC address of the device;
- 20 bytes for storing the password of the device.

By default, the special configuration area is not accessible to your application- the [stor.base](#)<sup>[523]</sup> property takes care of that. Unless you change it, this property specifies that your application's storage area starts at address 29. To see the MAC or password data, set the stor.base to 1. Reminder: EEPROM addresses are counted from 1.

### MAC address

Bytes 1-8 of the EEPROM store the MAC address of the device. On power-up, the MAC address is read out from the EEPROM and programmed into the Ethernet controller. You can always check the current MAC through the [net.mac](#)<sup>[360]</sup> read-only property of the [net.](#)<sup>[358]</sup> object but there is no direct way to change it. Instead, you can change the MAC address data in the EEPROM itself. Next time the device boots up, it will start using this new address.

MAC address data in the EEPROM has a special format -- you have to follow it if you want the MAC to be recognized by the firmware (TiOS). Here is this format:

addr1	addr2	addr3	addr4	addr5	addr6	addr7	addr8
6	MAC0	MAC1	MAC2	MAC3	MAC4	MAC5	Checksum

The byte at address 1 must be set to 6- this means that 6 bytes of data follow (MAC address consists of 6 bytes). Addresses from 2 to 7 carry the MAC address itself. Address 8 stores the checksum, which is calculated like this:

$$255 - (\text{modulo8\_sum\_of\_addr\_1\_through\_7})$$

Here is a sample code that stores new MAC address into the EEPROM and then reboots the device:

```
dim s as string
dim x as byte
...
s= "0.2.123.124.220.240" 'supposing, we want to set this MAC
```

```

...
...
s=chr(6)+ddval(s)           'added first byte (always 6) and converted
readable MAC into bytes
x=255-strsum(s)             'calculated checksum and assigned the result to a
BYTE variable ("modulo 8" checksum)
s=s+chr(x)                  'now our string is ready

stor.base(1)                'will access the EEPROM from the bottom
x=stor.set(s,1)             'save the data
if x<>len(s) then           'it is a good programming practice to check the
result
    'failed
else
    sys.reboot              'new MAC set, reboot!
end if

...

```

There are limitations on what MAC address you can set. When loading the MAC into the Ethernet controller, the device always resets the first byte of this address to 0. For example, if you set the MAC to 1.2.3.4.5.6 then the actual MAC used by the device will be 0.2.3.4.5.6.

- If you write incorrect MAC data (wrong "length" byte or erroneous checksum), the device will ignore the stored MAC and boot up with the default MAC, which is 0.1.2.3.4.100.

## Password

Bytes 9-28 store [device password](#)<sup>[41]</sup>. The password is stored in the following format:

addr9	up to 16 bytes	3 bytes
len	password	MD5 check data

The byte at address 9 indicates the length of the password (16 bytes max). This is followed by the password itself, followed by 3 check bytes. These bytes are first 3 bytes of the [md5](#)<sup>[218]</sup> hash calculated over the combined length and password data bytes.

TiOS itself can accept any binary password with 0-16 bytes length (zero means "no password protection"). TIDE software, however, always sets 16-byte passwords. These are MD5 hashes of the actual passwords you type into **Enter Device Password** and **Change Device Password** dialogs.

Here is a code snippet that verifies if the password set for the device is really DEVICE\_PASSWORD ("Tibbo" in the example below). If the EEPROM data is incorrect, the code sets the right data and reboots the device. By using this sort of code in your project you can make your devices self-protect themselves. This will spare you from manually setting the password for each device through TIDE.

```
'-----  
Const DEVICE_PASSWORD="Tibbo"  
  
'=====  
Sub On_sys_init()  
    Dim s As String(16)  
    Dim s2 As String(20)  
    Dim check As String(3)  
    Dim x As Byte  
  
    'take the hash of password (this is what is supposed to be stored)  
    s=md5(DEVICE_PASSWORD,"",MD5_FINISH,Len(DEVICE_PASSWORD))  
    check=md5(chr(16)+s,"",MD5_FINISH,17)  
  
    'see if this password is already set  
    x=stor.base 'will restore the original value later  
    stor.base=9 'this is where password data resides  
    s2=stor.getdata(1,20)  
    If asc(mid(s2,1,1))<>16 Or mid(s2,2,16)<>s Or mid(s2,18,3)<>check Then  
        'password data in the EEPROM is incorrect! -- set the password  
again  
        stor.setdata(chr(16)+s+check,1)  
        sys.reboot  
    End If  
    stor.base=x  
    ...
```

## Device Serial Number

Some Tibbo devices carry a unique serial number, and some devices even allow a portion of this serial number to be altered once.

To find out if your device contains a unique serial number and all the particulars regarding this number, refer to this device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

To read the serial number of your device, use the [sys.serialnum](#)<sup>[534]</sup> R/O property. On devices without the serial number, this will return an empty string. On devices with the serial number, this will return the entire serial number including, if any, the programmable portion thereof.

use the [sys.setserialnum](#)<sup>[535]</sup> method to set the programmable portion of the serial number. If your device does not contain a user-programmable serial number field, this method will return 1- NG.



Be careful -- you can only set the programmable portion of the serial number **once**. There is no way to correct a mistake!

## Flash Memory Configuration

Tibbo devices differ in their flash memory size and configuration. As [Sharing Flash Between your Application and Data](#)<sup>[237]</sup> explains, your device may *share* a single flash IC between the firmware, compiled Tibbo BASIC application, and application's data (accessible through the [fd.](#)<sup>[236]</sup> object). Alternatively, there may be a *dedicated* flash IC for firmware/application, and another IC for the [fd.](#) object's data. This second IC may not be present on the device itself.

To find out what flash memory arrangement your device utilizes, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

## Status LEDs).10

BASIC-programmable devices supplied by Tibbo have one or two pairs of LEDs (or lines to control them).

### Devices with 2 pairs of LEDs

On such devices, the first LED pair is comprised of green (SG) and red (SR) status LEDs, the second pair -- of green (EG) and yellow (EY) Ethernet LEDs.

Status LEDs have multiple functions:

- When the device is in the firmware upgrade mode, these LEDs indicate the status of the firmware upload process.
- When the device is under TiOS firmware control and Tibbo BASIC application is not running, these LEDs show current Tibbo BASIC application status.
- When the Tibbo BASIC application is running, status LEDs are under the control of the [pat.](#)<sup>[363]</sup> object.

The following table summarizes predefined status LED patterns:

<b>Firmware upgrade mode</b>		
	Green LED blinks slowly	File upload completed successfully.
	One long and one short "blink" of red LED	Communications error encountered during the serial file transfer.
	One long and two short "blinks" of red LED	FLASH memory failure.
<b>Normal operation, Tibbo BASIC application not running</b>		
	Fast-blinking GRGRGR... pattern	TiOS firmware not loaded or corrupted.
	Fast-blinking BBBB... pattern (B= red and green together)	Tibbo BASIC application loaded but cannot run due to insufficient variable (RAM) memory
	Fast-blinking G-G-G-... pattern	Tibbo BASIC application loaded but not running.
	Fast-blinking R-R-R-... pattern	Tibbo BASIC application not loaded or corrupted.

Ethernet LEDs indicate the following:

- Link/Data LED (green) is turned on when live Ethernet cable is plugged into the device. The LED blinks whenever an Ethernet packet is received.
- 100BaseT LED (yellow) is turned on when the device links with the hub at 100Mb. The LED is off when the link is established at 10Mb.

### Devices with a single LED pair

On such devices, there are green (SG) and red (SR) status LEDs (or lines to control them). They function just as described above, but with one caveat: the brightness of these LEDs is indicative of the current Ethernet link state. When live Ethernet cable is not plugged into the device, the LEDs "play" patterns at a reduced brightness. When live Ethernet cable is plugged into the device, the LEDs "play" patterns at full brightness.

On devices with a single LED pair, there is no indication for the 100BaseT/10BaseT connection mode.

Some such devices feature a single third LED (or line to control it). This LED indicates current Ethernet link status: it will be on when live Ethernet cable is plugged.

## Setup (MD) Button (Line)

Tibbo boards\* and external controllers (such as the [DS1206](#)<sup>[186]</sup>) have a button called "setup" or "MD" button ("MD" abbreviation stands for "mode"). Tibbo modules (such as the [EM1000](#)<sup>[143]</sup>) have an MD pin for connecting an external button.

The setup button (line) has three functions:

- When a Tibbo BASIC application is running, it can use the button for its own purposes (see the [button](#)<sup>[234]</sup> object).
- When the device is [password-protected](#)<sup>[4]</sup>, keeping the button pressed while accessing the device from TIDE allows to bypass the password. This is the way to reset the password on the device.
- When the device is powered up (exits from the hardware reset) with the button pressed (line pulled low), it enters a firmware upgrade mode in which new TiOS firmware, possibly with compiled Tibbo BASIC application attached, can be uploaded into the device. If the device is powered up with the setup button not pressed (line not pulled low), the device starts the execution of the TiOS firmware (if loaded).

*\* This only applies to boards that carry one of Tibbo modules or directly incorporate BASIC-programmable hardware (such as the T1000 ASIC).*

## Connecting GA1000

GA1000 is an add-on Wi-Fi module implementing 802.11b/g protocols (for documentation see *Programmable Hardware Manual*). This add-on device cannot work by itself and requires "external brains" in the form of one of Tibbo devices.

### GA1000 interface

The GA1000 communicates with Tibbo devices through an [SPI interface](#). Your device will control the GA1000 through five GPIO lines:

- **CS** -- SPI bus, chip select (active low);
- **CLK** -- SPI bus, clock;
- **DI** -- SPI bus, data in (must be connected to the GA1000's DO);
- **DO** -- SPI bus, data out (must be connected to the GA1000's DI);
- **RST** -- reset (active low). This line can be eliminated -- see below for details.

- On platforms with [unidirectional GPIOs](#)<sup>[194]</sup> lines, do not forget to configure CS, CLK, DO, and RST as outputs. DI must be configured as input. The [wln.](#)<sup>[536]</sup> object won't do this automatically.

See [Configuring Interface Lines](#)<sup>[545]</sup> topic of the [wln.](#)<sup>[536]</sup> object's manual for more information on proper selection and configuration of GPIO lines on various devices (platforms).

### Providing hardware reset



The [wln.](#)<sup>[536]</sup> object directly controls CS, CLK, DI, and DO lines. Your application, however, must take care of the proper hardware reset for the GA1000. There are two methods for doing this:

- Use a dedicated GPIO line to act as the RST line of the GA1000 interface (shown on diagram A below):

```
io.lineset(WLN_RST,LOW) 'apply reset (assuming that WLN_RST is a constant
that defines which GPIO line is connected to the GA1000's RST)
io.lineset(WLN_RST,HIGH) 'remove reset
```

- Use 2 NAND gates to combine CS and CLK signals and produce the reset signal for the GA1000 (shown on diagram B). This approach takes advantage of the fact that during SPI communications, CLK line will never be LOW while the CS line is HIGH. Schematic diagram on figure B generates reset when CS=HIGH and CLK=LOW. This way you save one GPIO line of your programmable module. Here is the code that will reset the GA1000:

```
io.lineset(WLN_CS,HIGH) 'set the CS line HIGH
io.lineset(WLN_CLK,LOW) 'apply reset
io.lineset(WLN_CLK,HIGH) 'remove reset
```



Tibbo devices differ in whether the CS, CLK, DI, and DO lines are remappable. On devices with remappable lines, you can choose any set of GPIOs to control the GA1000. On devices where remapping isn't provided, you just have to use "prescribed" GPIO lines. For information on this, see *Miscellaneous information* section of your platform's documentation (for example, EM1000W's is [here](#)<sup>[143]</sup>).

### Special case -- the EM500

Diagram C shows the recommended way of connecting the GA1000 to the [EM500](#)<sup>[138]</sup> module. GPIO lines are a precious commodity on the EM500 -- there are only eight of them available. As seen on the diagram C, you can get away with using only three lines to control the GA1000 (against the standard five lines). One line is saved by producing the reset out of CS and CLK lines. The second line is saved because EM500's [bidirectional GPIOs](#)<sup>[194]</sup> allow interconnecting DI and DO. The EM500 does not allow remapping of GA1000 lines, so GPIO line assignment shown below cannot be changed.



segment. Only the addressed Tibbo device will respond to the command. This is because each debug command contains a field specifying the MAC address of the target device. This method unnecessarily burdens all devices on the local network segment with having to "look at" all debug commands being transmitted. Also, some network equipment limits the amount of UDP broadcasts that can pass through it in one second. This may slow down your debug comms with the target.

### WinPCap transport

With this selection, debug commands are sent through the Ethernet network as unicast UDP datagrams -- the target device is addressed directly. This method is the **preferred** way of communicating with Tibbo devices. The method relies on a WinPCap library that must be installed together with TIDE software. You must have seen the request for this during TIDE installation. With WinPCap transport, only the target device receives the debugging commands, and there is no issue with slow comms because of restrictive network equipment.

**!** In most cases, debugging commands sent by TIDE cannot go across gateways (routers). This means the target and TIDE must reside on the same network segment -- remote debugging is not possible.

Also, debugging is not possible via Wi-Fi ports of Tibbo devices.

## Serial Channels vs. Serial Ports

Enter topic text here.

## Function Reference

Function reference section is a repository for all functions (syscalls) that have ever been created. The platform you are working with does not necessarily support every function. See your [platform specifications](#)<sup>[138]</sup> - you will find the list of support functions there.

## Aes128dec Function

<b>Function:</b>	Encrypts data in 16-byte blocks according to the AES128 algorithm.
<b>Syntax:</b>	<b>aes128enc(byref key as string, byref plain as string) as string</b>
<b>Returns:</b>	Encrypted data (which will consist of complete 16-character blocks).
<b>See Also:</b>	<a href="#">aes128enc</a> <sup>[206]</sup> , <a href="#">rc4</a> <sup>[222]</sup>

---

Part	Description
key	Encryption key. Must be 16 characters long, or NULL string will be returned.
plain	Plain (unencrypted) data. Will be processed in 16-byte

blocks. Last incomplete block will be padded with zeroes.

### Details

---

## Aes128enc Function

<b>Function:</b>	Decrypts data in 16-byte blocks according to the AES128 algorithm.
<b>Syntax:</b>	<b>aes128dec(byref key as string, byref cypher as string) as string</b>
<b>Returns:</b>	Decrypted data (which will consist of complete 16-character blocks).
<b>See Also:</b>	<a href="#">aes128dec</a> <sup>[205]</sup> , <a href="#">rc4</a> <sup>[222]</sup>

---

Part	Description
key	Encryption key. Must be 16 characters long, or NULL string will be returned.
cypher	Encrypted data, must consist of one or more complete 16-character blocks, or NULL string will be returned.

### Details

---

## Asc Function

<b>Function:</b>	Returns the ASCII code of the leftmost character of the string.
<b>Syntax:</b>	<b>asc(byref sourcestr as string) as byte</b>
<b>See Also:</b>	<a href="#">Chr</a> <sup>[208]</sup>

---

Part	Description
sourcestr	Input string; the function will return ASCII code of the leftmost character of this string.

### Details

---

**Examples**

```
x = asc("123") ' result will be 49 (ASCII code of '1')
```

**Bin Function**

**Function:** Converts unsigned 16-bit numeric value (word) into its binary string representation.

**Syntax:** **bin(num as integer) as string**

**See Also:** [str](#)<sup>[225]</sup>, [lstr](#)<sup>[216]</sup>, [stri](#)<sup>[226]</sup>, [lstri](#)<sup>[217]</sup>, [lbin](#)<sup>[214]</sup>, [hex](#)<sup>[212]</sup>, [lhex](#)<sup>[216]</sup>, [val](#)<sup>[229]</sup>, [lval](#)<sup>[218]</sup>

Part	Description
num	Value to convert.

**Details**

Standard "&b" prefix is added at the beginning of the string.

**Examples**

```
dim s as string
s = bin(34) ' result will be '&b100010'
```

**Cfloat Function**

**Function:** Verifies whether the value of a floating-point variable is valid. Returns 0- VALID if the floating point value is OK, and 1- INVALID if the floating-point value is invalid.

**Syntax:** **cfloat(byref num as real) as valid\_invalid**

**See Also:** [strtof](#)<sup>[228]</sup>, [ftostr](#)<sup>[211]</sup>

Part	Description
num	Variable to check.

**Details**

Floating-point calculations can lead to invalid result (#INF, -#INF errors, as per IEEE specification). When your application is in the [debug](#)<sup>[27]</sup> mode you will get a

[FPERR exception](#)<sup>[29]</sup> if such an error is encountered. In the release mode the Virtual Machine won't generate an exception, yet your application may need to know if a certain floating-point variable contains correct value. This is where cfloat function comes handy.

### Examples

```
dim r1 as real
dim v as invalid_valid

dim r1=10E30
v=cfloat(r1) 'v will return 0- VALID
r1=r1*10E20 'at this point you will get FPERR exception if you are in the
debug mode
v=cfloat(r1) 'v will return 1- INVALID
```

## Chr Function

**Function:** Returns the string that consists of a single character with ASCII code `asciicode`.

**Syntax:** **chr(asciicode as byte) as string**

**See Also:** [Asc](#)<sup>[206]</sup>

Part	Description
asciicode	ASCII code of the character to return.

### Details

It is also possible to use this function within string definitions, as shown in the example below.

### Examples

```
dim x as byte
dim s as string

x=49
s = chr(x) ' result will be '1'
s = "FooBar" + chr(13) ' would add a carriage return to the end of the
string
```

## Date Function

**Function:** Returns the date for a given day number.

**Syntax:** **date(daycount as word) as byte**

**Returns:** Date in the 1-31 range.  
**See Also:** [year](#)<sup>[230]</sup>, [month](#)<sup>[221]</sup>, [weekday](#)<sup>[230]</sup>, [daycount](#)<sup>[208]</sup>, [hours](#)<sup>[213]</sup>, [minutes](#)<sup>[221]</sup>, [mincount](#)<sup>[220]</sup>

Part	Description
daycount	Day number. Base date for the day count is 1-JAN-2000 (this is day #0).

**Details**

---

**Examples**

```
b = date(366) ' result will be 1 -- because day 366 is actually January 1st, 2001.
```

## Daycount Function

**Function:** Returns the day number for a given year, month, and date.  
**Syntax:** **daycount**(year **as byte**, month **as byte**, date **as byte**) **as word**  
**Returns:** Day number elapsed since 1-JAN-2000 (this is day #0). The range is 0-36524.  
**See Also:** [year](#)<sup>[230]</sup>, [month](#)<sup>[221]</sup>, [date](#)<sup>[208]</sup>, [weekday](#)<sup>[230]</sup>, [hours](#)<sup>[213]</sup>, [minutes](#)<sup>[221]</sup>, [mincount](#)<sup>[220]</sup>

Part	Description
year	The year is supplied as offset from year 2000 (so, it is 6 for year 2006). Acceptable year range is 0-99 (2000-2099).
month	1-12 for January-December
date	Date of the month

**Details**

If any input parameter is illegal (year exceeds 99, month exceeds 12, etc.) this syscall will return 65535. This error value cannot be confused with an actual valid day number since the maximum day number recognized by this syscall is 12-DEC-2099 (day number 36524).

**Examples**

```
w = daycount(06, 10, 15) ' result will be 2479 (the serial day number for
October 15th, 2006)
```

## Ddstr Function

**Function:** Converts "dot-decimal value" into "dot-decimal string".

**Syntax:** **ddstr(byref str as string) as string**

**Returns:** A dot-separated string consisting of decimal representations of all binary values in the input string. Each decimal value will be in the 0-255 range.

**See Also:** [ddval](#)<sup>[210]</sup>

Part	Description
str	String of binary values to be converted into a dot-decimal string.

### Details

This function is convenient for converting groups of bytes representing binary data (such as IP or MAC addresses) into their string representation.

### Examples

```
dim s as string

s = chr(192)+chr(168)+chr(100)+chr(40) 'produce a string that contains these
values: 192,168,100,40
s = ddstr(s) 'now s will be equal to "192.168.100.40"
```

## Ddval Function

**Function:** Converts "dot-decimal string" into "dot-decimal value".

**Syntax:** **ddval (byref str as string) as string**

**Returns:** A string of binary values.

**See Also:** [ddstr](#)<sup>[210]</sup>

Part	Description
str	Dot-decimal string to be converted into a string of binary values. This string should comprise one or more dot-separated decimal values in the 0-255 range. Values that exceed 255 will produce an overflow, so result will be incorrect. If any other character other than "0"- "9" or "." is encountered then all digits after this character and up to

the next "." (if any) will be ignored. Leading spaces before each decimal value are allowed.

### Details

This function is convenient for converting string representation of groups of bytes (such as IP or MAC addresses) into their binary form.

### Examples

```
dim s as string

s = "192_3.1254.. 30" 'One value has invalid character in it ("_") and "3"
after this character will be ignored. Dot-decimal string. Another value --
1254 -- is out of range. Yet another value is missing and will be replaced
with 0.
s = ddstr(s) 'now s will contain these values: 192, 230, 0, 30.
```

## Ftostr Function

**Function:** Converts real value into its string representation.

**Syntax:** **ftostr**(byref num as real, mode as ftostr\_mode, rnd as byte) as string

**See Also:** [strtof](#)<sup>[228]</sup>, [cfloat](#)<sup>[207]</sup>, [str](#)<sup>[225]</sup>, [val](#)<sup>[229]</sup>

Part	Description
num	Real value to convert.
mode	Desired output format: 0- FTOSTR_MODE_AUTO: Choose between plain and mantissa/exponent format automatically. If mantissa/exponent format results in shorter string it will be used, otherwise plain format will be used. 1- FTOSTR_MODE_ME: Use mantissa/exponent format. 2- FTOSTR_MODE_PLAIN: Use plain format, not mantissa/exponent representation.
rnd	Number of digits to round the result to (total number of non-zero digits in the integer and fractional part of mantissa).

### Details

Ftostr function offers much more control over the format of the output string compared to similar functions found on other systems. For starters, you can select whether you want to see mantissa/exponent, "regular" format, or let the function decide which format to use. Additionally, you control the rounding i.e. get to choose how many digits should be displayed -- and this influences the

representation both of the fractional and integer part of the value.

Examples below illustrate what you can do with `ftostr`. The `ftostr` has a counterpart `-- fstr --` which is invoked implicitly whenever you assign a real to a string (`string=real`). `Fstr` is just like `ftostr` but `mode` and `rnd` parameters are fixed at `0-FTOSTR_MODE_AUTO` and "maximum number of digits possible".

### Examples

```
dim r1 as real
dim s as string

'demonstrate output formats
r1=100000000000.0 'notice '.0' -- it is necessary or compiler will generate
an error
s=ftostr(r1,FTOSTR_MODE_ME,11) 'result will be '1E+010'
s=ftostr(r1,FTOSTR_MODE_PLAIN,11) 'result will be '100000000000'
s=ftostr(r1,FTOSTR_MODE_AUTO,11) 'result will be '1E+010' because this
representation is more
compact

'demonstrate rounding
r1=1234567.125
s=ftostr(r1,FTOSTR_MODE_AUTO,15) 'result will be '1234567.125'
s=ftostr(r1,FTOSTR_MODE_AUTO,9) 'result will be '1234567.13'
s=ftostr(r1,FTOSTR_MODE_AUTO,2) 'result will be '1200000'

s=r1 'fstr will be used, result will be '1234567.125'
```

## Hex Function

**Function:** Converts unsigned 16-bit numeric value (word) into its HEX string representation.

**Syntax:** **hex(num as integer) as string**

**See Also:** [str](#)<sup>[225]</sup>, [lstr](#)<sup>[216]</sup>, [stri](#)<sup>[226]</sup>, [lstri](#)<sup>[217]</sup>, [bin](#)<sup>[207]</sup>, [lbin](#)<sup>[214]</sup>, [lhex](#)<sup>[216]</sup>, [val](#)<sup>[229]</sup>, [lval](#)<sup>[218]</sup>

Part	Description
num	Value to convert.

### Details

Standard "&h" prefix is added at the beginning of the string.

### Examples

```
dim s as string

s = hex(34) 'result will be '&h22'
```

## Hours Function

<b>Function:</b>	Returns the hours value for a given minutes number.
<b>Syntax:</b>	<b>hours (mincount as word) as byte</b>
<b>Returns:</b>	Hours in the 0-23 range.
<b>See Also:</b>	<a href="#">year</a> <sup>[230]</sup> , <a href="#">month</a> <sup>[221]</sup> , <a href="#">date</a> <sup>[208]</sup> , <a href="#">weekday</a> <sup>[230]</sup> , <a href="#">daycount</a> <sup>[209]</sup> , <a href="#">minutes</a> <sup>[221]</sup> , <a href="#">mincount</a> <sup>[220]</sup>

Part	Description
mincount	The number of minutes elapsed since midnight (00:00 is minute #0). Maximum mincount number is 1439 (23:59).

### Details

If a value higher than 1439 is supplied, this call will return 255. This error value cannot be confused with valid output since normal hours value cannot exceed 23.

### Examples

```
b = hours(620) ' result will be 10 (because this minute number is falls
between 10:00 and 11:00)
```

## .Insert Function

<b>Function:</b>	Inserts insert_str string into the dest_str string at the insert position pos. Returns the new length of dest_str.
<b>Syntax:</b>	<b>insert(byref dest_str as string, pos as byte, byref insert_str as string) as byte</b>
<b>See Also:</b>	---

Part	Description
dest_str	The string to insert into.
pos	Insert position in the dest_str.
insert_str	The string to insert.

### Details

This is an insert with overwrite, meaning that the insert\_str will overwrite a portion of the dest\_str.

Dest\_str length can increase as a result of this operation (but not beyond declared string capacity). This will happen if the insertion position does not allow the

source\_str to fit within the current length of the dest\_string.

### Examples

```
s = "FLIGHT XXX STATUS"
insert(s,8,"123") 's will now be 'FLIGHT 123 STATUS'
```

## Instr Function

**Function:** Finds the Nth occurrence (defined by num, counting from 1) of a substring substr in a string sourcestr. Search is conducted from position frompos (leftmost character has position 1).

**Syntax:** **instr**(frompos **as byte**,byref sourcestr **as string**, byref substr **as string**, num **as byte**) **as byte**

**See Also:** ---

Part	Description
frompos	Position in the sourcestr from which to start searching. Leftmost character has position 1.
sourcestr	Source string in which the substring is to be found.
substr	Substring to search for within the source string.
num	Occurrence number of the substr, counting from 1.

### Details

This function returns position in a string or zero if the Nth occurrence of the substring is not found.

### Examples

```
x = instr(3,"ABCABCDEABC12","BC",2) ' result will be 10
```

## Lbin Function

**Function:** Converts unsigned 32-bit numeric value (dword) into its binary string representation.

**Syntax:** **lbin**(byref num **as dword**) **as string**

**See Also:** [str](#)<sup>[228]</sup>, [lstr](#)<sup>[216]</sup>, [stri](#)<sup>[226]</sup>, [lstri](#)<sup>[217]</sup>, [bin](#)<sup>[207]</sup>, [hex](#)<sup>[212]</sup>, [lhex](#)<sup>[216]</sup>, [val](#)<sup>[229]</sup>, [lval](#)<sup>[218]</sup>

Part	Description
num	Value to convert.

### Details

Standard "&b" prefix is added at the beginning of the string.

### Examples

```
dim s as string
s = lbin(2863311530) ' result will be '&b10101010101010101010101010101010'
```

## Left Function

**Function:** Returns len leftmost characters of a string sourcestring.

**Syntax:** **left**(byref sourcestr as string, len as byte) as string

**See Also:** [Right](#)<sup>[223]</sup>, [Mid](#)<sup>[219]</sup>

---

Part	Description
sourcestr	String from which to take <i>len</i> leftmost characters.
len	Number of characters to take.

### Details

---

### Examples

```
ss = left("ABCDE",3) ' result will be 'ABC'
```

## Len Function

**Function:** Returns the length of (number of characters in) the string sourcestr.

**Syntax:** **len**(byref sourcestr as string) as byte

**See Also:** ---

Part	Description
sourcestr	String whose length needs to be calculated.

### Details

---

### Examples

```
x = len("ABC") ' result will be 3
```

## Lhex Function

**Function:** Converts unsigned 32-bit numeric value (dword) into its HEX string representation.

**Syntax:** **lhex**(byref num as dword) as string

**See Also:** [str](#)<sup>[225]</sup>, [lstr](#)<sup>[216]</sup>, [stri](#)<sup>[226]</sup>, [lstri](#)<sup>[217]</sup>, [bin](#)<sup>[207]</sup>, [lbin](#)<sup>[214]</sup>, [hex](#)<sup>[212]</sup>, [val](#)<sup>[229]</sup>, [lval](#)<sup>[218]</sup>

Part	Description
num	Value to convert.

### Details

Standard "&h" prefix is added at the beginning of the string.

### Examples

```
dim s as string
s = lhex(65536) 'result will be '&h10000'
```

## Lstr Function

**Function:** Converts unsigned 32-bit numeric value (dword) into its decimal string representation.

**Syntax:** **lstr**(byref num as dword) as string

**See Also:** [str](#)<sup>[225]</sup>, [stri](#)<sup>[226]</sup>, [lstri](#)<sup>[217]</sup>, [bin](#)<sup>[207]</sup>, [lbin](#)<sup>[214]</sup>, [hex](#)<sup>[212]</sup>, [lhex](#)<sup>[216]</sup>, [val](#)<sup>[229]</sup>, [lval](#)<sup>[218]</sup>

Part	Description
num	Value to be converted to string.

### Details

Can be invoked implicitly, through the *string\_var = dword\_var* expression (see example below). Compiler is smart enough to pre-calculate constant-only expressions involving implicit use of *lstr* function.

### Examples

```
dim d as dword
dim s as string

d1=123456
s = lstr(d) 'explicit invocation. Result will be '123456'
s = d 'implicit invocation
s = 666666 'will be calculated at compilation -- no actual lstr function
invokation will be here
```

## Lstri Function

**Function:** Converts signed 32-bit numeric value (long) into its decimal string representation.

**Syntax:** **lstri(byref num as long) as string**

**See Also:** [str](#)<sup>[225]</sup>, [lstr](#)<sup>[216]</sup>, [stri](#)<sup>[226]</sup>, [bin](#)<sup>[207]</sup>, [lbin](#)<sup>[214]</sup>, [hex](#)<sup>[212]</sup>, [lhex](#)<sup>[216]</sup>, [val](#)<sup>[229]</sup>, [lval](#)<sup>[218]</sup>

Part	Description
num	Value to be converted to string.

### Details

Can be invoked implicitly, through the *string\_var = long\_var* expression (see example below). Compiler is smart enough to pre-calculate constant-only expressions involving implicit use of *lstri* function.

### Examples

```
dim l as long
dim s as string

l= -5123
s = lstri(l) 'explicit invocation.
s = l 'implicit invocation
s = lstri(-20) 'will be calculated at compilation -- no actual lstri
function invokation will be here
```

## Lval Function

**Function:** Converts string representation of a value into 32-bit value (dword or long).

**Syntax:** **lval**(byref sourcestr as string) as dword

**See Also:** [str](#)<sup>[225]</sup>, [lstr](#)<sup>[216]</sup>, [stri](#)<sup>[226]</sup>, [lstri](#)<sup>[217]</sup>, [bin](#)<sup>[207]</sup>, [lbin](#)<sup>[214]</sup>, [hex](#)<sup>[212]</sup>, [lhex](#)<sup>[216]</sup>, [val](#)<sup>[228]</sup>

Part	Description
sourcestr	String to convert.

### Details

Recognizes &b (binary) and &h (hexadecimal) prefixes. Can be invoked implicitly, through the `dword_var=string_var` expression (see example below). Compiler is smart enough to pre-calculate constant-only expressions involving implicit use of lval function.

### Examples

```
dim d as word
dim l as long
dim s as string

s = "4294967295"
d = lval(s) 'explicit invocation, result will be 4294967295
l = lval(s) '
d = s 'implicit invocation, result will be -1 (4294967295 -> &hFFFFFFFF -> -1 for signed variable)
d = "2402" 'be calculated at compilation -- no actual lval function invocation will be here
```

## Md5 Function

**Function:** Generates MD5 hash on the str string.

**Syntax:** **md5**(byref str as string,byref input\_hash as string, md5\_mode as md5\_modes,total\_len as word) as string

**Returns:** 16-character hash string; an empty string when invalid str or input\_hash argument was detected

**See Also:** [sha1](#)<sup>[223]</sup>

Part	Description
str	String containing (the next portion of) the input data to generate MD5 hash on. When md5_mode= 0- MD5_UPDATE,

	<p>this string must be 64, 128, or 192 characters in length. Any other length will result in error and the function will return an empty string. When md5_mode= 1- MD5_FINISH, this string can have any length (up to 255 bytes).</p>
input_hash	<p>Hash obtained as a result of MD5 calculation on the previous data portion. Leave it empty for the first portion of data. Use the result of MD5 calculation on the previous data portion for the second and all subsequent portions of data. The result of MD5 is always 16 characters long, so passing the string of any other length (except 0 -- see above) will result in error and this function will return an empty string.</p>
md5_mode	<p>0- MD5_UPDATE : Set this mode for all data portions except the last one.</p> <p>1- MD5_FINISH: Set this mode for the last data portion; also use this selection if you only have a single data portion.</p>
total_len	<p>Total length of processed data (in all data portions combined). Only relevant when md5_mode= 1- MD5_FINISH. That is, only relevant for the last or a single data portion.</p>

### Details

MD5 is a standard method of calculating hash codes on data of any size. The amount of input data can often exceed maximum capacity of string variables (255 characters). The md5 method can be invoked repeatedly in order to process the data of any size (see the example below).

### Examples

```
Dim s, hash As String

'simple calculation on a short string
s="Sting to calculate MD5 on"
hash=md5(s,"",MD5_FINISH,Len(s))

'calculation on the entire contents of data in the 'text.txt 'file
romfile.open("text.txt")
hash=""
s=romfile.getdata(192) 'use max portions
While Len(s)=192
    hash=md5(s,hash,MD5_UPDATE,0)
    s=romfile.getdata(192)
Wend
hash=md5(s,hash,MD5_FINISH,romfile.size) 'last portion for whatever
unprocessed data is remaining in the file
```

## Mid Function

<b>Function:</b>	Returns len characters from a string sourcestr starting from position pos.
<b>Syntax:</b>	<b>mid(byref sourcestr as string, frompos as byte, len as byte) as string</b>

**See Also:**[Left](#)<sup>[215]</sup>, [Right](#)<sup>[223]</sup>

Part	Description
sourcestr	String from which to take the middle section.
frompos	First character to take. The leftmost character is counted to be at position 1.
len	Number of characters to take.

**Details**

---

**Examples**

```
s = mid("ABCDE",2,3) ' result will be 'BCD'.
```

## Mincount Function

**Function:** Returns the minutes number for a given hours and minutes.**Syntax:** **mincount**(hours **as byte**, minutes **as byte**) **as word****Returns:** Minute number elapsed since midnight (00:00). This value is in the 0-1439 range.**See Also:** [year](#)<sup>[230]</sup>, [month](#)<sup>[221]</sup>, [date](#)<sup>[208]</sup>, [weekday](#)<sup>[230]</sup>, [daycount](#)<sup>[209]</sup>, [hours](#)<sup>[213]</sup>, [minutes](#)<sup>[221]</sup>

Part	Description
hours	An hour value, from 0 to 23.
minutes	A minute value, from 0 to 59.

**Details**

If any input parameter is illegal (hours exceeds 23, minutes exceeds 59, etc.) this syscall will return 65535. This error value cannot be confused with an actual valid minute number since the maximum minute number cannot exceed 1439.

**Examples**

```
w = mincount(14, 00) ' result will be 840
```

## Minutes Function

<b>Function:</b>	Returns the minutes value for given minutes number.
<b>Syntax:</b>	<b>minutes(mincount as word) as byte</b>
<b>Returns:</b>	Minutes in the 0-59 range.
<b>See Also:</b>	<a href="#">year</a> <sup>[230]</sup> , <a href="#">month</a> <sup>[221]</sup> , <a href="#">date</a> <sup>[208]</sup> , <a href="#">weekday</a> <sup>[230]</sup> , <a href="#">daycount</a> <sup>[209]</sup> , <a href="#">hours</a> <sup>[213]</sup> , <a href="#">mincount</a> <sup>[220]</sup>

Part	Description
mincount	The number of minutes elapsed since midnight (00:00 is minute #0).

### Details

If a value higher than 1439 is supplied, this call will return 255. This error value cannot be confused with valid output since normal minutes value cannot exceed 59.

### Examples

```
b = minutes(61) ' result will be 1 - this is the time 01:01.
```

## Month Function

<b>Function:</b>	Returns the month for a given day number.
<b>Syntax:</b>	<b>month(daycount as word) as pl_months</b>
<b>Returns:</b>	One of pl_months constants: 1- PL_MONTH_JANUARY: January. 2- PL_MONTH_FEBRUARY: February. 3- PL_MONTH_MARCH: March. 4- PL_MONTH_APRIL: April. 5- PL_MONTH_MAY: May. 6- PL_MONTH_JUNE: June. 7- PL_MONTH_JULY: July. 8- PL_MONTH_AUGUST: August. 9- PL_MONTH_SEPTEMBER: September. 10- PL_MONTH_OCTOBER: October. 11- PL_MONTH_NOVEMBER: November. 12- PL_MONTH_DECEMBER: December.

**See Also:** [year](#)<sup>[230]</sup>, [date](#)<sup>[208]</sup>, [weekday](#)<sup>[230]</sup>, [daycount](#)<sup>[209]</sup>, [hours](#)<sup>[213]</sup>

[minutes](#)<sup>[221]</sup>, [mincount](#)<sup>[220]</sup>

Part	Description
daycount	Day number. Base date for the day count is 1-JAN-2000 (this is day #0).

### Details

---

### Examples

```
dim m as pl_months
m = month(32) ' result will be PL_MONTH_FEBRUARY - day number 32 was in
February 2000.
```

## Random Function

**Function:** Generates a string consisting of len random characters.  
**Syntax:** **random(len as byte) as string**  
**See Also:** ---

Part	Description
len	Length of the string to generate.

### Details

---

## Rc4 Function

**Function:** Encrypts/decrypts the data stream according to the RC4 algorithm.  
**Syntax:** **rc4(byref key as string, skip as word, byref data as string) as string**  
**Returns:** Processed data.  
**See Also:** [aes128enc](#)<sup>[208]</sup>, [aes128dec](#)<sup>[205]</sup>

Part	Description
key	Encryption key, can have any length.

skip	The number of "skip" iterations. These are additional iterations added past the standard "key scheduling algorithm". Set this argument to 0 to obtain standard encryption results compatible with other systems.
data	Data to encrypt/decrypt.

### Details

With RC4 algorithm, the same function is used both for encrypting and decrypting the data.

## Right Function

<b>Function:</b>	Returns len rightmost characters of a string sourcestr.
<b>Syntax:</b>	<b>right(byref sourcestr as string, len as byte) as string</b>
<b>See Also:</b>	<a href="#">Left</a> <sup>[218]</sup> , <a href="#">Mid</a> <sup>[219]</sup>

Part	Description
sourcestr	String from which to take <i>len</i> rightmost characters.
len	Number of characters to take.

### Details

---

### Examples

```
s = right("ABCDE",3) ' result will be 'CDE'
```

## Sha1 Function

<b>Function:</b>	Generates SHA1 hash on the str string.
<b>Syntax:</b>	<b>sha1(byref str as string, byref input_hash as string, sha1_mode as sha1_modes, total_len as word) as string</b>
<b>Returns:</b>	20-character hash string; an empty string when invalid str or input_hash argument was detected
<b>See Also:</b>	<a href="#">md5</a> <sup>[218]</sup>

Part	Description
str	String containing (the next portion of) the input data to

	generate SHA1 hash on. When sha1_mode= 0- SHA1_UPDATE, this string must be 64, 128, or 192 characters in length. Any other length will result in error and the function will return an empty string. When sha1_mode= 1- SHA1_FINISH, this string can have any length (up to 255 bytes).
input_hash	Hash obtained as a result of SHA1 calculation on the previous data portion. Leave it empty for the first portion of data. Use the result of SHA1 calculation on the previous data portion for the second and all subsequent portions of data. The result of sha1 is always 20 characters long, so passing the string of any other length (except 0 -- see above) will result in error and this function will return an empty string.
sha1_mode	0- SHA1_UPDATE : Set this mode for all data portions except the last one. 1- SHA1_FINISH: Set this mode for the last data portion; also use this selection if you only have a single data portion.
total_len	Total length of processed data (in all data portions combined). Only relevant when sha1_mode= 1- SHA1_FINISH. That is, only relevant for the last or a single data portion.

### Details

SHA1 is a standard method of calculating hash codes on data of any size. The amount of input data can often exceed maximum capacity of string variables (255 characters). The sha1 method can be invoked repeatedly in order to process the data of any size (see the example below).

### Examples

```
Dim s, hash As String

'simple calculation on a short string
s="Sting to calculate SHA1 on"
hash=sha1(s,"",SHA1_FINISH,Len(s))

'calculation on the entire contents of data in the 'text.txt 'file
romfile.open("text.txt")
hash=""
s=romfile.getdata(192) 'use max portions
While Len(s)=192
    hash=sha1(s,hash,SHA1_UPDATE,0)
    s=romfile.getdata(192)
Wend
hash=sha1(s,hash,SHA1_FINISH,romfile.size) 'last portion for whatever
unprocessed data is remaining in the file
```

## Str Function

**Function:** Converts unsigned 16-bit numeric value (word) into its decimal string representation.

**Syntax:** **str(num as word) as string**

**See Also:** [lstr](#)<sup>[216]</sup>, [stri](#)<sup>[226]</sup>, [lstri](#)<sup>[217]</sup>, [bin](#)<sup>[207]</sup>, [lbin](#)<sup>[214]</sup>, [hex](#)<sup>[212]</sup>, [lhex](#)<sup>[216]</sup>, [val](#)<sup>[229]</sup>, [lval](#)<sup>[218]</sup>

Part	Description
num	Value to be converted to string.

### Details

Can be invoked implicitly, through the *string\_var = word\_var* expression (see example below). Compiler is smart enough to pre-calculate constant-only expressions involving implicit use of str function.

### Examples

```
dim w as word
dim s as string

w=3400
s = str(w) 'explicit invocation.
s = w 'implicit invocation
s = 100 'will be calculated at compilation -- no actual str function
invokation will be here
```

## Strand Function

**Function:** Calculates logical AND on data in str1 and str2 arguments.

**Syntax:** **strand(byref str1 as string, byref str2 as string) as string**

**Returns:** Result of logical AND operation.

**See Also:** [stror](#)<sup>[227]</sup>, [strxor](#)<sup>[228]</sup>

Part	Description
str1	Argument 1.
str2	Argument 2.

### Details

This function treats data in str1 and str2 as two byte arrays. Logical AND operation

is performed on corresponding byte pairs (first byte of str1 AND first byte of str2, etc.).

If one of the arguments contains less bytes, then this argument is padded with zeroes prior to performing logical AND operation.

## Strgen Function

<b>Function:</b>	Generates a string of len length consisting of repeating substrings substr.
<b>Syntax:</b>	<b>strgen(len as byte,byref substr as string) as string</b>
<b>See Also:</b>	---

Part	Description
len	Length of the string to generate
substr	Substring that will be used (repeatedly) to generate the string

### Details

Notice that len parameter specifies total resulting string length in bytes so the last substring will be truncated if necessary to achieve exact required length. This function is an expanded version of the STRING\$ function commonly found in other BASICs.

### Examples

```
string1 = strgen(10,"ABC") ' result will be 'ABCABCABCA'.
```

## Stri Function

<b>Function:</b>	Converts signed 16-bit numeric value (short) into its decimal string representation.
<b>Syntax:</b>	<b>stri(num as integer) as string</b>
<b>See Also:</b>	<a href="#">str</a> <sup>[225]</sup> , <a href="#">lstr</a> <sup>[216]</sup> , <a href="#">lstri</a> <sup>[217]</sup> , <a href="#">bin</a> <sup>[207]</sup> , <a href="#">lbin</a> <sup>[214]</sup> , <a href="#">hex</a> <sup>[212]</sup> , <a href="#">lhex</a> <sup>[216]</sup> , <a href="#">val</a> <sup>[229]</sup> , <a href="#">lval</a> <sup>[218]</sup>

Part	Description
num	Value to be converted to string.

### Details

Can be invoked implicitly, through the *string\_var=short\_var* expression (see example below). Compiler is smart enough to pre-calculate constant-only expressions involving implicit use of *stri* function.

### Examples

```
dim sh as short
dim s as string

sh= -3400
s = stri(sh) 'explicit invocation.
s = sh 'implicit invocation
s = stri(-100) 'will be calculated at compilation -- no actual stri function
invokation will be here
```

## Stor Function

<b>Function:</b>	Calculates logical OR on data in <i>str1</i> and <i>str2</i> arguments.
<b>Syntax:</b>	<b>stor(<i>byref</i> <i>str1</i> as string, <i>byref</i> <i>str2</i> as string) as string</b>
<b>Returns:</b>	Result of logical OR operation.
<b>See Also:</b>	<a href="#">strand</a> <sup>[225]</sup> , <a href="#">strxor</a> <sup>[228]</sup>

Part	Description
<i>str1</i>	Argument 1.
<i>str2</i>	Argument 2.

### Details

This function treats data in *str1* and *str2* as two byte arrays. Logical OR operation is performed on corresponding byte pairs (first byte of *str1* OR first byte of *str2*, etc.).

If one of the arguments contains less bytes, then this argument is padded with zeroes prior to performing logical OR operation.

## Strsum Function

<b>Function:</b>	Calculates 16-bit (word) sum of ASCII codes of all characters in a string.
<b>Syntax:</b>	<b>strsum(<i>byref</i> <i>sourcestr</i> as string) as word</b>
<b>See Also:</b>	---

Part	Description
<i>sourcestr</i>	String to work on

### Details

This function is useful for checksum calculation.

### Examples

```
w = strsum("012") ' will return 147 (48+49+50).
```

## Strtof Function

**Function:** Converts string representation of a real value into a real value.

**Syntax:** **strtof**(byref str as string) as real

**See Also:** [ftostr](#)<sup>[211]</sup>, [str](#)<sup>[225]</sup>, [val](#)<sup>[229]</sup>

Part	Description
str	String to convert.

### Details

You must keep in mind that floating-point calculations are inherently imprecise. Not every value can be converted into its exact floating-point representation. Also, strtof can be invoked implicitly. Examples below illustrates this.

### Examples

```
dim r1 as real
dim s as string

s="456.125"
r1=strtof(s) 'r1 will be equal to 456.125. This conversion will be done
without errors.
s="123.200"
r1=strtof(s) '123.200 will be converted with errors. Actual result will be
123.25.
r1=s 'implicit invocation. Same result as for the line above.
```

## Strxor Function

**Function:** Calculates exclusive OR (XOR) on data in str1 and str2 arguments.

**Syntax:** **strxor**(byref str1 as string, byref str2 as string) as string

**Returns:** Result of logical XOR operation.

**See Also:** [strand](#)<sup>[225]</sup>, [stror](#)<sup>[227]</sup>

Part	Description
str1	Argument 1.
str2	Argument 2.

### Details

This function treats data in str1 and str2 as two byte arrays. Logical XOR operation is performed on corresponding byte pairs (first byte of str1 XOR first byte of str2, etc.).

If one of the arguments contains less bytes, then this argument is padded with zeroes prior to performing logical XOR operation.

## Val Function

**Function:** Converts string representation of a value into 16-bit value (word or short).

**Syntax:** **val (byref sourcestr as string) as word**

**See Also:** [str](#)<sup>[225]</sup>, [lstr](#)<sup>[216]</sup>, [stri](#)<sup>[226]</sup>, [lstri](#)<sup>[217]</sup>, [bin](#)<sup>[207]</sup>, [lbin](#)<sup>[214]</sup>, [hex](#)<sup>[212]</sup>, [lhex](#)<sup>[216]</sup>, [lval](#)<sup>[218]</sup>

Part	Description
sourcestr	String to convert.

### Details

Recognizes &b (binary) and &h (hexadecimal) prefixes. Can be invoked implicitly, through the *word\_var= string\_var* expression (see example below). Compiler is smart enough to pre-calculate constant-only expressions involving implicit use of val function.

Beginning with release **2.0**, this function also plays the role of vali function, which has been removed.

### Examples

```
dim w as word
dim sh as short
dim s as string

s="&hF222"
w = val(s) 'explicit invocation, result will be 61986
sh= val(s) 'explicit invocation, result will be -3550 (sh is a 16-bit signed variable)
w = s 'implicit invocation
w = "2402" 'be calculated at compilation -- no actual val function invocation will be here
```

## Vali Function

Vali function is no longer available. Use [val](#)<sup>[229]</sup> function both for unsigned (word) and signed (short) conversions.

## Weekday Function

**Function:** Returns the day of the week for a given day number.

**Syntax:** **weekday(daycount as word) as pl\_days\_of\_week**

**Returns:** One of pl\_days\_of\_week constants:  
 1- PL\_DOW\_MONDAY: Monday.  
 2- PL\_DOW\_TUESDAY: Tuesday.  
 3- PL\_DOW\_WEDNESDAY: Wednesday.  
 4- PL\_DOW\_THURSDAY: Thursday.  
 5- PL\_DOW\_FRIDAY: Friday.  
 6- PL\_DOW\_SATURDAY: Saturday.  
 7- PL\_DOW\_SUNDAY: Sunday.

**See Also:** [year](#)<sup>[230]</sup>, [month](#)<sup>[221]</sup>, [date](#)<sup>[208]</sup>, [daycount](#)<sup>[209]</sup>, [hours](#)<sup>[213]</sup>, [minutes](#)<sup>[221]</sup>, [mincount](#)<sup>[220]</sup>

Part	Description
daycount	Day number. Base date for the day count is 1-JAN-2000 (this is day #0).

### Details

---

### Examples

```
dim w as pl_days_of_week
w = weekday(0) ' result will be PL_DOW_SATURDAY - the was the day of the
week for the 1st of January 2000.
```

## Year Function

**Function:** Returns the year for a given day number.

**Syntax:** **year(daycount as word) as byte**

**Returns:** Two last digits of the year (0 means 2000, 1 means 2001, and so on.)

**See Also:**

[month](#)<sup>[221]</sup>, [date](#)<sup>[208]</sup>, [weekday](#)<sup>[230]</sup>, [daycount](#)<sup>[209]</sup>, [hours](#)<sup>[213]</sup>,  
[minutes](#)<sup>[221]</sup>, [mincount](#)<sup>[220]</sup>

Part	Description
daycount	Day number. Base date for the day count is 1-JAN-2000 (this is day #0).

**Details**

---

**Examples**

```
b = year(366) ' result will be 1 (this day number is in year 2001).
```

## Object Reference

Object reference section is a repository for all objects that have ever been created. The platform you are working with does not necessarily support every object. See your [platform specifications](#)<sup>[138]</sup> - you will find the list of supported objects there.

Objects are...

- [Beep](#)<sup>[232]</sup> — generates buzzer patterns.
- [Button](#)<sup>[234]</sup> — monitors MD line (setup button).
- [Fd](#)<sup>[236]</sup> — manages flash memory file system and direct sector access.
- [Io](#)<sup>[294]</sup> — handles I/O lines, ports, and interrupts.
- [Kp](#)<sup>[304]</sup> — scans keypads of matrix and "binary" types.
- [Lcd](#)<sup>[317]</sup> — controls graphical display panels (several types supported).
- [Net](#)<sup>[358]</sup> — controls Ethernet port.
- [Pat](#)<sup>[363]</sup> — "plays" patterns on up to five LED pairs.
- [Ppp](#)<sup>[366]</sup> — accesses the Internet over the modem.
- [Pppoe](#)<sup>[369]</sup> — accesses the Internet over the ADSL modem.
- [Romfile](#)<sup>[370]</sup> — facilitates access to resource files (fixed data).
- [Rtc](#)<sup>[375]</sup> — keeps track of date and time.
- [Ser](#)<sup>[378]</sup> — up to 4 serial ports (UART, Wiegand, and clock/data modes).
- [Sock](#)<sup>[421]</sup> — socket comms (up to 16 UDP, TCP, and HTTP sessions).
- [Ssi](#)<sup>[512]</sup> — up to four serial synchronous interface channels (for SPI, I2C, etc.).
- [Stor](#)<sup>[522]</sup> — provides access to the EEPROM.
- [Sys](#)<sup>[526]</sup> — in charge of general device functionality.
- [Wln](#)<sup>[536]</sup> — handles Wi-Fi interface (requires GA1000 add-on module).

## Beep Object



The beep object allows you to generate "beep" patterns using the beeper (buzzer) attached to the CO pin of your device. "CO" stands for "clock output" and its output can be actually used for anything, not just controlling beeper. Frequency available on the CO pin is defined by the [beep.divider](#)<sup>[232]</sup> property.

When the pattern starts playing, the CO line becomes an output automatically. Therefore, you do not need to use the [io.enabled](#)<sup>[298]</sup> property to configure this line as output. When the pattern stops playing, the line will return to the input/output and HIGH/LOW state that it had before the pattern started playing.

The pattern you play can be up to 16 steps long. Each "step" can be either "-" (buzzer off), or "B" (buzzer on). You can also define whether the pattern will only execute one or loop and play indefinitely. Additionally, you can make the pattern play at "normal" or double speed.

You load the new pattern to play with the [beep.play](#)<sup>[233]</sup> method. If the pattern is looped it will continue playing until you changed it. If the pattern is not looped it will play once and then the [on\\_beep](#)<sup>[233]</sup> event will be generated.

Buzzer patterns offer a convenient way to tell the user what your system is doing. You can devise different patterns for different states of your device. You can use these patterns together with LED patterns generated by the [pat](#)<sup>[363]</sup> object.

Here is a simple example in which we generate three beeps on power up of the device.

```
sub on_sys_init
    beep.play("B-B-B", PL_PAT_CANINT)
end sub
```

To obtain a permanent, non-stop square wave on CO pin load the following pattern:

```
beep.play("B~", PL_PAT_CANINT)
```

## .Divider Property

<b>Function:</b>	Sets the frequency of the square wave output on the CO line.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default</b> = 1 (divide by 2)
<b>See Also:</b>	---

### Details

Actual frequency can be calculated as  $\text{base\_freq}/(2*\text{beep.divider})$ . Setting this property to 0 is equivalent to 65536 (i.e. actual frequency will be

base\_freq/131072).

Base\_freq depends on your platform -- you will find this information in your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

Most low-cost buzzers have resonant frequency at which they emit the loudest sound. Check the specifications for your buzzer and set the divider accordingly.

## On\_beep Event

**Function:** Generated when buzzer pattern finishes "playing".

**Declaration:** `on_beep`

**See Also:** [Beep Object](#)<sup>[232]</sup>, [beep.play](#)<sup>[233]</sup>

---

### Details

This can only happen for "non-looped" patterns. Multiple on\_beep events may be waiting in the event queue.

## .Play Method

**Function:** Loads new beeper pattern to play.

**Syntax:** `pat.play(byref pattern as string, patint as pl_beep_int)`

**Returns:** ---

**See Also:** [Beep Object](#)<sup>[232]</sup>

---

Part	Description
pattern	Pattern string, can include the following characters: '-' : the buzzer is off 'B' or 'b' : the buzzer is on '~' : looped pattern (can reside anywhere in the pattern string) '*' : double-speed pattern (can reside anywhere in the pattern string). New in <b>V1.1</b> : You can use this symbol twice and, thus, obtain x4 speed if necessary!
patint	Defines whether the beep.play method is allowed to interrupt another pattern that is already playing: 0- PL_BEEP_NOINT: cannot interrupt 1- PL_BEEP_CANINT: can interrupt)

### Details

Maximum pattern length is 16 "steps". The [on\\_pat](#)<sup>[365]</sup> event is generated once the

pattern finishes playing (looped patterns never finish playing).

## Button Object



All external devices and board offered by Tibbo feature a single button called "setup button". Our modules have a line to connect such a button externally. The setup button has a special system function: powering-up a Tibbo device with this button pressed (setup button line held LOW) causes the device to enter the serial upgrade mode. This mode is for uploading new [TiOS](#)<sup>[7]</sup> (firmware) file into the device through the serial port.

The button is not doing anything system-related at other times, so it can be used by your Tibbo BASIC application -- hence, the button object. The object offers the following:

The [button.pressed](#)<sup>[235]</sup> property returns current (immediate) state of the button.

The [on\\_button\\_pressed](#)<sup>[234]</sup> event is generated when the button is pressed. The [on\\_button\\_released](#)<sup>[235]</sup> event is generated when the button is released.

The [button.time](#)<sup>[235]</sup> read-only property returns the time (in 0.5 intervals) elapsed since the button was last pressed or released. You can use this property, for instance, to separate button pressing into "short" and "long":

```
sub on_button_released
  'see how much time has elapsed

  if button.time>4 then
    'the button for pressed for a "long" time -- do one thing
  else
    'the button was pressed for a "short" time -- do another thing
  end if
end sub
```

The button does not require any pre-configuration and works always.

Note that the [on\\_button\\_pressed](#)<sup>[234]</sup> and [on\\_button\\_released](#)<sup>[235]</sup> events, as well as the [button.time](#)<sup>[235]</sup> R/O property utilize "debouncing", which filters out very short transitions of the button state. The [button.pressed](#)<sup>[235]</sup> R/O property, however, does not rely on debouncing and returns the immediate state of the button at the very moment the property is read.

## On\_button\_pressed Event

<b>Function:</b>	Generated when the button on your device is pressed.
<b>Declaration:</b>	<b>on_button_pressed</b>
<b>See Also:</b>	<a href="#">Button.pressed</a> <sup>[235]</sup>

### Details

Multiple `on_button_pressed` events may be waiting in the event queue. You can check the time elapsed since the previous [on\\_button\\_released](#)<sup>[235]</sup> event by reading the value of the [button.time](#)<sup>[235]</sup> read-only property.

Note that the button object performs "debouncing" which rejects very brief transitions of the button state. This event will not be generated for such spurious transitions.

## On\_button\_released Event

**Function:** Generated when the button on your device is released.

**Declaration:** `on_button_released`

**See Also:** [Button.pressed](#)<sup>[235]</sup>

---

### Details

Multiple `on_button_released` events may be waiting in the event queue. You can check the time elapsed since the previous [on\\_button\\_pressed](#)<sup>[234]</sup> event by reading the value of the [button.time](#)<sup>[235]</sup> read-only property.

Note that the button object performs "debouncing" which rejects very brief transitions of the button state. This event will not be generated for such spurious transitions.

## .Pressed R/O Property

**Function:** Returns the current button state.

**Type:** Enum (no\_yes, byte)

**Value Range:** 0- NO: the button is not pressed.  
1- YES: the button is pressed.

**See Also:** ---

---

### Details

This property reflects an immediate state of the hardware at the very moment the property is read -- no "debouncing" performed. This is different from the [on\\_button\\_pressed](#)<sup>[234]</sup> and [on\\_button\\_released](#)<sup>[235]</sup> events, as well as the [button.time](#)<sup>[235]</sup> R/O property, which all take debouncing into the account.

## .Time R/O Property

**Function:** Returns the time (in 0.5 second intervals) elapsed since the button was last pressed or released (whichever happened) later.

**Type:** Byte

**Value Range:** 0-255

**See Also:** ---

### Details

It only makes sense to read this property inside the [on button pressed](#)<sup>[234]</sup> or [on button released](#)<sup>[235]</sup> event handlers. Once the value of this property reaches 255 (127 seconds) it stays at 255 (there is no roll-over to 0). Elapsed time is not counted when the execution of your application is paused.

## Fd Object



This is the flash disk (fd.) object, it allows you to use your device's flash memory for data storage. There are two methods of working with the flash memory:

- With [direct sector access](#)<sup>[240]</sup>, you can write and read flash sectors directly, without burdening yourself with the file system.
- With [file-based access](#)<sup>[245]</sup>, you create a formatted disk that stores files.

Both methods can be used [concurrently](#)<sup>[263]</sup> and complement each other whenever necessary.

Here is what the fd. object has to offer in terms of the file-based access:

- Ability to store up to 64 files located in a single root directory (subdirectories are not supported, but can be [emulated](#)<sup>[250]</sup>).
- Flexible [file attributes](#)<sup>[249]</sup> -- define and store any attributes you like.
- Methods to work with the [file directory](#)<sup>[252]</sup>.
- Ability to [open](#)<sup>[253]</sup> and work with several files at once.
- Methods to [write to and read from](#)<sup>[254]</sup> the file, also cut out a portion of the file from the [beginning or end](#)<sup>[255]</sup>.
- Fast and flexible [search](#)<sup>[256]</sup> to locate data within files. This also includes a record-style search!
- Automatic [sector leveling](#)<sup>[264]</sup>.
- [Transactions](#)<sup>[259]</sup> to ensure disk integrity in the toughest of conditions (power failures, etc).
- A method for firmware/application [self-upgrades](#)<sup>[243]</sup> (not supported by all platforms).

## Overview, 3.1

In this section:

- [Sharing Flash Between Your Application and Data](#)<sup>[237]</sup>
- [Fd. Object's Status Codes](#)<sup>[239]</sup>
- [Direct Sector Access](#)<sup>[240]</sup>
- [File-based Access](#)<sup>[245]</sup>

- [File-based and Direct Sector Access Coexistence](#)<sup>[263]</sup>
- [Prolonging Flash Memory Life](#)<sup>[264]</sup>

## Sharing Flash Between Your Application and Data

Discussed in this section: [fd.availableflashspace](#)<sup>[267]</sup>.

The flash memory used by the fd. object consists of 264-byte sectors. It is customary to use 256 bytes of each sector to store actual data, and reserve the rest for "service" data ([checksum](#)<sup>[242]</sup>, etc.).

Depending on what device you are using, the fd. object may be storing its data in one of the two ways (locations):


- On devices with *shared* flash memory, the firmware, compiled Tibbo Basic application, and the fd. object's data are stored on the same flash IC chip. All flash sectors that are not occupied by firmware/application are available for storing your data. We will refer to this area as a **data area** of the flash IC. The size of the data area, in sectors, can be obtained through the [fd.availableflashspace](#)<sup>[267]</sup> R/O property.
  - On devices with *dedicated* flash memory, one flash IC is used for firmware and application storage, while a second flash IC is used for fd. object's data storage. On such devices, the data area occupies the entire second flash IC, and [fd.availableflashspace](#)<sup>[267]</sup> always returns the number of sectors in this second flash IC. On certain device, the second flash IC is not present onboard and must be connected externally.
- To find out what flash memory arrangement your device has, refer to your device's [platform specification](#)<sup>[138]</sup> (for example, EM1000's is [here](#)<sup>[143]</sup>). You will find memory arrangement data under "Miscellaneous Information/ Flash memory configuration".

There are two ways in which you can store the data using the fd. object:

- The first way is to read and write flash sectors of the data area directly -- a so-called [direct sector access](#)<sup>[240]</sup>. This method is simple and allows you to "do whatever you please" with the data area you have.
- The second way is [file-based](#)<sup>[245]</sup> -- you create a full-blown flash disk that maintains a simple file system. This introduces a certain overhead, since the file system needs a number of sectors for its own internal "housekeeping". At the same time, using files may be infinitely more convenient and flexible, as many complex operations happen automatically, thus simplifying your application. In addition, [disk transactions](#)<sup>[259]</sup> bulletproof your file operations.

Both the direct sector access and the file based access can be [used at the same time](#)<sup>[263]</sup> -- your flash disk can occupy only a portion of the data area, and the rest of the space can be used for direct sector access.

The fd. object refers to physical sectors of the data area in reverse (refer to the drawing below, which shows memory allocation on the shared flash IC). While the firmware and application are loaded into the flash memory starting from the physical sector 0, the allocation for the data area starts from the topmost physical sector. For convenience, related methods and properties of the .fd object refer to this topmost physical sector as the (logical) sector 0, the sector before the topmost sector -- as 1, and so on.



\* For 512K flash having 2048 x 256-byte sectors

This approach was chosen to minimize the influence of the changing size of your Tibbo Basic application on the data you keep in the flash memory. Typically, the size of your application keeps changing as you develop and debug it. At the same time, you often need to keep certain data in the data area permanently, and don't want to recreate this data every time you upload a new iteration of your application. If the beginning of the data area was right after the end of the firmware/application area, any change in the application size would move the boundary of the data area, corrupt your data, and force you to recreate the data again. If, on the other hand, your data area starts from the top of the flash IC and continues downwards, then the chance of the data area corruption will be a lot smaller.

Naturally, the above applies to devices with *shared* flash memory. Devices with dedicated flash memory store firmware/application and fd. object's data in separate ICs, so there is no chance of corrupting the data area by loading a larger firmware/application.

- When debugging your application on devices with the shared flash memory, use only a portion of the data area and leave some part of this area unoccupied. This will create a gap of unused sectors between the data and the firmware/application areas of the flash. This way, your application will (mostly) be able to grow without corrupting the data area.

## Fd. Object's Status Codes

Discussed in this topic: [fd.laststatus](#)<sup>[282]</sup>.

Many things can go wrong when working with the flash memory. This is why methods of the fd. object return a status code. Good Tibbo Basic application doesn't just assume that all will be well and always checks the result of method execution.

Listed below are possible status codes returned by the flash disk object. Of course, not every code can be generated by every method:

- 0- PL\_FD\_STATUS\_OK: Completed successfully.
- 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal: disk dismounted, must be reformatted).
- 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal: disk dismounted, must be reformatted).
- 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal: disk dismounted, must be reformatted).
- 4- PL\_FD\_STATUS\_INV\_PARAM: Invalid argument have been provided for the invoked method.
- 5- PL\_FD\_STATUS\_DUPLICATE\_NAME: File with this name already exists.
- 6- PL\_FD\_STATUS\_FILE\_TABLE\_FULL: Maximum number of files that can be stored on the disk has been reached, new file cannot be created.
- 7- PL\_FD\_STATUS\_DATA\_FULL: The disk is full, new data cannot be added.
- 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
- 9- PL\_FD\_STATUS\_NOT\_FOUND: File not found.
- 10- PL\_FD\_STATUS\_NOT\_OPENED: No file is currently opened "on" the current [fd.filenum](#)<sup>[273]</sup>.
- 11- PL\_FD\_STATUS\_ALREADY\_OPENED: This file is already opened on some other file number.
- 12- PL\_FD\_STATUS\_TRANSACTION\_ALREADY\_STARTED: Disk transaction has already been started (and cannot be restarted).
- 13- PL\_FD\_STATUS\_TRANSACTION\_NOT\_YET\_STARTED: Disk transaction hasn't been started yet.
- 14- PL\_FD\_STATUS\_TRANSACTION\_CAPACITY\_EXCEEDED: Too many disk sectors have been modified in the cause of the current transaction (fatal: disk dismounted).
- 15- PL\_FD\_STATUS\_TRANSACTIONS\_NOT\_SUPPORTED: The disk wasn't formatted to support transactions (use [fd.formatj](#)<sup>[277]</sup> with maxjournalsectors>1 to enable transactions).
- 16- PL\_FD\_STATUS\_FLASH\_NOT\_DETECTED: Flash IC wasn't detected during boot, fd. object cannot operate normally.

The status code generated by the most recently invoked method is always kept by the [fd.laststatus](#)<sup>[282]</sup> R/O property. Some methods also return the status code directly:

```
If fd.create("File1.dat") <> PL_FD_STATUS_OK Then
    'some problem
End If
```

Other methods return data, so the only way to check the result of their execution is through the `fd.laststatus`:

```
s=fd.getdata(50) 'returns the data from the file, not the status code
If fd.laststatus<>PL_FD_STATUS_OK Then
    'some problem
End If
```


Most status codes are non-fatal, that is, they allow the disk to continue working. Selected status conditions result in the automatic [dismounting](#)<sup>[249]</sup> of the [flash disk](#)<sup>[245]</sup> (`fd.ready`<sup>[285]</sup> R/O property becomes 0- NO). Among these status codes, some (but not all) conditions also indicate that the disk is permanently damaged and must be [reformatted](#)<sup>[245]</sup>.

## Direct Sector Access

Discussed in this section: [fd.buffernum](#)<sup>[267]</sup>, [fd.getbuffer](#)<sup>[278]</sup>, [fd.setbuffer](#)<sup>[288]</sup>, [fd.getsector](#)<sup>[281]</sup>, [fd.setsector](#)<sup>[290]</sup>, [fd.checksum](#)<sup>[288]</sup>, [fd.copyfirmware](#)<sup>[269]</sup>, [fd.copyfirmwarelzo](#)<sup>[270]</sup>.

Direct sector access allows you to work with sectors in the [data area](#)<sup>[237]</sup> of your device's flash memory directly, without the need to create and manage any files. You work with sectors through two identical 264-byte RAM buffers numbered #0 and #1. The `fd.buffernum`<sup>[267]</sup> property selects one of the buffers as the source/destination for the data (see the drawing below).

All [file-based](#)<sup>[245]</sup> operations of the flash disk also rely on the RAM buffers and the selected buffer number may change as a result of their execution. When using direct sector access and file-based access [concurrently](#)<sup>[263]</sup>, switch to the RAM buffer #0 *each time* before performing direct sector access -- this will guarantee that you won't corrupt the files and/or the file system and cause disk dismounting (`fd.ready`<sup>[285]</sup> becoming 0- NO). There is more on this in the [File-based and Direct Sector Coexistence](#)<sup>[263]</sup> topic.



Reading data from a sector is a two-step process. First, you use `fd.getsector`<sup>[281]</sup> to load all 264 bytes from the desired sector into the currently selected RAM buffer. Next, you use `fd.getbuffer`<sup>[278]</sup> to read the data from the selected buffer. This method allows you to read up to 255 bytes beginning from any offset in the buffer (offsets are counted from 0):

```
Dim s As String
...
'we want bytes 20-29 from sector #3
fd.buffernum=0 'select RAM buffer #0
If fd.getsector(3)<>PL_FD_STATUS_OK Then
    'flash failure
End If
s=fd.getbuffer(20,10) 'now s contains the desired data
```

Since the sector and (RAM buffer size) exceeds 255 bytes (maximum length of string variables), you can't actually read the whole sector contents in one portion. At least two `fd.getbuffer` reads are necessary for that.

To modify the data in the selected RAM buffer, use the `fd.setbuffer`<sup>[288]</sup> method. The `fd.setbuffer` allows you to write new data at any offset of the selected RAM buffer. To store the contents of the RAM buffer back to the flash memory, use `fd.setsector`<sup>[290]</sup>:

```
Dim s As String
...
'modify first 3 bytes of sector #5
If fd.getsector(3)<>PL_FD_STATUS_OK Then
    'flash failure
End If
```

```
fd.setbuffer("ABC",0) 'write "ABC" to the buffer at offset 0
If fd.setsector(3)<>PL_FD_STATUS_OK Then
    'flash failure
End If
```

Since there are two identical RAM buffers, you can load the contents of two different sectors and work with the data concurrently, by switching between the buffers.

As covered under [Sharing Flash Between Your Application and Data](#)<sup>[237]</sup>, logical sector numbers for `fd.getsector` and `fd.setsector` are not actual physical sector numbers of the flash IC. Logical sector #0 corresponds to the topmost physical sector of the flash IC, so logical numbering is "in reverse".

You can only write to sectors that reside within the data area of your flash chip (that is, logical sector numbers from 0 to `fd.availableflashspace`<sup>[267]</sup>-1). For devices with shared flash memory, this prevents your application from inadvertently damaging its own code or firmware. Trespassing the data area boundary will result in the 4- `PL_FD_STATUS_INV_PARAM` [status code](#)<sup>[239]</sup>. If you want to alter the data in the firmware/application area, see [Upgrading the Firmware/Application](#)<sup>[243]</sup> topic.

If you are using direct sector access and [file-based access](#)<sup>[245]</sup> at the same time, be sure to read about ensuring their proper [coexistence](#)<sup>[263]</sup>.

Note also that `fd.getsector` and `fd.setsector` always access the actual specified target sector and not its cached copy even if the [disk transaction](#)<sup>[259]</sup> is in progress (`fd.transactionstarted`<sup>[294]</sup>= 1- YES) and the target sector has been cached already.

## Using Checksums

When dealing with the flash memory, it is very often desirable to make sure that the data stored in flash sectors is not corrupted. One way to do so is by calculating the checksum on the sector data and storing this checksum together with the data. Each sector of the flash memory conveniently stores 8 extra bytes on top of the "regular" 256 bytes usually storing the actual data.

The `fd.` object uses two bytes at offsets 262 and 263 to store the checksum of the first 262 bytes of data residing in the same sector. The checksum is a 16-bit value. When the checksum is correct, modulo 16 sum of the entire sector's data is zero.

16-bit values for these calculations are little-endian. That is, offset 0 of the sector is presumed to be the high byte of the first 16-bit value, offset 1 -- low byte of the first 16-bit value, offset 2 -- high byte of the second 16-bit value, and so on.

When you are using the [file-based access](#)<sup>[245]</sup>, the `fd.` object automatically calculates and/or verifies the checksum on all sectors it accesses. Should any sector turn out to contain an invalid checksum, the 2- `PL_FD_STATUS_CHECKSUM_ERR` [status code](#)<sup>[239]</sup> is generated.

Direct sector access is more primitive and it is your responsibility to maintain and verify the integrity of data you store in the flash memory. To aid you in this, the [fd.checksum](#)<sup>[268]</sup> method can be used to verify the checksum, or calculate and store it into the selected RAM buffer (where the sector's data is supposed to be already loaded):

```
'Load sector #10, verify its checksum, alter some data, recalculate the
checksum, and save new data
Dim i As word
...
'load the sector
If fd.getsector(10)<>PL_FD_STATUS_OK Then
```

```
'flash failure
End If

'verify the checksum
If fd.checksum(PL_FD_CSUM_MODE_VERIFY,i) <>OK Then
  'checksum error detected
End If

fd.setbuffer("ABC",20) 'alter data at offset 20

fd.checksum(PL_FD_CSUM_MODE_CALCULATE,i) 'recalculate the checksum, save it
back into the RAM buffer


'save back
If fd.setsector(10) <>PL_FD_STATUS_OK Then
  'flash failure
End If
```

## Upgrading the Firmware/Application

As was explained under [Direct Sector Access](#)<sup>[240]</sup>, you can't use [fd.setsector](#)<sup>[290]</sup> to write to the flash area occupied by the firmware and Tibbo Basic application. This is done to prevent your application from inadvertently damaging its own code or the firmware.

A special [fd.copyfirmware](#)<sup>[269]</sup> method is provided for changing the data in the firmware/application area of the flash. The method copies the specified number of sectors (starting from the logical sector 0) from the [data area](#)<sup>[237]</sup> and into the firmware/application area of the flash memory (starting from the physical sector 0), then reboots your device.

Before invoking this method, store the new "binary image" of the firmware/application in the data area of the flash memory starting from logical sector #0. Logical numbers are assigned to the sectors in reverse, so using [fd.setsector](#)<sup>[290]</sup> to write to logical sector #0 actually means storing to the topmost physical sector of the flash memory. It goes without saying that your data area *has* to have enough capacity to store the new binary image.



The diagram above presents the case of the [shared](#)<sup>[237]</sup> flash memory. With dedicated memory, the `fd.` object uses a separate flash IC to store its data. The size of this flash IC must be large enough to store the new firmware/application that you want to "activate" with the `fd.copyfirmware` method.

Exactly how you receive the new binary image is immaterial to this discussion. You can use any suitable transmission method, such as TCIP/IP, FTP, your own proprietary protocol, whatever! The important part is that before invoking `fd.copyfirmware` you must have the binary image stored in the data area of the flash, starting from the logical sector #0, and you must know how many sectors this occupies. After that, invoke `fd.copyfirmware` and hope that you prepared the right data!

Another method -- [fd.copyfirmwarelzo](#)<sup>[270]</sup> -- does the same job but assumes that the data prepared in the flash memory is not the binary image itself, but an LZO-compressed version of the same. This method will unpack the binary and copy it into the firmware/application area of the flash memory. Because the compressed data is not sector-aligned, this method takes the compressed data size length in bytes, not sectors.

Use "compressed" firmware upgrades whenever you are dealing with a sizeable Tibbo BASIC project. On devices with [shared](#)<sup>[237]</sup> flash memory, such projects will leave you with a small amount of free flash space, so the uncompressed "upgrade binary" will probably not fit there. In such cases LZO compression may be your way out, as it can achieve 30-50% reduction in file size.

The decompression algorithm accepts files compressed with **lzo1x-999.exe** utility.

- **BE VERY CAREFUL!** Using `fd.copyfirmware` or `fd.copyfirmwarelzo` on incorrect data will "incapacitate" your device and further remote upgrades will become impossible. You will need to physically go to your device and upload correct firmware and/or application, possibly through its serial port. Scary, huh?

## File-based Access

The following topics will explain how to work with the flash disk:

[Formatting the Flash Disk](#)<sup>[245]</sup>

[Mounting the Flash Disk](#)<sup>[249]</sup>

[File Names and Attributes](#)<sup>[249]</sup>

[Checking Disk Vitals](#)<sup>[249]</sup>

[Creating, Deleting, and Renaming Files](#)<sup>[250]</sup>

[Reading and Writing File Attributes](#)<sup>[251]</sup>

[Walking Through File Directory](#)<sup>[252]</sup>

[Opening Files](#)<sup>[253]</sup>

[Writing To and Reading From Files](#)<sup>[254]</sup>

[Removing Data From Files](#)<sup>[255]</sup>

[Searching Within Files](#)<sup>[256]</sup>

[Closing Files](#)<sup>[256]</sup>

[Using Disk Transactions](#)<sup>[259]</sup>

## Formatting the Flash Disk

Discussed in this section: [fd.formatj](#)<sup>[277]</sup>, [fd.format](#)<sup>[276]</sup>.

Before the flash disk can be used it must be formatted. Formatting allocates and initializes the "housekeeping" area of the disk. This consists of two boot sectors plus a certain number of sectors for the file record table (FRT), the file allocation table (FAT), and possibly the [transaction journal](#)<sup>[259]</sup> if you wanted one. For details see [Disk Area Allocation Details](#)<sup>[246]</sup>.

Formatting is performed using the [fd.format](#)<sup>[276]</sup> or [fd.formatj](#)<sup>[277]</sup> method. These methods accept, as arguments, two parameters: total number of sectors to be occupied by the disk, and the maximum number of files that you wish to be able to store on the disk. [Fd.formatj](#) additionally has the third argument: the number of sectors that you want to allocate to the transaction journal. [Fd.format](#) does not give any sectors to the latter, so it is like setting the journal size to 0.

- Be generous when allocating the journal area. A size of 50-100 sectors would be recommended. Journal sectors get written to all the time, and having many of them [prolongs](#)<sup>[264]</sup> the life of your flash memory.

The total number of sectors cannot exceed the size of the [data area](#)<sup>[237]</sup>. That is, the maximum "gross" disk size is [fd.availableflashspace](#)<sup>[267]</sup> sectors. The flash disk needs a number of sectors for its internal housekeeping, so actual useful capacity of the disk will be less. [Checking Disk Vitals](#)<sup>[249]</sup> topic explains how to find out current disk capacity, as well as get other useful info. There is also a minimum limit that will be accepted for the total disk size. The minimum exists because the number of sectors occupied by the disk must at least be enough for the "housekeeping" data.

- When debugging your application on devices with the [shared](#)<sup>[237]</sup> flash memory, use only a portion of the data area and leave some part of this area unoccupied. This will create a gap of unused sectors between the data and

the firmware/application areas of the flash. This way, your application will (mostly) be able to grow without corrupting the data area.

The fd. object stores up to 64 files on the disk, in a single "root" directory. You can choose to have less files if you don't need so many. This will reduce the number of "housekeeping" sectors required for the disk. The economy is not dramatic, but you can still save some space. Each file record occupies 64 bytes, so one sector of the FRT table can store 4 file records. For this reason, the number of files you specify will always be adjusted to be the multiple of 4. For example:

```
'format a disk to occupy 3/4th of available space and store at least 10
files
If fd.formatj((fd.availableflashspace/4)*3,10,100)<>PL_FD_STATUS_OK Then
    'some problem...
End If
'actual maximum number of files will be 12 (adjusted up from 10 to be a
multiple of 4)
```


After the formatting the disk will be in the dismounted state and will need to be [mounted](#)<sup>[249]</sup> before any disk-related activity can be successfully performed.

This topic provides details on the internal structure of the flash disk.

The flash disk has a number of areas. Each area includes one or more flash sectors. Each sector has a physical size of 264 bytes. Of those, only 256 bytes are used to store the data. Two last bytes of each sector store the [checksum](#)<sup>[242]</sup>. Six remaining bytes are mostly left unused, except in the FRT/FAT areas (see below), where they do serve a useful function.

The flash disk has the following areas:

- **BOOT** sector, always at logical sector #0 (so it is the topmost physical sector of the flash -- this was explained in [Sharing Flash Between Your Application and Data](#)<sup>[237]</sup>). The boot sector contains the information about the sizes of other areas of the disk.
- File record table (**FRT**) area.
- File allocation table (**FAT**) area.
- **Data area** -- actual data sectors of files.
- **Transaction journal area** -- caches modified sectors during the [disk transaction](#)<sup>[259]</sup>. This area only exists if you format the disk with the [fd.formatj](#)<sup>[277]</sup> method.
- **END BOOT** sector -- keeps the same data as the BOOT sector, but is located past the data area.



### FRT area

Each file record occupies 64 bytes. Therefore, each sector of the FRT area can fit 4 file records. Therefore, if you specify (during formatting) that you would like to have 15 different files, the `fd.format`<sup>[276]</sup> (or `fd.formatj`<sup>[277]</sup>) method will round this up to 16 files. This will require 4 sectors to fit. Actual amount of allocated sectors is always *double* that. This is done for sector `leveling`<sup>[264]</sup>, which the `fd.` object takes care of internally. Also, the number of allocated sectors is never less than 8, again, for sector leveling reasons.

The maximum number of files stored by the `.fd` object is 64. Therefore, the maximum size of the FRT area is  $(64/4)*2=32$  sectors. Hence, the size of the FRT area is always between 8 and 32 sectors depending on the maximum number of files you need to store on the disk.

### FAT area

Each FAT sector consists of 128 FAT entries, 2 bytes per entry. Therefore, each FAT sector can fit the allocation data for 128 sectors from the data area of the disk. To improve sector leveling, the number of sectors allocated for the FAT area is, again, double against what's necessary. So, for every 128 sectors in the data area of the disk there are 2 sectors in the FAT area. At least 16 sectors are always allocated to FAT.

An example; supposing the data area has 1100 sectors. Therefore,  $1100/128=9$  FAT sectors are needed. The `fd.` object will allocate double this required minimum, so 18 FAT sectors will be prepared. Let's suppose now that we only have 500 data sectors. This requires 4 FAT sectors, 8 after we double this amount. This is less than the minimal 16 FAT sectors that are always provided, so the `fd.` object will still allocate 16 sectors.

### Allocation and capacity calculation example

The `fd.format` method takes, as an input parameter, the total number of sectors that you wish the disk to occupy. From that, and the supplied desired max number of files, the `fd.format` will work out the size of each area of the disk. Let's see this on a real example:

Supposing, you call **fd.formatj(1300,41,100)** -- you want the disk to occupy 1300 sectors and store 41 file. You want the journal area to have 100 free sectors. So, what will be the size of the FRT, FAT, and data areas?

First, the fd.format deducts 2 sectors to account for the BOOT and the END BOOT sectors that must always be present. This leaves us with 1298 sectors.

Next, deduct the journal area -- now only 1198 sectors are left.

Next, the fd.format determines the size of the FRT area: 41 is rounded to 44, this works out to that  $(44/4)*2=22$  sectors are needed (this exceeds the minimum of 8, so we do not need to correct this number). We have  $1198-22=1176$  sectors left.

Now, how many FAT sectors we need?  $1176/128=9.18$ , i.e. 10. Actual amount will be doubled, so we need 20 sectors (exceeds the minimum of 16, so we do not need to correct this number). Therefore, we are left with  $1176-20=1156$  data sectors. This is what you will get from the [fd.capacity](#)<sup>[268]</sup> R/O property (see [Checking Disk Vitals](#)<sup>[249]</sup>).

### One small caveat...

Now let us show you one trickier example. Say, you do **fd.format(1301,4)**. You can quickly work out that you have 1301 sector for the FAT and data areas combined. Now, how should this be divided?

If you had 1300 sectors, then there would be no problem. Of them, 1280 would go to the data area, and 20 will belong to the FAT. 10 "necessary" FAT sectors will together hold  $10*128=1280$  entries -- just right for the size of the data area. The number of FAT sectors is always doubled, so FAT will get 20 sectors. Everything fits perfectly!

Now, there is no good solution for 1301 sectors. If you give this extra one sector to the data area, then you will need two more sectors for the FAT area -- and you don't have those sectors. Allocating this extra sector to the FAT is useless, because you are not increasing the number of data sectors, so you don't really need an extra FAT sector. Hence, the value of 1301 is actually not suitable to us. Same goes for 1302. 1303 is good again, because three extra sectors allow us to give one sector to the data area, and add two sectors to the FAT area (FAT always increased in "doubles", remember?).

Fd.format avoid falling into the trap by correcting downwards the total disk size you request if it turns out to be one of the "problematic" values. So, if you do **fd.format(1302,4)**, then the result would be as if you did **fd.format(1300,4)**. The [fd.totalsize](#)<sup>[292]</sup> R/O property reflect this.

### Why is there the END BOOT sector?

The END BOOT sector exists for one purpose -- to detect whether your application has encroached on the flash disk. As was already [explained](#)<sup>[237]</sup>, on devices with the shared flash memory, the firmware/application and the data area reside in the same flash IC. Data area sectors are counted from the topmost physical sector of the flash memory. Therefore, the END BOOT sector is the one "closest" to your application. Should the application become larger and take some of the space that was previously occupied by the flash disk, the END BOOT sector will be overwritten. The fd. object will detect this during [mounting](#)<sup>[249]</sup> and return 3-PL\_FD\_STATUS\_FORMAT\_ERR [status code](#)<sup>[239]</sup>.

## Mounting the Flash Disk

Discussed in this topic: [fd.mount](#)<sup>[283]</sup>, [fd.ready](#)<sup>[285]</sup>.

The flash disk will not be accessible unless it is mounted using [fd.mount](#)<sup>[283]</sup>. It can only be mounted after the flash memory has been successfully formatted using [fd.formatj](#)<sup>[277]</sup> (recommended) or [fd.format](#)<sup>[276]</sup>. The disk has to be mounted after every reboot of your device (if you need to access it, of course). After the disk is mounted successfully, the [fd.ready](#)<sup>[285]</sup> R/O property will read 1- YES.

During mounting, the fd. object accesses the [BOOT sectors](#)<sup>[246]</sup> of the disk, reads the size of all [disk areas](#)<sup>[246]</sup>, and determines if the flash disk is healthy. This does not include detailed checks of each file or data sector of the disk, but is enough to "catch" gross problems, such as disk corruption due to an increase in the application size.

Once the disk has been mounted, you can [check its vitals](#)<sup>[249]</sup>, [create and delete files](#)<sup>[250]</sup>, and perform other disk-related operations.

There is no way to explicitly dismount the disk, nor it is necessary. The disk will be dismounted (and [fd.ready](#)<sup>[285]</sup> become 0- NO) if:

- Any fatal condition is detected when working with it. This condition will be reflected by the [fd.laststatus](#)<sup>[282]</sup> R/O property. Not every error indicated by the fd.laststatus is fatal (see [Fd. Object's Status Codes](#)<sup>[239]</sup> topic).
- The disk is formatted using [fd.formatj](#)<sup>[277]</sup> ([fd.format](#)<sup>[276]</sup>).
- Your application invokes [fd.setbuffer](#)<sup>[288]</sup>/[fd.setsector](#)<sup>[290]</sup> [inappropriately](#)<sup>[263]</sup>.

## Checking Disk Vitals

Once the disk is [mounted](#)<sup>[249]</sup>, you can check several important flash disk parameters:

- [Fd.capacity](#)<sup>[268]</sup> will tell you the number of usable data sectors on the disk (this excludes housekeeping sectors maintained by the disk).
- [Fd.numservicesectors](#)<sup>[284]</sup> will tell you how many sectors are used for internal "housekeeping" of the flash disk (see [Disk Area Allocation Details](#)<sup>[246]</sup> for... details).
- [Fd.totalsize](#)<sup>[292]</sup> will indicate how many sectors the disk occupies in the flash memory.  $Fd.totalsize = fd.capacity + fd.numservicesectors$ .
- [Fd.getfreespace](#)<sup>[280]</sup> method will return the number of free data sectors on the disk (those not yet occupied for file data storage).
- [Fd.maxstoredfiles](#)<sup>[283]</sup> will report the maximum number of files that can be stored on the disk (this is defined at the time of [disk formatting](#)<sup>[245]</sup>).
- [Fd.getnumfiles](#)<sup>[281]</sup> fetches the number of files currently stored on the disk.

Keep in mind that currently existing disk might not be the largest one that could fit in the current data area ([fd.availableflashspace](#)<sup>[267]</sup>).

## File Names and Attributes

Every file you create on the flash disk has a file name and attributes. Both share a single text string that can be up to 56 characters long. The attributes (if any) are separated from the file name by a space. In other words, everything up to the first space is the file name, and everything else -- attributes.

The file names are case-sensitive and can include any characters, except, obviously, the space. This includes "/" and "\". The flash disk does not support subdirectories, but it is possible to emulate them by including "/" or "\" characters in the file name. The "." character can be used too, so you can have any extensions you like. The attributes portion of the string may contain any characters whatsoever, including spaces.

It is quite common for file systems to define attributes for the files. Typically, however, these attributes are preset. That is, you have a fixed list of things you can define about the file, such as the creating time, read-only flag, etc.

The fd. object uses a different approach. In a system that only runs a single application at any given time, it makes no sense to have, say, a fixed read-only flag. There is only one application running, after all. This application probably knows what files not to touch anyway! Or how about the date and time of the file creation? Does it make sense to keep this on a system without a real-time clock? Quite obviously, no.

For the above reasons, the fd. object allows you to store any attribute data and interpret it in any way you want. There is an attribute string and you can fill it with any data of your choosing and in accordance with the needs of your application. And yes, you can implement the read-only flag and record the creation date and time -- but only if you need to.

Here is an example where we [create a file](#)<sup>[250]</sup> and set its attributes too:

```
...
fd.create("File1.dat R 25-JUL-2008") ' <File1.dat> is the file name, <R 25-
JUL-2008> -- attributes, it is up to our program how to interpret this!
```

For more info on file attributes see [Reading and Writing File Attributes](#)<sup>[251]</sup>.

## Creating, Deleting, and Renaming Files

Discussed in this topic: [fd.create](#)<sup>[271]</sup>, [fd.rename](#)<sup>[285]</sup>, [fd.delete](#)<sup>[272]</sup>, [fd.getnumfiles](#)<sup>[281]</sup>, [fd.maxstoredfiles](#)<sup>[283]</sup>.

You can't really do anything useful with the flash disk unless you create at least one file. The [fd.create](#)<sup>[271]</sup> method is used for this. The string you supply as an argument must include a file name and may also contain the [attributes](#)<sup>[249]</sup>. Some examples:

```
If fd.create("File1.dat R 25-JUL-2008")<>PL_FD_STATUS_OK Then ' <File1.dat>
is the file name, <R 25-JUL-2008> -- attributes.
  'some problem
End If
If fd.create("  File2")<>PL_FD_STATUS_OK Then 'no attributes defined for
this file. Notice leading spaces -- they will be removed.
  'some problem
End If
If fd.create("Database/users.dat")<>PL_FD_STATUS_OK Then 'and here we
emulate a directory
  'some problem
End If
If fd.create("file 3")<>PL_FD_STATUS_OK Then 'if the idea was to create a
<file 3> file, then this won't work! "3" will be interpreted as attributes!
  'some problem
```

```
End If
```

Naturally, each file on the flash disk must have a unique name, or the 5-PL\_FD\_STATUS\_DUPLICATE\_NAME [error](#)<sup>[239]</sup> will be generated. Every existing file always has at least one data sector allocated to it. This is how the 7-PL\_FD\_STATUS\_DATA\_FULL error may be generated when you are creating a new file. Finally, the total number of files stored on the flash disk is limited to what you defined when [formatting](#)<sup>[245]</sup> your disk. This maximum can be checked through the [fd.maxstoredfiles](#)<sup>[283]</sup> R/O property. Try to exceed this number and you will get the 6- PL\_FD\_STATUS\_FILE\_TABLE\_FULL error code. Current file count can be obtained through [fd.getnumfiles](#)<sup>[281]</sup>.

To delete a file, use the [fd.delete](#)<sup>[272]</sup> method:

```
If fd.delete("File1.dat") <> PL_FD_STATUS_OK Then
    'some problem
End If
If fd.delete("File2 abc") <> PL_FD_STATUS_OK Then 'the "abc" part will be
ignored -- everything after the space is NOT a part of the file name
    'some problem
End If
If fd.delete(" Database/users.dat") <> PL_FD_STATUS_OK Then 'leading spaces
will be ignored
    'some problem
End If
```

The file you are deleting must, of course, still exist, or you will get the 9-PL\_FD\_STATUS\_NOT\_FOUND [error](#)<sup>[239]</sup>. You can also rename a file using the [fd.rename](#)<sup>[285]</sup> method (this will preserve file [attributes](#)<sup>[251]</sup>). It is OK to delete or rename a file which is currently [opened](#)<sup>[253]</sup>.

[Fd.create](#)<sup>[271]</sup>, [fd.rename](#)<sup>[285]</sup>, and [fd.delete](#)<sup>[272]</sup> make changes to the sectors of the flash disk. For the highest possible reliability, use [disk transactions](#)<sup>[259]</sup> when invoking these methods.

## Reading and Writing File Attributes

Discussed in this topic: [fd.getattributes](#)<sup>[278]</sup>, [fd.setattributes](#)<sup>[287]</sup>.

You can set initial file [attributes](#)<sup>[249]</sup> right when [creating](#)<sup>[250]</sup> a new file. To read existing file attributes, use the [fd.getattributes](#)<sup>[278]</sup> method:

```
'this example ignores potential error conditions
Dim s As String
...
s=fd.getattributes("File1.dat") 'get the attributes for this file
If instr(1,s,"R",1)=0 Then 'delete the file only if there is no 'R' in the
attributes
fd.delete("File1.dat")
End If
```

You can set new (change) attributes with the [fd.setattributes](#)<sup>[287]</sup> method:

```
If fd.setattributes("File1.dat", "D")<>PL_FD_STATUS_OK Then 'the attribute
string will now consist of a single 'D'
    'some problem
End If
```

Remember that the file name and the attributes share the same 56-byte string in the file record table of the flash disk. Therefore, the maximum length of the attributes is limited to 56-length\_of\_the\_file\_name-1. This "-1" accounts for the space character that separates the file name from the attributes.

Attempting to perform the `fd.getattributes` or `fd.setattributes` on a file that does not exist will generate the 9- PL\_FD\_STATUS\_NOT\_FOUND [error](#)<sup>[239]</sup>.

[Fd.setattributes](#)<sup>[287]</sup> makes changes to the sectors of the flash disk. For the highest possible reliability, use [disk transactions](#)<sup>[259]</sup> when invoking it.

## Walking Through File Directory

Discussed in this topic: [fd.resetdirpointer](#)<sup>[286]</sup>, [fd.getnextdirmember](#)<sup>[280]</sup>, [fd.getnumfiles](#)<sup>[281]</sup>.

At times it is necessary to get the list of all files stored on the flash disk. Most operating systems provide this feature in the form of a DIR command. The `fd.` object offers two methods -- [fd.resetdirpointer](#)<sup>[286]</sup> and [fd.getnextdirmember](#)<sup>[280]</sup> -- that allow you to get the names of all stored files one by one.

An imaginary "directory pointer" walks through the [file record table](#)<sup>[246]</sup> (FRT) of the flash disk. The `fd.resetdirpointer` method resets the directory pointer to 0, i.e. to the very first directory record. The `fd.getnextdirmember` returns the next file name and advances the pointer. Only file names are returned, [attributes](#)<sup>[251]</sup> are excluded.

Calling the `fd.getnextdirmember` repeatedly will get you all the file names. When there are no more names left to go through, the method will return an empty string. You can use this to end your directory walk:

```
'walk through the file directory -- method #1
Dim s As String

fd.resetdirpointer
Do
    s=fd.getnextdirmember
    If fd.laststatus<>PL_FD_STATUS_OK Then
        'some problem
    End If
    ... 'process the file name in s
Loop While s<>"" 'we exit on empty string
```

Alternatively, you can use a for-next cycle, since the number of currently stored files can be checked through the [fd.getnumfiles](#)<sup>[281]</sup> method:

```
'walk through the file directory -- method #2
Dim s As String
Dim f As Byte

fd.resetdirpointer
For f=1 To fd.getnumfiles
  s=fd.getnextdirmember
  If fd.laststatus<>PL_FD_STATUS_OK Then
    'some problem
  End If
  ... 'process the file name in s
Next f
```

## Opening Files

Discussed in this topic: [fd.filenum](#)<sup>[273]</sup>, [fd.open](#)<sup>[284]</sup>, [fd.fileopened](#)<sup>[273]</sup>, [fd.maxopenedfiles](#)<sup>[282]</sup>.

You must first open a file in order to work with its data. The [fd.open](#)<sup>[284]</sup> method opens a file with a specified name and "on" a file number currently selected by the [fd.filenum](#)<sup>[273]</sup> property. All operations related to the file data are then performed by referring to the file number, not the file name. These operations include [writing to and reading from files](#)<sup>[254]</sup>, [removing data from files](#)<sup>[255]</sup>, [searching within files](#)<sup>[256]</sup>, and [closing files](#)<sup>[258]</sup>.

The concept of file numbers is not new -- other operating systems, too, assign a number to the file when the file is opened. In Tibbo Basic, you select the number you want to open the file on yourself. You do this by selecting a desired value for the [fd.filenum](#) property:

```
'will open two files 'on' numbers 3 and 5

fd.filenum=3
If fd.open("File1")<>PL_FD_STATUS_OK Then
  'some problem
End If
fd.filenum=5
If fd.open("TrestFile")<>PL_FD_STATUS_OK Then
  'some problem
End If
```

Whenever you want to work with one of the currently opened files, just set the [fd.filenum](#) to the number on which this file was opened (naturally, you need to somehow remember this number). And how many files can be opened concurrently? The [fd.maxopenedfiles](#)<sup>[282]</sup> R/O property will tell you that. This value is platform-dependent. Your [fd.filenum](#) value can move between 0 and [fd.maxopenedfiles](#)-1.

When the file is opened "on" a certain file number, the [fd.fileopened](#)<sup>[273]</sup> R/O property returns 1- YES when this file number is selected in the [fd.filenum](#).

Any leading spaces in the file name you supply for [fd.open](#) are removed. After that, only the part up to the first space is processed -- the rest of the string is ignored. The following three code lines all open the same file:

```
fd.open("File1")
fd.open("      File1") 'leading spaces will be removed
fd.open("File1 some more stuff") 'everything after the first space will be
ignored too
```

Naturally, the file with the specified name must exist, or you get the 9-PL\_FD\_STATUS\_NOT\_FOUND [error](#)<sup>[239]</sup>. You may not open the same file "on" two different file numbers -- this will generate the 11-PL\_FD\_STATUS\_ALREADY\_OPENED error. You may reopen the same or another file "on" the same file number, but this can lead to the loss of (some) changes made to the previously opened file. To avoid this, [close](#)<sup>[258]</sup> the file or use the [fd.flush](#)<sup>[275]</sup> method before opening it again. Note that the fd.flush method does not depend on the current fd.filenum value and works globally on any most recently changed file.

## Writing To and Reading From Files

Discussed in this topic: [fd.getdata](#)<sup>[279]</sup>, [fd.setdata](#)<sup>[289]</sup>, [fd.pointer](#)<sup>[285]</sup>, [fd.setpointer](#)<sup>[291]</sup>, [fd.filesize](#)<sup>[274]</sup>.

Writing to and reading from files are two most important file operations. Having a flash disk would be pointless without them. Writing and reading is done using two methods -- [fd.setdata](#)<sup>[289]</sup> and [fd.getdata](#)<sup>[279]</sup> respectively. For these to work, the file must first be [opened](#)<sup>[253]</sup>. [fd.setdata](#) and [fd.getdata](#) work on the currently selected file, and the selection is made through the [fd.filenum](#)<sup>[273]</sup> property.

### The pointer

Both reading and writing operations are always performed from the *current pointer position*. This position can be checked through the [fd.pointer](#)<sup>[285]</sup> R/O property and changed through the [fd.setpointer](#)<sup>[291]</sup> method. Executing the [fd.setdata](#) or [fd.getdata](#) moves the pointer forward by the number of file positions written or read.

The pointer always points at the position (offset) in the file from which the next reading or writing will be done. File offsets are counted from one, not zero. The very first byte in the file is at offset one, the next byte -- at offset two, and so on. The very last byte in the file is at offset equal to the size of the file, which is indicated by the [fd.filesize](#)<sup>[274]</sup> R/O property. The maximum pointer value, however, is [fd.filesize+1](#)! When the pointer is at maximum, it effectively points at the file position that doesn't yet exist. So, writing to the file at this position will append new data to the end of the file. Writing to the file when the pointer is not at the maximum will overwrite existing data.

When the file is [opened](#)<sup>[253]</sup>, the pointer is set to 1 if the file has any data in it ([fd.filesize](#)<>0), or 0 if the file is empty ([fd.filesize](#)=0). It is not possible to set the pointer to zero if the file is not empty. The pointer will be moved automatically if the file [becomes smaller](#)<sup>[255]</sup> and will be set to zero if the file becomes empty.

### Writing and reading

In the following example, we append the data to the end of the file, then read the data from the beginning of the file:

```
Dim s As String

'open a file 'on' file number 3
fd.filenum=3
fd.open("SomeFile")
fd.setpointer(fd.filesize+1) 'works always -- no matter whether the file is
empty or not
fd.setdata("Append this to the file")
fd.setpointer(1) 'go back to the beginning of the file
s=fd.getdata(10) 'read 10 bytes from the beginning of the file
```

If `fd.setdata` is executed when the pointer isn't at the end of the file (at `fd.filesize` <sup>[274]</sup>+1 position) then some of the existing file data will be partially overwritten. If the pointer moves past the current file size (see `file.size` <sup>[274]</sup>), the size will be increased automatically. As you append new data to the file, the file will grow larger. New data sectors will be allocated and added to the file automatically as needed. You will get the 7- `PL_FD_STATUS_DATA_FULL` error <sup>[239]</sup> if the disk runs out of free sectors. When the `fd.setdata` is executed and the disk full condition is detected, the entire data string supplied with `fd.setdata` is not saved into the file (and not just the part that couldn't fit).

`fd.setdata` <sup>[289]</sup> makes changes to the sectors of the flash disk. For the highest possible reliability, use `disk transactions` <sup>[259]</sup> when invoking this method.

### File data caching

The `fd.` object uses the `RAM buffer #1` <sup>[240]</sup> as an intermediary storage for the sector's data. When you access a certain data sector, the contents of this sector are loaded into the RAM buffer #1. When you change the data in the sector, it is the data in the RAM buffer that gets changed. The changed contents of the RAM buffer will not be saved back to the flash memory until the contents of *another* sector must be loaded into the buffer. So, for example, if you do this...

```
fd.setdata("Write this to a file")
```

... and then leave the disk alone, then the new data may stay in the RAM buffer indefinitely. It may get lost -- for example, if you reboot the device. To prevent this, `close` <sup>[258]</sup> the file or use the `fd.flush` <sup>[275]</sup> method -- either one will cause the changed data in the RAM buffer to be saved back to the flash memory. Note that the `fd.flush` method does not depend on the current `fd.filenum` value and works globally on any most recently changed file.

It is not necessary to use `fd.flush` if your disk operations are performed within a `disk transaction` <sup>[259]</sup>.

### Removing Data From Files

Discussed in this topic: `fd.setfilesize` <sup>[289]</sup>, `fd.cutfromtop` <sup>[271]</sup>.

Using the `fd.setdata` <sup>[289]</sup> method can only increase the size of your file. To reduce the file size, i.e. remove some data from it, use one of the two following methods. Both methods work on a currently selected file, and the selection is made through

the [fd.filenum](#)<sup>[273]</sup> property.

The [fd.setfilesize](#)<sup>[289]</sup> method cuts the end portion of your file and preserves a specified amount of bytes in the beginning of the file:

```
'open a file 'on' file number 4
fd.filenum=4
fd.open("SomeFile")
fd.setfilesize(fd.filesize/2) 'cut the file size in half
```

The [fd.setfilesize](#) can't be used to enlarge your file, only to make it smaller. Data sectors previously allocated to the file will be "released" (marked unused) if they become unnecessary due to the reduction in the file size. The first data sector of the file, however, will always remain allocated, even when the file size is set to 0.

The size of the file, indicated by the [fd.filesize](#)<sup>[274]</sup> R/O property, will be corrected downwards to reflect the amount of data left in the file.

The [pointer position](#)<sup>[254]</sup> will be affected by this method. If the file becomes empty, the pointer will be set to 0. If the new file size is not zero, but the new size makes current pointer position invalid (that is, `fd.pointer > fd.filesize+1`) then the pointer will be set to `fd.filesize+1`.

The second method -- [fd.cutfromtop](#)<sup>[271]</sup> -- removes a specified number of *sectors* (not bytes) from the beginning of the file and leaves the end portion of the file intact:

```
'open a file 'on' file number 2
fd.filenum=2
fd.open("SomeFile")
fd.cutfromtop(3) 'remove three front sectors from the file (that is, remove
up to 3*256= 768 bytes of data)
```

The size of the file will be corrected downwards in accordance with the amount of removed data. For example, performing `fd.cutfromtop(2)` on a file occupying 3 data sectors will reduce its size by 512 bytes (amount of data in 2 sectors removed). Performing `fd.cutfromtop(3)` will set the file size to 0.

The pointer position is always reset as a result of this method execution. If the new file size is 0, then the pointer will be set to 0 as well. If the file size is not 0, then the pointer will be set to 1.

[Fd.setfilesize](#)<sup>[289]</sup> and [fd.cutfromtop](#)<sup>[271]</sup> make changes to the sectors of the flash disk. For the highest possible reliability, use [disk transactions](#)<sup>[259]</sup> when invoking these methods.

## Searching Within Files

Discussed in this topic: [fd.find](#)<sup>[274]</sup>.

The [fd.find](#)<sup>[274]</sup> method allows you to quickly search through the file from a specified starting position, either in forward or back direction, and locate the Nth instance of a search substring. The method also allows you to specify the search "increment" (step). The search is performed on a currently selected file, and the

selection is made through the `fd.fileenum`<sup>273</sup> property.

The search returns the position within the file, counting from 1, where the target occurrence of the substring has been encountered, or 0 if the target occurrence of the substring was not found.

The increment parameter is very important as it allows you to perform two fundamentally different classes of search.

### Full text search

Set the increment to 1 and you will search through the entire contents of the file:

```
Dim dw As dword

'try to find the 2nd occurrence of 'ABC', search forward starting at the
beginning of the file
dw=fd.find(1,"ABC",2,FORWARD,1)
If fd.laststatus<>PL_FD_STATUS_OK Then
    'some disk-related error
Else
    If dw<>0 Then
        'found! process this...
    Else
        'not found...
    End If
```

Since the search substring in the above example -- "ABC" -- does not have repeating fragments, you can actually set the search increment to 3 (the length of the substring). This will improve the search speed:

```
fd.find(1,"ABC",2,FORWARD,3) 'no repeating fragments in the substring, use
its length as increment
```


### Record-style search

If the file in question is a data table consisting of individual records, then you can arrange for a very efficient search for the record with desired field value. All you need to achieve this is to have record fields occupy fixed offsets within records. For example, supposing you have the data table consisting of records with the following structure:

Field name	Offset in bytes*	Length in bytes
Category	+0	1
ID-code	+1	11
Last name	+12	21
First name	+43	21

\* with respect to the beginning of the record

Each record of this data table occupies 54 bytes, so this will be our step. Three fields -- "ID-code", "last name", and first name" are strings which, of course, can have a variable length. To facilitate the use of the `fd.find` method, each field must reside at a fixed offset relative to the beginning of the record. That is, even if the "ID-code" for a particular record is shorter than the maximum possible field length, the "Last name" field will still be at offset +12. To reflect actual length of the field data, each field of string type starts with a byte that denotes the length of the string, followed by the string data itself:



Now let's suppose you want to find a record whose "last name" is "Smith". For this we search starting from file offset 21, which is the offset of the "Last name" field within the record (this assumes that the first record starts right from the beginning of the file, which is usually the case). The search step will be 54 -- the size of the record:

```
Dim dw As dword

'try to find the record with the "Last name" set to "Smith"
dw=fd.find(21,chr(5)+"Smith",1,FORWARD,54) 'notice how we supply the string
length
If fd.laststatus<>PL_FD_STATUS_OK Then
    'some disk-related error
Else
    If dw<>0 Then
        'found- convert into the record number and process...
        dw=dw/54
    Else
        'not found...
    End If
```

You can also search back, but remember that this is less efficient (takes ~ 50% longer) compared to forward searches.

## Closing Files

Discussed in this topic: [fd.close](#)<sup>[269]</sup>, [fd.flush](#)<sup>[275]</sup>.

Files are closed using the [fd.close](#)<sup>[269]</sup> method. The method is performed on a currently selected file (selection is made through the [fd.fileenum](#)<sup>[273]</sup> property). Attempting to invoke this method "on" a file number that did not have any opened file associated with it generates no error.

Proper file closing is only required if you made changes to the file. If you only read

data from the file you don't have to bother closing it -- you can [open](#)<sup>[253]</sup> another file right "on" the same file number. Doing so on a file that was changed may cause some recent changes to be lost. To prevent this, use the `fd.close` method or [fd.flush](#)<sup>[275]</sup> method. Note that `fd.flush` does not depend on the current `fd.filenum` value and works globally on any most recently changed file.

It is not necessary to use `fd.flush` if your disk operations are performed within a [disk transaction](#)<sup>[259]</sup>.

## Using Disk Transactions

Discussed in this topic: [fd.transactionstart](#)<sup>[293]</sup>, [fd.transactioncommit](#)<sup>[293]</sup>, [fd.transactionstarted](#)<sup>[294]</sup>, [fd.transactioncapacityremaining](#)<sup>[292]</sup>.

Flash disk is a sensitive media. Many things can go wrong -- especially if a disk operation is abruptly interrupted due to the power failure or for some other reason. Try appending data to a file in a loop while power-cycling the device at random. It won't be long before the file, and even the disk itself become corrupted.

Many systems require reliable disk operation, even during random power cuts. For such systems, disk transactions are the answer!

Transactions help strengthen your application on two levels:

- **Disk level:** seemingly simple operations of the disk often involve complex internal changes to the disk data. Losing power while executing such operations may corrupt your files and the disk itself. Transactions make sure it won't happen.
- **Logical level:** there are often group operations that must be performed together (in synchronicity), or not at all. For example, you may have the data table file and its index file. Change the first one, and the other one must be changed too. Transactions allow you to effect such changes in unison and make sure that both files are changed or no files are changed at all.

Transactions only make sense for disk data changing operations. These are [fd.create](#)<sup>[271]</sup>, [fd.rename](#)<sup>[285]</sup>, [fd.delete](#)<sup>[272]</sup>, [fd.setattributes](#)<sup>[287]</sup>, [fd.setdata](#)<sup>[289]</sup>, [fd.setfilesize](#)<sup>[289]</sup>, and [fd.cutfromtop](#)<sup>[271]</sup>. Using transaction with `fd` object's methods that only read the data is pointless.

## Performing disk operations within transactions

Transactions are only possible when the flash disk is formatted with the [fd.formatj](#)<sup>[277]</sup> method, and the `maxjournalsectors` argument was `>1`. For good [disk leveling](#)<sup>[264]</sup>, choose this parameter to be in the 50-100 range, and definitely not below 17 (see the explanation [here](#)<sup>[261]</sup>).

To start a disk transaction, use the [fd.transactionstart](#)<sup>[293]</sup> method. To finish with the transaction and commit (save) all changes to the disk, invoke [fd.transactioncommit](#)<sup>[293]</sup>. Between these two statements, add any operations that lead to the changing of the disk data.

With transaction in progress, no changes are made to the disk data. Turn the power off before executing `fd.transactioncommit`, turn the power back on, mount the disk, and it will look as if the disk operations within the unfinished transaction have never happened. This is because all changed sectors are temporarily cached in the [journal area](#)<sup>[261]</sup> of the disk. Every sector that gets changed in the course of a transaction is saved to the journal, and not back to its original place. Invoking `fd.transactioncommit` starts the process of copying changed sectors from the

journal memory and into their original locations. This work can be safely interrupted. If the device loses power while committing changes, next [fd.mount](#)<sup>[283]</sup> will finish this job!

Here is a simple example:

```
fd.transactionstart
fd.setdata("write some data to a file")
fd.transactioncommit
```

It may seem that `fd.setdata` is a trivial operation, so why put it inside the transaction? In reality, performing this simple task may lead to changing of as many as [eight](#)<sup>[261]</sup> (!) sectors on the disk. If your device experiences a power failure while in the middle of writing to a file, then this file, and even the disk itself can become corrupted!

Here is another example, where we change two files. Encasing this within the transaction makes sure that both files are changed, or no files are changed at all:

```
'we presume that there are two files opened 'on' file numbers 0 and 1
fd.transactionstart
fd.filenum=0
fd.setdata("write some data to the first file")
fd.filenum=1
fd.setdata("write some more to the second file")
fd.transactioncommit
```

[Fd.transactionstarted](#)<sup>[294]</sup> exists so you can check if any disk transaction is already in progress. Executing `fd.transactioncommit` while `fd.transactionstarted=0`- NO general a non-fatal 13- PL\_FD\_STATUS\_TRANSACTION\_NOT\_YET\_STARTED [error](#)<sup>[239]</sup>. Executing `fd.transactionstart` when `fd.transactionstarted=1`- YES generates 12- PL\_FD\_STATUS\_TRANSACTION\_ALREADY\_STARTED non-fatal error code. 15- PL\_FD\_STATUS\_TRANSACTIONS\_NOT\_SUPPORTED non-fatal error is generated if the disk was formatted with [fd.format](#)<sup>[276]</sup>, or `maxjournalsectors` argument of [fd.formatj](#)<sup>[277]</sup> was set to 0 or 1.

You cannot abort the transaction that has already been started. If you started it, you must follow through with it. There is no need to execute [fd.flush](#)<sup>[275]</sup> when using disk transactions.

### Transaction journal has limited capacity

You can't just pile up a large number of disk write operations within a single transaction. This is because transactions have a limit: the number of sectors that can be changed within a single transaction. [Understanding Transaction Capacity](#)<sup>[261]</sup> provides further details.

### Direct sector access is not affected by transactions

[Fd.setsector](#)<sup>[290]</sup> and [fd.getsector](#)<sup>[281]</sup> always access the specified target sector and

not its cached copy even if the disk transaction is in progress the target sector has been cached already.

Discussed in this topic: [fd.transactioncapacityremaining](#)<sup>[292]</sup>.

[Fd.transactioncapacityremaining](#)<sup>[292]</sup> can tell you how many changed sectors the transaction journal can still accommodate. The initial value of the `fd.transactioncapacityremaining` (just after [fd.transactionstart](#)<sup>[293]</sup>) depends on two factors, whichever is smaller:

- The value of 16 (this is the absolute maximum).
- `Maxjournalsectors-1`, where `maxjournalsectors` is the argument of the [fd.formatj](#)<sup>[277]</sup> method.

The `maxjournalsectors` allocates the journal area of the flash disk. In this journal area, one sector is always needed for internal housekeeping, while other sectors cache the data sectors changed during the transaction. Therefore, if you want to achieve the maximum journal capacity (16), the journal must have at least 17 sectors in it. It is very important to use the maximum transaction memory capacity. The value of 16 is not random -- it guarantees that you will always be able, within a single transaction, to change the data in two different files.

In practice, do set a much higher journal size. This won't increase transaction memory, but it will [prolong](#)<sup>[264]</sup> the life of the flash IC. Values in the 50-100 range are recommended.

14- `PL_FD_STATUS_TRANSACTION_CAPACITY_EXCEEDED` [error](#)<sup>[239]</sup> will be generated if transaction capacity is exceeded by performing too many disk write operations within a single transaction. The disk will be dismounted (but not damaged) and all changes to the disk made within this failed transaction will be forgotten.

### Disk operations and the number of sectors they may affect

So how many sectors may be changed during various disk operations? The table below provides the worst-case numbers.

Fd. object's method that changes disk data	Maximum number of journal entries used
<a href="#">fd.create</a> <sup>[271]</sup>	$FRT * 2 + FAT * 2 + DATA = 5$
<a href="#">fd.rename</a> <sup>[285]</sup> , <a href="#">fd.setattributes</a> <sup>[287]</sup>	$FRT * 2 = 2$
<a href="#">fd.delete</a> <sup>[272]</sup> , <a href="#">fd.setfilesize</a> <sup>[289]</sup> , <a href="#">fd.cutfromtop</a> <sup>[271]*</sup>	$FRT * 2 + FAT * X * 2 = ?$
<a href="#">fd.setdata</a> <sup>[289]</sup>	$FRT * 2 + FAT * 2 * 2 + DATA * 2 = 8$

\* Executing these methods can potentially overflow the transaction journal.

And now, the explanation for the table data. It is based on the material from the [Disk Area Allocation Details](#)<sup>[246]</sup> topic.

- "FRT" means "one sector from the file records table". File records are changed when files are created, renamed, or deleted. They are also changed when the file

size changes, or when your application sets new file attributes.

- "FAT" -- "one sector from the file allocation table". File allocation sectors change when files are created and when file sectors are allocated or released in accordance with changing file sizes.
- "DATA" -- "one sector from the data sectors area of the disk". Data sectors hold actual file data. They change when you write new data to files.
- "FRT\*2" and "FAT\*2" are caused by [sector leveling](#)<sup>[264]</sup>: changing one FAT or FRT sector actually means changing two sectors.
- "DATA\*2" means that two data sectors can change when you write some data to the disk. This is because a portion of this data may reside in one data sectors, and the rest -- in another data sector.
- "X" parameter represents the number of *active* FAT sectors that can potentially be affected by invoking the corresponding method.

Here is how to calculate the X parameter:

Supposing, the flash disk capacity ([fd.capacity](#)<sup>[268]</sup>) is 1000 sectors. The FAT, then, must hold 1000 entries. Each FAT sector can hold 128 entries, so there will be 8 *active* FAT sectors ( $X = 8$ ). Do not confuse this with the *total* number of sectors in the FAT area -- it is at least twice this amount (because of [sector leveling](#)<sup>[264]</sup> measures). "8" here represents the number of FAT sectors that are needed at *any given time*.

[Fd.delete](#)<sup>[272]</sup>, [fd.setfilesize](#)<sup>[289]</sup>, and [fd.cutfromtop](#)<sup>[271]</sup> top have one thing in common: they can potentially cut a huge file (occupying the entire disk) to zero. In the process, X FAT sectors will be altered!

Therefore, for the disk with `fd.capacity=1000`, executing these methods can potentially change  $2+8*2=18$  sectors. This is above the maximum journal capacity, which is 16! So, how to avoid 14-PL\_FD\_STATUS\_TRANSACTION\_CAPACITY\_EXCEEDED [error](#)<sup>[239]</sup> and still use transactions?

And the answer is: do it in stages. The following example deletes a very large file in a "safe" manner:

```
dim i as byte

i=(fd.transactioncapacityremaining-1)/2 'this is how many FAT sectors we can
change at once
i=i*128 'and this is how many data sectors we can cut from the file at once
(one FAT sector holds 128 entries)

fd.open("FILE1")
while fd.filesize>0
    fd.transactionstart
    fd.cutfromtop(i)
    fd.transactioncommit
wend
fd.transactionstart
fd.delete("FILE1")
fd.transactioncommit
```

## Not a direct sum total

The worst-case number of sectors that may be changed during a transaction is *not* the sum total of maximum numbers for each `fd.` object's method. In the example below, the maximum number of changed sectors is 9, not 10.

```
fd.transactionstart
fd.setdata("write some data to a file") 'up to 8 sectors changed, and this
includes 2 change FRT sectors
fd.setattributes("ABC") 'FRT changes again, but for the same FRT record
(this will use only 1 entry in the journal)
fd.transactioncommit 'therefore, the total is up to 9
```

In this example, the worst-case number is 10, because we are working with 2 different files and their FRT records could be in different FRT sectors:

```
fd.transactionstart
fd.finenum=0
fd.setdata("write some data to a file") 'up to 8 sectors changed for file #0
fd.filenum=1
fd.setattributes("ABC") '2 FRT sectors changed for file #1
fd.transactioncommit 'therefore, the total is up to 10
```

## File-based and Direct Sector Access Coexistence

[File-based](#)<sup>[245]</sup> and [direct sector](#)<sup>[240]</sup> access methods can be used at the same time, as long as you understand how direct access may affect (and possibly *screw up*) the flash disk.

[Direct Sector Access](#)<sup>[240]</sup> explains that working with flash sectors is done through two RAM buffers numbered #0 and #1. Flash disk operation depends on these buffers as well.

Buffer #0 is used for processing housekeeping data and stores no valuable content that must be preserved past the end of a single disk-related method execution. That is, once the method such as the [fd.setdata](#)<sup>[289]</sup> has executed, buffer #0 has no valuable data in it.

Buffer #1 is used to load and store the contents of the most recently loaded (and possibly changed) data sector. So, if `fd.setdata` was recently called, this buffer may still hold new data, and this data may not be saved to the flash memory yet. Corrupting this unsaved data would have unpleasant consequences for the file. To prevent this, the `fd.` object automatically dismounts the disk (sets [fd.ready](#)<sup>[285]</sup>= 0-NO) if your application does [fd.setbuffer](#)<sup>[288]</sup> or [fd.getsector](#)<sup>[281]</sup> while the [fd.buffernum](#)<sup>[267]</sup>= 1 and while this buffer was loaded with *new and as yet unsaved* sector data.

Preventing disk dismounting is easy. You can opt to work on the RAM buffer #0 (set `fd.buffernum= 0`), or flush the unsaved data by invoking [fd.flush](#)<sup>[275]</sup> or [fd.close](#)<sup>[269]</sup>.

[Fd.setsector](#)<sup>[290]</sup> method will cause disk dismounting if the destination was within the disk area (sectors 0 through [fd.totalsize](#)<sup>[292]</sup>-1). Writing outside the disk area will not interfere with the flash disk operation.

The [fd.getbuffer](#)<sup>[278]</sup> method does not cause any interference with the flash disk, so

it can be used freely.

The [fd.checksum](#)<sup>[268]</sup> will write to the RAM buffer (when in the "PL\_FD\_CSUM\_MODE\_CALCULATE" mode), but the checksum calculation method is the same as the one used by the disk itself, so setting this checksum will never be wrong.

Note, finally, that any file-related method will affect the value of the `fd.buffernum`. Never assume that you know what this property is set to. Always set it explicitly and each time before performing direct sector access.

## Prolonging Flash Memory Life

Flash memory has a huge limitation -- the number of times you can rewrite each of its sectors is limited to around 100'000 times. At first this may seem like a virtually unreachable limit, but in reality you can "get there" quite fast, which is not a good thing. Once the flash wears down, you will start having data errors, data corruption, failed sectors, etc. This topic explains what you can do to prolong the life of the flash memory used in your device. This is generally achieved by (1) reducing the number of writes to the flash memory, and (2) using sector leveling, i.e. spreading sector writes, as evenly as possible, between the sectors.

### File-based access

For [file-based access](#)<sup>[245]</sup>, the `fd.` object does the bulk of work for you. We have already [explained](#)<sup>[246]</sup> that the file record table (FRT) and the file allocation table (FAT) -- the most heavily written to areas of the disk -- occupy at least double the space needed to store their data. They also have the minimum number of sectors they will take, regardless of what is necessary. This ensures that at any given time, the FRT and the FAT have spare sectors. These spare sectors, as well as occupied sectors, are in constant rotation. For example, every time you create a file, a change is made to one of the sectors of the FRT. This change requires writing data to one of the physical sectors. In the process, the `fd.` object will take the previously used FRT sector and "release it" into the pool of spare FRT sectors. At the same time, one of the spare FRT sectors will become active and store changed data. The FAT operates in the same manner. While being fully transparent to your application, the process greatly prolongs useful flash memory life.

You can, and are advised to, further reduce the wear of the FAT and FRT by decreasing the number of writes that will be required. One way to do so is to create all necessary files and allocate space for them once -- typically when your application "initializes" your device.

Say, you have a log file, which stores events collected by your application. An obvious approach would be to simply append each new event's data to the file. This way, the file will grow with each event added. But wait a second, this means that the FRT area, which keeps current file size, will be changed each time you add to the file! The FAT area will be stressed too!

An alternative approach would have us create a file of desired maximum size once and fill it up with "blank" data (such as `&hFF` codes). We will then overwrite this blank data with actual event data as events are generated. This time around, our actions will be causing no changes in the FRT and FAT areas, thus prolonging the life of the flash IC.

Not only this approach prolongs the life of the flash IC, but disk writing to the log will be faster (less sectors to change), and, in case you use [transactions](#)<sup>[259]</sup>, less [journal entries](#)<sup>[261]</sup> will be used (a single transaction can fit more operations).

When using transactions, do allow a generous space for the [journal memory](#)<sup>[261]</sup>. Recommended `maxjournalsectors` value for [fd.formatj](#)<sup>[277]</sup> is 50-100. Journal memory

is a high-traffic disk area, so having more sectors there will improve flash memory life.

The data area of the disk has limited leveling that results in spreading unused sector utilization. The fd. object makes sure that when your file needs a new data sector, this data sector will be selected from a pool of available data sectors in a random fashion. Once the data sector has been allocated to a file, however, it stays with that file for as long as necessary. So, if you are writing at a certain file offset over and over again, you are stressing the same physical sector of the flash IC.

On large files, you rarely write at the same offset all the time. For example, if you have a log file that has 1000 data sectors, then it is unlikely you will be writing to the same sector over and over again. For smaller files the probability is higher. Your solution is to erase the file and recreate it again from time to time. This will randomly allocate new sectors for the file.

**Direct sector access**

[Direct sector access](#)<sup>[240]</sup> is a low-level form of working with the flash. You are your own master, the fd. object does not help you with anything, and it is up to you to make sure that the flash IC is not being worn out unevenly. Generally speaking, limit the number of times you are writing to the flash and/or implement some form of leveling where a large number of sectors are used to share the same task and each sector gets its fair share of work.

**Properties and Methods**

The following classification groups properties and methods of the fd. object by their logical function.

Properties and methods under [fd.filenum](#)<sup>[273]</sup> are indented to reflect the fact that they are performed on the file currently selected by the fd.filenum.

Member	Type	Where to read about it
<b>Direct sector access</b>		
<a href="#">fd.buffernum</a> <sup>[267]</sup>	Property	<a href="#">Direct Sector Access</a> <sup>[240]</sup>
<a href="#">fd.getsector</a> <sup>[281]</sup>	Method	<a href="#">Direct Sector Access</a> <sup>[240]</sup>
<a href="#">fd.setsector</a> <sup>[290]</sup>	Method	<a href="#">Direct Sector Access</a> <sup>[240]</sup>
<a href="#">fd.getbuffer</a> <sup>[278]</sup>	Method	<a href="#">Direct Sector Access</a> <sup>[240]</sup>
<a href="#">fd.setbuffer</a> <sup>[288]</sup>	Method	<a href="#">Direct Sector Access</a> <sup>[240]</sup>
<a href="#">fd.checksum</a> <sup>[268]</sup>	Method	<a href="#">Using Checksums</a> <sup>[242]</sup>
<a href="#">fd.copyfirmware</a> <sup>[269]</sup>	Method	<a href="#">Upgrading the Firmware/Application</a> <sup>[243]</sup>
<a href="#">fd.copyfirmwarelzo</a> <sup>[270]</sup>	Method	<a href="#">Upgrading the Firmware/Application</a> <sup>[243]</sup>
<b>General disk info and operations</b>		
<a href="#">fd.availableflashspace</a> <sup>[267]</sup>	R/O property	
<a href="#">fd.maxopenedfiles</a> <sup>[282]</sup>	R/O property	<a href="#">Opening Files</a> <sup>[253]</sup>

<a href="#">fd.formatj</a> <sup>[277]</sup>	Method	<a href="#">Formatting the Flash Disk</a> <sup>[245]</sup>
<a href="#">fd.format</a> <sup>[276]</sup>	Method	<a href="#">Formatting the Flash Disk</a> <sup>[245]</sup>
<a href="#">fd.mount</a> <sup>[283]</sup>	Method	<a href="#">Mounting the Flash Disk</a> <sup>[249]</sup>
<a href="#">fd.ready</a> <sup>[285]</sup>	R/O propert y	<a href="#">Mounting the Flash Disk</a> <sup>[249]</sup>
<a href="#">fd.capacity</a> <sup>[268]</sup>	R/O propert y	<a href="#">Checking Disk Vitals</a> <sup>[249]</sup>
<a href="#">fd.numservicesectors</a> <sup>[284]</sup>	R/O propert y	<a href="#">Checking Disk Vitals</a> <sup>[249]</sup>
<a href="#">fd.totalsize</a> <sup>[292]</sup>	R/O propert y	<a href="#">Checking Disk Vitals</a> <sup>[249]</sup>
<a href="#">fd.getfreespace</a> <sup>[280]</sup>	Method	<a href="#">Checking Disk Vitals</a> <sup>[249]</sup>
<a href="#">fd.laststatus</a> <sup>[282]</sup>	R/O propert y	<a href="#">Fd. Object's Status Codes</a> <sup>[239]</sup>
<b>File directory</b>		
<a href="#">fd.maxstoredfiles</a> <sup>[283]</sup>	R/O propert y	<a href="#">Checking Disk Vitals</a> <sup>[249]</sup> , <a href="#">Creating, Deleting, and Renaming Files</a> <sup>[250]</sup>
<a href="#">fd.getnumfiles</a> <sup>[281]</sup>	Method	<a href="#">Checking Disk Vitals</a> <sup>[249]</sup> , <a href="#">Creating, Deleting, and Renaming Files</a> <sup>[250]</sup> , <a href="#">Walking Through File Directory</a> <sup>[252]</sup>
<a href="#">fd.resetdirpointer</a> <sup>[286]</sup>	Method	<a href="#">Walking Through File Directory</a> <sup>[252]</sup>
<a href="#">fd.getnextfirmember</a> <sup>[280]</sup>	Method	<a href="#">Walking Through File Directory</a> <sup>[252]</sup>
<a href="#">fd.getattributes</a> <sup>[278]</sup>	Method	<a href="#">Reading and Writing File Attributes</a> <sup>[251]</sup>
<a href="#">fd.setattributes</a> <sup>[287]</sup>	Method	<a href="#">Reading and Writing File Attributes</a> <sup>[251]</sup>
<a href="#">fd.create</a> <sup>[271]</sup>	Method	<a href="#">Creating, Deleting, and Renaming Files</a> <sup>[250]</sup>
<a href="#">fd.rename</a> <sup>[285]</sup>	Method	<a href="#">Creating, Deleting, and Renaming Files</a> <sup>[250]</sup>
<a href="#">fd.delete</a> <sup>[272]</sup>	Method	<a href="#">Creating, Deleting, and Renaming Files</a> <sup>[250]</sup>
<b>File access</b>		
<a href="#">fd.flush</a> <sup>[275]</sup>	Method	<a href="#">Closing Files</a> <sup>[258]</sup>
<a href="#">fd.filenum</a> <sup>[273]</sup>	Propert y	<a href="#">Opening Files</a> <sup>[253]</sup>
<a href="#">fd.open</a> <sup>[284]</sup>	Method	<a href="#">Opening Files</a> <sup>[253]</sup>
<a href="#">fd.close</a> <sup>[269]</sup>	Method	<a href="#">Closing Files</a> <sup>[258]</sup>
<a href="#">fd.fileopened</a> <sup>[273]</sup>	R/O propert y	<a href="#">Opening Files</a> <sup>[253]</sup>
<a href="#">fd.filesize</a> <sup>[274]</sup>	R/O propert y	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup>
<a href="#">fd.pointer</a> <sup>[285]</sup>	R/O	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup>

	property	
<a href="#">fd.setpointer</a> <sup>[291]</sup>	Method	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup>
<a href="#">fd.getdata</a> <sup>[279]</sup>	Method	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup>
<a href="#">fd.setdata</a> <sup>[289]</sup>	Method	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup>
<a href="#">fd.cutfromtop</a> <sup>[271]</sup>	Method	<a href="#">Removing Data From Files</a> <sup>[255]</sup>
<a href="#">fd.setfilesize</a> <sup>[289]</sup>	Method	<a href="#">Removing Data From Files</a> <sup>[255]</sup>
<a href="#">fd.find</a> <sup>[274]</sup>	Method	<a href="#">Searching Within Files</a> <sup>[256]</sup>
<a href="#">fd.sector</a> <sup>[287]</sup>	R/O property	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup>
<b>Transactions</b>		
<a href="#">fd.transactionstart</a> <sup>[293]</sup>	Method	<a href="#">Using Disk Transactions</a> <sup>[259]</sup>
<a href="#">fd.transactioncommit</a> <sup>[293]</sup>	Method	<a href="#">Using Disk Transactions</a> <sup>[259]</sup>
<a href="#">fd.transactionstarted</a> <sup>[294]</sup>	R/O property	<a href="#">Using Disk Transactions</a> <sup>[259]</sup>
<a href="#">fd.transactioncapacityremaining</a> <sup>[292]</sup>	R/O property	<a href="#">Using Disk Transactions</a> <sup>[259]</sup>

### .Availableflashspace R/O Property

<b>Function:</b>	Returns the total number of sectors available to store application's data.
<b>Type:</b>	Word
<b>Value Range:</b>	The value depends on the flash capacity and the flash memory arrangement of your device.
<b>See Also:</b>	<a href="#">Sharing Flash Between Your Application and Data</a> <sup>[237]</sup>

### Details

---

### .Buffernum Property

<b>Function:</b>	Sets/returns the number of the RAM buffer that will be used for direct sector access.
<b>Type:</b>	Byte
<b>Value Range:</b>	0 or 1. <b>Default</b> = 0 (RAM buffer #0 selected).
<b>See Also:</b>	<a href="#">Direct Sector Access</a> <sup>[240]</sup> , <a href="#">fd.getbuffer</a> <sup>[278]</sup> , <a href="#">fd.setbuffer</a> <sup>[288]</sup> , <a href="#">fd.getsector</a> <sup>[281]</sup> , <a href="#">fd.setsector</a> <sup>[290]</sup> , <a href="#">fd.checksum</a> <sup>[268]</sup> , <a href="#">fd.copyfirmware</a> <sup>[269]</sup> , <a href="#">fd.copyfirmwarelzo</a> <sup>[270]</sup>

### Details

All [file-based](#)<sup>[245]</sup> operations of the flash disk also load data into the RAM buffers. Switch to the RAM buffer #0 *each time* before performing [direct sector access](#)<sup>[240]</sup> with this or other related methods -- this will guarantee that you won't corrupt the files and/or the file system and cause disk dismounting ([fd.ready](#)<sup>[285]</sup> becoming 0-NO).

## .Capacity R/O Property

<b>Function:</b>	Returns the capacity, in sectors, of the currently existing flash disk.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535
<b>See Also:</b>	<a href="#">Checking Disk Vitals</a> <sup>[249]</sup> , <a href="#">fd.numservicesectors</a> <sup>[284]</sup> , <a href="#">fd.totalsize</a> <sup>[292]</sup> , <a href="#">fd.getfreespace</a> <sup>[280]</sup> , <a href="#">fd.maxstoredfiles</a> <sup>[283]</sup> , <a href="#">fd.getnumfiles</a> <sup>[281]</sup>

### Details

The disk must be mounted (see [fd.mount](#)<sup>[283]</sup>) for this property to return a meaningful value.

## .Checksum Method

<b>Function:</b>	Calculates and writes into the RAM buffer, or verifies the checksum for the data in the currently selected RAM buffer of the flash memory (selection is made through the <a href="#">fd.buffernum</a> <sup>[267]</sup> property).
<b>Syntax:</b>	<b>fd.checksum(mode as pl_fd_csum_mode, byref csum as word) as ok_ng</b>
<b>Returns:</b>	0- OK: Completed successfully (always the case when the mode= 1- PL_FD_CSUM_MODE_CALCULATE). 1- NG : The checksum was found to be invalid (can only be generated when the mode= 0- PL_FD_CSUM_MODE_VERIFY). Also returns the calculation result indirectly, through the csum argument.
<b>See Also:</b>	<a href="#">Using Checksums</a> <sup>[242]</sup> , <a href="#">Direct Sector Access</a> <sup>[240]</sup> , <a href="#">fd.buffernum</a> <sup>[267]</sup> , <a href="#">fd.getbuffer</a> <sup>[278]</sup> , <a href="#">fd.setbuffer</a> <sup>[288]</sup> , <a href="#">fd.getsector</a> <sup>[281]</sup> , <a href="#">fd.setsector</a> <sup>[290]</sup> , <a href="#">fd.copyfirmware</a> <sup>[269]</sup> , <a href="#">fd.copyfirmwarelzo</a> <sup>[270]</sup>

Part	Description
------	-------------

mod 0- PL\_FD\_CSUM\_MODE\_VERIFY: verify the checksum.  
 e 1- PL\_FD\_CSUM\_MODE\_CALCULATE: calculate the checksum and store it into the selected RAM buffer.  
 csu Indirectly returns calculated value. When the mode= 0-  
 m PL\_FD\_CSUM\_MODE\_VERIFY, this value returned will be 0 if the checksum was found to be correct, or some other value if the checksum was found to be wrong. When the mode= 1- PL\_FD\_CSUM\_MODE\_CALCULATE, the method will return a newly calculated checksum and store the same checksum into the RAM buffer.

### Details

---

## **.Close Method**

**Function:** Closes the file opened "on" a currently selected file number (selection is made through [fd.filenum](#)<sup>[273]</sup>).

**Syntax:** **fd.close()** as **pl\_fd\_status\_codes**

**Returns:** One of the following [pl fd status codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:  
 0- PL\_FD\_STATUS\_OK: Completed successfully.  
 1- PL\_FD\_STATUS\_FAIL: Physical flash memory failure (fatal).

**See Also:** [Closing Files](#)<sup>[258]</sup>,  
[fd.flush](#)<sup>[275]</sup>

### Details

Invoking the method also does the job performed by the [fd.flush](#)<sup>[275]</sup> method (and this is why the 1- PL\_FD\_STATUS\_FAIL status code may be returned here).

Attempting to invoke this method "on" a file number that did not have any opened file associated with it generates no error.

## **.Copyfirmware Method**

**Function:** Copies the specified number of sectors (starting from logical sector 0) from the data area, and into the firmware/application area (starting from physical sector 0) of the flash memory, then reboots the device to make it run the new firmware/application.

**Syntax:** **fd.copyfirmware(numsectors as word)**

**Returns:** ---

**See Also:** [Upgrading the Firmware/Application](#)<sup>[243]</sup>, [Direct Sector Access](#)<sup>[240]</sup>  
[fd.buffernum](#)<sup>[267]</sup>, [fd.getbuffer](#)<sup>[278]</sup>, [fd.setbuffer](#)<sup>[288]</sup>,  
[fd.getsector](#)<sup>[281]</sup>, [fd.setsector](#)<sup>[290]</sup>, [fd.checksum](#)<sup>[268]</sup>,

[fd.copyfirmwarelzo](#)<sup>[270]</sup>

Part	Description
num	Number of sectors to copy.
sect	
ors	

### Details

Certain platforms do not support this method. Refer to your [platform documentation](#)<sup>[138]</sup> for details.

- **BE VERY CAREFUL!** Using the fd.copyfirmware on incorrect data will "incapacitate" your device and further remote upgrades will become impossible. You will need to physically go to your device and upload correct firmware and/or application, possibly through its serial port. Scary, huh?

## .Copyfirmwarelzo Method

<b>Function:</b>	Assumes that there is LZO-compressed firmware/application file of length bytes stored at logical sector 0 of the flash memory. Decompresses the file into the firmware/application area (starting from physical sector 0), then reboots the device to make it run the new firmware/application.
<b>Syntax:</b>	<b>fd.copyfirmware(byref length as dword)</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Upgrading the Firmware/Application</a> <sup>[243]</sup> , <a href="#">Direct Sector Access</a> <sup>[240]</sup> , <a href="#">fd.buffernum</a> <sup>[267]</sup> , <a href="#">fd.getbuffer</a> <sup>[278]</sup> , <a href="#">fd.setbuffer</a> <sup>[288]</sup> , <a href="#">fd.getsector</a> <sup>[281]</sup> , <a href="#">fd.setsector</a> <sup>[290]</sup> , <a href="#">fd.checksum</a> <sup>[268]</sup> , <a href="#">fd.copyfirmware</a> <sup>[269]</sup>

Part	Description
lengt	Compressed data length in bytes.
h	

### Details

Certain platforms do not support this method. Refer to your [platform documentation](#)<sup>[138]</sup> for details.

The decompression algorithm accepts files compressed with **lzo1x-999.exe** utility.

- **BE VERY CAREFUL!** Using the fd.copyfirmwarelzo on incorrect data will

"incapacitate" your device and further remote upgrades will become impossible. You will need to physically go to your device and upload correct firmware and/or application, possibly through its serial port. Scary, huh?

## .Cutfromtop Method

- Function:** Removes a specified number of sectors from the beginning of a file opened "on" a currently selected file number (selection is made through [fd.filenum](#)<sup>[273]</sup>).
- Syntax:** **fd.cutfromtop**(numsectors **as dword**) **as pl\_fd\_status\_codes**
- Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.
  - 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
  - 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
  - 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).
  - 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
  - 14- PL\_FD\_STATUS\_TRANSACTION\_CAPACITY\_EXCEEDED: Too many disk sectors have been modified in the cause of the current transaction (fatal).
- See Also:** [Removing Data From Files](#)<sup>[255]</sup>, [fd.setfilesize](#)<sup>[289]</sup>

Part	Description
numsectors	Number of sectors to remove from the beginning of the file. Supplied value will be corrected downwards if exceeded the total number of sectors allocated to this file.

### Details

As a result of this method invocation, the pointer will be set to 0 if the file becomes empty, or 1 if the file still has some data in it.

This method makes changes to the sectors of the flash disk. For the highest possible reliability, use [disk transactions](#)<sup>[259]</sup> when invoking this method.

## .Create Method

- Function:** Creates a new file with the specified name and attributes.
- Syntax:** **fd.create**(byref name\_attr **as string**) **as pl\_fd\_status\_codes**
- Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.

- 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
- 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
- 4- PL\_FD\_STATUS\_INV\_PARAM: Invalid argument have been provided.
- 5- PL\_FD\_STATUS\_DUPLICATE\_NAME: File with this name already exists.
- 6- PL\_FD\_STATUS\_FILE\_TABLE\_FULL: Maximum number of files that can be stored on the disk has been reached, new file cannot be created.
- 7- PL\_FD\_STATUS\_DATA\_FULL: The disk is full, new data cannot be added.
- 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
- 14- PL\_FD\_STATUS\_TRANSACTION\_CAPACITY\_EXCEEDED: Too many disk sectors have been modified in the cause of the current transaction (fatal).

**See Also:**

[Creating, Deleting, and Renaming Files](#)<sup>[250]</sup>, [File Names and Attributes](#)<sup>[249]</sup>,

[fd.rename](#)<sup>[285]</sup>, [fd.delete](#)<sup>[272]</sup>, [fd.getnumfiles](#)<sup>[281]</sup>,  
[fd.maxstoredfiles](#)<sup>[283]</sup>

Part	Description
name_attribute	A string (1-56 characters), must contain a file name and, optionally, attributes separated from the file name by a space. File names are case-sensitive.

**Details**

This method makes changes to the sectors of the flash disk. For the highest possible reliability, use [disk transactions](#)<sup>[259]</sup> when invoking it.

**.Delete Method**

- Function:** Deletes a file with the specified file name from the flash disk.
- Syntax:** **fd.delete(byref name as string) as pl\_fd\_status\_codes**
- Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.
  - 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
  - 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
  - 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).

- 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
- 9- PL\_FD\_STATUS\_NOT\_FOUND: File not found.
- 14- PL\_FD\_STATUS\_TRANSACTION\_CAPACITY\_EXCEEDED: Too many disk sectors have been modified in the cause of the current transaction (fatal).

**See Also:** [Creating, Deleting, and Renaming Files](#)<sup>[250]</sup>, [File Names and Attributes](#)<sup>[249]</sup>,  
[fd.create](#)<sup>[271]</sup>, [fd.rename](#)<sup>[285]</sup>, [fd.getnumfiles](#)<sup>[281]</sup>,  
[fd.maxstoredfiles](#)<sup>[283]</sup>

Part	Description
name	A string (1-56 characters) with the file name. All characters after the first space encountered (excluding leading spaces) will be ignored. File names are case-sensitive.

**Details**

This method makes changes to the sectors of the flash disk. For the highest possible reliability, use [disk transactions](#)<sup>[259]</sup> when invoking it.

**.Filenum Property**

**Function:** Sets/returns the number of the currently selected file.  
**Type:** Byte  
**Value Range:** 0 to [fd.maxopenedfiles](#)<sup>[282]</sup>-1. **Default**= 0 (file #0 selected)  
**See Also:** [Opening Files](#)<sup>[253]</sup>,  
[fd.open](#)<sup>[284]</sup>

**Details**

---

**.Fileopened R/O Property**

**Function:** Reports if any file is currently opened "on" the selected file number (selection is made through [fd.fileenum](#)<sup>[273]</sup>).  
**Type:** Enum (no\_yes, byte)  
**Value Range:** 0- NO: No file is currently opened on this file number (**default**).  
1- YES: The file is currently opened on this file number.  
**See Also:** [Opening Files](#)<sup>[253]</sup>,

[fd.filenum](#)<sup>[273]</sup>, [fd.open](#)<sup>[284]</sup>, [fd.maxopenedfiles](#)<sup>[282]</sup>

---

## Details

---

### .Filesize R/O Property

<b>Function:</b>	Returns the size, in bytes, of the file opened "on" the currently selected file number (selection is made through the <a href="#">fd.filenum</a> <sup>[273]</sup> ). Returns zero if no file is currently opened.
<b>Type:</b>	Dword
<b>Value Range:</b>	0 to "whatever is physically possible for the currently existing flash disk".
<b>See Also:</b>	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup> , <a href="#">fd.getdata</a> <sup>[279]</sup> , <a href="#">fd.setdata</a> <sup>[289]</sup> , <a href="#">fd.pointer</a> <sup>[285]</sup> , <a href="#">fd.setpointer</a> <sup>[291]</sup>

---

## Details

---

### .Find Method

<b>Function:</b>	Finds the Nth instance of data satisfying selected criteria in a file opened "on" a currently selected file number (selection is made through <a href="#">fd.filenum</a> <sup>[273]</sup> ).
<b>Syntax:</b>	<b>fd.find</b> (frompos <b>as dword</b> , byref substr <b>as string</b> , instance <b>as word</b> , dir <b>as forward_back</b> , incr <b>as word</b> , mode <b>as pl_fd_find_modes</b> ) <b>as dword</b>
<b>Returns:</b>	File position (counting from one) at which the target occurrence of the substr was discovered, or 0 if the target occurrence of the substr was not found. The method also affects the state of the <a href="#">fd.laststatus</a> <sup>[282]</sup> . The following status codes are possible: 0- PL_FD_STATUS_OK: Completed successfully. 1- PL_FD_STATUS_FAIL : Physical flash memory failure (fatal). 2- PL_FD_STATUS_CHECKSUM_ERR: Checksum error has been detected in one of the disk sectors (fatal). 3- PL_FD_STATUS_FORMAT_ERR: Disk formatting error has been detected (fatal). 4- PL_FD_STATUS_INV_PARAM: Invalid argument have been provided. 8- PL_FD_STATUS_NOT_READY: The disk is not mounted.
<b>See Also:</b>	<a href="#">Searching Files</a> <sup>[256]</sup>

Part	Description
frompos	Starting position in a file from which the search will be conducted. File positions are counted from 1. Will be corrected automatically if out of range.
substr	The string to search for.
instance	Instance (occurrence) number to find.
dir	Search direction: 0- FORWARD: the search will be conducted from the frompos position and towards the end of the file. 1- BACK: the search will be conducted from the frompos position and towards the beginning of the file.
incr	Search position increment (or decrement for BACK searches).
mode	Search mode: 0- PL_FD_FIND_EQUAL: Find data that is equal to the substr. 1- PL_FD_FIND_NOT_EQUAL: Find data that is not equal to the substr. 2- PL_FD_FIND_GREATER: Find data with value greater than the value of the substr. 3- FIND_GREATER_EQUAL: Find data with value greater than or equal to the value of the substr. 4- PL_FD_FIND_LESSER: Find data with value less than the value of the substr. 4- PL_FD_FIND_LESSER_EQUAL: Find data with value less than or equal to the value of the substr.

## Details

---

### **.Flush Method**

<b>Function:</b>	Saves back to the flash memory ("flushes") the changes made to the most recently edited file.
<b>Syntax:</b>	<b>fd.close() as pl_fd_status_codes</b>
<b>Returns:</b>	One of the following <a href="#">pl_fd_status_codes</a> <sup>[282]</sup> , also affects the status of <a href="#">fd.laststatus</a> <sup>[282]</sup> : 0- PL_FD_STATUS_OK: Completed successfully. 1- PL_FD_STATUS_FAIL: Physical flash memory failure (fatal).
<b>See Also:</b>	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup> (see "File Data Caching!"), <a href="#">Closing Files</a> <sup>[258]</sup> ,

[fd.close](#)<sup>[269]</sup>

### Details

The `fd.flush` method does not depend on the current [fd.filenum](#)<sup>[273]</sup> value and works globally on any most recently changed file.

Executing [fd.close](#)<sup>[269]</sup> also does the job of `fd.flush`.

It is not necessary to use `fd.flush` if your disk operations are performed within a [disk transaction](#)<sup>[259]</sup>.

## .Format Method

- Function:** Formats the flash memory to create a flash disk; no [transaction journal](#)<sup>[259]</sup> sectors will be allocated.
- Syntax:** **fd.format**(totalsize **as word**, numstoredfiles **as byte**) **as pl\_fd\_status\_codes**
- Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.
  - 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
  - 4- PL\_FD\_STATUS\_INV\_PARAM: Invalid argument have been provided for the invoked method.
  - 16- PL\_FD\_STATUS\_FLASH\_NOT\_DETECTED: Flash IC wasn't detected during boot, fd. object cannot operate normally.
- See Also:** [Formatting the Flash Disk](#)<sup>[245]</sup>, [Checking Disk Vitals](#)<sup>[249]</sup>, [fd.mount](#)<sup>[283]</sup>, [fd.ready](#)<sup>[285]</sup>

Part	Description
totalsize	Desired number of sectors occupied by the disk in flash memory. Cannot exceed available space ( <a href="#">fd.availableflashspace</a> <sup>[267]</sup> ) and may be slightly corrected downwards for internal housekeeping reasons. Actual total size can be checked through the <a href="#">fd.totalsize</a> <sup>[292]</sup> .
maxstoredfiles	Desired maximum number of files that the disk will allow to create. Actual maximum number of files will be adjusted automatically to be a multiple of four and not exceed 64 (for example, specifying 6 will result in the actual value of 8). If you specify 0 you will get 4 files.

### Details

`Fd.format` will not allocate and transaction journal sectors, so [disk transactions](#)<sup>[259]</sup> will be impossible. Use [fd.formatj](#)<sup>[277]</sup> (recommended) to create the disk that will support transaction.

After formatting the disk will be in the dismounted state and will need to be mounted (see [fd.mount](#)<sup>[283]</sup>) before any disk-related activity can be successfully performed.

## .Formatj Method

<b>Function:</b>	Formats the flash memory to create a flash disk.
<b>Syntax:</b>	<b>fd.format</b> (totalsize <b>as word</b> , numstoredfiles <b>as byte</b> , maxjournalsectors <b>as byte</b> ) <b>as pl_fd_status_codes</b>
<b>Returns:</b>	One of the following <a href="#">pl_fd_status_codes</a> <sup>[282]</sup> , also affects <a href="#">fd.laststatus</a> <sup>[282]</sup> : 0- PL_FD_STATUS_OK: Completed successfully. 1- PL_FD_STATUS_FAIL : Physical flash memory failure (fatal). 4- PL_FD_STATUS_INV_PARAM: Invalid argument have been provided for the invoked method. 16- PL_FD_STATUS_FLASH_NOT_DETECTED: Flash IC wasn't detected during boot, fd. object cannot operate normally.
<b>See Also:</b>	<a href="#">Formatting the Flash Disk</a> <sup>[245]</sup> , <a href="#">Checking Disk Vitals</a> <sup>[249]</sup> , <a href="#">fd.mount</a> <sup>[283]</sup> , <a href="#">fd.ready</a> <sup>[285]</sup>

Part	Description
totalsize	Desired number of sectors occupied by the disk in flash memory. Cannot exceed available space ( <a href="#">fd.availableflashspace</a> <sup>[267]</sup> ) and may be slightly corrected downwards for internal housekeeping reasons. Actual total size can be checked through the <a href="#">fd.totalsize</a> <sup>[292]</sup> .
maxstoredfiles	Desired maximum number of files that the disk will allow to create. Actual maximum number of files will be adjusted automatically to be a multiple of four and not exceed 64 (for example, specifying 6 will result in the actual value of 8). If you specify 0 you will get 4 files.
maxjournalsectors	Number of sectors to allocate for the <a href="#">transaction journal</a> <sup>[259]</sup> . Give this disk area a generous number of sectors, possibly 50-100. Do not set below 17 -- this will limit the transaction capacity of the journal. Setting this parameter to 0 or 1 disables disk transactions completely.

### Details

After formatting the disk will be in the dismounted state and will need to be mounted (see [fd.mount](#)<sup>[283]</sup>) before any disk-related activity can be successfully performed.

## .Getattributes Method

- Function:** Returns the attributes string for a file with the specified file name.
- Syntax:** **fd.getattributes(byref name as string) as string**
- Returns:** The string with attributes (may be up to 54 characters long) or an empty string if no attributes were set for this file. The method also affects the state of [fd.laststatus](#)<sup>[282]</sup>. The following status codes are possible:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.
  - 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
  - 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
  - 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).
  - 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
  - 9- PL\_FD\_STATUS\_NOT\_FOUND: File not found.
- See Also:** [Reading and Writing File Attributes](#)<sup>[251]</sup>, [Creating, Deleting, and Renaming Files](#)<sup>[250]</sup>, [File Names and Attributes](#)<sup>[249]</sup>, [fd.setattributes](#)<sup>[287]</sup>, [fd.create](#)<sup>[271]</sup>

Part	Description
name	A string (1-56 characters) with the file name. All characters after the first space encountered (excluding leading spaces) will be ignored. File names are case-sensitive.

### Details

---

## .Getbuffer Method

- Function:** Reads the specified number of bytes from the currently selected RAM buffer of the flash memory (selection is made through the [fd.buffernum](#)<sup>[267]</sup> property).
- Syntax:** **fd.getbuffer(offset as word, len as word) as string**
- Returns:** The string with the data from the buffer.
- See Also:** [Direct Sector Access](#)<sup>[240]</sup>, [fd.buffernum](#)<sup>[267]</sup>, [fd.setbuffer](#)<sup>[288]</sup>, [fd.getsector](#)<sup>[281]</sup>, [fd.setsector](#)<sup>[290]</sup>, [fd.checksum](#)<sup>[268]</sup>, [fd.copyfirmware](#)<sup>[269]</sup>, [fd.copyfirmwarelzo](#)<sup>[270]</sup>

Part	Description
offset	Starting offset in the buffer. Possible value range is 0-263 (the buffer stores 264 bytes of data, offset is counted from 0).
len	Number of bytes to read. The length of returned data will depend on one of three factors, whichever is smaller: <i>len</i> argument, amount of data still available in the buffer counting from the <i>offset</i> position, and the capacity of receiving string variable.

### Details

---

## .Getdata Method

<b>Function:</b>	Reads a specified number of bytes from the file opened "on" a currently selected file number (selection is made through <a href="#">fd.filenum</a> <sup>[273]</sup> ). The data is read starting at the <a href="#">fd.pointer</a> <sup>[285]</sup> position.
<b>Syntax:</b>	<b>fd.getdata(maxinplen as byte) as string</b>
<b>Returns:</b>	The string with the data read from the file. The method also affects the state of <a href="#">fd.laststatus</a> <sup>[282]</sup> . The following status codes are possible: <ul style="list-style-type: none"> <li>0- PL_FD_STATUS_OK: Completed successfully.</li> <li>1- PL_FD_STATUS_FAIL : Physical flash memory failure (fatal).</li> <li>2- PL_FD_STATUS_CHECKSUM_ERR: Checksum error has been detected in one of the disk sectors (fatal).</li> <li>3- PL_FD_STATUS_FORMAT_ERR: Disk formatting error has been detected (fatal).</li> <li>8- PL_FD_STATUS_NOT_READY: The disk is not mounted.</li> <li>10- PL_FD_STATUS_NOT_OPENED: No file is currently opened "on" the current value of the <a href="#">fd.filenum</a><sup>[273]</sup> property.</li> </ul>
<b>See Also:</b>	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup> , <a href="#">fd.setdata</a> <sup>[289]</sup> , <a href="#">fd.pointer</a> <sup>[285]</sup> , <a href="#">fd.setpointer</a> <sup>[291]</sup> , <a href="#">fd.filesize</a> <sup>[274]</sup>

Part	Description
maxinplen	Maximum number of bytes to read from the file. The length of returned data will depend on one of three factors, whichever is smaller: maxinplen argument, amount of data still available in the file counting from the current pointer position, and the capacity of receiving string variable.

### Details

As a result of this method invocation, the pointer will be advanced forward by the

number of bytes actually read from the file.

## .Getfreespace Method

- Function:** Returns the total number of free data sectors available on the flash disk.
- Syntax:** **fd.getfreespace() as word**
- Returns:** 0-65535, also affects the state of [fd.laststatus](#)<sup>[282]</sup>. The following status codes are possible:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.
  - 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
  - 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
  - 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).
  - 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
- See Also:** [Checking Disk Vitals](#)<sup>[249]</sup>,  
[fd.capacity](#)<sup>[268]</sup>, [fd.numservicesectors](#)<sup>[284]</sup>, [fd.totalsize](#)<sup>[292]</sup>,  
[fd.maxstoredfiles](#)<sup>[283]</sup>, [fd.getnumfiles](#)<sup>[281]</sup>

---

### Details

One data sectors carries 256 bytes of file data. Each existing file occupies at least one data sector, even if the file is empty.

The disk must be mounted (see [fd.mount](#)<sup>[283]</sup>) for this property to return a meaningful value.

## .Getnextdirmember Method

- Function:** Returns the next filename (if any) found in the disk directory.
- Syntax:** **fd.getnextdirmember() as string**
- Returns:** The string containing the file name of the next directory member or an empty string if all file names have already been returned. The method also affects the state of [fd.laststatus](#)<sup>[282]</sup>. The following status codes are possible:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.
  - 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
  - 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
  - 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).
  - 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
- See Also:** [Walking Through File Directory](#)<sup>[252]</sup>,  
[fd.resetdirpointer](#)<sup>[286]</sup>, [fd.getnumfiles](#)<sup>[281]</sup>

## Details

---

### **.Getnumfiles Method**

- Function:** Returns the total number of files currently stored on the disk.
- Syntax:** **fd.getfreespace()** as word
- Returns:** 0-65535, also affects the state of [fd.laststatus](#)<sup>[282]</sup>. The following status codes are possible:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.
  - 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
  - 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
  - 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).
  - 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
- See Also:** [Creating, Deleting, and Renaming Files](#)<sup>[250]</sup>, [Walking Through File Directory](#)<sup>[252]</sup>, [Checking Disk Vitals](#)<sup>[249]</sup>, [fd.capacity](#)<sup>[268]</sup>, [fd.numservicesectors](#)<sup>[284]</sup>, [fd.totalsize](#)<sup>[292]</sup>, [fd.getfreespace](#)<sup>[280]</sup>, [fd.maxstoredfiles](#)<sup>[283]</sup>

## Details

The disk must be mounted (see [fd.mount](#)<sup>[283]</sup>) for this property to return a meaningful value.

### **.Getsector Method**

- Function:** Reads the entire 264 bytes from the specified sector into the currently selected RAM buffer of the flash memory (selection is made through the [fd.buffernum](#)<sup>[267]</sup> property).
- Syntax:** **fd.getsector(num as word) as pl\_fd\_status\_codes**
- Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects the state of [fd.laststatus](#)<sup>[282]</sup>:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.
  - 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
  - 16- PL\_FD\_STATUS\_FLASH\_NOT\_DETECTED: Flash IC wasn't detected during boot, fd. object cannot operate normally.
- See Also:** [Direct Sector Access](#)<sup>[240]</sup>, [File-based and Direct Sector Access Coexistence](#)<sup>[263]</sup>

[fd.buffernum](#)<sup>[267]</sup>, [fd.getbuffer](#)<sup>[278]</sup>, [fd.setbuffer](#)<sup>[288]</sup>,  
[fd.setsector](#)<sup>[290]</sup>, [fd.checksum](#)<sup>[268]</sup>, [fd.copyfirmware](#)<sup>[269]</sup>,  
[fd.copyfirmwarelzo](#)<sup>[270]</sup>

Part	Description
num	<i>Logical</i> number of the sector to read from (logical numbers are in reverse: reading from the logical sector 0 actually means reading from the last physical sector of the flash IC).

### Details

All [file-based](#)<sup>[245]</sup> operations of the flash disk also load data into the RAM buffers. Switch to the RAM buffer #0 *each time* before performing [direct sector access](#)<sup>[240]</sup> with this or other related methods -- this will guarantee that you won't corrupt the files and/or the file system and cause disk dismounting ([fd.ready](#)<sup>[285]</sup> becoming 0-NO).

This method always accesses the actual specified target sector and not its cached copy even if the [disk transaction](#)<sup>[259]</sup> is in progress ([fd.transactionstarted](#)<sup>[294]</sup> = 1-YES) and the target sector has been cached already.

## .Laststatus R/O Property

<b>Function:</b>	Returns the execution result for the most recent disk-related method execution.
<b>Type:</b>	Enum (pl_fd_status_code, byte)
<b>Value Range:</b>	Many different fatal and non-fatal conditions are returned -- see <a href="#">Fd. Object's status codes</a> <sup>[239]</sup> for details.
<b>See Also:</b>	<a href="#">Fd. Object's Status Codes</a> <sup>[239]</sup>

### Details

Some methods, such as [fd.create](#)<sup>[271]</sup>, return execution status directly. For those, the fd.laststatus will contain the same status as the one directly returned.

Other methods return some other data. For example, [fd.getdata](#)<sup>[279]</sup> returns the data requested (or an empty string if something went wrong). The execution result for such methods can only be verified through this R/O property.

Note that some errors are fatal and the disk is dismounted ([fd.ready](#)<sup>[285]</sup> is set to 0-NO) immediately upon the detection of any such fatal error.

## .Maxopenedfiles R/O Property

<b>Function:</b>	Returns the total number of files that can be simultaneously opened by your application.
<b>Type:</b>	Byte
<b>Value Range:</b>	Platform-dependent.

**See Also:** [Opening Files](#)<sup>[253]</sup>,  
[fd.filenum](#)<sup>[273]</sup>, [fd.open](#)<sup>[284]</sup>, [fd.fileopened](#)<sup>[273]</sup>

---

### Details

The value of this property depends on the hardware (selected [platform](#)<sup>[138]</sup>) and has nothing to do with the formatting of your flash disk.

## **.Maxstoredfiles R/O Property**

**Function:** Returns the total number of files that can be simultaneously stored on the currently existing flash disk.

**Type:** Byte

**Value Range:** Value depends on the current disk formatting.

**See Also:** [Formatting the Flash Disk](#)<sup>[245]</sup>, [Creating, Deleting, and Renaming Files](#)<sup>[250]</sup>, [Checking Disk Vitals](#)<sup>[249]</sup>,  
[fd.capacity](#)<sup>[268]</sup>, [fd.numservicesectors](#)<sup>[284]</sup>, [fd.totalsize](#)<sup>[292]</sup>,  
[fd.getfreespace](#)<sup>[280]</sup>, [fd.getnumfiles](#)<sup>[281]</sup>

---

### Details

This number cannot be changed unless the disk is reformatted (see [fd.formatj](#)<sup>[277]</sup>). The disk must be mounted (see [fd.mount](#)<sup>[283]</sup>) for this property to return a meaningful value.

## **.Mount Method**

**Function:** Mounts (prepares for use) the flash disk already existing in the flash memory.

**Syntax:** **fd.format()** as **pl\_fd\_status\_codes**

**Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:

- 0- PL\_FD\_STATUS\_OK: Completed successfully.
- 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
- 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
- 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
- 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).
- 16- PL\_FD\_STATUS\_FLASH\_NOT\_DETECTED: Flash IC wasn't detected during boot, fd. object cannot operate normally.

**See Also:** [Mounting the Flash Disk](#)<sup>[249]</sup>,

[fd.format](#)<sup>[277]</sup>, [fd.ready](#)<sup>[285]</sup>

---

### Details

This method also finishes the [transaction commit job](#)<sup>[259]</sup> if it was started with the [fd.transactioncommit](#)<sup>[293]</sup> method and wasn't completed properly due to the power failure or some other reason.

## **.Numservicesectors R/O Property**

**Function:** Returns the total number of sectors occupied by the "housekeeping" data of the currently existing flash disk.

**Type:** Byte

**Value Range:** Value depends on the current disk formatting.

**See Also:** [Checking Disk Vitals](#)<sup>[249]</sup>, [Disk Area Allocation Details](#)<sup>[246]</sup>, [fd.capacity](#)<sup>[268]</sup>, [fd.totalsize](#)<sup>[292]</sup>, [fd.getfreespace](#)<sup>[280]</sup>, [fd.maxstoredfiles](#)<sup>[283]</sup>, [fd.getnumfiles](#)<sup>[281]</sup>

---

### Details

The disk must be mounted (see [fd.mount](#)<sup>[283]</sup>) for this property to return a meaningful value.

## **.Open Method**

**Function:** Opens a file with a specified name "on" a currently selected file number (selection is made through [fd.fileenum](#)<sup>[273]</sup>).

**Syntax:** **fd.open(byref name as string) as pl\_fd\_status\_codes**

**Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:

- 0- PL\_FD\_STATUS\_OK: Completed successfully.
- 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
- 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
- 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).
- 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
- 9- PL\_FD\_STATUS\_NOT\_FOUND: File not found.
- 11- PL\_FD\_STATUS\_ALREADY\_OPENED: This file is already opened "on" some other file number.

**See Also:** [Opening Files](#)<sup>[253]</sup>, [fd.fileenum](#)<sup>[273]</sup>, [fd.fileopened](#)<sup>[273]</sup>, [fd.maxopenedfiles](#)<sup>[282]</sup>

Part	Description
name	A string (1-56 characters) with the file name. All characters after the first space encountered (excluding leading spaces) will be ignored. File names are case-sensitive.

### Details

---

## .Pointer R/O Property

<b>Function:</b>	Returns the pointer position for the file opened "on" the currently selected file number (selection is made through <a href="#">fd.fileenum</a> <sup>[273]</sup> ). Returns zero if no file is currently opened or the file is empty.
<b>Type:</b>	Dword
<b>Value Range:</b>	0 to <a href="#">fd.filesize</a> <sup>[274]</sup> +1 (except for fd.filesize= 0, in which case fd.pointer= 0 too).
<b>See Also:</b>	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup> , <a href="#">fd.getdata</a> <sup>[279]</sup> , <a href="#">fd.setdata</a> <sup>[289]</sup> , <a href="#">fd.setpointer</a> <sup>[291]</sup> , <a href="#">fd.filesize</a> <sup>[274]</sup>

### Details

---

## .Ready R/O Property

<b>Function:</b>	Informs whether the flash disk is mounted and ready for use.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO: The disk is not mounted and not ready for use <b>(default)</b> . 1- YES: The disk is mounted and ready for use.
<b>See Also:</b>	<a href="#">Mounting the Flash Disk</a> <sup>[249]</sup> , <a href="#">fd.formatj</a> <sup>[277]</sup> , <a href="#">fd.mount</a> <sup>[283]</sup>

### Details

---

## .Rename Method

<b>Function:</b>	Renames a file specified by its name.
<b>Syntax:</b>	<b>fd.create</b> (byref old_name as string, byref new_name as

**string) as pl\_fd\_status\_codes****Returns:**

One of the following [pl fd status codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:

- 0- PL\_FD\_STATUS\_OK: Completed successfully.
- 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
- 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
- 4- PL\_FD\_STATUS\_INV\_PARAM: Old\_name is a NULL string, which is not allowed.
- 5- PL\_FD\_STATUS\_DUPLICATE\_NAME: File with the new\_name already exists.
- 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
- 9- PL\_FD\_STATUS\_NOT\_FOUND: The old\_name file is not found.
- 14- PL\_FD\_STATUS\_TRANSACTION\_CAPACITY\_EXCEEDED: Too many disk sectors have been modified in the cause of the current transaction (fatal).

**See Also:**

[Creating, Deleting, and Renaming Files](#)<sup>[250]</sup>, [File Names and Attributes](#)<sup>[249]</sup>,

[fd.create](#)<sup>[271]</sup>, [fd.delete](#)<sup>[272]</sup>, [fd.getnumfiles](#)<sup>[281]</sup>,  
[fd.maxstoredfiles](#)<sup>[283]</sup>

Part	Description
old_name	A string (1-56 characters) with the name of the file to be renamed. All characters after the first space encountered (excluding leading spaces) will be ignored. File names are case-sensitive.
new_name	A string (1-56 characters) with the new name for the file. All characters after the first space encountered (excluding leading spaces) will be ignored.

**Details**

Renaming a file preserves file attributes.

This method makes changes to the sectors of the flash disk. For the highest possible reliability, use [disk transactions](#)<sup>[259]</sup> when invoking it.

**.Resetdirpointer Method****Function:**

Resets the directory pointer to zero.

**Syntax:**

**fd.resetdirpointer()**

**Returns:**

---

**See Also:**

[Walking Through File Directory](#)<sup>[252]</sup>,

[fd.getnextdirmember](#)<sup>[280]</sup>, [fd.getnumfiles](#)<sup>[281]</sup>

## Details

---

### **.Sector R/O Property**

<b>Function:</b>	Returns the physical sector number corresponding to the current position of the file pointer.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535
<b>See Also:</b>	<a href="#">Writing To and Reading From Files</a> <sup>[254]</sup>

## Details

Because the sectors belonging to a given file may be scattered around the flash disk, there is no simple way to figure out the number of the physical sector corresponding to the current file pointer position (see [fd.pointer](#)<sup>[285]</sup>). This property exists purely for informational purposes. There is no real need for you to know where the fd. object stores your data.

### **.Setattributes Method**

<b>Function:</b>	Sets the attributes string for a file with the specified file name.
<b>Syntax:</b>	<b>fd.setattributes(<i>byref</i> name <i>as</i> string, <i>byref</i> attr <i>as</i> string) <i>as</i> pl_fd_status_codes</b>
<b>Returns:</b>	One of the following <a href="#">pl fd status codes</a> <sup>[282]</sup> , also affects <a href="#">fd.laststatus</a> <sup>[282]</sup> : <ul style="list-style-type: none"> <li>0- PL_FD_STATUS_OK: Completed successfully.</li> <li>1- PL_FD_STATUS_FAIL : Physical flash memory failure (fatal).</li> <li>2- PL_FD_STATUS_CHECKSUM_ERR: Checksum error has been detected in one of the disk sectors (fatal).</li> <li>3- PL_FD_STATUS_FORMAT_ERR: Disk formatting error has been detected (fatal).</li> <li>8- PL_FD_STATUS_NOT_READY: The disk is not mounted.</li> <li>9- PL_FD_STATUS_NOT_FOUND: File not found.</li> <li>14- PL_FD_STATUS_TRANSACTION_CAPACITY_EXCEEDED: Too many disk sectors have been modified in the cause of the current transaction (fatal).</li> </ul>
<b>See Also:</b>	<a href="#">Reading and Writing File Attributes</a> <sup>[251]</sup> , <a href="#">Creating, Deleting, and Renaming Files</a> <sup>[250]</sup> , <a href="#">File Names and Attributes</a> <sup>[249]</sup> , <a href="#">fd.getattributes</a> <sup>[278]</sup> , <a href="#">fd.create</a> <sup>[271]</sup>

Part	Description
name	A string (1-56 characters) with the file name. All characters after the first space encountered (excluding leading spaces) will be ignored. File names are case-sensitive.
attr	A string with attributes to be set. Attributes length cannot exceed 56-length_of_the_file_name-1. This "-1" accounts for the space character that separates the file name from the attributes.

### Details

This method makes changes to the sectors of the flash disk. For the highest possible reliability, use [disk transactions](#)<sup>[259]</sup> when invoking it.

## .Setbuffer Method

<b>Function:</b>	Writes a specified number of bytes into the currently selected RAM buffer of the flash memory (selection is made through the <a href="#">fd.buffernum</a> <sup>[267]</sup> property).
<b>Syntax:</b>	<b>fd.setbuffer(byref data as string, offset as word) as word</b>
<b>Returns:</b>	Actual number of bytes written.
<b>See Also:</b>	<a href="#">Direct Sector Access</a> <sup>[240]</sup> , <a href="#">File-based and Direct Sector Access Coexistence</a> <sup>[263]</sup>  <a href="#">fd.buffernum</a> <sup>[267]</sup> , <a href="#">fd.getbuffer</a> <sup>[278]</sup> , <a href="#">fd.getsector</a> <sup>[281]</sup> , <a href="#">fd.setsector</a> <sup>[290]</sup> , <a href="#">fd.checksum</a> <sup>[268]</sup> , <a href="#">fd.copyfirmware</a> <sup>[269]</sup> , <a href="#">fd.copyfirmwarelzo</a> <sup>[270]</sup>

Part	Description
data	A string with the data to be written to the buffer.
offset	Starting offset in the buffer. Possible value range is 0-263 (the buffer stores 264 bytes of data, offset is counted from 0).

### Details

The length of data actually written into the buffer may be limited if all supplied data can't fit between the offset position in the buffer and the end of the buffer.

All [file-based](#)<sup>[245]</sup> operations of the flash disk also load data into the RAM buffers. Switch to the RAM buffer #0 *each time* before performing [direct sector access](#)<sup>[240]</sup> with this or other related methods -- this will guarantee that you won't corrupt the files and/or the file system and cause disk dismounting ([fd.ready](#)<sup>[285]</sup> becoming 0-NO).

## .Setdata Method

- Function:** Writes data to a file opened "on" a currently selected file number (selection is made through [fd.filenum](#)<sup>[273]</sup>). The data is written starting at the [fd.pointer](#)<sup>[285]</sup> position.
- Syntax:** **fd.setdata(byref data as string) as pl\_fd\_status\_codes**
- Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.
  - 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
  - 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
  - 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).
  - 7- PL\_FD\_STATUS\_DATA\_FULL: The disk is full, new data cannot be added.
  - 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
  - 10- PL\_FD\_STATUS\_NOT\_OPENED: No file is currently opened on the current value of the [fd.filenum](#)<sup>[273]</sup> property.
  - 14- PL\_FD\_STATUS\_TRANSACTION\_CAPACITY\_EXCEEDED: Too many disk sectors have been modified in the cause of the current transaction (fatal).
- See Also:** [Writing To and Reading From Files](#)<sup>[254]</sup>, [fd.getdata](#)<sup>[279]</sup>, [fd.pointer](#)<sup>[285]</sup>, [fd.setpointer](#)<sup>[291]</sup>, [fd.filesize](#)<sup>[274]</sup>

Par t	Description
dat a	A string containing data to be written to the file. If the disk becomes full, then no data will be written (and not just the portion that could not fit).

### Details

As a result of this method invocation, the pointer will be advanced forward by the number of bytes actually written to the file.

This method makes changes to the sectors of the flash disk. For the highest possible reliability, use [disk transactions](#)<sup>[259]</sup> when invoking this method.

## .Setfilesize Method

- Function:** Sets (reduces) the file size of a file opened "on" a currently selected file number (selection is made through [fd.filenum](#)<sup>[273]</sup>).
- Syntax:** **fd.setfilesize(newsize as dword) as pl\_fd\_status\_codes**
- Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:
- 0- PL\_FD\_STATUS\_OK: Completed successfully.

- 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
- 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
- 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).
- 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.
- 14- PL\_FD\_STATUS\_TRANSACTION\_CAPACITY\_EXCEEDED: Too many disk sectors have been modified in the cause of the current transaction (fatal).

**See Also:** [Removing Data From Files](#)<sup>[255]</sup>,  
[fd.cutfromtop](#)<sup>[271]</sup>

Part	Description
new size	Desired new file size in bytes. Supplied value will be corrected downwards if exceeded previous file size.

### Details

As a result of this method invocation, the pointer position may be corrected downwards.

This method makes changes to the sectors of the flash disk. For the highest possible reliability, use [disk transactions](#)<sup>[259]</sup> when invoking this method.

## .Setsector Method

**Function:** Writes the entire 264 bytes of the specified sector with the data from the currently selected RAM buffer of the flash memory (selection is made through the [fd.buffernum](#)<sup>[267]</sup> property).

**Syntax:** **fd.getsector(num as word) as pl\_fd\_status\_codes**

**Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:

- 0- PL\_FD\_STATUS\_OK: Completed successfully.
- 1- PL\_FD\_STATUS\_FAIL: Physical flash memory failure (fatal).
- 4- PL\_FD\_STATUS\_INV\_PARAM: specified sector number is in the firmware/application area of the flash memory; access has been denied.
- 16- PL\_FD\_STATUS\_FLASH\_NOT\_DETECTED: Flash IC wasn't detected during boot, fd. object cannot operate normally.

**See Also:** [Direct Sector Access](#)<sup>[240]</sup>, [Sharing Flash Between Your Application and Data](#)<sup>[237]</sup>, [File-based and Direct Sector Access Coexistence](#)<sup>[263]</sup>,

[fd.buffernum](#)<sup>[267]</sup>, [fd.getbuffer](#)<sup>[278]</sup>, [fd.setbuffer](#)<sup>[288]</sup>,  
[fd.getsector](#)<sup>[281]</sup>, [fd.checksum](#)<sup>[268]</sup>, [fd.copyfirmware](#)<sup>[269]</sup>,  
[fd.copyfirmwarelzo](#)<sup>[270]</sup>

Part	Description
------	-------------

num *Logical* number of the sector to write to (logical numbers are in reverse: writing to the logical sector 0 actually means writing to the last physical sector of the flash IC). Acceptable range is 0 - [fd.availableflashspace](#)<sup>[267]</sup>-1.

**Details**

The data area of the flash memory may house a formatted [flash disk](#)<sup>[245]</sup>. Writing to the sector that belongs to the flash disk when the disk is mounted will automatically dismount the disk (set [fd.ready](#)<sup>[285]</sup>= 0- NO) and may render the disk unusable.

This method always accesses the specified target sector and not its cached copy even if the [disk transaction](#)<sup>[259]</sup> is in progress ([fd.transactionstarted](#)<sup>[294]</sup>= 1- YES) and the target sector has been cached already.

**.Setpointer Method**

**Function:** Sets the new pointer position for a file opened "on" a currently selected file number (selection is made through [fd.filenum](#)<sup>[273]</sup>).

**Syntax:** **fd.setpointer(pos as dword) as pl\_fd\_status\_codes**

**Returns:** One of the following [pl\\_fd\\_status\\_codes](#)<sup>[282]</sup>, also affects [fd.laststatus](#)<sup>[282]</sup>:

- 0- PL\_FD\_STATUS\_OK: Completed successfully.
- 1- PL\_FD\_STATUS\_FAIL : Physical flash memory failure (fatal).
- 2- PL\_FD\_STATUS\_CHECKSUM\_ERR: Checksum error has been detected in one of the disk sectors (fatal).
- 3- PL\_FD\_STATUS\_FORMAT\_ERR: Disk formatting error has been detected (fatal).
- 8- PL\_FD\_STATUS\_NOT\_READY: The disk is not mounted.

**See Also:** [Writing To and Reading From Files](#)<sup>[254]</sup>,  
[fd.getdata](#)<sup>[279]</sup>, [fd.setdata](#)<sup>[289]</sup>, [fd.pointer](#)<sup>[285]</sup>, [fd.filesize](#)<sup>[274]</sup>

Part	Description
------	-------------

pos Desired new pointer position. Supplied value will be corrected if out of range. For the files of 0 size (see [fd.filesize](#)<sup>[274]</sup>), the pointer may only have one value -- 0. If the file has non-zero size, the pointer can be between 1 and fd.filesize+1. "1" is the position of the first byte of the file. The last existing byte of the file is at position equal to the value of

fd.filesize. "Fd.filesize+1" is the position at which new data can be added to the file.

### Details

---

## .Totalsize R/O Property

<b>Function:</b>	Returns the total number of sectors occupied by the currently existing flash disk.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535
<b>See Also:</b>	<a href="#">Checking Disk Vitals</a> <sup>[249]</sup> , <a href="#">fd.capacity</a> <sup>[268]</sup> , <a href="#">fd.numservicesectors</a> <sup>[284]</sup> , <a href="#">fd.getfreespace</a> <sup>[280]</sup> , <a href="#">fd.maxstoredfiles</a> <sup>[283]</sup> , <a href="#">fd.getnumfiles</a> <sup>[281]</sup>

### Details

For [internal reasons](#)<sup>[246]</sup>, the total size of the disk as returned by this property may be less than the size that was requested when formatting the disk with the [fd.formatj](#)<sup>[277]</sup> ([fd.format](#)<sup>[276]</sup>) method. Actual usable capacity ([fd.capacity](#)<sup>[268]</sup>) of the disk is less because the disk also needs a number of sectors for its "housekeeping" data (see [fd.numservicesectors](#)<sup>[284]</sup>).

The disk must be mounted (see [fd.mount](#)<sup>[283]</sup>) for this property to return a meaningful value.

## .Transactioncapacityremaining R/O Property

<b>Function:</b>	Returns the number of sectors that can still be changed in the cause of the current disk transaction.
<b>Type:</b>	Byte
<b>Value Range:</b>	0 to 16 or maxjournalsectors-1, whichever is smaller. Maxjournalsectors is the argument of the <a href="#">fd.formatj</a> <sup>[277]</sup> method.
<b>See Also:</b>	<a href="#">Using Disk Transactions</a> <sup>[259]</sup> , <a href="#">Understanding Transaction Capacity</a> <sup>[261]</sup> , <a href="#">fd.transactionstart</a> <sup>[293]</sup> , <a href="#">fd.transactioncommit</a> <sup>[293]</sup> , <a href="#">fd.transactionstarted</a> <sup>[294]</sup>

### Details

---

## .Transactioncommit Method

<b>Function:</b>	Commits a disk transaction.
<b>Syntax:</b>	<b>fd.transactioncommit()</b> as <b>pl_fd_status_codes</b>
<b>Returns:</b>	One of the following <a href="#">pl_fd_status_codes</a> <sup>[282]</sup> , also affects <a href="#">fd.laststatus</a> <sup>[282]</sup> : 0- PL_FD_STATUS_OK: Completed successfully. 1- PL_FD_STATUS_FAIL : Physical flash memory failure (fatal). 8- PL_FD_STATUS_NOT_READY: The disk is not mounted. 13- PL_FD_STATUS_TRANSACTION_NOT_YET_STARTED: Disk transaction hasn't been started yet. 15- PL_FD_STATUS_TRANSACTIONS_NOT_SUPPORTED: The disk wasn't formatted to support transactions (use <a href="#">fd.formatj</a> <sup>[277]</sup> with maxjournalsectors>1 to enable transactions).
<b>See Also:</b>	<a href="#">Using Disk Transactions</a> <sup>[259]</sup> , <a href="#">fd.transactionstart</a> <sup>[293]</sup> , <a href="#">fd.transactionstarted</a> <sup>[294]</sup> , <a href="#">fd.transactioncapacityremaining</a> <sup>[292]</sup>

---

### Details

---

## .Transactionstart Method

<b>Function:</b>	Starts a disk transaction.
<b>Syntax:</b>	<b>fd.transactionstart()</b> as <b>pl_fd_status_codes</b>
<b>Returns:</b>	One of the following <a href="#">pl_fd_status_codes</a> <sup>[282]</sup> , also affects <a href="#">fd.laststatus</a> <sup>[282]</sup> : 0- PL_FD_STATUS_OK: Completed successfully. 8- PL_FD_STATUS_NOT_READY: The disk is not mounted. 12- PL_FD_STATUS_TRANSACTION_ALREADY_STARTED: Disk transaction has already been started (and cannot be restarted). 15- PL_FD_STATUS_TRANSACTIONS_NOT_SUPPORTED: The disk wasn't formatted to support transactions (use <a href="#">fd.formatj</a> <sup>[277]</sup> with maxjournalsectors>1 to enable transactions).
<b>See Also:</b>	<a href="#">Using Disk Transactions</a> <sup>[259]</sup> , <a href="#">fd.transactioncommit</a> <sup>[293]</sup> , <a href="#">fd.transactionstarted</a> <sup>[294]</sup> , <a href="#">fd.transactioncapacityremaining</a> <sup>[292]</sup>

---

### Details

---

## .Transactionstarted R/O Property

<b>Function:</b>	Reports whether a disk transaction is currently in progress.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO: Disk transaction is not in progress ( <b>default</b> ). 1- YES: Disk transaction is in progress.
<b>See Also:</b>	<a href="#">Using Disk Transactions</a> <sup>[259]</sup> , <a href="#">fd.transactionstart</a> <sup>[293]</sup> , <a href="#">fd.transactioncommit</a> <sup>[293]</sup> , <a href="#">fd.transactioncapacityremaining</a> <sup>[292]</sup>

---

### Details

---

## IO Object



The io object controls I/O lines, ports, and interrupt lines of your device.

### Overview, 4.1

The I/O object controls your device's individual I/O lines and ports. Each port groups eight I/O lines. You can control the state of each line or entire port.

The list of available I/O lines and ports is platform-specific, i.e. it depends on your device. Two enum constant sets -- pl\_io\_num and pl\_io\_port\_num -- define the set of available lines and ports. You can find the declaration of these enums in your platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

There are two different methods for controlling I/O lines (ports):

- [Method with pre-selection](#)<sup>[295]</sup>;
- [Method without pre-selection](#)<sup>[295]</sup>.

I/O lines of your device can work as both inputs and outputs -- [Controlling Output Buffers](#)<sup>[296]</sup> topic explains this.

Some I/O lines can work as interrupts -- see [Working With Interrupts](#)<sup>[297]</sup> for explanation. The list of available interrupt lines is platform-specific. The pl\_int\_num enum constant set defines the set of related variables. Again, please refer to your platform documentation.

On many devices, a number of I/O lines may be shared with inputs/outputs of special function blocks (serial ports, etc.). When a special function block is enabled, I/O lines it uses cannot (should not) be manipulated though the io object.

## Line/Port Manipulation With Pre-selection

I/O line manipulation with pre-selection works like this: you first select the line you want to work with using the `io.num` property. You can then read and set the state of this line using the `io.state` property. On certain platforms, you can also enable/disable the output buffer of the line with the `io.enabled` property -- more on this in the [Controlling Output Buffers](#) topic. Here is a code example:

```
io.num=PL_IO_NUM_5 'select line #5
io.enabled=YES 'enable this line
io.state=HIGH 'set this line to HIGH
io.state=LOW 'now set this line to LOW
io.enabled=NO 'configure the line as input now
x=io.state 'read the state of the line
```

Same can be done with ports -- use `io.portnum`, `io.portstate`, and `io.portenabled` properties to achieve this:

```
io.portnum=2 'select port #2
io.portenabled=&hFF 'this means that every port line's output buffer will be
enabled (&hFF=&b11111111)
'output &h55: port lines 0, 2, 4, and 6 will be at HIGH, 4 remaining lines
will be at LOW (&h55=&b01010101)
io.portstate=&h55
'output another value
op.portstate=0
'configure the port for input and read its state
io.portenabled=0
x=io.portstate
```

This way of controlling the lines/ports of your device is good when you are going to manipulate the same line/port repeatedly. Performance is improved because you select the line/port once and then address this line/port as many times as you need.

Note that I/O line and port names are platform-specific and are defined by `pl_io_num` and `pl_io_port_num` enums respectively. The declarations for these enums can be found in your device's platform documentation (for example, EM1000's is [here](#)).

On many devices, a number of I/O lines may be shared with inputs/outputs of special function blocks (serial ports, etc.). When a special function block is enabled, I/O lines it uses cannot (should not) be manipulated through the io object.

## Line/Port Manipulation Without Pre-selection

I/O line manipulation without pre-selection is good when you need to deal with several I/O lines at once. For this, use `io.lineset`, `io.lineget`, and `io.invert` methods. These methods require the line number to be supplied directly, as a parameter. Therefore, pre-selection with the `io.num` property is not necessary.

Moreover, executing these methods leaves the `io.num` value intact.

Here is an example of a serialized clock/data output. The clock line is `PL_IO_NUM_0` and the data line is `PL_IO_NUM_1`. Notice how this is implemented -- clock line is preselected once, then set LOW and HIGH using the `io.state`<sup>[303]</sup> property. Meanwhile, the data line is updated using the `io.lineset` method. The variable `x` supposedly carries a bit of data to be output (where `x` gets is data is not shown).

```
Dim f As Byte
Dim x As low_high

io.num=PL_IO_NUM_0 'pre-select the clock line
For f=0 To 7
    ... 'obtain the value of the next bit, put it into x (not shown)
    io.state=LOW 'set the clock line LOW (the clock line has already been
preselected)
    io.lineset(PL_IO_NUM_1,x) 'output the next data bit
    io.state=HIGH 'set the clock line HIGH (the clock line has already been
preselected)
Next f
```

Direct port manipulation is achieved using `io.portset`<sup>[303]</sup> and `io.portget`<sup>[302]</sup> methods.

Note that I/O line and port names are platform-specific and are defined by `pl_io_num` and `pl_io_port_num` enums respectively. The declarations for these enums can be found in your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

On many devices, a number of I/O lines may be shared with inputs/outputs of special function blocks (serial ports, etc.). When a special function block is enabled, I/O lines it uses cannot (should not) be manipulated though the `io` object.

## Controlling Output Buffers

As far as the I/O line/port control goes, there are [two kinds](#)<sup>[194]</sup> of Tibbo devices and corresponding platforms -- those without output buffer control, and those with output buffer control. You can find this information in your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

On devices without the output buffer control each I/O line's output driver is always enabled. If you want to use this line as an input, set its state to HIGH. After that, you can read this line's state. If the line is left unconnected or is not being pulled low externally you will read HIGH. If the line is being pulled low externally you will read LOW. Pulling the line LOW externally while this line's output driver is at HIGH will do no damage to the line.

Here is a code example in which we wait for the line #1 to become LOW:

```
io.num=PL_IO_NUM_1 'select the line
io.state=HIGH 'set it to HIGH so we can use it as an input
While io.state=HIGH 'wait until the line is pulled LOW externally
Wend
```

On devices with explicit output buffer control, you need to define whether the line

is an output (set `io.enabled` = 1- YES) or input (set `io.enabled` = 0- NO). Trying to read the line while it is in the output mode will simply return the state of the line's own output driver. Forcing the line externally while it works as an output may cause a permanent damage to the device. For this kind of devices, the above code must be modified to look like this:

```
io.num=PL_IO_NUM_1 'select the line
io.enabled=NO 'disable the output driver (line will function as an input
now)
While io.state=HIGH 'wait until the line is pulled LOW externally
Wend
```

Since ports consist of individual lines, the same applies to ports as well. What needs to be understood is that each port line can be configured as input or output individually. Hence, a particular port doesn't have to be "all outputs" or "all inputs". Here is an example where the lower half of the port lines is configured for output, and the rest of the lines serve as inputs:

```
'This is an example for devices with explicit output buffer control
io.portnum=PL_IO_PORT_1
io.portenabled= &h0F 'configure lower 4 lines as outputs, the rest will be
used as inputs
```

Some I/O lines are shared with inputs/outputs of special function blocks (serial ports, etc.). When a special function block is enabled, certain (not all) I/O lines it uses may be configured for input or output automatically. For such lines, when the corresponding special function block is disabled, the state of the output buffer is restored automatically to what it used to be prior to enabling this function block.

Note that I/O line and port names are platform-specific and are defined by `pl_io_num` and `pl_io_port_num` enums respectively. The declarations for these enums can be found in your device's platform documentation (for example, EM1000's is [here](#)).

## Working With Interrupts

Some platforms have a number of I/O lines that can work as interrupt inputs. To enable a particular interrupt line, select it using the `io.intnum` property and enable the line with the `io.intenabled` property:

```
'enable interrupt line #0
io.intnum=PL_INT_NUM_0
io.intenabled=YES
```

Once the line has been enabled, the change in this line's state will generate an

[on\\_io\\_int](#)<sup>[301]</sup> event. The `linestate` argument of this event is bit-encoded: each bit of the value represents one interrupt line. For the `PL_INT_NUM_0`, the corresponding bit is bit 0, for `PL_INT_NUM_1` -- bit 1, and so on. A particular bit of the `linestate` argument is set when the state change (from LOW to HIGH, or from HIGH to LOW) has been detected on the related interrupt line. Event handler for the [on\\_io\\_int](#)<sup>[301]</sup> event can then determine what triggered the interrupt:

```
Sub On_io_int(linestate As Byte)
    'check if it is the interrupt line #0 that has caused the interrupt
    If linestate And &h01 <>0 Then
        'yes, interrupt has been triggered by the interrupt line #0
        ...
    End If
End Sub
```

Please, note that the word "interrupt" is used here in a somewhat loose sense. On traditional microcontrollers, interrupt line status change causes a near-instantaneous pause to the execution of the main code and a jump to an "interrupt routine". Hence, the term "interrupt" -- the execution of the main code gets interrupted.

With the `io` object, the interrupt line state change does not disrupt the execution of the any event handler or reordering of pending events in the event [queue](#)<sup>[7]</sup>. The [on\\_io\\_int](#)<sup>[301]</sup> event is added to the end of the event queue and is not handled until all earlier events are processed. Therefore, nothing is actually interrupted. Note also that there is no guaranteed interrupt response speed here -- the time between line state change detection and the execution of the [on\\_io\\_int](#)<sup>[301]</sup> event handler depends on the number of prior events waiting in the queue and, hence, cannot be pre-determined with any certainty.

Further, there may be only one `on_io_int` event waiting in the event queue. Another such event will not be generated unless the previous one is processed (this prevents the event queue from getting overflowed). Therefore, some short-lived state changes may remain undetected.

Bottom line: the "interrupts" of the `io` object should be viewed as a more convenient alternative to programmatic polling of the I/O lines.

Note that interrupt line names, such as "PL\_INT\_NUM\_0" are defined by the `pl_int_num` enum, which is platform-specific. The declaration of this enum can be found in the your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

## Properties, Events, Methods

This section provides an alphabetical list of all properties, methods, and events of the `io` object.

### .Enabled Property (Selected Platforms Only)

**Function:** Sets/returns the state of the output buffer for the currently selected I/O line (selection is made through the [io.num](#)<sup>[301]</sup> property).

**Type:** Enum (`no_yes`, `byte`)

**Value Range:** 0- NO (**default**): disabled, I/O line works as an input  
1- YES: enabled, I/O line works as an output

**See Also:** [Controlling Output Buffers](#)<sup>[296]</sup>, [io.state](#)<sup>[303]</sup>

---

### Details

Depending on the platform, [explicit configuration](#)<sup>[194]</sup> of the output buffers may or may not be required. For information on your device, see its platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>). The property is either not available or has no effect on platforms that do not require buffer configuration.

## **.Intenabled Property**

**Function:** Enabled/disables currently selected interrupt line (selection is made through the [io.intnum](#)<sup>[299]</sup> property).

**Type:** Enum (no\_yes, byte)

**Value Range:** 0- NO (**default**): the interrupt line is disabled  
1- YES: the interrupt line is enabled

**See Also:** [Working With Interrupts](#)<sup>[297]</sup>

---

### Details

Change of state of any enabled interrupt line leads to the [on\\_int\\_ev](#)<sup>[301]</sup> event generation. State change of disabled interrupt lines produces no effect.

## **.Intnum Property**

**Function:** Sets/returns the number of currently selected interrupt line.

**Type:** Enum (pl\_int\_num, byte)

**Value Range:** Platform-specific. See the list of pl\_int\_num constants in the platform specifications.

**See Also:** [Working With Interrupts](#)<sup>[297]</sup>

---

### Details

Selected interrupt line can be enabled or disabled using the [io.intenabled](#)<sup>[299]</sup> property. State change on enabled interrupt lines causes [on\\_io\\_int](#)<sup>[301]</sup> event generation.

In order to work correctly as an interrupt on certain platforms, the line may need to be configured as an input -- see [Controlling Output Buffers](#)<sup>[296]</sup> for details.

## .Invert Method

<b>Function:</b>	Inverts the state of the I/O line specified by the num argument.
<b>Syntax:</b>	<b>io.invert(num as pl_io_num)</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Line/Port Manipulation Without Pre-selection</a> <sup>[295]</sup> , <a href="#">io.lineget</a> <sup>[300]</sup> , <a href="#">io.lineset</a> <sup>[300]</sup>

Part	Description
num	Platform-specific. See the list of pl_io_num constants in the platform specifications.

### Details

No line pre-selection with the [io.num](#)<sup>[301]</sup> property is required and the value of the io.num will not be changed.

## .Lineget Method

<b>Function:</b>	Returns the state of the I/O line specified by the num argument.
<b>Syntax:</b>	<b>io.lineget(num as pl_io_num) as low_high</b>
<b>Returns:</b>	Current line state as LOW or HIGH (low_high enum values)
<b>See Also:</b>	<a href="#">Line/Port Manipulation Without Pre-selection</a> <sup>[295]</sup> , <a href="#">io.lineset</a> <sup>[300]</sup> , <a href="#">io.invert</a> <sup>[300]</sup>

Part	Description
num	Platform-specific. See the list of pl_io_num constants in the platform specifications.

### Details

No line pre-selection with the [io.num](#)<sup>[301]</sup> property is required and the value of the io.num will not be changed.

## .Lineset Method

<b>Function:</b>	Sets the I/O line specified by the num argument HIGH or LOW as specified by the state argument.
<b>Syntax:</b>	<b>io.lineset(num as pl_io_num, state as low_high)</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Line/Port Manipulation Without Pre-selection</a> <sup>[295]</sup> , <a href="#">io.lineget</a> <sup>[300]</sup> , <a href="#">io.invert</a> <sup>[300]</sup>

Part	Description
num	Platform-specific. See the list of pl_io_num constants in the platform specifications.
state	LOW or HIGH (low_high enum values).

**Details**

No line pre-selection with the [io.num](#)<sup>[301]</sup> property is required and the value of the io.num will not be changed.

**.Num Property**

- Function:** Sets/returns the number of currently selected I/O line.
- Type:** Enum (pl\_io\_num, byte)
- Value Range:** Platform-specific. See the list of pl\_io\_num constants in the platform specifications.
- See Also:** [Line/Port Manipulation with Pre-selection](#)<sup>[295]</sup>

**Details**

Selects a particular I/O line to be manipulated through the [io.state](#)<sup>[303]</sup> and [io.enabled](#)<sup>[298]</sup> properties (the latter may or not be available on your platform). The list of available I/O lines is defined by the pl\_io\_num constant.

**On\_io\_int Event**

- Function:** Generated when the change of state on one of the enabled interrupt lines is detected.
- Declaration:** **on\_io\_int**(linestate as byte)
- See Also:** [Working With Interrupts](#)<sup>[297]</sup>

Part	Description
linestate	0-255. Each bit of this value corresponds to one interrupt line in the order that these lines are declared in the pl_int_num enum.

**Details**

Interrupt lines are enabled/disabled through the [io.intenbled](#)<sup>[299]</sup> property. Another on\_io\_int event is never generated until the previous one is processed.

## .Portenabled Property (Selected Platforms Only)

<b>Function:</b>	Sets/returns the state of the output buffers for the currently selected I/O port (selection is made through the <a href="#">io.portnum</a> <sup>[302]</sup> property).
<b>Type:</b>	Byte
<b>Value Range:</b>	<b>Default</b> = 0 (all eight I/O lines of the port are configured as inputs)
<b>See Also:</b>	<a href="#">Controlling Output Buffers</a> <sup>[296]</sup> , <a href="#">io.portstate</a> <sup>[303]</sup>

### Details

Each I/O port groups eight I/O lines. Each bit of this property's byte value corresponds to one "member" I/O line. Setting the bit to 0 keeps the output buffer turned off, while setting the bit to 1 enables the output buffer.

Depending on the platform, [explicit configuration](#)<sup>[194]</sup> of the output buffers may or may not be required. For information on your device, see its platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>). The property is either not available or has no effect on platforms that do not require buffer configuration.

## .Portget Method

<b>Function:</b>	Returns the state of the I/O port specified by the num argument.
<b>Syntax:</b>	<b>io.portget(num as pl_io_port_num) as byte</b>
<b>Returns:</b>	0-255. Each bit of this value corresponds to one member I/O line of the 8-bit port.
<b>See Also:</b>	<a href="#">Line/Port Manipulation Without Pre-selection</a> <sup>[295]</sup> , <a href="#">io.portset</a> <sup>[303]</sup>

Part	Description
num	Platform-specific. See the list of pl_io_port_num constants in the platform specifications.

### Details

No line pre-selection with the [io.portnum](#)<sup>[302]</sup> property is required and the value of the io.portnum will not be changed.

## .Portnum Property

<b>Function:</b>	Sets/returns the number of currently selected I/O port.
<b>Type:</b>	Enum (pl_io_port_num, byte)
<b>Value Range:</b>	Platform-specific. See the list of pl_io_port_num constants in the platform specifications.
<b>See Also:</b>	<a href="#">Line/Port Manipulation With Pre-selection</a> <sup>[295]</sup>

**Details**

Selects a particular I/O port to be manipulated through the [io.portstate](#)<sup>[303]</sup> and [io.portenabled](#)<sup>[302]</sup> properties (the latter may or not be available on your platform). Each port groups eight I/O lines. The list of available I/O ports is defined by the pl\_io\_port\_num constant.

**.Portset Method**

- Function:** Sets the I/O port specified by the num argument to the state specified by the state argument.
- Syntax:** **io.portset(num as pl\_io\_port\_num, state as byte)**
- Returns:** ---
- See Also:** [Line/Port Manipulation Without Pre-selection](#)<sup>[295]</sup>, [io.portget](#)<sup>[302]</sup>

Part	Description
num	Platform-specific. See the list of pl_io_port_num constants in the platform specifications.
state	0-255. Each bit of this value corresponds to one member I/O line of the 8-bit port.

**Details**

No line pre-selection with the [io.portnum](#)<sup>[302]</sup> property is required and the value of the io.portnum will not be changed.

**.Portstate property**

- Function:** Sets/returns the state of the currently selected I/O port (selection is made through the [io.portnum](#)<sup>[302]</sup> property).
- Type:** Byte
- Value Range:** 0-255. **Default** value is hardware-dependent.
- See Also:** [Line/Port Manipulation With Pre-selection](#)<sup>[295]</sup>, [io.portenabled](#)<sup>[302]</sup>

**Details**

Each I/O port groups eight I/O lines. Each bit of this property's byte value corresponds to one "member" I/O line.

**.State Property**

- Function:** Sets/returns the state of the currently selected I/O line (selection is made through the [io.num](#)<sup>[301]</sup> property).

<b>Type:</b>	Enum (low_high, byte)
<b>Value Range:</b>	0- LOW 1- HIGH ( <b>Default</b> value is hardware-dependent)
<b>See Also:</b>	<a href="#">Line/Port Manipulation with Pre-selection</a> <sup>[295]</sup> , <a href="#">io.enabled</a> <sup>[298]</sup>

---

### Details

---

## Kp Object



This is the keypad (kp.) object, it allows you to work with a "matrix" keypad of up to 64 keys (8 scan lines by 8 return lines).

Features:


- Flexible [keypad arrangement](#)<sup>[304]</sup>. Scan lines can double as LED control lines too.
- Five [distinctive states](#)<sup>[306]</sup> for each key allow you to create sophisticated keypad input. Individual programming of [delay times](#)<sup>[307]</sup> for each state transition.
- Flexible [mapping](#)<sup>[307]</sup> for scan and return lines -- use any I/O lines, in any order.
- Ability to [auto-disable](#)<sup>[307]</sup> the keypad when a certain key event/code combination is encountered.

## Possible Keypad Configurations

The kp object works with a "matrix" keypad formed by scan and return lines. The keypad object supports up to 8 scan and 8 return lines, which means that you can build a keypad with up to 64 keys. A sample schematic diagram for a typical keypad is shown below.


During the scanning process, the kp object "activates" one scan line after another. The line is activated by setting it LOW, while keeping all other scan lines HIGH. For each scan line, the kp object samples the state of return lines. If any return line is at LOW, this means the key located at the intersection of this return line and the currently active scan line is pressed.

A detailed discussion of the schematics falls outside the scope of this manual. We will only notice, in passing, that the diodes D1-D4 are necessary and should not be omitted. For best result, use Schottky diodes -- they have low drop voltage. Pull-up resistors R1-R4 prevent the return lines from floating and should be present as well.



On platforms with [output buffer control](#)<sup>[296]</sup>, all intended scan lines should be configured as outputs, and all return lines -- as inputs (see [io.num](#)<sup>[301]</sup>, [io.enabled](#)<sup>[296]</sup>).


Scan lines can optionally perform a double duty and drive LEDs. One such LED can be connected to each scan line, preferably through a buffer, as shown on the drawing below. These LEDs can be used for any purpose you desire -- and this purpose can be completely unrelated to the keypad itself.



If the LED is connected as shown on the drawing, you need to set the corresponding I/O line LOW in order to turn this LED on. Each time the kp. object is to scan the keypad for pressed keys -- and this happens every 10ms -- it will first

set all scan lines to HIGH. This is necessary for correct keypad operation. Before doing so, however, the kp object will memorize the state of each scan line. This state will be restored after the scanning is complete. To your eye, this will look like that LED connected to the scan line was on all the time (of course, it was on in the first place).

To build a functioning keypad you will need to have at least one return line. A sensible count of scan lines, however, starts from two! Having a single scan line is like having no scan lines whatsoever -- you might just as well ground this single scan line of the keypad, i.e. keep it active permanently. This arrangement is shown on the drawing below.




[Preparing the Keypad for Operation](#)<sup>[307]</sup> topic explains how to setup the kp. object properly for the keypad hardware you are using.

## Key States and Transitions

Each key on your keypad can be in five different states, as defined by the pl\_kp\_event\_codes constant. Here are those states:

- 0- PL\_KP\_EVENT\_LONGRELEASED: The key has been released "for a while".
- 1- PL\_KP\_EVENT\_RELEASED: The key has been released (just now).
- 2- PL\_KP\_EVENT\_PRESSED: The key has been pressed (just now).
- 3- PL\_KP\_EVENT\_LONGPRESSED: The key has been pressed "for a while".
- 4- PL\_KP\_EVENT\_REPEATPRESSED: Auto-repeat for the key.

The diagram below shows all key states and possible state transitions.



Possible state transitions are indicated by arrows. Red arrows show transitions for when the key is pressed (or remains pressed), blue -- for when the key is released (or remains released). The time it takes for the key to transition from one state to another is quantified in 10ms intervals. This is the time period at which the `kp.` object will perform keypad scans. Each transition delay, expressed in 10ms intervals, is defined by a dedicated property, so you can decide for yourself what "just now" and "for a while" mean. Each time the key transitions to the next state, the `on_kp` <sup>[314]</sup> event is generated. See [Servicing Keypad Events](#) <sup>[310]</sup> for how to work with events. The keypad object has a buffer that can hold up to 8 keypad events.

When the keypad is enabled (`kp.enabled` <sup>[312]</sup> is set to 1- YES), the keypad buffer is cleared and each key's state is set to "longreleased". Press the key long enough, and the key will go into the "pressed" state. From there, the key can go to "released" and, later, "longreleased" if you let go of that key, or into "longpressed" and then "repeatpressed" if you keep the key pressed.

Five available key states, along with adjustable state transition times, allow you to create sophisticated keypad input. For example, it is possible to have a mixed alphanumerical input, like the one used on mobile phones for SMS entry.

"Longpressed" events can be assigned to add a digit, for example, "1" if you press the "1ABC" key. "Pressed" events rotate between letters of the key ("A"->"B"->"C"->"A", etc.), unless another key is pressed or rotation times out on "longreleased" event. In both cases, input advances to the next character.

## Preparing the Keypad for Operation

This topic explains what you need to do to properly set up the `kp.` object. All preparations should be made with the keypad disabled (`kp.enabled` <sup>[312]</sup> = 0- NO), or this setup won't work.

## Mapping scan and return lines

First, you need to define the list of scan and return lines. One great feature of the `kp` object is that you can assign ("map") any I/O line of your device to be a scan or return line. I/O lines serving as scan or return lines don't even have to be "together" (have consecutive numbers). Scan lines are assigned through the [`kp.scanlinesmapping`](#)<sup>[317]</sup> property, return lines -- through the [`kp.returnlinesmapping`](#)<sup>[316]</sup> property. For example, here is how you select lines 24, 20, and 27 to serve as scan lines, and 28, 21, and 25 to serve as return lines:

```
kp.scanlinesmapping="24,20,27"
kp.returnlinesmapping="28,21,25"

io.num=PL_IO_NUM_24
io.enabled=YES
io.num=PL_IO_NUM_20_INT4
io.enabled=YES
io.num=PL_IO_NUM_27
io.enabled=YES
```

On platforms with [output buffer control](#)<sup>[296]</sup> each scan line must be configured as output, each return line -- as input (shown in the example above).

Notice how we did not have any order in specifying return and scan lines -- this simply does not matter. Select any lines, order then in any way you want. The only limitations are:

- You can't have more than 8 scan lines and 8 return lines;
- You must have at least 1 return line;
- Any given I/O line can only serve as a scan or return line, not both.

Line numbers are platform-dependent. They come from `pl_io_num` -- see its declaration in the "Platform-dependent Constants" section of your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>). The `pl_io_num` is a list of constants like "PL\_IO\_NUM\_24". You cannot just drop "PL\_IO\_NUM\_24" into `kp.scanlinesmapping` (or `kp.returnlinesmapping`). The correct way is to write "24" or use `str(PL_IO_NUM_24)`. So, another way to do the above setup would look like this:

```
kp.scanlinesmapping=str(PL_IO_NUM_24)+", "+str(PL_IO_NUM_20_INT4)+", "+str
(PL_IO_NUM_27)
kp.returnlinesmapping=str(PL_IO_NUM_28)+", "+str(PL_IO_NUM_21_INT5)+", "+str
(PL_IO_NUM_25)
...
s=kp.returnlinesmapping 's will be equal to '28,21,25' (full constant names
like PL_IO_NUM_28 are not preserved)
```

Notice that no matter how you set `kp.scanlinesmapping` and `kp.returnlinesmapping`, reading them will always return a simple list of numbers (shown in the example above).

## Defining state transition delays

Your second step is to set proper delay times for [key state transitions](#)<sup>[306]</sup>. Five different properties are responsible for that: [kp.pressdelay](#)<sup>[315]</sup>, [kp.longpressdelay](#)<sup>[313]</sup>, [kp.repeatdelay](#)<sup>[315]</sup>, [kp.releasedelay](#)<sup>[315]</sup>, and [kp.longreleasedelay](#)<sup>[313]</sup>. Each property sets the transition delay time in 10ms increments. Setting a property to 0 means that the corresponding transition will never happen. Note that the maximum value for each property is 254, not 255. All five properties already have sensible default values, so you only need to change them if you don't like what we have chosen for you:

```
kp.pressdelay=4 '40ms (4 successive keypad scans) to confirm that the key is
pressed
kp.longpressdelay=150 '1.5 seconds
kp.repeatdelay=0 'we do not want auto-repeat to work
kp.releasedelay=4 '40ms
kp.longreleasedelay=200 '2 seconds
```

## Keypad auto-disable

Finally, you can select several event/code combinations that will automatically disable the keypad. This is done through the [kp.autodisablecodes](#)<sup>[312]</sup> property. Each time one of the pre-sent combinations of the key state and key code is detected, the `kp.enabled` property will be set to 0- NO, thus preventing further input until you re-enable the keypad.

This behavior can be very useful. Supposing, you have an application where you need to enter a certain code, then press <ENTER>. After you press <ENTER>, your application processes the input, which may take some time. What you often need is to prevent any further keypad input while the code is being processed. If you do not do this, the user might continue punching away and creating garbage input that your system does not need. This might even overwhelm the keypad buffer (see [Servicing Keypad Events](#)<sup>[310]</sup>). The `kp.autodisablecodes` makes sure that the input stops at a certain event/code combination. Up to four such combinations can be defined.

Here is an example of how this property could be set:

```
kp.autodisablecodes=str(PL_KP_EVENT_PRESSED)+",49" 'assuming that <ENTER>
key has the code of 49
kp.autodisablecodes="2,49" 'this is because the PL_KP_EVENT_PRESSED constant
is equal to 2
```


Once all the properties have been preset, enable the `kp.` object (`kp.enabled= 1-YES`), and start processing [keypad events](#)<sup>[310]</sup>.

## Servicing Keypad Events

Once you have correctly [preset and enabled](#)<sup>[307]</sup> the `kp.` object, you only need to process keypad events.

The `on_kp`<sup>[314]</sup> is the main event that is generated each time a key transitions to a new [key state](#)<sup>[306]</sup>. The `key_event` argument will tell you what that new state is, while the `key_code` will tell you the code of the key. Event codes are defined in the `on_kp_event_codes` enum. The key code is composed of the scan line number (bits 7-4 of the key code), and the return line number (bits 3-0). Scan and return lines are numbered in the same order they are listed in the [kp.scanlinesmapping](#)<sup>[317]</sup> and [kp.returnlinesmapping](#)<sup>[316]</sup> properties.

For example, supposing you have a 4x4 keypad with <0> - <9> keys, also <F1> - <F4>, <E> (enter) and <C> (cancel). Notice how key codes in their hex representation reflect the number of the scan line (high digit) and return line (low digit):



Set up the `kp.` object to work correctly with your hardware:

```
kp.scanlinesmapping="24,25,26,27"
kp.returnlinesmapping="28,29,30,31"

io.num=PL_IO_NUM_24
io.enabled=YES
io.num=PL_IO_NUM_25
```

```

io.enabled=YES
io.num=PL_IO_NUM_26
io.enabled=YES
io.num=PL_IO_NUM_27
io.enabled=YES

'we are not going to change default delay values -- we like them as they are
(we came up with them, after all)

kp.autodisablecodes=str(PL_KP_EVENT_PRESSED)+" ,49" '<ENTER> will disable
further input

kp.enabled=YES

```

Here is an example of the event handler that adds your input to the `inp_str` string (global variable), clears the string when the `<CANCEL>` key is pressed, and launches the mysterious `process_it` procedure when the `<ENTER>` key is pressed:

```

Sub On_kp(key_event As pl_kp_event_codes, key_code As Byte)
  Dim x As Byte
  If key_event=PL_KP_EVENT_PRESSED Then
    Select Case key_code
      Case &h1: x=1
      Case &h11: x=2
      Case &h21: x=3
      Case &h2: x=4
      Case &h12: x=5
      Case &h22: x=6
      Case &h3: x=7
      Case &h13: x=8
      Case &h23: x=9
      Case &h33: x=0
      Case &h32: '<CANCEL>'
        inp_str=""
        Exit Sub
      Case &h31: '<ENTER> will disable the keypad...'
        process_it()
        inp_str=""
        kp.enabled=YES '... so we re-enable it
        Exit Sub
    End Select
    inp_str=inp_str+chr(x) 'we will be here only when a numerical key is
    pressed (see 'exit sub' under CANCEL and ENTER keys)
  End If
End Sub

```

### Handling keypad buffer overflows

Another event -- [on\\_kp\\_overflow](#)<sup>[314]</sup> -- tells you that the input buffer of the keypad has been overwhelmed with frantic user input and the `kp` object is not disabled. You respond appropriately:

```

Sub On_kp_overflow

```

```

lcd.print("WHAT'S THE RUSH? SLOW DOWN!",0,0) 'tell the user
inp_str="" 'clear the string
kp.enabled=YES 're-enable the keypad
End Sub

```

## Properties, Methods, Events

Properties, methods, and events of the kp object.

### .Autodisablecodes Property

<b>Function:</b>	Defines which key event/code combinations disable the keypad.
<b>Type:</b>	String
<b>Value Range:</b>	Up to four comma-separated event/code pairs. <b>Default=</b> "".
<b>See Also:</b>	<a href="#">Preparing the Keypad for Operation</a> <sup>[307]</sup> , <a href="#">Key States and Transitions</a> <sup>[306]</sup>

#### Details

This property should contain a comma-separated list of event codes and key codes, for example: "2,15,0,20". In this example, two event/code pairs are set: "2,15" and "0,20". Event "2" is 2- PL\_KP\_EVENT\_PRESSED, and event "0" is 0- PL\_KP\_EVENT\_LONGRELEASED (see [on\\_kp](#)<sup>[314]</sup> event for a full list of codes). "15" and "20" are key codes. So, the keypad will be disabled ([kp.enabled](#)<sup>[312]</sup> set to 0- NO) when the key with code 15 is detected to be "pressed", or the key with code 20 is detected to be "longreleased".

The kp.autodisablecodes string should only contain a list of decimal numbers. That is, use "2" and not "2- PL\_KP\_EVENT\_PRESSED". Only numerical characters are processed anyway -- writing "2- PL\_KP\_EVENT\_PRESSED,15,0- PL\_KP\_EVENT\_LONGRELEASED,20" will set this property to "2,15,0,20" anyway. You can, of course, write str(PL\_KP\_EVENT\_PRESSED)+"+"15"+"+"str(PL\_KP\_EVENT\_LONGRELEASED)+"+"20" instead of "2,15,0,20".

This property can only be changed when the keypad is disabled (kp.enabled= 0- NO). Setting the property to "" means that no event and key combination will disable the keypad automatically.

### .Enabled Property

<b>Function:</b>	Enables or disables the keypad.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO ( <b>default</b> ): The keypad is disabled. 1- YES: The keypad is enabled.
<b>See Also:</b>	<a href="#">Preparing the Keypad for Operation</a> <sup>[307]</sup>

## Details

The keypad matrix is being scanned and your application receives the [on\\_kp](#)<sup>[314]</sup> and [on\\_kp\\_overflow](#)<sup>[314]</sup> events only when the keypad is enabled (kp.enabled= 1- YES).

The following properties can be changed only when the keypad is disabled (kp.enabled= 0- NO): [kp.autodisablecodes](#)<sup>[312]</sup>, [kp.longreleasedelay](#)<sup>[313]</sup>, [kp.longpressdelay](#)<sup>[313]</sup>, [kp.pressdelay](#)<sup>[315]</sup>, [kp.repeatdelay](#)<sup>[315]</sup>, [kp.returlinesmapping](#)<sup>[316]</sup>, [kp.scanlinesmapping](#)<sup>[317]</sup>.

The keypad will be auto-disabled if an overflow is detected (see [on\\_kp\\_overflow](#)<sup>[314]</sup> event), or if one of the conditions for automatic keypad disablement is met (see [kp.autodisablecodes](#)<sup>[312]</sup>).

Every time the keypad is enabled, each key's state is set to 0- PL\_KP\_EVENT\_LONGRELEASED and the keypad event buffer is cleared.

## .Longpressdelay Property

<b>Function:</b>	Defines (in 10ms increments) the amount of time a key should remain pressed for the key state to transition from "pressed" into "longpressed".
<b>Type:</b>	Byte
<b>Value Range:</b>	0-254. <b>Default</b> = 100 (1000ms).
<b>See Also:</b>	<a href="#">Key States and Transitions</a> <sup>[306]</sup> , <a href="#">Preparing the Keypad for Operation</a> <sup>[307]</sup>

## Details

The [on\\_kp](#)<sup>[314]</sup> event with 3- PL\_KP\_EVENT\_LONGPRESSED event code will be generated once the key transitions into the "longpressed" state.

This property can only be changed when the keypad is disabled ([kp.enabled](#)<sup>[312]</sup>= 0- NO). Setting the property to 0 means that the key will never transition into the "longpressed" state.

## .Longreleasedelay Property

<b>Function:</b>	Defines (in 10ms increments) the amount of time a key should remain released for the key state to transition from "released" into "longreleased".
<b>Type:</b>	Byte
<b>Value Range:</b>	0-254. <b>Default</b> = 100 (1000ms).
<b>See Also:</b>	<a href="#">Key States and Transitions</a> <sup>[306]</sup> , <a href="#">Preparing the Keypad for Operation</a> <sup>[307]</sup>

## Details

The [on\\_kp](#)<sup>[314]</sup> event with 0- PL\_KP\_EVENT\_LONGRELEASED event code will be generated once the key transitions into the "longreleased" state.

This property can only be changed when the keypad is disabled ([kp.enabled](#)<sup>[312]</sup>= 0-NO). Setting the property to 0 means that the key will never transition into the "longreleased" state.

## On\_kp Event

**Function:** Generated whenever a key transitions to another state.

**Declaration:** `on_kp(key_event as pl_kp_event_codes, key_code as byte)`

**See Also:** [Servicing Keypad Events](#)<sup>[310]</sup>, [on\\_kp\\_overflow](#)<sup>[314]</sup>

Part	Description
key_event	0- PL_KP_EVENT_LONGRELEASED: The key has transitioned into the "longreleased" state. 1- PL_KP_EVENT_RELEASED: The key has transitioned into the "released" state. 2- PL_KP_EVENT_PRESSED: The key has transitioned into the "pressed" state. 3- PL_KP_EVENT_LONGPRESSED: The key has transitioned into the "longpressed" state. 4- PL_KP_EVENT_REPEATPRESSED: Auto-repeat for the key.
key_code	Key code (byte). Bits 7-4 of this code represent scan line number, bits 3-0 -- return line number.

### Details

Pressing and releasing any key on the keypad can generate up to five different events, as explained in [Key States and Transitions](#)<sup>[306]</sup>. Scan lines and return lines are numbered as they are listed in [kp.returnlinesmapping](#)<sup>[316]</sup> and [kp.scanlinesmapping](#)<sup>[317]</sup>.

This event can only be generated when the keypad is enabled ([kp.enabled](#)<sup>[312]</sup>= 1-YES).

## On\_kp\_overflow Event

**Function:** Indicates that the keypad buffer has overflowed and some key events may have been lost.

**Declaration:** `on_kp_overflow`

**See Also:** [Servicing Keypad Events](#)<sup>[310]</sup>

### Details

The keypad buffer stores up to 16 keypad events. Each such event causes the [on\\_kp](#)<sup>[314]</sup> generation. If your application is slow to process the keypad events, it is possible to overflow the keypad by pressing the keys in rapid succession. Once the

buffer overflows, the keypad is disabled automatically ([kp.enabled](#)<sup>[312]</sup> is set to 0-NO). You can re-enable the keypad by setting `kp.enabled= 1- YES` (this will clear the keypad buffer).

## .Pressdelay Property

<b>Function:</b>	Defines (in 10ms increments) the amount of time a key should remain pressed for the key state to transition from "released" into "pressed".
<b>Type:</b>	Byte
<b>Value Range:</b>	0-254. <b>Default</b> = 3 (30ms).
<b>See Also:</b>	<a href="#">Key States and Transitions</a> <sup>[306]</sup> , <a href="#">Preparing the Keypad for Operation</a> <sup>[307]</sup>

---

### Details

The [on\\_kp](#)<sup>[314]</sup> event with 2- PL\_KP\_EVENT\_PRESSED event code will be generated once the key transitions into the "pressed" state.

This property can only be changed when the keypad is disabled ([kp.enabled](#)<sup>[312]</sup>= 0-NO). Setting the property to 0 means that the key will never transition into the "pressed" state.

## .Releasedelay Property

<b>Function:</b>	Defines (in 10ms increments) the amount of time a key should remain released for the key state to transition from "pressed" or "longpressed" into "released".
<b>Type:</b>	Byte
<b>Value Range:</b>	0-254. <b>Default</b> = 3 (30ms).
<b>See Also:</b>	<a href="#">Key States and Transitions</a> <sup>[306]</sup> , <a href="#">Preparing the Keypad for Operation</a> <sup>[307]</sup>

---

### Details

The [on\\_kp](#)<sup>[314]</sup> event with 1- PL\_KP\_EVENT\_RELEASED event code will be generated once the key transitions into the "released" state.

This property can only be changed when the keypad is disabled ([kp.enabled](#)<sup>[312]</sup>= 0-NO). Setting the property to 0 means that the key will never transition into the "released" state.

## .Repeatdelay Property

<b>Function:</b>	Defines (in 10ms increments) the time period at which the <a href="#">on_kp</a> <sup>[314]</sup> event with 4- PL_KP_EVENT_REPEATPRESSED event code will be generated once the key reaches the "longpressed" state and remains pressed.
------------------	---

<b>Type:</b>	Byte
<b>Value Range:</b>	0-254. <b>Default</b> = 50 (500ms).
<b>See Also:</b>	<a href="#">Key States and Transitions</a> <sup>[306]</sup> , <a href="#">Preparing the Keypad for Operation</a> <sup>[307]</sup>

### Details

This property can only be changed when the keypad is disabled ([kp.enabled](#)<sup>[312]</sup>= 0-NO). Setting the property to 0 means that the on\_kp event with 4-PL\_KP\_EVENT\_REPEATPRESSED event code will never be generated.

## .Returnlinesmapping Property

<b>Function:</b>	Defines the list of up to 8 I/O lines that will serve as return lines of the keypad matrix.
<b>Type:</b>	String
<b>Value Range:</b>	Up to eight comma-separated I/O line numbers can be listed. <b>Default</b> = "".
<b>See Also:</b>	<a href="#">Possible Keypad Configurations</a> <sup>[304]</sup> , <a href="#">Preparing the Keypad for Operation</a> <sup>[307]</sup> , <a href="#">kp.scanlinesmapping</a> <sup>[317]</sup>

### Details

This property should contain a comma-separated list of I/O lines numbers, for example: "24, 26, 27". Line numbers correspond to those of the pl\_io\_num enum. This enum is platform-specific. The declarations for the pl\_io\_num can be found in the "Platform-dependent Constants" section of your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

The kp.returnlinesmapping string should only contain a list of decimal numbers. That is, use "24" and not "24- PL\_IO\_NUM\_24". Only numerical characters are processed anyway -- writing "24- PL\_IO\_NUM\_24,25-PL\_IO\_NUM\_25" will set this property to "24,25". You can, of course, write str(PL\_IO\_NUM\_24)+"," +str(PL\_IO\_NUM\_25) as well.

The order in which you list the return lines *does matter* -- this is the order in which the lines will be numbered. All keys connected to the first return line will have their return field (bits 4-0) of the key code set to 0. For keys connected to the second line this field will contain 1, third line -- 2, and so on.

On platforms with [output buffer control](#)<sup>[296]</sup>, all intended return lines should be configured as inputs by your application (see [io.num](#)<sup>[301]</sup>, [io.enabled](#)<sup>[298]</sup>).

This property can only be changed when the keypad is disabled ([kp.enabled](#)<sup>[312]</sup>= 0-NO). Setting the property to "" means that the keypad will have no return lines. A keypad must have at least one return line to be able to work.

Return lines of the keypad should be separate from the scan lines (see [kp.scanlinesmapping](#)<sup>[317]</sup>). The keypad will not work properly if you designate any I/O line as both a scan and return line.

## .Scanlinesmapping Property

<b>Function:</b>	Defines the list of up to 8 I/O lines that will serve as scan lines of the keypad matrix.
<b>Type:</b>	String
<b>Value Range:</b>	Up to eight comma-separated I/O line numbers can be listed. <b>Default</b> = "".
<b>See Also:</b>	<a href="#">Possible Keypad Configurations</a> <sup>[304]</sup> , <a href="#">Preparing the Keypad for Operation</a> <sup>[307]</sup> , <a href="#">kp.scanlinesmapping</a> <sup>[317]</sup>

### Details

This property should contain a comma-separated list of I/O lines numbers, for example: "28, 30, 31". Line numbers correspond to those of the `pl_io_num` enum. This enum is platform-specific. The declarations for the `pl_io_num` can be found in the "Platform-dependent Constants" section of your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

The `kp.scanlinesmapping` string should only contain a list of decimal numbers. That is, use "28" and not "28- PL\_IO\_NUM\_28". Only numerical characters are processed anyway -- writing "28- PL\_IO\_NUM\_28,30-PL\_IO\_NUM\_30" will set this property to "28,30". You can, of course, write `str(28- PL_IO_NUM_28)+","+str(30- PL_IO_NUM_30)` as well.

The order in which you list the scan lines *does matter* -- this is the order in which the lines will be numbered. All keys connected to the first scan line will have their scan field (bits 7-4) of the key code set to 0. For keys connected to the second line this field will contain 1, third line -- 2, and so on.

On platforms with [output buffer control](#)<sup>[296]</sup>, all intended scan lines should be configured as outputs by your application (see [io.num](#)<sup>[301]</sup>, [io.enabled](#)<sup>[298]</sup>).

This property can only be changed when the keypad is disabled (`kp.enabled`<sup>[312]</sup>= 0-NO). Setting the property to "" means that the keypad will have no scan lines, which is also a *valid* keypad configuration.

Scan lines of the keypad should be separate from the return lines (see [kp.returnlinesmapping](#)<sup>[316]</sup>). The keypad will not work properly if you designate any I/O line as both the scan line and return line.

## LCD Object



This is the display (lcd.) object, it allows you to operate a display panel. With the `lcd.` object you can:

- Use any display from a growing list of [supported controllers/panels](#)<sup>[333]</sup>.
- Inquire about the [properties](#)<sup>[318]</sup> of selected controller/panel.
- Draw [pixels](#)<sup>[320]</sup>, [lines](#)<sup>[321]</sup>, and [rectangles](#)<sup>[321]</sup>; [fill areas](#)<sup>[321]</sup>.
- [Print text](#)<sup>[322]</sup> -- non-aligned, aligned, rotated, etc.
- Display [BMP images](#)<sup>[329]</sup>.

## Overview, 6.1

In this section:

- [Understanding Controller Properties](#)<sup>[318]</sup>
- [Preparing the Display for Operation](#)<sup>[320]</sup>
- [Working With Pixels and Colors](#)<sup>[320]</sup>
- [Lines, Rectangles, and Fills](#)<sup>[321]</sup>
- [Working With Text](#)<sup>[322]</sup>
- [Displaying Images](#)<sup>[329]</sup>
- [Improving Graphical Performance](#)<sup>[330]</sup>
- [Supported Controllers/Panels](#)<sup>[333]</sup>

### Understanding Controller Properties

Display panels come in all types, shapes, and sizes. Tibbo supports a limited but growing number of [controllers/panels](#)<sup>[333]</sup>. Each supported controller requires its own "mini-driver". Your application cannot specify the desired controller. Instead, controller type is selected through the Customize Platform dialog, accessible through the Project Settings dialog. Once this is done, a proper "mini-driver" is added to the executable binary during compilation.


The `lcd` object is ready to work with a wide range of displays, some of which are not actually of LCD type. So, the proper name for this object should be "display object". Nevertheless, we have decided to keep this name -- typing "lcd" is faster and the name has been in use for a while.

A number of R/O properties inform your application about the type and other vital parameters of the currently selected display:

[`Lcd.paneltype`](#)<sup>[349]</sup> indicates whether this panel is of monochrome/grayscale or color type.

[`Lcd.bitsperpixel`](#)<sup>[339]</sup> tells you how many bits in the display controller's memory are allocated for each display pixel. Of course, the more bits/pixel you get, the higher is your display quality.


For displays with 1, 2, or 4 bits/pixel, a single byte of memory packs the data for 8, 4, or 2 pixels. [`Lcd.pixelpacking`](#)<sup>[350]</sup> will inform you how pixels are packed into memory bytes: vertically, or horizontally (see the drawing below). The reason you may want to know this is to achieve faster [text output](#)<sup>[322]</sup>.



### Color displays

For color displays (`lcd.paneltype= 1- PL_LCD_PANELTYPE_COLOR`), three additional R/O properties -- `lcd.redbits`<sup>[352]</sup>, `lcd.greenbits`<sup>[345]</sup>, and `lcd.bluebits`<sup>[340]</sup> -- will indicate how many bits are available in each color channel, and also how three color fields are combined into a word describing the overall color of the pixel. You need to know this for setting pixels, as well as defining the foreground/background color used in drawing lines and rectangles, filling areas, and printing text (see [Working With Pixels and Colors](#)<sup>[320]</sup>).

These three properties are of word type. Each 16-bit value packs two 8-bit parameters: number of bits per pixel for this color channel (high byte) and the bit position of the field in the color word (low byte). Supposing, `lcd.redbits=&h0500`, `lcd.bluebits=&h0605`, and `lcd.greenbits=&h050B`. You reconstruct the composition of the red, green, and blue bits in a word:



In this example, the red field is the first one on the right, followed by the blue field (this field starts from bit 5), then green field (starts from bit 11 or 7hB). You now also know that there are  $5^2=32$  brightness levels for red and green, and 64 brightness levels for blue.

You can use this detailed information to select color values that will work correctly on all color displays, even those you haven't tested yet. Here is a useful example where you work out three constants -- `color_red`, `color_green`, and `color_blue` -- that will universally work for any color display.

```
Dim color_red, color_green, color_blue As word
...
```

```

lcd_red=val("&b"+strgen(lcd.redbits/&hFF,"1")+strgen(lcd.redbits And
&hFF,"0"))
lcd_green=val("&b"+strgen(lcd.greenbits/&hFF,"1")+strgen(lcd.greenbits And
&hFF,"0"))
lcd_blue=val("&b"+strgen(lcd.bluebits/&hFF,"1")+strgen(lcd.bluebits And
&hFF,"0"))

```

Now you can scientifically work out the constant for the white color:

```

...
lcd_white=lcd_red+lcd_green+lcd_blue

```

- In reality, you don't have to bother calculating `color_white` like this. Just select the highest possible value (`&hFFFF`) and this will be your white.

## Preparing the Display for Operation

Several steps need to be taken before the display will become operational. Some of these steps are display-specific. [Supported Controllers/Panels](#)<sup>[333]</sup> section provides examples of startup code for each supported display.

Generally speaking, you need to take the following steps:

- Define which I/O lines and ports of your device control the display. This is done through the [lcd.iomapping](#)<sup>[347]</sup> property.
- Configure some I/O lines/ports as outputs, as required for controlling your particular display. This is only necessary on platforms with [explicit output buffer control](#)<sup>[194]</sup>. For more details see your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).
- Set the resolution of the display ([lcd.width](#)<sup>[357]</sup>, [lcd.height](#)<sup>[346]</sup>). These values depend on the panel, not the controller, so they cannot be detected automatically. Your application needs to set them "manually".
- Set [lcd.rotated](#)<sup>[353]</sup>= 1- YES if you wish the display image to be rotated 180 degrees (that is, the display of your device is installed up side down).
- Set [lcd.inverted](#)<sup>[347]</sup>= 1- YES if you need to invert the image on the display (may be required for certain panels).
- Enable the display by setting [lcd.enabled](#)<sup>[347]</sup>= 1- YES. This step will only work if your display is properly connected, correct display type is selected in your project, `lcd.iomapping` is set property, and necessary I/O lines are configured as outputs. The [lcd.error](#)<sup>[342]</sup> R/O property will indicate 1- YES if there was a problem enabling the display.
- Enable, the backlight, if needed -- this is not related to the controller/panel itself, but is still a necessary step. Light it up, don't linger in the dark!

## Working With Pixels and Colors

The [lcd.setpixel](#)<sup>[354]</sup> method allows you to set the color of a single pixel. The method accepts a 16-bit color word, and the interpretation of this word is controller/panel-specific (see [Understanding Controller Properties](#)<sup>[318]</sup>). In the following example, we determine the proper value for the green color and put a single green dot in the middle of the display:

```
Dim color_green As word
...
lcd_green=val("&b"+strgen(lcd.greenbits/&hFF,"1")+strgen(lcd.greenbits And
&hFF,"0"))
lcd.setpixel(lcd_green,lcd.width/2,lcd.height/2)
```

Lcd.setpixel is the only method that accepts the color directly. All other methods rely on two color properties: [lcd.forecolor](#)<sup>[344]</sup> and [lcd.backcolor](#)<sup>[339]</sup>. Each property is a 16-bit value, just like the one used by the lcd.setpixel. The forecolor is the color of the "drawing pen", and the backcolor is the color of the background. In the following example, we set the lcd.forecolor to the brightest color available, and the lcd.backcolor to the darkest color available:


```
lcd.forecolor=&hFFFF
lcd.backcolor=0
```

The following methods are provided to output data onto the screen, and they all use the lcd.forecolor and, where necessary, the lcd.backcolor:

- [Lcd.line](#)<sup>[348]</sup>, [Lcd.verline](#)<sup>[357]</sup>, [Lcd.horline](#)<sup>[346]</sup> -- the line is drawn using the forecolor.
- [Lcd.rectangle](#)<sup>[352]</sup> -- the border is drawn using the forecolor, the internal area of the rectangle is not filled.
- [Lcd.filledrectangle](#)<sup>[343]</sup> -- the border is drawn using the forecolor, the internal area is filled with the backcolor.
- [Lcd.fill](#)<sup>[342]</sup> -- the entire area is filled with the forecolor.
- [Lcd.print](#)<sup>[351]</sup> and [Lcd.printaligned](#)<sup>[351]</sup> -- print text, where each "on" dot of each character is displayed in forecolor, while each "off" dot is displayed in backcolor.

The following two sections -- [Lines, Rectangles, and Fills](#)<sup>[321]</sup>, and [Working With Text](#)<sup>[322]</sup> -- discuss the above methods in more details.

## Lines, Rectangles, and Fills



### Lines

The [lcd.line](#)<sup>[348]</sup> method draws a line between any points. [Lcd.verline](#)<sup>[357]</sup> and [lcd.horline](#)<sup>[346]</sup> draw vertical and horizontal lines correspondingly. Use the last two methods whenever possible because they work faster than generic lcd.line. The line is drawn using the color set in the [lcd.forecolor](#)<sup>[344]</sup> property (see [Working With Pixels/Lines](#)<sup>[320]</sup>), and the line width is defined by the [lcd.linewidth](#)<sup>[348]</sup> property. In the following example, we draw a picture as shown above, on the left:

```
lcd.forecolor=color_blue 'we assume we have already set color_blue
lcd.verline(0,0,20) 'vertical line, width=1 (default)
lcd.horline(0,20,0) 'horizontal line, width=1 (default)
lcd.linewidth=3 'change the width
lcd.line(2,2,20,20) 'line at 45 degrees, width=3
```

Defining `lcd.linewidth>1` (3 for one of the lines in the above example) creates "fatter" lines. Notice how two points of the line are drawn and where each specified coordinate actually is.

## Rectangles

[Lcd.rectangle](#)<sup>[352]</sup> draws an unfilled rectangle using `lcd.forecolor` as "pen" color, and pen width defined by the `lcd.linewidth` property. [Lcd.filledrectangle](#)<sup>[343]</sup> will additionally paint the internal area using `lcd.backcolor`. Example and its result:

```
lcd.forecolor=color_blue 'we assume we have already set color_blue
lcd.backcolor=color_green 'we assume we have already set color_green
lcd.rectangle(0,0,20,20) 'width=1 (default)
lcd.linewidth=3
lcd.filledrectangle(5,5,15,15) 'width=3, filled with background color
```

## Fills

[Lcd.fill](#)<sup>[342]</sup> paints specified area with the `lcd.forecolor`:

```
lcd.forecolor=color_blue 'we assume we have already set color_blue
lcd.fill(0,0,16,16)
lcd.forecolor=color_green 'we assume we have already set color_green
lcd.fill(5,5,16,16)
```

## Working With Text

[Lcd.print](#)<sup>[351]</sup> and [Lcd.printaligned](#)<sup>[351]</sup> display text. The text is printed using the selected font. This means you need to have at least one font file in your project (see how to [add](#)<sup>[132]</sup> a file), and have this font selected before you can print anything.

[Lcd.setfont](#)<sup>[353]</sup> is used to select the font:

```
romfile.open("Tibbo-5x7 (VP).bin")
lcd.setfont(romfile.offset)
```

Note that `lcd.setfont` will return 1- NG if you try to feed it a wrong file!

Once the font has been successfully selected, the `lcd.fontheight`<sup>[343]</sup> and `lcd.fontpixelpacking`<sup>[344]</sup> R/O properties will tell you the maximum height of characters in this font and how pixel data is packed within the font file. The meaning of the first one is obvious. The meaning of the second one will become apparent after (and if) you read [Raster Font File \(TRF\) Format](#)<sup>[325]</sup>. If you don't want to read this, it's OK too, we can just go straight to the summary:


Fonts can be encoded horizontally or vertically, and the `lcd.fontpixelpacking` will tell you what type of font you have selected. You should only care about this for displays with `lcd.bitsperpixel`<sup>[339]</sup><8. if your display has `lcd.bitsperpixel`>8 then it doesn't matter what kind of font you use. If it is <8, then you are better off selecting a font for which `lcd.fontpixelpacking` is equal to `lcd.pixelpacking`<sup>[350]</sup> (depends on selected controller/panel). You achieve better performance when these two properties are "aligned". It will also work if you select a font which is "perpendicular" to your display, but text printing might slow down considerably.

We typically offer two versions for each font, for example, "Tibbo-5x7(V).bin" and "Tibbo-5x7(H)". V stands for "vertical" and "H" stands "horizontal".

### Non-aligned text

Once the font has been selected, you can start printing. You do this with the `lcd.print`<sup>[351]</sup> method. This method always produces a single-line output. Two properties -- `lcd.textorientation`<sup>[356]</sup> and `lcd.texthorizontalspacing`<sup>[355]</sup> -- affect how your text is printed. The reference point of your text is at the top-left pixel of the output. X and Y arguments of `lcd.print` specify this corner, and the text is rotated "around" this pixel as well. Example:

```
lcd.print("Text", 30, 10)
lcd.textorientation=PL_LCD_TEXT_ORIENTATION_180
lcd.texthorizontalspacing=4
lcd.print("Text", 30, 10)
```



`lcd.print` returns the total width of produced textual output in pixels. This can be very useful. Here is an example where you draw a frame around the text, and you want the frame size to be "just right":

```
x=lcd.print("Text", 30, 10)
lcd.rectangle(28, 8, 30+x+1, 10+lcd.fontheight+1)
```


Sometimes, it is desirable to know the width of the text output before actual printing. `lcd.getprintwidth`<sup>[345]</sup> will tell you how many pixels will be taken by your text horizontally (remember, text height is equal to `lcd.fontheight`<sup>[343]</sup>). In the following example, we align the text output along the right side of the screen. This requires us to know how wide this output will be:

```
x=lcd.getprintwidth("Text")
x=lcd.print("Text",lcd.width-x,10)
```

### Aligned text

The `lcd.printaligned`<sup>[351]</sup> method outputs your text within a specified rectangular area. Four properties -- `lcd.textorientation`<sup>[356]</sup>, `lcd.textalignment`<sup>[355]</sup>, `lcd.texthorizontalspacing`<sup>[355]</sup>, and `lcd.textverticalspacing`<sup>[356]</sup> -- define how your text will be printed. To fit within the target area, the `lcd.` object will split the text into several lines as necessary. Only the text that can fit within the area will be displayed. You can add your own line breaks by using the ``` character (ASCII code 96). Example:

```
lcd.textverticalspacing=2
lcd.textalignment=PL_LCD_TEXT_ALIGNMENT_BOTTOM_RIGHT
lcd.printaligned("Multi-line text",0,0,35,33)
```




Note that `lcd.printaligned` returns the number of text lines that were produced.

## Raster Font File Format

This topic details font file format used by the LCD object. The font file is a resource file that is added to your Tibbo Basic project. Like all other resource files "attached" to your project, font files are accessible through the [romfile](#)<sup>[370]</sup> object. Use and interpretation of font file data, however, is the responsibility of the lcd.object. The Romfile object merely stores these files.

Tibbo font files have "TRF" (Tibbo Raster Font) extension. TRF file format was designed with the following considerations in mind:

- Ability to handle large character sets (such as those required for Chinese language support). Hence, the use of 16-bit character codes.
- 16-bit character sets usually have large "gaps" (i.e. areas of unused codes). The TRF format offers an efficient way to define which characters are included into the font file and allows to conduct very efficient character search within the file.
- Support for proportional fonts. Hence, each character's width is individually defined.
- Support for fonts with anti-aliasing. Anti-aliasing is achieved by adjusting the "intensity" (brightness) of individual pixels. In an anti-aliased font, each pixel of character bitmap is represented by 2 or more bits of data. Fonts without anti-aliasing just need 1 data bit/pixel because each pixel can only be ON or OFF. At the time of writing, TiOS supported only fonts with 1 bit/pixel.
- Support for vertical and horizontal character bitmap encoding. Displays with [lcd.bitsperpixel](#)<sup>[339]</sup> = 1, 2, or 4 pack 8, 4, or 2 pixels into a single byte of display memory. Problem is, some displays combine the pixels vertically (see drawing A below), and some -- horizontally (drawing B). Text output on such displays is more efficient if character bitmaps of the TRF file use the same direction of packing.



### TRF file format

The TRF file consists of four data areas:

Data area	Description
Header	Contains various information such as the total number of characters in this font, character height, etc. Also contains the number of code groups in the code groups table (see below).
Code groups table	Contains descriptors of "code groups". Each code group contains information about a range of codes that has no "gaps" (i.e. unused codes in the middle). The font file can have as many code groups as necessary.
Bitmap offset table	Contains addresses (offsets) of all character bitmaps in the TRF file. In combination with the code groups table provides a way to find the bitmap of any specific character.
Bitmaps	Contains all bitmaps of each character included into the font file. The width of each bitmap is defined individually and is stored together with the bitmap.

### Header format

The header has a fixed length of 16 bytes and stores the following information:

Offset*	Bytes	Data	Comment
+0	2	<b>Num_of_chars</b>	Total number of characters in this font file
+2	1	<b>Pixels_per_byte</b>	0- eight pixels/byte (1 bit/pixel, no anti-aliasing); 1- four pixels/byte, 2- two pixels/byte, 3- one pixel/byte. Modes 1, 2, and 3 are currently not supported; these modes are for anti-aliasing and will be supported in the future.
+3	1	<b>Orientat ion</b>	0- pixels are grouped vertically; 1- pixels are grouped horizontally (irrelevant when <b>pixels_per_byte</b> =3)
+4	1	<b>Height</b>	Maximum character height in this font, in pixels.
+5	9	<Reserv ed>	Reserved for future use
+14	2	<b>Num_of _groups</b>	Number of entries in the code groups table

\*With respect to the beginning of the file

### Code groups table

This table has variable number of entries. This number is stored in the **num\_of\_groups** field of the header. Each code group represents a range of codes that contains no gaps (no unused character codes in the middle). For example, supposing that we have a font that only contains characters '0'-'9' and 'A'-'Z'. This means that this font file will contain two groups of codes: 0030H through 0039H ('0'-'9') and 0041H through 005AH ('A'-'Z').

Each entry in the code groups table is 8 bytes long and has the following format:

Of fs et *	B y t e s	Data	Comment
+0	2	<b>Start_code</b>	The first code in the group
+2	2	<b>Num_codes</b>	Number of individual character codes in this group
+4	4	<b>Bitmap_addr_offset</b>	Address (that falls within the bitmap offset table and is given with respect to the beginning of the file) at which the address of the bitmap of the first character in the code group is stored.

\* *With respect to the beginning of a particular table entry*

For the above example the code groups table will have two entries:

Start_code	Num_codes	Bitmap_offset
0030H	000AH	00000020H
0041H	001AH	00000048H

Here is how the above data was calculated. Start codes are obvious. Group one starts with code 0030H because this is the character code of '0'. The second group starts with the character code of 'A'. It is also easy to fill out the number of codes in each group: 10 (000AH) for '0'-'9' and 26 (001AH) for 'A'-'Z'.

**Bitmap\_addr\_offset** calculation is explained in the next section.

### Bitmap offset table

This table has the same number of entries as the total number of characters included in the font file. Each entry consists of one field -- a 32-bit offset of a particular bitmap with respect to the beginning of the font file. Now you can see how we were able to calculate the data for the **bitmap\_addr\_offset** field of the code groups table. The header of the font file has a fixed length of 16 bytes. There are two code groups in our example, so the code groups table occupies  $8 \times 2 = 16$  bytes. This means that the bitmap offset table starts from address  $16 + 16 = 32$  (0020H). Hence, the first entry in the code groups table points at address 0020H. The first code group contains 10 characters ('0'-'9'). These will "occupy" 10 entries in the bitmap offset table, which results in  $10 \times 4 = 40$  bytes. Hence, the **bitmap\_addr\_offset** field for the second code group is set to  $32 + 40 = 72$  (0048H).

### Bitmaps

Each bitmap starts with a single byte that encodes the width of the bitmap in pixels, followed by the necessary number of bytes representing this bitmap. Depending on the **pixels\_per\_byte** field of the header, each byte of data may


encode just one or several pixels. Additionally, when using more than 1 pixel-per-byte encoding, the **orientation** field of the header defines whether pixels are combined horizontally or vertically.

The drawings below illustrate how character bitmaps are stored in the font file. As an example, characters of 10x14 size (in pixels) are used. Drawing A is for one pixel/byte encoding, drawing B -- for 8 pixels/byte with vertical orientation, C -- for 8 pixels/byte with horizontal orientation. Notice that for cases B and C a portion of some bytes used to store the bitmaps is unused. Offsets of bytes relative to the beginning of the bitmap data are shown with a '+' sign.

Bitmap A takes 140 bytes. The first byte (+0) represents the pixel at the top left corner of the bitmap. Subsequent bytes represent all other pixels and the order is "left-to-right, top-to-bottom".

Bitmap B takes 20 bytes. The first byte encodes 8 vertically arranged pixels at the top left corner of the bitmap. Subsequent bytes represent all other pixel groups and the order is "left-to-right, top-to-bottom". There are 2 rows of bytes, and bits 6 and 7 of each byte in the second row are unused.

Bitmap C takes 28 bytes. The first byte encodes 8 horizontally arranged pixels at the top left corner of the bitmap. Subsequent bytes represent all other pixel groups and the order is "top-to-bottom, left-to-right". There are 2 columns of bytes, and bits 2-7 of each byte in the second column are unused.



### Searching for a character bitmap

Here is how a target character bitmap is found within the font file. Again, we are using the example of the font file that contains characters '0'-'9' and 'A'-'Z'.

Supposing, we need to find the bitmap of character 'C' (code 0043H).

First, we need to see which code group code 004AH belongs to. We read the **num\_of\_groups** field of the header to find out how many code groups are contained in the font file. The field tells us that there are two groups.

Next, we start reading the code groups table (located at file offset +00000010H), entry by entry, in order to determine which code group the target character belong to. The first group starts from code 0030H and contains 10 character. Therefore, target character doesn't belong to it. The second group starts from code 0041H and contains 26 characters. The target code is 0043H. Therefore, target character belongs to this second group.

Next, we find the corresponding entry in the bitmap offset table. For this, we do a simple calculation:

**bitmap\_offset** + (desired\_code - **start\_code**)\*4: 00000048H + (0043H-0041H)\*4= 00000050H.


Next, we read a 32-bit value at file offset 00000050H. This will tell us the file offset at which the target bitmap is stored.

At this file offset, the first byte will be the width of the bitmap in pixels. Based on this width and also **height**, **pixels\_per\_byte** and **orientation** fields of the header we can calculate the number of bytes in the bitmap. For example, supposing that **height** = 14, **pixels\_per\_byte** = 0 (8 pixels/byte), and **orientation** = 0 (pixels are grouped vertically). Also, let's suppose that the width of the target character is 10 pixels. In this case the bitmap will occupy 20 bytes, as shown on the drawing B above. Two bits of each byte in the second byte row will be unused.

## Displaying Images

`Lcd.bmp`<sup>[340]</sup> outputs a full image, or a portion of the image from a BMP file. Naturally, this file must be present in your project (see how to `add`<sup>[132]</sup> a file). Here is a simple example of how to display an image:


```
romfile.open("mad_happiness.bmp")
lcd.bmp(romfile.offset,0,0,0,0,65535,65535) 'see how we set maxwidth and
maxheight to 65535 (max value). This way we specify that the entire image
should be displayed (if only it can fit on the screen)
```



One powerful feature of the `lcd.bmp` method is that you can selectively display a portion of the image stored in a BMP file. This opens up two interesting possibilities. First, you can scroll around a large file image by specifying which part you want to see. Second, you can combine several images into one large file and display required portions when needed. For example, if your project requires several icons you can put them all into a single "strip". This improves performance because you

don't have to open a separate file to display each icon:

```
romfile.open("icon_strip.bmp")
lcd.bmp(romfile.offset,0,0,11,0,11,11) 'display the second icon (right
arrow)
```



Note that only 2-, 16-, and 256-color modes are currently supported and the `lcd.bmp` will return 1-NG if you try to display any other type of BMP file. Compressed BMP files will be rejected too.

The method takes into account the type of the currently selected controller/panel. The method will check the values of `lcd.paneltype`<sup>[349]</sup>, `lcd.bitsperpixel`<sup>[339]</sup>, `lcd.redbits`<sup>[352]</sup>, `lcd.greenbits`<sup>[345]</sup>, and `lcd.bluebits`<sup>[340]</sup> (explained in [Understanding Controller Properties](#)<sup>[318]</sup>) and produce the best output possible for the selected display.

## Improving Graphical Performance

Nobody likes sluggish products, and the way you work with your display can greatly influence *perceived* performance of your product. We say "perceived" because very often this has nothing to do with the actual speed at which your device completes required operations.

### Group display-related operations together

The most important aspect of your application's performance (related to the display) is how fast the data on the display appears to have changed. Interestingly, what matters most is not the total time it takes to prepare and show the new data, but the "togetherness" at which all new displayed items pop up on the screen.

Let's illustrate this point. Here are two code examples that do the same and take roughly the same time to execute. We calculate and print two values. In the first

example, we calculate and print value 1, then calculate and print value 2:

```
Dim dw1,dw2 As dword
...
'Note so good! The user will see a noticeable delay between the first and
the second print.
lcd.print(str(dw1*100/200),0,0)
lcd.print(str(dw2*100/200),0,10)
```

In the second example we calculate values 1 and 2 first, then print them together:

```
Dim dw1,dw2 As dword
Dim s1,s2 As String
...
'Much better. The user will have a feeling that both values were calculated
and printed instantly!
s1=str(dw1*100/200)
s2=str(dw2*100/200)
lcd.print(s1,0,0)
lcd.print(s2,0,10)
```

Testing both examples shows that the perceived performance of the second code snippet is much better, while, in fact, the total working time of the processor was roughly the same. Why is there a difference? Because the output of the two values in the second example was spaced closer!

Bottom line: keep all display output as close together as possible. Pre-calculate everything first, then display all your items "at once".

### Use display locking

No matter how hard you try to group all display-related output together, executing lcd. object's methods one after another may still take considerable time. Perceived performance can be improved on displays that allow you to "lock" display picture, change display data, then unlock the display again. With this approach, the user will see all changes appear instantly! Not all displays are suitable for this. Typically, this works well for TFT panels which continue to display the image for several seconds after the "refresh" was disabled. Other display types are not suitable for locking. We have provided locking-related info for each [supported controller/panel](#) <sup>333</sup>.

The display is locked/unlocked using the [Lcd.lock](#)<sup>348</sup> and [lcd.unlock](#)<sup>356</sup> methods. You can place lcd.lock before the block of code that changes display data, and put lcd.unlock at the end of this code block:

```
...
s1=str(dw1*100/200)
s2=str(dw2*100/200)
lcd.lock 'lock the display
lcd.print(s1,0,0)
lcd.print(s2,0,10)
```

```
lcd.unlock 'unlock the display
...
```

Display-related code is often nested, with one procedure calling another, and so on. If you are using display locking, you should ideally place locks/unlocks in each related routine. A complication arises with regards to when to unlock the display. For example, supposing you have two subs: lcd\_sub1 and lcd\_sub2:

```
'some main routine that invokes lcd_sub1 and lcd_sub2
....
....
lcd_sub1
...
...
lcd_sub2
...
End Sub

'-----
Sub lcd_sub1 'calls sub2 too
lcd.lock
...
lcd_sub2
...
lcd.unlock
End Sub

'-----
Sub lcd_sub2 'called by sub1
lcd.lock
...
lcd.unlock
End Sub
```

Lcd\_sub2 gets executed when invoked directly by the main code, and also when the lcd\_sub1 is called. In the second case, the display should not be unlocked at the end of lcd\_sub2 because the output is to be continued in lcd\_sub1! And you know what? The display won't be unlocked because with the lcd object it is possible to nest locks/unlocks! In the following example, we do three consecutive locks and the display is locked right on the first one. We then do three consecutive unlocks, and the display is not unlocked until after the third one is executed:

```
...
lcd.lock 'lcd.lockcount=1, display is now locked
lcd.lock 'lcd.lockcount=2
lcd.lock 'lcd.lockcount=3
lcd.unlock 'lcd.lockcount=2
lcd.unlock 'lcd.lockcount=1
lcd.unlock 'lcd.lockcount=0, display is now unlocked
...
```

The lock/unlock mechanism maintains a counter, which can actually be read through the [lcd.lockcount](#)<sup>[349]</sup> R/O property. Each invocation of `lcd.lock` increments the counter by 1, each `lcd.unlock` decrements it by 1. The display is only unlocked when the counter is at 0, and locked when the counter is >0. This allows you to nest display-related procedures and safely have lock/unlock in each one of them!

## Supported Controllers/Panels

The following controllers/panels are currently supported:

- [Samsung S6B0108 \(Winstar WG12864F\)](#)<sup>[333]</sup>.
- [Solomon SSD1329 \(Ritdisplay RGS13128096\)](#)<sup>[335]</sup>.
- [Himax HX8309 \(Ampire AM176220\)](#)<sup>[336]</sup>.

- None of the above suits your project's needs? Tibbo can be contracted to develop a driver for another display you want to use. We offer reasonable development prices and ZNR (zero non-refundable) payment scheme, in which your initial payment for the driver development is gradually returned to you as you purchase Tibbo hardware.

### Samsung S6B0108 (Winstar WG12864F)

**Controller:** Samsung S6B0108.

**Panel:** Winstar WG12864F and similar panels.

**Type:** LCD with blue backlight/white dots, monochrome (1 bit/pixel), vertical [pixel packing](#)<sup>[318]</sup>.

**Locking:** Supported, but the display image is not visible when the display is [locked](#)<sup>[330]</sup>. This causes a noticeable "glitch" on the display when the lock/unlock is performed.

**Test hardware:** TEV-LB0 test board. This board is a part of the EM1000-TEV development system. See Programmable Hardware Manual for details.

#### I/O mapping for WG12864F

This panel requires 6 I/O lines and an 8-bit data bus. Control lines are **RST**, **EN**, **CS1**, **CS2**, **D/I**, and **R/W**. Each control line can be connected to any I/O pin of your device, and each such I/O pin must be configured as an output (if your device requires explicit I/O line buffer configuration). The data bus can be connected to any 8-bit port. DO NOT configure this port for output.

The value of the [lcd.iomapping](#)<sup>[347]</sup> property must be set correctly for the display to work (see [Preparing the Display for Operation](#)<sup>[320]</sup>). For this particular display, the mapping string consists of 7 comma-separated decimal values:

1. Number of the I/O line connected to **RST**.
2. Number of the I/O line connected to **EN**.

3. Number of the I/O line connected to **CS1**.
4. Number of the I/O line connected to **CS2**.
5. Number of the I/O line connected to **D/I**.
6. Number of the I/O line connected to **R/W**.
7. Number of the I/O *port* connected to **DATA7-0**.

I/O line numbers are from the `pl_io_num` enum. Port number is from the `pl_io_port_num` enum. Line and port numbers are platform-specific. See the list of `pl_io_num` and `pl_io_port_num` constants in the platform specifications.

For the TEV-LB0 board, the `lcd.iomapping` property should be set to `"44,46,40,41,43,42,4"`.

### Code example -- TEV-LB0

This code will properly setup and enable this controller/panel (we assume that the testing is done using the TEV-LB0 board):

```
lcd.iomapping="44,46,40,41,43,42,4" 'RST,EN,CS1,CS2,D/I,R/W,DATA7-0

'configure control lines as outputs
io.num=PL_IO_NUM_46 'EN
io.enabled=YES
io.num=PL_IO_NUM_44 'RST
io.enabled=YES
io.num=PL_IO_NUM_40 'CS1
io.enabled=YES
io.num=PL_IO_NUM_41 'CS2
io.enabled=YES
io.num=PL_IO_NUM_42 'R/W
io.enabled=YES
io.num=PL_IO_NUM_43 'D/I
io.enabled=YES

'set resolution
lcd.width=128
lcd.height=64

'optionally set lcd.rotated here

lcd.enabled=YES 'done!

'turn on the backlight (strictly speaking, this is not related to the LCD
control, but we still show it here)
io.num=PL_IO_NUM_47
io.enabled=YES
io.state=HIGH

set_lcd_contrast(11) 'this is for external contrast control circuit
```

### Contrast control

This is not a part of the panel itself, but we are still providing the code that will work on the TEV-LB0:

```
Sub set_lcd_contrast(level As Byte)
  'enable port, output data
  io.portnum=PL_IO_PORT_NUM_4
  io.portenabled=255
  io.portstate=level

  'generate strobe for the data register (on the LCD PCB)
  io.num=PL_IO_NUM_48
  io.enabled=YES
  io.state=HIGH
  io.state=LOW

  'disable port
  io.portenabled=0
End Sub
```

You can design your own contrast control circuit, of course.

## Solomon SSD1329 (Ritdisplay RGS13128096)

**Controller:** Solomon SSD1329.

**Panel:** Ritdisplay RGS13128096 and similar panels.

**Type:** OLED, green, 16 levels (4 bits/pixel), horizontal [pixel packing](#)<sup>[318]</sup>.

**Locking:** Supported, but the display image is not visible when the display is [locked](#)<sup>[330]</sup>. This causes a noticeable "glitch" on the display when the lock/unlock is performed.

**Test hardware:** TEV-LB1 test board. This board is a part of the EM1000-TEV development system. See Programmable Hardware Manual for details.

### I/O mapping for RGS13128096

This panel requires 5 I/O lines and an 8-bit data bus. Control lines are **RES**, **D/C**, **R/W**, **E**, and **CS**. Each control line can be connected to any I/O pin of your device, and each such I/O pin must be configured as an output (if your device requires explicit I/O line buffer configuration). The data bus can be connected to any 8-bit port. DO NOT configure this port for output.

The controller also has **BS1** and **BS2** interface type selection pin. For proper operation, tie these pins to Vcc.

The value of the [lcd.iomapping](#)<sup>[347]</sup> property must be set correctly for the display to work (see [Preparing the Display for Operation](#)<sup>[320]</sup>). For this particular display, the mapping string consists of 6 comma-separated decimal values:

1. Number of the I/O line connected to **RES**.
2. Number of the I/O line connected to **D/C**.
3. Number of the I/O line connected to **R/W**.
4. Number of the I/O line connected to **E**.
5. Number of the I/O line connected to **CS**.
6. Number of the I/O *port* connected to **D7-0**.

I/O line numbers are from the `pl_io_num` enum. Port number is from the `pl_io_port_num` enum. Line and port numbers are platform-specific. See the list of `pl_io_num` and `pl_io_port_num` constants in your platform specifications.

For the TEV-LB0 board, `lcd.iomapping` should be set to "44,43,42,41,40,4".

### Code example -- TEV-LB1

This code will properly setup and enable this controller/panel (we assume that the testing is done using the TEV-LB1 board):

```
lcd.iomapping="44,43,42,41,40,4" 'RST,D/C,R/W,E,CS,D7-0

'configure control lines as outputs
io.num=PL_IO_NUM_44 'RST
io.enabled=YES
io.num=PL_IO_NUM_43 'D/C
io.enabled=YES
io.num=PL_IO_NUM_42 'R/W
io.enabled=YES
io.num=PL_IO_NUM_41 'E
io.enabled=YES
io.num=PL_IO_NUM_40 'CS
io.enabled=YES

'set resolution
lcd.width=128
lcd.height=96

'optionally set lcd.rotated here

lcd.enabled=YES 'done!
```

## Himax HX8309 (Ampire AM176220)

**Controller:** Himax HX8309.

**Panel:** Ampire AM176220 and similar panels.

**Type:** TFT, color, 16 bits/pixel.

**Locking:** Supported, display picture stays stable for at least 1 second after the display is [locked](#)<sup>[336]</sup>. Unfortunately, there appears to be a hardware bug in the HX8309. This bug causes one of the horizontal lines of the panel (usually, the top or bottom line) to display random garbage while the display is locked. We have some ideas for workaround -- contact us if you encounter this problem.

**Test hardware:** TEV-LB2 test board. This board is a part of the EM1000-TEV development system. See Programmable Hardware Manual for details.

### I/O mapping for AM176220

The panel requires 5 I/O lines and a 17-bit data bus, of which only bits DB7-0 are used (8-bit interface mode). Control lines are **RESET**, **RS**, **WR**, **RD**, and **CS**. Each control line can be connected to any I/O pin of your device, and each such I/O pin must be configured as an output (if your device requires explicit I/O line buffer configuration). The data bus can be connected to any 8-bit port. DO NOT configure this port for output.

The controller also has **IMO** and **IM3** interface type selection pin. For proper

operation, tie IM0 to Vcc, **IM3** - to the ground.

The value of the `lcd.iomapping`<sup>[347]</sup> property must be set correctly for the display to work (see [Preparing the Display for Operation](#)<sup>[320]</sup>). For this particular display, the mapping string consists of 6 comma-separated decimal values:

1. Number of the I/O line connected to **RESET**.
2. Number of the I/O line connected to **RS**.
3. Number of the I/O line connected to **WR**.
4. Number of the I/O line connected to **RD**.
5. Number of the I/O line connected to **CS**.
6. Number of the I/O *port* connected to **DB7-0**.

I/O line numbers are from the `pl_io_num` enum. Port number is from the `pl_io_port_num` enum. Line and port numbers are platform-specific. See the list of `pl_io_num` and `pl_io_port_num` constants in the platform specifications.

For the TEV-LB0 board, the `lcd.iomapping` should be set to "44,43,42,41,40,4".

### Code example -- TEV-LB2

This code will properly setup and enable this controller/panel (we assume that the testing is done using the TEV-LB2 board):

```
lcd.iomapping="44,43,42,41,40,4" 'RESET,RS,WR,RD,CS,DB7-0

io.num=PL_IO_NUM_44 'RESET
io.enabled=YES
io.num=PL_IO_NUM_43 'RS
io.enabled=YES
io.num=PL_IO_NUM_42 'WR
io.enabled=YES
io.num=PL_IO_NUM_41 'RD
io.enabled=YES
io.num=PL_IO_NUM_40 'CS
io.enabled=YES

'set resolution
lcd.width=176
lcd.height=220

'optionally set lcd.rotated here

lcd.enabled=YES 'done!

'turn on the backlight (strictly speaking, this is not related to the LCD
control, but we still show it here)
io.num=PL_IO_NUM_47
io.enabled=YES
io.state=HIGH
```

## Properties and Methods

The following classification groups properties and methods of the `lcd.` object by their logical function.

### LCD panel characteristics:

- [lcd.panelpixel](#)<sup>[349]</sup> [R/O Property]
- [lcd.pixelpacking](#)<sup>[350]</sup> [R/O Property]
- [lcd.bitsperpixel](#)<sup>[339]</sup> [R/O Property]
- [lcd.redbits](#)<sup>[352]</sup> [R/O Property]
- [lcd.greenbits](#)<sup>[345]</sup> [R/O Property]
- [lcd.bluebits](#)<sup>[340]</sup> [R/O Property]

### Preparing to work:

- [lcd.iomapping](#)<sup>[347]</sup> [Property]
- [lcd.width](#)<sup>[357]</sup> [Property]
- [lcd.height](#)<sup>[346]</sup> [Property]
- [lcd.inverted](#)<sup>[347]</sup> [Property]
- [lcd.rotated](#)<sup>[353]</sup> [Property]
- [lcd.enabled](#)<sup>[341]</sup> [Property]

### Graphical operations:

- [lcd.setpixel](#)<sup>[354]</sup> [Method]
- [lcd.forecolor](#)<sup>[344]</sup> [Property]
- [lcd.backcolor](#)<sup>[339]</sup> [Property]
- [lcd.linewidth](#)<sup>[348]</sup> [Property]
  - [lcd.line](#)<sup>[348]</sup> [Method]
  - [lcd.horline](#)<sup>[346]</sup> [Method]
  - [lcd.verline](#)<sup>[357]</sup> [Method]
  - [lcd.rectangle](#)<sup>[352]</sup> [Method]
  - [lcd.filledrectangle](#)<sup>[343]</sup> [Method]
  - [lcd.fill](#)<sup>[342]</sup> [Method]
- [lcd.setfont](#)<sup>[353]</sup> [Method]
- [lcd.fontheight](#)<sup>[343]</sup> [R/O Property]
- [lcd.fontpixelpacking](#)<sup>[344]</sup> [R/O Property]
- [lcd.textalignment](#)<sup>[355]</sup> [Property]
- [lcd.textorientation](#)<sup>[356]</sup> [Property]
- [lcd.texthorizontalspacing](#)<sup>[355]</sup> [Property]
- [lcd.textverticalspacing](#)<sup>[356]</sup> [Property]
  - [lcd.print](#)<sup>[351]</sup> [Method]
  - [lcd.printaligned](#)<sup>[351]</sup> [Method]
  - [lcd.getprintwidth](#)<sup>[345]</sup> [Method]
- [lcd.bmp](#)<sup>[340]</sup> [Method]

**Miscellaneous:**

- [lcd.error](#)<sup>[342]</sup> [R/O Property]
- [lcd.lock](#)<sup>[346]</sup> [Method]
- [lcd.unlock](#)<sup>[356]</sup> [Method]
- [lcd.lockcount](#)<sup>[349]</sup> [R/O Property]

**.BackColor Property**

<b>Function:</b>	Specifies current background color.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535. <b>Default</b> = 0.
<b>See Also:</b>	<a href="#">Understanding Controller Properties</a> <sup>[318]</sup> , <a href="#">Working With Pixels and Colors</a> <sup>[320]</sup> , <a href="#">lcd.forecolor</a> <sup>[344]</sup> , <a href="#">lcd.linewidth</a> <sup>[348]</sup>

**Details**

The background color is used when drawing filled rectangles ([lcd.filledrectangle](#)<sup>[343]</sup>) and performing fills ([lcd.fill](#)<sup>[342]</sup>).

Property value interpretation depends on the currently selected controller/panel. Selection is made through the Customize Platform dialog, accessible through the Project Settings dialog.

The property is of word type, but only the [lcd.bitsperpixel](#)<sup>[339]</sup> lower bits of this value will be relevant. All higher bits will be ignored.

For monochrome and grayscale controllers/panels ([lcd.paneltype](#)<sup>[349]</sup>= 0- PL\_LCD\_PANELTYPE\_GRAYSCALE), this value will relate to the brightness of the pixel. For color panels/controllers ([lcd.paneltype](#)= 1- PL\_LCD\_PANELTYPE\_COLOR) the value is composed of three fields -- one each for the red, green, and blue "channels". Check [lcd.redbits](#)<sup>[352]</sup>, [lcd.greenbits](#)<sup>[345]</sup>, and [lcd.bluebits](#)<sup>[340]</sup> properties to see how the fields are combined into the color word.

**.Bitsperpixel R/O Property**

<b>Function:</b>	Returns the number of bits available for each pixel of the currently selected controller/panel.
<b>Type:</b>	Byte
<b>Value Range:</b>	Value depends on the currently selected controller/panel
<b>See Also:</b>	<a href="#">Understanding Controller Properties</a> <sup>[318]</sup> , <a href="#">Working With Pixels and Colors</a> <sup>[320]</sup>

**Details**

Controller/panel selection is made through the Customize Platform dialog, accessible through the Project Settings dialog.

For monochrome controllers/panels (see [lcd.paneltype](#)<sup>[349]</sup>) the [lcd.bitsperpixel](#) will return 1, that is, the pixel can only be on or off. For grayscale panels, this value will

be >1, which indicates that each pixel can be set to a number of brightness levels. For example, if the `lcd.bitsperpixel=4`, then each pixel's brightness can be adjusted in 16 steps.

For color panels, this property reflects the combined number of red, green, and blue bits available for each pixel (see [`lcd.redbits`](#)<sup>[352]</sup>, [`lcd.greenbits`](#)<sup>[345]</sup>, and [`lcd.bluebits`](#)<sup>[340]</sup>).

The number of bits per pixel affects how [`lcd.forecolor`](#)<sup>[344]</sup>, [`lcd.backcolor`](#)<sup>[339]</sup>, and [`lcd.setpixel`](#)<sup>[354]</sup> are interpreted. Also, the output produced by [`lcd.bmp`](#)<sup>[340]</sup> depends on this property.

## .Bluebits R/O Property

<b>Function:</b>	A 16-bit value packing two 8-bit parameters: number of "blue" bits per pixel (high byte) and the position of the least significant blue bit within the color word (low byte).
<b>Type:</b>	Word
<b>Value Range:</b>	Value depends on the currently selected controller/panel.
<b>See Also:</b>	<a href="#">Understanding Controller Properties</a> <sup>[318]</sup> , <a href="#">Working With Pixels and Colors</a> <sup>[320]</sup>

### Details

The value of this property depends on the currently selected controller/panel. Selection is made through the Customize Platform dialog, accessible through the Project Settings dialog. This property is only relevant for color panels ([`lcd.paneltype`](#)<sup>[349]</sup>= 1- PL\_LCD\_PANELTYPE\_COLOR).

By taking the value of the high byte you can determine the number of the steps in which the brightness of the blue "channel" can be adjusted. For example, if the high byte is equal to 6, then there are 64 levels for blue.

This property also tells you the bit position and length of the blue field in color values used by [`lcd.forecolor`](#)<sup>[344]</sup>, [`lcd.backcolor`](#)<sup>[339]</sup>, and [`lcd.setpixel`](#)<sup>[354]</sup>. If, for example, the [`lcd.redbits`](#)<sup>[352]</sup>=&h0500, `lcd.bluebits=&h0605`, and [`lcd.greenbits`](#)<sup>[345]</sup>=&h050B, then you can reconstruct the composition of the red, green, and blue bits in a word: bit 15 -> gggggbbbbbbrrrrr <- bit 0. In this example, the blue field is in the middle and occupies 6 bits (10-5).

## .Bmp Method

<b>Function:</b>	Displays a portion of or full image stored in a BMP file.
<b>Syntax:</b>	<b><code>lcd.bmp(offset as dword, x as word, y as word, x_offset as word, y_offset as word, maxwidth as word, maxheight as word) as ok_ng</code></b>
<b>Returns:</b>	0- OK: Processed successfully. 1- NG: Unsupported or invalid file format.
<b>See Also:</b>	<a href="#">Displaying Images</a> <sup>[329]</sup>

Part	Description
offset	Offset within the compiled binary of your application at which the BMP file is stored.
x	X coordinate of the top-left point of the image position on the screen. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> -1.
y	Y coordinate of the top-left point of the image position on the screen. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> -1.
x_offset	Horizontal offset within the BMP file marking the top-left corner of the image portion to be displayed.
y_offset	Vertical offset within the BMP file marking the top-left corner of the image portion to be displayed.
maxwidth	Maximum width of the image portion to be displayed. Actual width of the output will be defined by the total width of the image and specified <code>x_offset</code> .
maxheight	Maximum height of the image portion to be displayed. Actual height of the output will be defined by the total height of the image and specified <code>y_offset</code> .

### Details

To obtain the offset, open the BMP file with [romfile.open](#)<sup>[374]</sup>, then read the offset of this file from the [romfile.offset](#)<sup>[373]</sup> R/O property. Naturally, the BMP file must be present in your project for this to work (see how to [add](#)<sup>[132]</sup> a file).

Note that only 2-, 16-, and 256-color modes are currently supported and the `lcd.bmp` will return 1- NG if you try to display any other type of BMP file. Compressed BMP files will be rejected too.

The method takes into account the type of the currently selected controller/panel (selection is made through the Customize Platform dialog, accessible through the Project Settings dialog). It will check the values of [lcd.paneltype](#)<sup>[349]</sup>, [lcd.bitsperpixel](#)<sup>[339]</sup>, [lcd.redbits](#)<sup>[352]</sup>, [lcd.greenbits](#)<sup>[345]</sup>, and [lcd.bluebits](#)<sup>[340]</sup> and produce the best output possible for the selected display.

`X_offset`, `y_offset`, `maxwidth`, and `maxheight` arguments allow you to display only a portion of the BMP image. This way it is possible to scroll around a large image that does not fit on the screen. Another use is to combine several separate images into a single file and display selected portions. This improves efficiency because [romfile.open](#)<sup>[374]</sup> needs only be done once.

### .Enabled Property

<b>Function:</b>	Specifies whether the display panel is enabled.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO: Disabled ( <b>default</b> ). 1- YES: Enabled.
<b>See Also:</b>	<a href="#">Preparing the Display for Operation</a> <sup>[320]</sup>

### Details

Several properties -- [lcd.iomapping](#)<sup>[347]</sup>, [lcd.width](#)<sup>[357]</sup>, [lcd.height](#)<sup>[346]</sup>, [lcd.inverted](#)<sup>[347]</sup>, [lcd.rotated](#)<sup>[353]</sup> -- can only be changed when the display panel is disabled.

When you set this property to 1- YES, the controller of the panel is initialized and enabled. This will only work if your display is properly connected, correct display type is selected in your project, [lcd.iomapping](#) is set property, and necessary I/O lines are configured as outputs. The [lcd.error](#)<sup>[342]</sup> R/O property will indicate 1- YES if there was a problem enabling the display.

Setting the property to 0- NO disables the controller/panel.

### .Error R/O Property

<b>Function:</b>	Indicates whether controller/panel I/O error has been detected.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO: No error detected. 1- YES: I/O error.
<b>See Also:</b>	<a href="#">Preparing the Display for Operation</a> <sup>[320]</sup>

### Details

The lcd. object will detect a malfunction (or absence) of the controller/panel that is expected to be connected. If the display is not properly connected, or the lcd. object is not set up property to work with this display, the [lcd.error](#) will be set to 1- YES on attempt to enable the display (set [lcd.enabled](#)<sup>[341]</sup>= 1- YES).

### .Fill Method

<b>Function:</b>	Paints the area with the "pen" color ( <a href="#">lcd.forecolor</a> <sup>[344]</sup> ).
<b>Syntax:</b>	<b>lcd.fill(x as word,y as word, width as word, height as word)</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Lines, Rectangles, and Fills</a> <sup>[321]</sup> , <a href="#">Working With Pixels and Colors</a> <sup>[320]</sup> , <a href="#">lcd.line</a> <sup>[348]</sup> , <a href="#">lcd.verline</a> <sup>[357]</sup> , <a href="#">lcd.horline</a> <sup>[348]</sup> , <a href="#">lcd.rectangle</a> <sup>[352]</sup> , <a href="#">lcd.filledrectangle</a> <sup>[343]</sup>

Part	Description
x	X coordinate of the top-left point of the area to be painted. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> - 1.
y	Y coordinate of the top-left point of the area to be painted. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> - 1.

wid Width of the paint area in pixels.  
th  
heig Height of the paint area in pixels.  
ht

**Details**

The display panel must be enabled ([lcd.enabled](#)<sup>[341]</sup>= 1- YES) for this method to work.

**.Filledrectangle Method**

**Function:** Draws a filled rectangle.  
**Syntax:** **lcd.filledrectangle**(x1 as word,y1 as word, x2 as word, y2 as word)  
**Returns:** ---  
**See Also:** [Lines, Rectangles, and Fills](#)<sup>[321]</sup>, [Working With Pixels and Colors](#)<sup>[320]</sup>, [lcd.line](#)<sup>[348]</sup>, [lcd.verline](#)<sup>[357]</sup>, [lcd.horline](#)<sup>[346]</sup>, [lcd.rectangle](#)<sup>[352]</sup>, [lcd.fill](#)<sup>[342]</sup>

Part	Description
x1	X coordinate of the first point. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> - 1.
y1	Y coordinate of the first point. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> - 1.
x2	X coordinate of the second point. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> - 1.
y2	Y coordinate of the second point. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> - 1.

**Details**

The border is drawn with the specified line width ([lcd.linewidth](#)<sup>[348]</sup>) and "pen" color ([lcd.forecolor](#)<sup>[344]</sup>). The rectangle is then filled using the background color ([lcd.backcolor](#)<sup>[339]</sup>). Setting the lcd.linewidth to 0 will create a rectangle with no border -- basically, a filled area.

The display panel must be enabled ([lcd.enabled](#)<sup>[341]</sup>= 1- YES) for this method to work.

**.Fontheight R/O Property**

**Function:** Returns the maximum height, in pixels, of characters in the currently selected font.  
**Type:** Byte  
**Value Range:** 0-255. **Default**= 0.  
**See Also:** [Working With Text](#)<sup>[320]</sup>, [lcd.fontpixelpacking](#)<sup>[344]</sup>

### Details

This property will only return meaningful data after you select a font using the [lcd.setfont](#)<sup>[353]</sup> method.

## **.Fontpixelpacking R/O Property**

<b>Function:</b>	Indicates how pixels are packed into bytes in a currently selected font.
<b>Type:</b>	Enum (ver_hor, byte)
<b>Value Range:</b>	0- PL_VERTICAL: Several vertically adjacent pixels are packed into each byte of character bitmaps. 1- PL_HORIZONTAL: Several horizontally adjacent pixels are packed into each byte of character bitmaps.
<b>See Also:</b>	<a href="#">Working With Text</a> <sup>[322]</sup> , <a href="#">lcd.fontheight</a> <sup>[343]</sup>

### Details

Display controllers/panels can have vertical or horizontal pixel packing (see [lcd.pixelpacking](#)<sup>[350]</sup>). The speed at which you can output the text onto the screen is improved when the lcd.pixelpacking and lcd.fontpixelpacking have the same value, i.e. controller memory pixels and font encoding are "aligned". Our font files are typically available both in vertical and horizontal pixel packing. Pick the right file for your controller/panel.

This property will only return meaningful data after you select a font using the [lcd.setfont](#)<sup>[353]</sup> method.

## **.Forecolor Property**

<b>Function:</b>	Specifies current "pen" (drawing) color.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535. <b>Default</b> = 65535 (&hFFFF).
<b>See Also:</b>	<a href="#">Understanding Controller Properties</a> <sup>[318]</sup> , <a href="#">Working With Pixels and Colors</a> <sup>[320]</sup> , <a href="#">lcd.backcolor</a> <sup>[339]</sup> , <a href="#">lcd.linewidth</a> <sup>[348]</sup>

### Details

Pen color is used when drawing lines ([lcd.line](#)<sup>[348]</sup>, [lcd.verline](#)<sup>[357]</sup>, [lcd.horline](#)<sup>[346]</sup>) and rectangles ([lcd.rectangle](#)<sup>[352]</sup>, [lcd.filledrectangle](#)<sup>[343]</sup>), as well as displaying text ([lcd.print](#)<sup>[351]</sup>, [lcd.printaligned](#)<sup>[351]</sup>).

Property value interpretation depends on the currently selected controller/panel. Selection is made through the Customize Platform dialog, accessible through the Project Settings dialog.

The property is of word type, but only [lcd.bitsperpixel](#)<sup>[339]</sup> lower bits of this value will be relevant. All higher bits will be ignored.

For monochrome and grayscale controllers/panels ([lcd.paneltype](#)<sup>[349]</sup>= 0-

PL\_LCD\_PANELTYPE\_GRAYSCALE), this value will relate to the brightness of the pixel. For color panels/controllers (lcd.paneltype= 1- PL\_LCD\_PANELTYPE\_COLOR) the value is composed of three fields -- one for the red, green, and blue "channels". Check [lcd.redbits](#)<sup>[352]</sup>, [lcd.greenbits](#)<sup>[345]</sup>, and [lcd.bluebits](#)<sup>[340]</sup> properties to see how the fields are combined into the color word.

## .Getprintwidth Method

<b>Function:</b>	Returns the width, in pixels, of the text output that will be produced if the same line is actually printed with the <a href="#">lcd.print</a> <sup>[351]</sup> method.
<b>Syntax:</b>	<b>lcd.getprintwidth(byref str as string) as word</b>
<b>Returns:</b>	Total width of text output in pixels.
<b>See Also:</b>	<a href="#">Working With Text</a> <sup>[322]</sup>

Part	Description
str	Text to estimate the output width for.

### Details

This method does not produce any output on the display, it merely estimates the width of the text *if* it was to be printed. Lcd.print also returns the width of the text in pixels, but this data comes *after* the printing. Sometimes it is desirable to know the output width for the line of text before printing it, and this method allows you to do so.

The width calculation will be affected by the value of the [lcd.texthorizontalspacing](#)<sup>[355]</sup> property.

## .Greenbits R/O Property

<b>Function:</b>	A 16-bit value packing two 8-bit parameters: number of "green" bits per pixel (high byte) and the position of the least significant green bit within the color word (low byte).
<b>Type:</b>	Word
<b>Value Range:</b>	Value depends on the currently selected controller/panel.
<b>See Also:</b>	<a href="#">Understanding Controller Properties</a> <sup>[318]</sup> , <a href="#">Working With Pixels and Colors</a> <sup>[320]</sup>

### Details

The value of this property depends on the currently selected controller/panel. Selection is made through the Customize Platform dialog, accessible through the Project Settings dialog. This property is only relevant for color panels ([lcd.paneltype](#)<sup>[349]</sup>= 1- PL\_LCD\_PANELTYPE\_COLOR).

By taking the value of the high byte you can determine the number of the steps in which the brightness of the green "channel" can be adjusted. For example, if the

high byte is equal to 5, then there are 32 levels for green.

This property also tells you the bit position and length of the green field in values used by [lcd.forecolor](#)<sup>[344]</sup>, [lcd.backcolor](#)<sup>[339]</sup>, and [lcd.setpixel](#)<sup>[354]</sup>. If, for example, the [lcd.redbits](#)<sup>[352]</sup>=&h0500, [lcd.bluebits](#)<sup>[340]</sup>=&h0605, and [lcd.greenbits](#)=&h050B, then you can reconstruct the composition of the red, green, and blue bits in a word: bit 15 -> ggggbbbbbbrrrr <- bit 0. In this example, the green field is the last field and occupies 5 bits (15-11).

## .Height Property

<b>Function:</b>	Sets the vertical resolution of the display panel in pixels.
<b>Type:</b>	Word
<b>Value Range:</b>	Appropriate value depends on the panel. <b>Default</b> = 0.
<b>See Also:</b>	<a href="#">Preparing the Display for Operation</a> <sup>[320]</sup> , <a href="#">lcd.width</a> <sup>[357]</sup>

### Details

Set this property according to the characteristics of your display panel.

This value is not set automatically when you select a certain controller because the capability of the controller may exceed the actual resolution of the panel, i.e. only "part" of the controller may be utilized.

This property can only be changed when the lcd is disabled ([lcd.enabled](#)<sup>[341]</sup>= 0- NO)

## .Horline Method

<b>Function:</b>	Draws a horizontal line.
<b>Syntax:</b>	<b>lcd.horline(x1 as word,x2 as word,y as word)</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Lines, Rectangles, and Fills</a> <sup>[321]</sup> , <a href="#">lcd.rectangle</a> <sup>[352]</sup> , <a href="#">lcd.filledrectangle</a> <sup>[343]</sup> , <a href="#">lcd.fill</a> <sup>[342]</sup>

Part	Description
x1	X coordinate of the first point. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> - 1.
x2	X coordinate of the second point. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> - 1.
y	Y coordinates of the first and second points. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> - 1.

### Details

The line is drawn with the specified line width ([lcd.linewidth](#)<sup>[348]</sup>) and "pen" color ([lcd.forecolor](#)<sup>[344]</sup>). Drawing horizontal or vertical ([lcd.verline](#)<sup>[357]</sup>) lines is more efficient than drawing generic lines ([lcd.line](#)<sup>[348]</sup>), and should be used whenever possible.

The display panel must be enabled ([lcd.enabled](#)<sup>[341]</sup>= 1- YES) for this method to work.

## .Inverted Property

<b>Function:</b>	Specifies whether the image on the display panel has to be inverted.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO: Not inverted, higher memory value of the pixel corresponds to higher brightness <b>(default)</b> . 1- YES: Inverted, higher memory value of the pixel corresponds to lower brightness.
<b>See Also:</b>	<a href="#">Preparing the Display for Operation</a> <sup>[320]</sup>

---

### Details

Set this property according to the characteristics of your display panel.

This value is not set automatically when you select a certain controller because the display characteristics cannot be detected automatically, as they depend on the panel and its backlight arrangement.

This property can only be changed when the display is disabled ([lcd.enabled](#)<sup>[341]</sup>= 0- NO).

## .Iomapping Property

<b>Function:</b>	Defines the list of I/O lines to interface with the currently selected controller/panel.
<b>Type:</b>	String
<b>Value Range:</b>	Value depends on the currently selected controller/panel. <b>Default= ""</b> .
<b>See Also:</b>	<a href="#">Preparing the Display for Operation</a> <sup>[320]</sup>

---

### Details

Controller/panel selection is made through the Customize Platform dialog, accessible through the Project Settings dialog.

Different controllers/panels require a different set of interface lines, and even the number of lines depends on the hardware. This property should contain a comma-separated list of decimal numbers that indicate which I/O lines and ports are used to connect the controller/panel to your device. The meaning of each number in the list is controller- and panel-specific. See the [Supported Controllers](#)<sup>[333]</sup> section for details.

This property can only be changed when the display is disabled ([lcd.enabled](#)<sup>[341]</sup>= 0- NO).

## .Line Method

<b>Function:</b>	Draws a line.
<b>Syntax:</b>	<b>lcd.line</b> (x1 as word,y1 as word, x2 as word, y2 as word)
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Lines, Rectangles, and Fills</a> <sup>[321]</sup> , <a href="#">lcd.rectangle</a> <sup>[352]</sup> , <a href="#">lcd.filledrectangle</a> <sup>[343]</sup> , <a href="#">lcd.fill</a> <sup>[342]</sup>

Part	Description
x1	X coordinate of the first point. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> -1.
y1	Y coordinate of the first point. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> -1.
x2	X coordinate of the second point. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> -1.
y2	Y coordinate of the second point. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> -1.

### Details

The line is drawn with the specified line width ([lcd.linewidth](#)<sup>[348]</sup>) and "pen" color ([lcd.forecolor](#)<sup>[344]</sup>). Drawing horizontal ([lcd.horline](#)<sup>[346]</sup>) or vertical ([lcd.verline](#)<sup>[357]</sup>) lines is more efficient than drawing generic lines, and should be used whenever possible.

The display panel must be enabled ([lcd.enabled](#)<sup>[341]</sup>= 1- YES) for this method to work.

## .Linewidth Property

<b>Function:</b>	Specifies current "pen" width in pixels.
<b>Type:</b>	Byte
<b>Value Range:</b>	1-255. <b>Default</b> = 1 (1 pixel).
<b>See Also:</b>	<a href="#">Lines, Rectangles, and Fills</a> <sup>[321]</sup> , <a href="#">lcd.forecolor</a> <sup>[344]</sup> , <a href="#">lcd.backcolor</a> <sup>[339]</sup>

### Details

Pen width is used when drawing lines ([lcd.line](#)<sup>[348]</sup>, [lcd.verline](#)<sup>[357]</sup>, [lcd.horline](#)<sup>[346]</sup>) and rectangles ([lcd.rectangle](#)<sup>[352]</sup>, [lcd.filledrectangle](#)<sup>[343]</sup>).

## .Lock Method

<b>Function:</b>	Freezes display output (on controllers/panels that support this feature).
<b>Syntax:</b>	<b>lcd.lock</b>
<b>Returns:</b>	---
<b>See Also:</b>	---

## Details

When the display is locked, you can make changes to the display data without showing these changes on the screen. You can then unlock the display (`lcd.unlock`) and show all the changes made at once. This usually greatly improves the display agility *perception* by the user (see [Improving Graphical Performance](#)<sup>[330]</sup>).

Locking the display also prolongs the life of some displays, notably the displays of the OLED type.

When you execute this method for the first time, the display gets locked and the `lcd.lockcount`<sup>[349]</sup> R/O property changes from 0 to 1. You can invoke `lcd.lock` again and again, and the `lcd.lockcount` will increase with each call to the `lcd.lock`. This allows you to nest locks/unlocks (again, see [Improving Graphical Performance](#)<sup>[330]</sup>). Of course, the display is not locked "any harder" at `lcd.lockcount=2` compared to `lcd.lockcount=1`. The display is simply locked for all `lcd.lockcount` values other than 0.

Not all controllers/panels support this feature. See the [Supported Controllers/Panels](#)<sup>[333]</sup> section for details on the display you are using. If your display does not support locking, executing `lcd.lock` will have no effect and `lcd.lockcount`<sup>[349]</sup> will always stay at 0.

## .Lockcount R/O Property

<b>Function:</b>	Indicates the current nesting level of the display lock.
<b>Type:</b>	Byte
<b>Value Range:</b>	0-255. <b>Default</b> = 0 (display unlocked).
<b>See Also:</b>	---

## Details

Invoking `lcd.lock`<sup>[348]</sup> increases the value of this property by 1. If 255 is reached, the value does not roll over to 0 and stays at 255. Invoking `lcd.unlock`<sup>[356]</sup> decreases the value of this property by 1. When 0 is reached, the value does not roll over to 255 and stays at 0. The display is locked when `lcd.lockcount` is not at 0. Of course, the display does not get locked any "harder" with every increment of the `lcd.lockcount`.

When the display is locked, you can make changes to the display data without showing these changes on the screen. You can then unlock the display and show all the changes made at once. This usually greatly improves the display agility *perception* (see [Improving Graphical Performance](#)<sup>[330]</sup>).

Not all controllers/panels support this feature. See the [Supported Controllers/Panels](#)<sup>[333]</sup> section for details on the display you are using. If your display does not support locking, executing `lcd.lock` will have no effect and `lcd.lockcount`<sup>[349]</sup> will always stay at 0.

## .Paneltype R/O Property

<b>Function:</b>	Returns the type of the currently selected controller/panel.
<b>Type:</b>	Enum ( <code>pl_lcd_paneltype</code> , byte)

**Value Range:** 0- PL\_LCD\_PANELTYPE\_GRAYSCALE: This is a monochrome or grayscale panel/controller.  
1- PL\_LCD\_PANELTYPE\_COLOR: This is a color panel/controller.

**See Also:** [Understanding Controller Properties](#)<sup>[318]</sup>, [Working With Pixels and Colors](#)<sup>[320]</sup>

### Details

Controller/panel selection is made through the Customize Platform dialog, accessible through the Project Settings dialog.

Monochrome panels/controllers only allow you to turn pixels on and off. Grayscale panels/controllers allow you to set the brightness of pixels in steps. The number of available steps is defined by the number of bits assigned to each pixel (see [lcd.bitsperpixel](#)<sup>[339]</sup> property). Finally, color panels/controllers allow you to set the brightness separately for the red, green, and blue components of each pixel. [Lcd.redbits](#)<sup>[352]</sup>, [lcd.greenbits](#)<sup>[345]</sup>, and [lcd.bluebits](#)<sup>[340]</sup> R/O properties will tell you how many bits there are for each color "channel".

Panel/controller type affects how [lcd.forecolor](#)<sup>[344]</sup>, [lcd.backcolor](#)<sup>[339]</sup>, and [lcd.setpixel](#)<sup>[354]</sup> are interpreted. Also, the output produced by [lcd.bmp](#)<sup>[340]</sup> is affected by this.

## **.Pixelpacking R/O Property**

**Function:** Indicates how pixels are packed into controller memory for the currently selected controller/panel.

**Type:** Enum (ver\_hor, byte)

**Value Range:** 0- PL\_VERTICAL: Several vertically adjacent pixels are packed into each byte of controller memory.  
1- PL\_HORIZONTAL: Several horizontally adjacent pixels are packed into each byte of controller memory.

**See Also:** [Understanding Controller Properties](#)<sup>[318]</sup>

### Details

Controller/panel selection is made through the Customize Platform dialog, accessible through the Project Settings dialog.

This property is only relevant for controllers/panels whose [lcd.bitsperpixel](#)<sup>[339]</sup> value is less than 8. In this case, 2, 4, or 8 pixels are packed into a single byte of controller memory.

This property is purely informational and largely has no influence over how you write your application. The only exception is related to [working with text](#)<sup>[322]</sup>. [Fonts](#)<sup>[325]</sup> can also have vertical or horizontal packing and the speed at which you can output the text onto the screen is improved when the [lcd.pixelpacking](#)<sup>[344]</sup> and [lcd.fontpixelpacking](#)<sup>[344]</sup> have the same value, i.e. controller memory pixels and font encoding are "aligned".

## .Print Method

<b>Function:</b>	Prints a line of text.
<b>Syntax:</b>	<b>lcd.print(byref str as string,x as word,y as word) as word</b>
<b>Returns:</b>	Total width of created output in pixels.
<b>See Also:</b>	<a href="#">Working With Text</a> <sup>[322]</sup> , <a href="#">lcd.getprintwidth</a> <sup>[345]</sup>

Part	Description
str	Text to print.
x	X coordinate of the top-left corner of the text output. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> -1.
y	Y coordinate of the top-left corner of the text output. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> -1.

### Details

For this method to work, a font must first be selected with the [lcd.setfont](#)<sup>[353]</sup> method. The [lcd.textorientation](#)<sup>[356]</sup> and [lcd.texthorizontalspacing](#)<sup>[355]</sup> properties affect how the text is printed.

This method always produces a single-line text output. Use [lcd.printaligned](#)<sup>[351]</sup> if you want to print several lines of text at once.

The display panel must be enabled ([lcd.enabled](#)<sup>[341]</sup>= 1- YES) for this method to work.

## .Printaligned Method

<b>Function:</b>	Print texts, on several lines if necessary, within a specified rectangular area.
<b>Syntax:</b>	<b>lcd.printaligned(byref str as string,x as word,y as word,width as word,height as word) as byte</b>
<b>Returns:</b>	Total number of text lines produced.
<b>See Also:</b>	<a href="#">Working With Text</a> <sup>[322]</sup>

Part	Description
str	Text to print. Inserting ` character will create a line break.
x	X coordinate of the top-left point of the print area. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> -1.
y	Y coordinate of the top-left point of the print area. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> -1.
width	Width of the print area in pixels.

heig Height of the print area in pixels.  
ht

### Details

For this method to work, a font must first be selected with the [lcd.setfont](#)<sup>[353]</sup> method. The [lcd.textalignment](#)<sup>[355]</sup>, [lcd.textorientation](#)<sup>[356]</sup>, [lcd.texthorizontalspacing](#)<sup>[355]</sup>, and [lcd.textverticalspacing](#)<sup>[356]</sup> properties will affect how the text is printed.

This method breaks the text into lines to stay within the specified rectangular output area. Whenever possible, text is split without breaking up the words. A word will be split if it is wider than the width of the print area. You can add arbitrary line brakes by inserting ` (ASCII code 96).

The display panel must be enabled ([lcd.enabled](#)<sup>[341]</sup>= 1- YES) for this method to work.

## **.Rectangle Method**

**Function:** Draws an unfilled rectangle.

**Syntax:** **lcd.rectangle(x1 as word, y1 as word, x2 as word, y2 as word)**

**Returns:** ---

**See Also:** [Lines, Rectangles, and Fills](#)<sup>[321]</sup>, [lcd.line](#)<sup>[348]</sup>, [lcd.verline](#)<sup>[357]</sup>, [lcd.horline](#)<sup>[346]</sup>, [lcd.filledrectangle](#)<sup>[343]</sup>, [lcd.fill](#)<sup>[342]</sup>

Part	Description
x1	X coordinate of the first point. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> -1.
y1	Y coordinate of the first point. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> -1.
x2	X coordinate of the second point. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> -1.
y2	Y coordinate of the second point. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> -1.

### Details

The rectangle is drawn with the specified line width ([lcd.linewidth](#)<sup>[348]</sup>) and "pen" color ([lcd.forecolor](#)<sup>[344]</sup>).

The display panel must be enabled ([lcd.enabled](#)<sup>[341]</sup>= 1- YES) for this method to work.

## **.Redbits R/O Property**

**Function:** A 16-bit value packing two 8-bit parameters: number of "red" bits per pixel (high byte) and the position of the least significant red bit within the color word (low byte).

**Type:** Word

**Value Range:** Value depends on the currently selected controller/panel.

**See Also:** [Understanding Controller Properties](#)<sup>[318]</sup>, [Working With Pixels and Colors](#)<sup>[320]</sup>

**Details**

The value of this property depends on the currently selected controller/panel. Selection is made through the Customize Platform dialog, accessible through the Project Settings dialog. This property is only relevant for color panels ([lcd.paneltype](#)<sup>[349]</sup>= 1- PL\_LCD\_PANELTYPE\_COLOR).

By taking the value of the high byte you can determine the number of the steps in which the brightness of the red "channel" can be adjusted. For example, if the high byte is equal to 5, then there are 32 levels for red.

This property also tells you the bit position and length of the red field in values used by [lcd.forecolor](#)<sup>[344]</sup>, [lcd.backcolor](#)<sup>[339]</sup>, and [lcd.setpixel](#)<sup>[354]</sup>. If, for example, the `lcd.redbits=&h0500`, [lcd.bluebits](#)<sup>[340]</sup>=&h0605, and [lcd.greenbits](#)<sup>[345]</sup>=&h050B, then you can reconstruct the composition of the red, green, and blue bits in a word: bit 15 - > ggggbbbbbbrrrr <- bit 0. In this example, the red field is the first field and occupies 5 bits (4-0).

**.Rotated Property**

**Function:** Specifies whether the image on the display panel is to be rotated 180 degrees.

**Type:** Enum (no\_yes, byte)

**Value Range:** 0- NO: Not rotated (**default**).  
1- YES: Rotated 180 degrees.

**See Also:** [Preparing the Display for Operation](#)<sup>[320]</sup>

**Details**

Set this property according to the orientation of the display panel in your device. This property can only be changed when the display is disabled ([lcd.enabled](#)<sup>[341]</sup>= 0- NO).

**.SetFont Method**

**Function:** Selects a font to use for printing text.

**Syntax:** **lcd.setFont(offset as dword) as ok\_ng**

**Returns:** 0- OK: The font was found and the data appears to be valid.  
1- NG: There is no valid font data at specified offset.

**See Also:** [Working with Text](#)<sup>[322]</sup>

Par	Description
-----	-------------

**t**

offs    Offset within the compiled binary of your application at which the font file  
et        is stored.

**Details**

A valid font file must be selected before you can use the [lcd.print](#)<sup>[351]</sup>, [lcd.printaligned](#)<sup>[351]</sup>, or [lcd.getprintwidth](#)<sup>[345]</sup> methods. Naturally, the font file must be present in your project for this to work (see how to [add](#)<sup>[132]</sup> a font file). To obtain correct offset, open the file using the [romfile.open](#)<sup>[374]</sup> method, then read the offset of this file from the [romfile.offset](#)<sup>[373]</sup> R/O property.

When the font file is successfully selected, the [lcd.fontheight](#)<sup>[343]</sup> and [lcd.fontpixelpacking](#)<sup>[344]</sup> R/O properties will be updated to reflect actual font parameters.

**.Setpixel Method**

**Function:**                    Directly writes pixel data for a single pixel into the controller's memory.

**Syntax:**                      **lcd.setpixel(dt as word,x as word,y as word)**

**Returns:**                      ---

**See Also:**                    [Working With Pixels and Colors](#)<sup>[320]</sup>, [Understanding Controller Properties](#)<sup>[318]</sup>

Par t	Description
----------	-------------

dt	Pixel data to write.
x	X coordinate of the pixel. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> -1.
y	Y coordinate of the pixel. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> -1.

**Details**

Interpretation of the dt argument depends on the selected controller/panel. Selection is made through the Customize Platform dialog, accessible through the Project Settings dialog.

The dt argument is of word type, but only [lcd.bitsperpixel](#)<sup>[339]</sup> lower bits of this value will be relevant. All higher bits will be ignored.

For monochrome and grayscale controllers/panels ([lcd.panelpixeltype](#)<sup>[349]</sup>= 0-PL\_LCD\_PANELTYPE\_GRAYSCALE), the value of the dt argument sets the brightness of the pixel. For color panels/controllers ([lcd.panelpixeltype](#)= 1-PL\_LCD\_PANELTYPE\_COLOR) the value is composed of three fields -- one for the red, green, and blue "channels". Check [lcd.redbits](#)<sup>[352]</sup>, [lcd.greenbits](#)<sup>[343]</sup>, and [lcd.bluebits](#)<sup>[340]</sup> properties to see how the fields are combined into the dt word.

The display panel must be enabled ([lcd.enabled](#)<sup>[341]</sup>= 1- YES) for this method to work.

## .Textalignment Property

<b>Function:</b>	Specifies the alignment for text output produced by the <a href="#">lcd.printaligned</a> <sup>[351]</sup> method.
<b>Type:</b>	Enum (pl_lcd_text_alignment, byte)
<b>Value Range:</b>	0- PL_LCD_TEXT_ALIGNMENT_TOP_LEFT: Top, left <b>(default).</b> 1- PL_LCD_TEXT_ALIGNMENT_TOP_CENTER: Top, center. 2- PL_LCD_TEXT_ALIGNMENT_TOP_RIGHT: Top, right. 3- PL_LCD_TEXT_ALIGNMENT_MIDDLE_LEFT: Middle, left. 4- PL_LCD_TEXT_ALIGNMENT_MIDDLE_CENTER: Middle, center. 5- PL_LCD_TEXT_ALIGNMENT_MIDDLE_RIGHT: Middle, right. 6- PL_LCD_TEXT_ALIGNMENT_BOTTOM_LEFT: Bottom, left. 7- PL_LCD_TEXT_ALIGNMENT_BOTTOM_CENTER: Bottom, center. 8- PL_LCD_TEXT_ALIGNMENT_BOTTOM_RIGHT: Bottom, right.
<b>See Also:</b>	<a href="#">Working With Text</a> <sup>[322]</sup> , <a href="#">lcd.textorientation</a> <sup>[356]</sup> , <a href="#">lcd.texthorizontalspacing</a> <sup>[355]</sup> , <a href="#">lcd.textverticalspacing</a> <sup>[356]</sup>

---

### Details

[Lcd.printaligned](#)<sup>[351]</sup> fits the text within a specified rectangular area. Lcd.textalignment defines how the text will be aligned within this area. The property has no bearing on the output produced by [lcd.print](#)<sup>[351]</sup>.

## .Texthorizontalspacing Property

<b>Function:</b>	Specifies the gap, in pixels, between characters of text output produced by the <a href="#">lcd.print</a> <sup>[351]</sup> and <a href="#">lcd.printaligned</a> <sup>[351]</sup> methods.
<b>Type:</b>	Byte
<b>Value Range:</b>	0- 255. <b>Default</b> = 1 (1 pixel).
<b>See Also:</b>	<a href="#">Working With Text</a> <sup>[322]</sup> , <a href="#">lcd.textalignment</a> <sup>[355]</sup> , <a href="#">lcd.textorientation</a> <sup>[356]</sup> , <a href="#">lcd.textverticalspacing</a> <sup>[356]</sup>

---

### Details

---

## .Textorientation Property

<b>Function:</b>	Specifies the print angle for text output produced by the <a href="#">lcd.print</a> <sup>[351]</sup> and <a href="#">lcd.printaligned</a> <sup>[351]</sup> methods.
<b>Type:</b>	Enum (pl_lcd_text_orientation, byte)
<b>Value Range:</b>	0- PL_LCD_TEXT_ORIENTATION_0: At 0 degrees ( <b>default</b> ) . 1- PL_LCD_TEXT_ORIENTATION_90: At 90 degrees. 2- PL_LCD_TEXT_ORIENTATION_180: At 180 degrees. 3- PL_LCD_TEXT_ORIENTATION_270: At 270 degrees.
<b>See Also:</b>	<a href="#">Working With Text</a> <sup>[322]</sup> , <a href="#">lcd.textalignment</a> <sup>[355]</sup> , <a href="#">lcd.texthorizontalspacing</a> <sup>[355]</sup> , <a href="#">lcd.textverticalspacing</a> <sup>[356]</sup>

---

### Details

---

## .Textverticalspacing Property

<b>Function:</b>	Specifies the gap, in pixels, between the lines of text output produced by the <a href="#">lcd.printaligned</a> <sup>[351]</sup> method.
<b>Type:</b>	Byte
<b>Value Range:</b>	0- 255. <b>Default</b> = 1 (1 pixel).
<b>See Also:</b>	<a href="#">Working With Text</a> <sup>[322]</sup> , <a href="#">lcd.textalignment</a> <sup>[355]</sup> , <a href="#">lcd.textorientation</a> <sup>[356]</sup> , <a href="#">lcd.texthorizontalspacing</a> <sup>[355]</sup>

---

### Details

The property has no bearing on the output produced by [lcd.print](#)<sup>[351]</sup>, because this method always creates a single-line output.

## .Unlock Method

<b>Function:</b>	Unfreezes display output (on controllers/panels that support this feature).
<b>Syntax:</b>	<b>lcd.unlock</b>
<b>Returns:</b>	---
<b>See Also:</b>	---

---

### Details

When the display is locked (see [lcd.lock](#)<sup>[348]</sup>), you can make changes to the display data without showing these changes on the screen. You can then unlock the display with `lcd.unlock` and show all the changes made at once. This usually greatly improves the display agility perception by the user, even if your application is not

working any faster (see [Improving Graphical Performance](#)<sup>[330]</sup>).

Each time you execute this method on a previously locked display, the value of the [lcd.lockcount](#)<sup>[349]</sup> R/O property decreases by 1. Once this value reaches 0, the display is unlocked and the user sees updated display data. The [lcd.lockcount](#) allows you to nest locks/unlocks (again, see [Improving Graphical Performance](#)<sup>[330]</sup>).

Not all controllers/panels support this feature. See the [Supported Controllers/Panels](#)<sup>[333]</sup> section for details on the display you are using. If your display does not support locking, executing [lcd.lock](#) will have no effect and [lcd.lockcount](#)<sup>[349]</sup> will always stay at 0.

## .Verline Method

**Function:** Draws a vertical line.

**Syntax:** `lcd.verline(x as word,y1 as word,y2 as word)`

**Returns:** ---

**See Also:** [Lines, Rectangles, and Fills](#)<sup>[321]</sup>, [lcd.rectangle](#)<sup>[352]</sup>, [lcd.filledrectangle](#)<sup>[343]</sup>, [lcd.fill](#)<sup>[342]</sup>

Part	Description
x	X coordinates of the first and second points. Value range is 0 to <a href="#">lcd.width</a> <sup>[357]</sup> -1.
y1	Y coordinate of the first point. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> -1.
y2	Y coordinate of the second point. Value range is 0 to <a href="#">lcd.height</a> <sup>[346]</sup> -1.

### Details

The line is drawn with the specified line width ([lcd.linewidth](#)<sup>[348]</sup>) and "pen" color ([lcd.forecolor](#)<sup>[344]</sup>). Drawing horizontal ([lcd.horline](#)<sup>[346]</sup>) or vertical lines is more efficient than drawing generic lines ([lcd.line](#)<sup>[348]</sup>) and should be used whenever possible.

The display panel must be enabled ([lcd.enabled](#)<sup>[341]</sup>= 1- YES) for this method to work.

## .Width Property

**Function:** Sets the horizontal resolution of the display panel in pixels.

**Type:** Word

**Value Range:** Appropriate value depends on the panel. **Default**= 0.

**See Also:** [Preparing the Display for Operation](#)<sup>[320]</sup>, [lcd.height](#)<sup>[346]</sup>

### Details

Set this property according to the characteristics of your display panel.

The reason why this value is not set automatically when you select a certain

controller is because the capability of the controller may exceed the actual resolution of the panel, i.e. only "part" of the controller may be utilized.

This property can only be changed when the display is disabled ([lcd.enabled](#)<sup>[341]</sup>= 0-NO).

## Net Object



The net object represents the Ethernet interface of your device. This object only specifies various parameters related to the Ethernet interface and is not responsible for sending/transmitting network data. The latter is the job of the [sock](#)<sup>[42]</sup> object.

Here is what you can do with the net object:

- Check if the Network Interface Controller (NIC) IC is functioning properly.
- Check your device's Ethernet MAC address.
- Set the IP-address of the Ethernet Interface.
- Set default gateway IP and the netmask.
- Be notified when the Ethernet cable is plugged or unplugged and check current link status.
- Be notified when data overflow occurs in the NIC.

## Overview, 7.1

Here you will find:

- [Main Parameters](#)<sup>[358]</sup> (IP, gateway IP, netmask, MAC).
- [Checking Ethernet status](#)<sup>[359]</sup> (link status change, failure, overflows).

## Main Parameters

To enable Ethernet communications, you need to set the [net.ip](#)<sup>[360]</sup>, [net.gatewayip](#)<sup>[361]</sup>, and the [net.netmask](#)<sup>[360]</sup> properties. Actually, [net.gatewayip](#) and [net.netmask](#) are only needed when your device will be establishing outgoing connections to other hosts on the network (perform active opens). If your device will only be accepting incoming connections then you *do not have to* set the [net.gatewayip](#) and the [net.netmask](#).



Strangely, a lot of people hold a passionate belief that default gateway IP and the netmask are necessary always, even for incoming connections. This is not true!

The net object is usually initialized once on startup, like this:

```
sub on_sys_init
  ... some other stuff

  net.ip = "192.168.1.95" 'just an example! May not work on your
```

```
network!  
  net.gatewayip = "192.168.1.1" 'just an example! May not work on your  
network!  
  net.netmask= "255.255.255.0" 'just an example! May not work on your  
network!  
  
  ...some other stuff  
end sub
```



On a lot of networks the IP, gateway IP, and the netmask parameters of the hosts are configured automatically, through the use of a special protocol called "DHCP". The net object does not support dhcp directly by we provide a BASIC library that implements DHCP functionality.

One additional read-only property- the [net.mac](#)<sup>[360]</sup> can be used to extract the MAC address of your device. Your program cannot change the MAC address directly. The MAC is stored in the special configuration area of the EEPROM. Access to the EEPROM is provided by the [stor](#)<sup>[522]</sup> object. To change the MAC address you need to rewrite the data in the EEPROM. For more details, see the [Stor Object](#)<sup>[522]</sup> and [Stor.Base](#)<sup>[523]</sup> Property topics.

## Checking Ethernet Status

The [net.failure](#)<sup>[361]</sup> read-only property tells you if the NIC is functioning properly.

The [net.linkstate](#)<sup>[361]</sup> read-only property tells you if there is a live Ethernet cable plugged into the Ethernet port of your device, and, if yes, whether this is a 10BaseT or 100BaseT connection. The [on\\_net\\_link\\_change](#)<sup>[362]</sup> event is generated each time the link status changes:

```
sub on_net_link_change  
  
  if net.linkstate= PL_NET_LINKSTATE_NOLINK then  
    'switch the RED LED on (just an example of what you could do)  
    pat.play("RRRRRRRRRRRRRRRR", YES)  
  else  
    'switch the GREEN LED on  
    pat.play("GGGGGGGGGGGGGGGG", YES)  
  end if  
  
end sub
```

Notice, that the net.linkstate always reflects current link status, not the link at the time of event generation.

Finally, there is a [on\\_net\\_overrun](#)<sup>[362]</sup> event that is generated when internal RX buffer of NIC overflows.

## Properties, Methods, Events

This section provides an alphabetical list of all properties, methods, and events of the net object.

### .Mac R/O Property

<b>Function:</b>	Returns the MAC address of the Ethernet interface.
<b>Type:</b>	Dot-decimal string
<b>Value Range:</b>	Any valid MAC address, i.e. "0.1.2.3.4.5". Each device is preset with individual MAC address during production.
<b>See Also:</b>	---

---

#### Details

BASIC application cannot change MAC address directly. The MAC is stored in the EEPROM memory. This is the same memory used by the [stor](#)<sup>[522]</sup> object. On power-up the MAC address is loaded from the EEPROM and programmed into the Ethernet controller of the device. Stor object provides a way to change MAC address in the EEPROM- see [Stor Object](#)<sup>[522]</sup> for details.

### .Ip Property

<b>Function:</b>	Sets/returns the IP address of the Ethernet interface of your device.
<b>Type:</b>	Dot-decimal string
<b>Value Range:</b>	Any IP address, such as "192.168.100.40". <b>Default=</b> "1.0.0.1"
<b>See Also:</b>	<a href="#">net.gatewayip</a> <sup>[361]</sup> , <a href="#">net.netmask</a> <sup>[360]</sup>

---

#### Details

This property can only be written to when no socket is engaged in communications through the Ethernet interface, i.e. there is no socket for which [sock.statesimple](#)<sup>[505]</sup> <> 0- PL\_SSTS\_CLOSED and [sock.currentinterface](#)<sup>[478]</sup>= 1- PL\_INTERFACE\_ETHERNET.

### .Netmask Property

<b>Function:</b>	Sets/returns the netmask of the Ethernet interface of your device.
<b>Type:</b>	String
<b>Value Range:</b>	Any valid netmask, such as "255.255.255.0". <b>Default=</b> "0.0.0.0"
<b>See Also:</b>	<a href="#">net.ip</a> <sup>[360]</sup> , <a href="#">net.gatewayip</a> <sup>[361]</sup>

### Details

This property can only be written to when no socket is engaged in communications through the Ethernet interface, i.e. there is no socket for which [sock.statesimple](#)<sup>[505]</sup> <> 0- PL\_SSTS\_CLOSED and [sock.currentinterface](#)<sup>[478]</sup>= 1- PL\_INTERFACE\_ETHERNET.

## **.Gatewayip Property**

<b>Function:</b>	Sets/returns the IP address of the default gateway for the Ethernet interface of your device.
<b>Type:</b>	String
<b>Value Range:</b>	Any valid IP address, such as "192.168.100.40". <b>Default=</b> "127.0.0.1"
<b>See Also:</b>	<a href="#">net.ip</a> <sup>[360]</sup> , <a href="#">net.netmask</a> <sup>[360]</sup>

### Details

This property can only be written to when no socket is engaged in communications through the Ethernet interface, i.e. there is no socket for which [sock.statesimple](#)<sup>[505]</sup> <> 0- PL\_SSTS\_CLOSED and [sock.currentinterface](#)<sup>[478]</sup>= 1- PL\_INTERFACE\_ETHERNET.

## **.Failure R/O Property**

<b>Function:</b>	Reports whether the Network Interface Controller (NIC) IC has failed.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO ( <b>default</b> ): No failure 1- YES: NIC failure
<b>See Also:</b>	---

### Details

---

## **.Linkstate R/O Property**

<b>Function:</b>	Returns current link status of the Ethernet port of the device.
<b>Type:</b>	Enum (pl_net_linkstate, byte)
<b>Value Range:</b>	0- PL_NET_LINKSTAT_NOLINK: No physical Ethernet link exists at the moment (the Ethernet port of the device is not connected to a hub).

1- PL\_NET\_LINKSTAT\_10BASET: The Ethernet port of the device is linked to a hub (or directly to another device) at 10Mbit/sec.

2- PL\_NET\_LINKSTAT\_100BASET: The Ethernet port of the device is linked to a hub (or directly to another device) at 100Mbit/sec.

**See Also:** [on\\_net\\_link\\_change](#)<sup>[362]</sup>

---

### Details

---

## On\_net\_link\_change Event

**Function:** Generated when the state of the physical link of Ethernet port changes.

**Declaration:** **on\_net\_link\_change**

**See Also:** ---

---

### Details

Multiple on\_net\_link\_change events may be waiting in the event queue. This event does not "bring" with it new link state at the time of event generation. Current link state can be queried through the [net.linkstate](#)<sup>[361]</sup> property.

## On\_net\_overrun Event

**Function:** Generated when overflow occurs on the internal RX buffer of the Network Interface Controller (NIC) IC.

**Declaration:** **on\_net\_overrun**

**See Also:** ---

---

### Details

Another on\_net\_overrun event is never generated until the previous one is processed. Notice, that this event signifies the overrun of the hardware RX buffer of the NIC itself. This has nothing to do with the overrun of RX buffers of individual sockets (see [on\\_sock\\_overrun](#)<sup>[491]</sup> event).

## Pat Object



The pat object allows you to "play" signal patterns on up to five LED pairs, each pair consisting of a green and red LED.

The channel to work with is selected through the [pat.channel](#)<sup>[364]</sup> property. The first channel (channel 0) is the primary channel of your system. It utilizes green and red status LEDs that are present on all external devices, boards, and some modules offered by Tibbo. All modules have SG and SR I/O lines that are meant for controlling external status LEDs. Note that when the Tibbo BASIC application is not running, green and red status LEDs are used to display various [status information](#)<sup>[200]</sup>.

The remaining four channels (channel 1-4) are identical in function, but use regular I/O lines of Tibbo devices. Moreover, [pat.greenmap](#)<sup>[364]</sup> and [pat.redmap](#)<sup>[368]</sup> properties allow you to flexibly map the green and red LED control lines of each channel to any I/O lines of the device.

The pattern you play can be up to 16 steps long. Each "step" can be either "-" (both LEDs off), "R" (red LED on), "G" (green LED on), or "B" (both LEDs on). You can also define whether the pattern will only execute once or loop and play indefinitely. Additionally, you can make the pattern play at a normal, double, or quadruple speed.

You load the new pattern to play with the [pat.play](#)<sup>[365]</sup> method. If the pattern is looped it will continue playing until you change it. If the pattern is not looped it will play once and then the [on\\_pat](#)<sup>[365]</sup> event will be generated. When the event handler is entered, the pat.channel property will be automatically set to the channel number for which the event was generated.

LED patterns offer a convenient way to tell the user what your system is doing. You can devise different patterns for different states of your device.

Here is a simple example in which we keep the green LED on at all times, except when the button is pressed, after which the green LED is turned off and the red LED blinks three times *fast*. Additionally, both green and red LEDs blink 4 times on startup. In this example we work on channel 0:

```
Sub On_sys_init
    pat.channel=0 'not really necessary since 0 is the default value for this
property
    pat.play("B-B-B-B-", PL_PAT_CANINT)
End Sub

Sub On_button_pressed
    pat.play("*R-R-R-", PL_PAT_CANINT)
End Sub

Sub On_pat
    If pat.channel=0 Then 'not really necessary since we are not using any
other channels
        pat.play("~G", PL_PAT_CANINT)
    End If
End Sub
```

In the above example, the power-up pattern is loaded inside the [on\\_sys\\_init](#)<sup>[533]</sup> event handler. This is not a looped pattern, so once it finishes playing the [on\\_pat](#)<sup>[365]</sup> event is generated and the "permanent" pattern "green LED on" is loaded inside

this event's handler. This new pattern is looped (notice "~"). When the button is pressed, a fast pattern (notice "\*") is loaded. This one makes the red LED blink three times. Again, this is not a looped pattern, so after it finishes playing the on\_pat event is generated and the "permanent green" pattern is loaded again.

## .Channel Property

<b>Function:</b>	Selects/returns the LED channel (status LED pair) to work with.
<b>Type:</b>	Byte
<b>Value Range:</b>	The value of this property won't exceed 4 (even if you attempt to set higher value). <b>Default</b> = 0 (channel 0 selected).
<b>See Also:</b>	---

---

### Details

Channels are enumerated from 0. All other properties, methods, and an event of this object relate to the currently selected channel. Note that this property's value will be set automatically when the event handle for the [on\\_pat](#)<sup>[365]</sup> event is entered.

## .Greenmap Property

<b>Function:</b>	For the selected LED channel (selection is made through the <a href="#">pat.channel</a> <sup>[364]</sup> property), sets/returns the number of the I/O line that will act as a green LED control line.
<b>Type:</b>	Enum (pl_int_num, byte)
<b>Value Range:</b>	Platform-specific, see the list of pl_int_num constants in the platform specifications.
	<b>Default values:</b>
	Channel 0: <b>(-1)</b> (no mapping, read-only): the green status LED (control line) of Tibbo device is always used by this channel;
	Channels 1-4: <b>PL_IO_NULL</b> (non-existent line).
<b>See Also:</b>	<a href="#">Pat.redmap</a> <sup>[366]</sup>

---

### Details

Channel 0 is special -- its LED control lines can't be remapped. This is because channel 0 uses standard green and red status LEDs (they are called SG and SR). For channel 0, reading the property always returns (-1), and writing has no effect.

All other channels use regular I/O lines of Tibbo devices. Any I/O line can be selected to be the green control line of the selected channel. By default, all control lines are mapped to the non-existent line PL\_IO\_NULL. Remap as needed and don't forget to configure the selected I/O line as an output -- this won't happen automatically.

## On\_pat Event

**Function:** Generated when an LED pattern finishes playing.

**Declaration:** `on_pat`

**See Also:** [Pat.play](#)<sup>[365]</sup>

### Details

This can only happen for "non-looped" patterns. Multiple on\_pat events may be waiting in the event queue. When the event handler for this event is entered the [pat.channel](#)<sup>[364]</sup> property is automatically set to the channel for which this event was generated.

## .Play Method

**Function:** Loads a new LED pattern to play on the currently selected LED channel (selection is made through the [pat.channel](#)<sup>[364]</sup> property).

**Syntax:** `pat.play(byref pattern as string, patint as pl_pat_int)`

**Returns:** ---

**See Also:** ---

Part	Description
pattern	Pattern string, can include the following characters: '-' : both LEDs off 'R' or 'r' : red LED on 'G' or 'g' : green LED on 'B' or 'b' : both LEDs on '~' : looped pattern (can reside anywhere in the pattern string) '*' : double-speed pattern (can reside anywhere in the pattern string). You can use this symbol twice to x4 speed. Adding even more '*' will not have any effect.
patint	Defines whether the pat.play method is allowed to interrupt another pattern that is already playing: 0- PL_PAT_NOINT: cannot interrupt 1- PL_PAT_CANINT: can interrupt)

### Details

Maximum pattern length is 16 "steps". The [on\\_pat](#)<sup>[365]</sup> event is generated once the pattern finishes playing. Looped patterns never finish playing and thus the event is never generated for them.

Note that channels 1-4 require you to map LED control lines. See [pat.greenmap](#)<sup>[364]</sup> and [pat.redmap](#)<sup>[366]</sup> properties for details.

## .Redmap Property

<b>Function:</b>	For the selected LED channel (selection is made through the <a href="#">pat.channel</a> <sup>[364]</sup> property), sets/returns the number of the I/O line that will act as a red LED control line.
<b>Type:</b>	Enum (pl_int_num, byte)
<b>Value Range:</b>	Platform-specific, see the list of pl_int_num constants in the platform specifications.
	<b>Default values:</b>
	Channel 0: <b>(-1)</b> (no mapping, read-only): the green status LED (control line) of Tibbo device is always used by this channel;
	Channels 1-4: <b>PL_IO_NULL</b> (non-existent line).
<b>See Also:</b>	<a href="#">Pat.greenmap</a> <sup>[364]</sup>

### Details

Channel 0 is special -- its LED control lines can't be remapped. This is because channel 0 uses standard green and red status LEDs (they are called SG and SR). For channel 0, reading the property always returns (-1), and writing has no effect.

All other channels use regular I/O lines of Tibbo devices. Any I/O line can be selected to be the red control line of the selected channel. By default, all control lines are mapped to the non-existent line PL\_IO\_NULL. Remap as needed and don't forget to configure the selected I/O line as an output -- this won't happen automatically.

## Ppp Object



The ppp. object represents the PPP interface of your device. This is the interface that uses one of the serial ports of your device and works with traditional landline or GPRS modems.

The ppp. object itself does not handle the PPP link negotiation, which is quite complex. This needs to be done in Tibbo BASIC code. For GPRS modems there is a very convenient [GPRS library](#)<sup>[645]</sup> that implements the entire link negotiation process.

The ppp. object only specifies parameters related to the PPP interface and is not responsible for sending/transmitting network data. The latter is the job of the [sock](#).

[\[421\]](#) object. You will find PPP interface listed or available on the following sock object's properties:

- [Sock.availableinterfaces](#) [\[475\]](#)
- [Sock.allowedinterfaces](#) [\[474\]](#)
- [Sock.currentinterface](#) [\[476\]](#)
- [Sock.targetinterface](#) [\[506\]](#)

## .Buffrq Method

<b>Function:</b>	Pre-requests "numpages" number of buffer pages (1 page= 256 bytes) for the TX buffer of the ppp. object.
<b>Syntax:</b>	<b>ppp.buffrq(numpages as byte) as byte</b>
<b>Returns:</b>	Actual number of pages that can be allocated (byte).
<b>See Also:</b>	<a href="#">ppp.bufsize</a> <a href="#">[367]</a>

Part	Description
numpages	Requested numbers of buffer pages to allocate (recommended value is <b>5</b> )

### Details

Actual allocation happens when the [sys.bufalloc](#) [\[530\]](#) method is used.

The PPP object will be unable to operate properly if its buffer has inadequate capacity. Recommended buffer size is 5 pages.

The buffer can only be allocated when the PPP channel is not enabled ([ppp.enabled](#) [\[368\]](#)= 0- NO). Executing `sys.bufalloc` while `ppp.enabled= 1- YES` will leave the buffer size unchanged.

The actual current buffer size can be verified through the [ppp.bufsize](#) [\[367\]](#) read-only property.

## .Bufsize R/O Property

<b>Function:</b>	Returns the current capacity (in bytes) of the ppp. object's buffer.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default</b> = 0 (0 bytes).
<b>See Also:</b>	<a href="#">wln.buffrq</a> <a href="#">[367]</a>

### Details

Buffer capacity can be changed through the [ppp.buffrq](#) [\[367\]](#) method followed by the [sys.bufalloc](#) [\[530\]](#) method invocation.

The PPP object will be unable to operate properly if its buffer has inadequate capacity. Recommended buffer size is **5 pages**.

## .Enabled Property

<b>Function:</b>	Enables/disables PPP interface on the serial port specified by the <a href="#">ppp.portnum</a> <sup>[368]</sup> property.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO ( <b>default</b> ): not enabled 1- YES: enabled
<b>See Also:</b>	---

### Details

Once this property is set to 1- YES, the selected serial port seizes to be under the control of your application and works exclusively for the ppp. object.

PPP channel setup ([ppp.buffrq](#)<sup>[367]</sup>, [ppp.ip](#)<sup>[368]</sup>, [ppp.portnum](#)<sup>[368]</sup>) can only be altered when the ppp. object is disabled.

## .Ip Property .4

<b>Function:</b>	Sets/returns the IP address of the PPP interface of your device.
<b>Type:</b>	Dot-decimal string
<b>Value Range:</b>	Any IP address, such as "192.168.100.40". <b>Default</b> = "1.0.0.1".
<b>See Also:</b>	---

### Details

Typically, the IP address of the PPP interface is negotiated with the ISP. Our (very convenient) [GPRS library](#)<sup>[645]</sup> implements all necessary steps of PPP link negotiation for GPRS modems.

This property can only be written to when the ppp. object is disabled ([ppp.enabled](#)<sup>[368]</sup>= 0- NO).

## .Portnum Property

<b>Function:</b>	Sets/returns the number of the serial port that will be used by the ppp. object.
<b>Type:</b>	Byte
<b>Value Range:</b>	0 to <a href="#">ser.numofports</a> <sup>[411]</sup> -1
<b>See Also:</b>	---

### Details

Once the PPP interface is enabled ([ppp.enabled](#)<sup>[368]</sup>= 1- YES), the selected serial port seizes to be under the control of your application and works exclusively for the

ppp. object.

The value of this property won't exceed [ser.numofports](#)<sup>[411]</sup>-1 (even if you attempt to set a higher value).

You can only change this property when the PPP channel is disabled (ppp.enabled=0- NO).

## Pppoe Object



The pppoe. object represents the PPPoE interface of your device. This is the interface that works over the Ethernet ([net.](#)<sup>[358]</sup>) interface to carry the data between the device and the ADSL modem, the kind that needs user name and login to connect to the Internet. More about PPPoE here: <http://en.wikipedia.org/wiki/Pppoe>.

It is important to understand that net. and pppoe. represent two different network interfaces of your system, even though they both send and receive data through the same Ethernet wire. For example, PPPoE interface has its own IP address ([pppoe.ip](#)<sup>[370]</sup>), which is different from [net.ip](#)<sup>[360]</sup>.

The pppoe. object itself does not handle the ADSL login, which is quite complex. This task is performed by the [PPPOE library](#)<sup>[655]</sup>. This library's code will perform all necessary login and configuration steps, and then set the only three properties that are needed for pppoe. object's operation:

- The IP address of your device on the PPPoE interface ([pppoe.ip](#)<sup>[370]</sup>);
- The MAC address of the ADSL modem, a.k.a. "access concentrator" ([pppoe.acmac](#)<sup>[369]</sup>);
- Session ID ([pppoe.sessionid](#)<sup>[370]</sup>).

It follows from the above that the PPPoE interface is not automatically ready after the device boot. It has to be properly configured by the PPPoE library.

The pppoe. object only specifies parameters related to the PPPoE interface and is not responsible for sending/transmitting network data. The latter is the job of the [sock.](#)<sup>[421]</sup> object. You will find PPPoE interface listed or available on the following sock. object's properties:

- [Sock.availableinterfaces](#)<sup>[475]</sup>
- [Sock.allowedinterfaces](#)<sup>[474]</sup>
- [Sock.currentinterface](#)<sup>[478]</sup>
- [Sock.targetinterface](#)<sup>[506]</sup>

## .Acmac Property

<b>Function:</b>	Sets/returns the MAC address of the ADSL modem (a.k.a. "access concentrator").
<b>Type:</b>	Dot-decimal string
<b>Value Range:</b>	Any MAC address, i.e. "0.1.2.3.4.5". <b>Default=</b> "0.0.0.0.0.0"
<b>See Also:</b>	---

### Details

This property uniquely identifies the ADSL modem (access concentrator) that your device will use to access the Internet.

## .Ip Property 0.2

<b>Function:</b>	Sets/returns the IP address of the PPPoE interface of your device.
<b>Type:</b>	Dot-decimal string
<b>Value Range:</b>	Any IP address, such as "192.168.100.40". <b>Default=</b> "0.0.0.0"
<b>See Also:</b>	---

### Details

This property can only be written to when no socket is engaged in communications through the PPPoE interface, i.e. there is no socket for which [sock.statesimple](#)<sup>[505]</sup> <> 0- PL\_SSTS\_CLOSED and [sock.currentinterface](#)<sup>[478]</sup>= 1- PL\_INTERFACE\_PPPOE.

## .Sessionid Property

<b>Function:</b>	Sets/returns the ID of the current PPPoE session.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535. <b>Default=</b> 0
<b>See Also:</b>	---

### Details

Session ID is required for correct interaction between your device and ADSL modem (access concentrator). Use the [PPPOE library](#)<sup>[655]</sup> and let it take care of this and (almost) everything else.

## Romfile Object



The romfile object allows you to access resource (ROM) files of your project. Resource files appear in the "Resource Files" folder of your project tree. These are files that are not processed by the compiler in any way -- they are just added to the compiled binary. Resource files are ideal for storing permanent data that never changes.

Data bytes in resource files are counted from 1.

Calling [romfile.open](#)<sup>[374]</sup> opens a resource file. Only one file can be opened at any given time and there is no need to close it. The size of the file you have opened can be checked through the [romfile.size](#)<sup>[375]</sup> read-only property. If you attempt to open a non-existent file its size will be returned as 0. This is how you know that the file does not exist!

There is a file pointer. When you open or reopen the file the pointer is set to 1 (the first byte in the file), unless the file does not exist or empty, in which case the pointer will be at 0.

You read the data from the file using the [romfile.getdata](#)<sup>[373]</sup> method. As you read from the file, the pointer moves - each time by the number of characters you've just read. The pointer can't exceed `romfile.size+1` (unless the file does not exist or is empty, in which case the pointer will always be at 0).

You can read and set the pointer position directly using two properties -- [romfile.pointer](#)<sup>[374]</sup> and [romfile.pointer32](#)<sup>[374]</sup>. The difference between them is that `romfile.pointer` is of the [word type](#)<sup>[48]</sup> and, hence, can only be used to set the pointer in the 1-65535 range. If the pointer is already above 65535, `romfile.pointer` will still return 65535.

The `romfile.pointer32` property is of the [dword type](#)<sup>[48]</sup> and can handle all pointer positions. Use it if you access resource files that are larger than 65535 bytes. The disadvantage of `romfile.pointer32` is that using it will result in reduced code performance. For this reason, rely on `romfile.pointer` whenever possible.

The [romfile.find](#)<sup>[372]</sup> and [romfile.find32](#)<sup>[372]</sup> methods search through the currently opened resource file. For example, supposing you have the following data in the file <parameters.txt>:

```
IP=192.168.1.40
PORT=1001
...
```

This sample data represents the list of parameters that your program uses. Now, supposing you need to extract the value of the "PORT" parameter. Here is the code:

```
dim dw,dw2 as dword
dim s as string(10)

'look for "PORT" first
romfile.open("resource2.txt")
dw=romfile.find(1,"PORT",1)
if dw=0 then sys.halt
dw=dw+len("PORT=")

'OK, now loop for CR after "PORT"
dw2=romfile.find(dw,chr(13),1)
if dw2=0 then sys.halt

'extract the value
romfile.pointer=dw
s=romfile.getdata(dw2-dw)
's now contains the port number
```

The difference between [romfile.find](#)<sup>[372]</sup> and [romfile.find32](#)<sup>[372]</sup> is that the former is of the [word type](#)<sup>[48]</sup> and the latter is of the [dword type](#)<sup>[48]</sup>. Romfile.find can only "report back" file positions that are in the 1-65535 range. If the target instance of the substring was found beyond the 65535 position, romfile.find will still return 65535. Romfile.find32 doesn't have this limitation, but it will slow down your code, so use romfile.find whenever possible.

Sometimes you will need to open a resource file not for the purpose of accessing it, but for the purpose of "passing" this file to another object. Such reference is provided by the [romfile.offset](#)<sup>[373]</sup> read-only property. For illustration of use, see [lcd.setfont](#)<sup>[353]</sup> and [wln.boot](#)<sup>[558]</sup>.

## .Find Method.1

<b>Function:</b>	Locates the Nth occurrence of a substring within the currently opened resource (ROM) file.
<b>Syntax:</b>	<b>romfile.find</b> (frompos <b>as dword</b> , byref substr <b>as string</b> , num <b>as word</b> ) <b>as word</b>
<b>Returns:</b>	16-bit value indicating the file position at which the specified occurrence of the substring was found or 0 if the specified occurrence wasn't found. If the specified occurrence was found at file position 65535 or higher, the value of 65535 will be returned.
<b>See Also:</b>	<a href="#">Romfile Object</a> <sup>[370]</sup>

Part	Description
frompos	Starting search position in the file.
substr	Substring to search for.
num	Substring occurrence to search for.

### Details

Bytes in the resource files are counted from 1. Use [romfile.find32](#)<sup>[372]</sup> if you are searching within a file larger than 65535 bytes.

## .Find32 Method

<b>Function:</b>	Locates the Nth occurrence of a substring within the currently opened resource (ROM) file.
<b>Syntax:</b>	<b>romfile.find32</b> (frompos <b>as dword</b> , byref substr <b>as string</b> , num <b>as word</b> ) <b>as dword</b>
<b>Returns:</b>	32-bit value indicating the file position at which the specified occurrence of the substring was found or 0 if the specified occurrence wasn't found.
<b>See Also:</b>	<a href="#">Romfile Object</a> <sup>[370]</sup>

Part	Description
frompos	Starting search position in the file.
substr	Substring to search for.
num	Substring occurrence to search for.

**Details**

Bytes in the resource files are counted from 1. When searching inside files that do not exceed 65535 bytes, use [romfile.find](#)<sup>[372]</sup> instead -- this will speed up your application.

**.GetData Method**

**Function:** Reads data from a currently opened resource (ROM) file.  
**Syntax:** **romfile.getdata(maxinplen as byte) as string**  
**Returns:** String containing a part of the ROM file's data  
**See Also:** [Romfile Object](#)<sup>[370]</sup>

Part	Description
maxinplen	Maximum number of characters to read from the file.

**Details**

The actual return string length is limited by three factors, whichever is smaller: the capacity of the receiving string, the amount of remaining data in the file ([romfile.size](#)<sup>[375]</sup>+1-[romfile.pointer](#)<sup>[374]</sup>), and the maxinplen argument. Invoking this method moves the current pointer position forward by the actual number of bytes read.

**.Offset R/O Property**

**Function:** For the currently opened resource (ROM) file returns the absolute file offset in the compiled project binary.  
**Type:** Dword  
**Value Range:** ---  
**See Also:** [Romfile Object](#)<sup>[370]</sup>

**Details**

The property is used to pass the file data to some other object that may need this data. This way, the "separation of labor" is maintained between the objects. The romfile object opens the ROM file ([romfile.open](#)<sup>[374]</sup>) and passes the pointer to this file (through romfile.offset) to another object that requires this information.

For illustration of use, see [lcd.setfont](#)<sup>[353]</sup> and [wln.boot](#)<sup>[558]</sup>.

## .Open Method5

<b>Function:</b>	Opens or re-opens a resource (ROM) file.
<b>Syntax:</b>	<b>romfile.open</b> (byref filename as string)
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Romfile Object</a> <sup>[370]</sup>

Part	Description
filename	Name of the resource file to open.

### Details

If the file exists and is not empty, the [romfile.pointer](#)<sup>[374]</sup> and [romfile.pointer32](#)<sup>[374]</sup> properties are set to 1 (each time you (re)open the file). If the file doesn't exist or is empty, these two properties are set to 0.

There is no method (or need) to explicitly close resource files. Only one resource file can be opened at any given time.

## .Pointer Property

<b>Function:</b>	Sets/returns the current pointer position in the resource (ROM) file.
<b>Type:</b>	Word
<b>Value Range:</b>	See the explanation below.
<b>See Also:</b>	<a href="#">Romfile Object</a> <sup>[370]</sup>

### Details

When the file is (re)opened with the [romfile.open](#)<sup>[374]</sup> method, the pointer is reset to the first character of the file (position 1). If the file is not found or contains no data, the pointer is set to 0.

Pointer position cannot exceed [romfile.size](#)<sup>[375]</sup>+1. When you read from the file with [romfile.getdata](#)<sup>[373]</sup>, the pointer is automatically moved forward by the number of bytes that have been read out.

Since this property is of the word type, the maximum pointer value you can set with it is 65535. Reading the current pointer position with this property will return 65535 for all pointer positions from 65535 and up. To navigate within the files that exceed 65535 bytes, use [romfile.pointer32](#)<sup>[374]</sup> instead.

## .Pointer32 Property

<b>Function:</b>	Sets/returns the current pointer position in the resource (ROM) file.
------------------	---

<b>Type:</b>	Dword
<b>Value Range:</b>	See the explanation below.
<b>See Also:</b>	<a href="#">Romfile Object</a> <sup>[370]</sup>

### Details

When the file is (re)opened with the [romfile.open](#)<sup>[374]</sup> method, the pointer is reset to the first character of the file (position 1). If the file is not found or contains no data, the pointer is set to 0.

Pointer position cannot exceed [romfile.size](#)<sup>[375]</sup>+1. When you read from the file with [romfile.getdata](#)<sup>[373]</sup>, the pointer is automatically moved forward by the number of bytes that have been read out.

To navigate within files that do not exceed 65535 bytes, use [romfile.pointer](#)<sup>[374]</sup> instead -- this will speed up your application.

## .Size R/O Property

<b>Function:</b>	Returns the size of the currently opened resource (ROM) file.
<b>Type:</b>	Dword
<b>Value Range:</b>	---
<b>See Also:</b>	<a href="#">romfile.open</a> <sup>[374]</sup>

### Details

Zero size is returned when the file does not exist or the file is empty.

## RTC Object



The RTC object facilitates access to the real-time counter (RTC) of the device. The RTC is an independent hardware counter that has its own power input. When the backup battery is installed, the RTC will continue running even when the rest of the device is powered off. The RTC keeps track of elapsed days, minutes, and seconds, not actual date and time. This is why it is called the "counter", not "clock". This platform includes a set of convenient date and time conversion syscalls that can be used to transform RTC data into current date/time and back (see [year](#)<sup>[230]</sup>, [month](#)<sup>[221]</sup>, [date](#)<sup>[208]</sup>, [weekday](#)<sup>[230]</sup>, [daycount](#)<sup>[209]</sup>, [hours](#)<sup>[213]</sup>, [minutes](#)<sup>[221]</sup>, and [mincount](#)<sup>[220]</sup>).

Two methods of the RTC object- [rtc.getdata](#)<sup>[376]</sup> and [rtc.setdata](#)<sup>[377]</sup> are used to read and set the counter value.

Supposing that your project has curr\_year, curr\_month, curr\_date, curr\_hours, curr\_minutes, and curr\_seconds variables, here is how you set and get the time:

```

dim curr_year, curr_month, curr_date, curr_hours, curr_minutes,
curr_seconds as byte
dim x,y as word
...
...
'set RTC now (data is supposed to be prepared in curr_ variables)
rtc.set(daycount(curr_year,curr_month,curr_date),mincount(curr_hours,
curr_minutes),curr_seconds)
...
...
'get RTC now- first get the daycount and mincount into x and y
rtc.getdata(x,y,curr_seconds)
'now convert daycount and mincount into date and time
curr_year=year(x)
curr_month=month(x)
curr_date=date(x)
curr_hours=hours(y)
curr_minutes=minutes(y)

```

There is also [rtc.running](#)<sup>[377]</sup> read-only property that tells you whether the RTC is working.

- Notice, that after the device powers up and provided that the backup power was not present at all times the RTC may be in the undetermined state and not work properly until the `rtc.set` method is executed at least once. Incorrect behavior may include failure to increment or incrementing at an abnormal rate. `Rtc.running` cannot be used to reliably check RTC state in this situation.

It is not necessary to use `rtc.set` if the backup power was present at all times while the device was off.

## .Getdata Method (Previously .Get)

<b>Function:</b>	Returns current RTC data as the number of elapsed days, minutes and seconds.
<b>Syntax:</b>	<b>rtc.getdata(byref daycount as word, byref mincount as word, byref seconds as byte)</b>
<b>Returns:</b>	Number of elapsed days, minutes, and seconds. Notice that this is done indirectly, through byref arguments.
<b>See Also:</b>	<a href="#">RTC Object</a> <sup>[375]</sup>

Part	Description
daycount	Number of elapsed days.
mincount	Number of elapsed minutes.
seconds	Number of elapsed seconds.

### Details

Some platforms include a set of convenient date and time conversion functions that can be used to transform "elapsed time" values into current weekday, date, and time (see [weekday](#)<sup>[230]</sup>, [year](#)<sup>[230]</sup>, [month](#)<sup>[221]</sup>, [date](#)<sup>[208]</sup>, [hours](#)<sup>[213]</sup>, [minutes](#)<sup>[221]</sup>).

- When the RTC is powered up after being off (that is, device had not power AND no backup power for a period of time), it may not work correctly until you set it using [rtc.set](#)<sup>[377]</sup> method. Incorrect behavior may include failure to increment or incrementing at an abnormal rate. Rtc.running cannot be used to reliably check RTC state in this situation.

It is not necessary to use rtc.set if the backup power was present while the device was off.



With Tibbo Basic release **V2**, this method had to be renamed from .get to .getdata. This is because the period (".") separating "rtc" from "getdata" is now a "true" part of the language, i.e. it is recognized as a syntax unit, not just part of identifier. Hence, Tibbo Basic sees "rtc" and "get" as separate entities and "get" is a reserved word that can't be used.

## .Running R/O Property

<b>Function:</b>	Returns current RTC state.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO: RTC is not running. 1- YES: RTC is running.
<b>See Also:</b>	<a href="#">RTC Object</a> <sup>[375]</sup>

---

### Details

When this property returns 0- NO this typically is the sign of a hardware malfunction (for instance, RTC crystal failure).

- When the RTC is powered up after being off (that is, device had not power AND no backup power for a period of time), it may not work correctly until you set it using [rtc.set](#)<sup>[377]</sup> method. Rtc.running cannot be used to reliably check RTC state in this situation.

## .Setdata Method (Previously .Set)

<b>Function:</b>	Presets the RTC with a number of elapsed days , minutes , and seconds.
<b>Syntax:</b>	<b>rtc.setdata</b> (daycount <b>as word</b> , mincount <b>as word</b> , seconds <b>as byte</b> )
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">RTC Object</a> <sup>[375]</sup>

Part	Description
daycount	Number of elapsed days.
mincount	Number of elapsed minutes.
seconds	Number of elapsed seconds.

### Details

Some platforms includes a set of convenient date and time conversion functions that can be used to transform actual date into time into "elapsed time" values (see [daycount](#)<sup>[209]</sup> and [mincount](#)<sup>[220]</sup>).

- Notice, that after the device powers up and provided that the backup power was not present at all times the RTC may be in the undetermined state and not work properly until the `rtc.set` method is executed at least once. Incorrect behavior may include failure to increment or incrementing at an abnormal rate. `Rtc.running` cannot be used to reliably check RTC state in this situation.

It is not necessary to use `rtc.set` if the backup power was present at all times while the device was off.



With Tibbo Basic release **V2**, this method had to be renamed from `.get` to `.getdata`. This is because the period (".") separating "stor" from "setdata" is now a "true" part of the language, i.e. it is recognized as a syntax unit, not just part of identifier. Hence, Tibbo Basic sees "stor" and "set" as separate entities and "set" is a reserved word that can't be used.

## Ser Object



This is the *serial port* object. This object encompasses all serial ports available on a particular platform. Each serial port can function as a standard [UART](#)<sup>[380]</sup>, [Wiegand](#)<sup>[383]</sup> device, or [clock/data](#)<sup>[386]</sup> device. Direct support for Wiegand and clock/data interfaces is a unique feature of the serial port object.

Each serial port has a set of standard programmable parameters that you would expect to find, such as baudrate and parity. In addition, it has some unique features like the ability to automatically filter out so-called 'escape sequences' or select UART, Wiegand, or clock/data operating mode.

Follows is the list of features offered by the serial port object:

- Ability to work in UART, Wiegand, or clock/data mode
- Fully asynchronous operation with separate "data arrival" and "data sent" events.
- Automatic data overrun detection on the RX buffer.
- Adjustable receive (RX) and transmit (TX) buffer sizes for optimal RAM utilization.
- Data "grouping" in the RX buffer based on "intercharacter" delay (gap between two consecutive arriving characters) and amount of data in the buffer.

- Optional automatic port disabling when a data group has been received.
- Buffer shorting feature for fast data exchange between the ser object and other objects (such as the [sock](#)<sup>[421]</sup> object) that support standard Tibbo Basic data buffers.

For the UART mode:

- Ability to set any baudrate (that is physically possible on a particular platform) by specifying "divider value" instead of a "baudrate from a list" as is usually done on other products
- Standard parity selection: parity off, even, odd, mark, or space.
- Choice of word length- 7 or 8 data bits/word.
- Full duplex or half duplex operation.
- Optional automatic CTS/RTS flow control in the full-duplex mode.
- Automatic direction control via RTS line in the half-duplex mode with direction control polarity selection.
- Automatic detection of "escape sequences", active even when the buffer shorting is enabled (see below).

## Overview, 13.1

This section covers the serial port object in detail. Here you will find:

- [Anatomy of a Serial Port](#)<sup>[379]</sup>
- [Three modes of the serial port](#)<sup>[380]</sup>
- [Port Selection](#)<sup>[388]</sup>
- [Serial Settings](#)<sup>[390]</sup>
- [Sending and Receiving Data \(TX and RX buffers\)](#)<sup>[393]</sup>

### Anatomy of a Serial Port

A serial port is composed of actual hardware which controls serial port lines, and of buffers that store incoming data (which is to be processed by your application) and outgoing data (which has not yet left the port).

The serial port object contains properties, methods and events which relate both to the buffers and the UART itself (see [Serial Settings](#)<sup>[390]</sup>).

The *buffers* available are:

- The **TX buffer**, which contains data due to be sent out of the port (i.e, it's the transmit *of your device!*). Your Tibbo Basic application puts the data into the TX buffer.
- The **RX buffer**, which contains incoming data received by the port. This data is to be processed by your application.

The *logical lines* available are:

- The **TX/W1out/dout output** line.
- The **RX/W1in/din input** line.
- The **RTS/W0out/cout output** line.
- The **CTS/W0&1in/cin input** line.

TX/W1out/dout and RX/W1in/din lines always have fixed "position" in the device i.e. they cannot be re-mapped to a different I/O pin. RTS/W0out/cout and CTS/W0&1in/cin lines can be re-mapped on select devices. Also, depending on the device and the serial port mode you may or may not require to explicitly configure

the lines of the serial port as inputs or outputs. Sometimes it will happen automatically, and sometimes you need to take care of this in your application through the [io](#)<sup>[294]</sup> object. You will find this information in the "Platform-related Programming Information" topic inside your platform specifications section.

Details of I/O line usage in each of the three operating modes of the port can be found [here](#)<sup>[380]</sup>.

## Three Modes of the Serial Port


Each port of the serial object can operate in one of the three modes:

- [UART Mode](#)<sup>[380]</sup>
- [Wiegand Mode](#)<sup>[383]</sup>
- [Clock/data Mode](#)<sup>[386]</sup>

The following subsections detail the signals that the serial port sends and expects to receive in each mode.

### UART Mode

In the UART mode the serial port has standard UART functionality. You can select the baudrate, parity, number of bits in each character, and full- or half-duplex operation (see [Serial Settings](#)<sup>[390]</sup>). The UART works with signals of "TTL-serial" polarity -- RX and TX lines are at logical HIGH when no data transmission is taking place, the start bit is LOW, stop bit is HIGH (shown below for the case of 8 bits/character and enabled parity).



UART data is sent and received via **TX** output and **RX** input lines. Two additional lines- **RTS** output and **CTS** input may also be used depending on the serial port setup (see below).

- !** Please, remember that on your platform you may be required to correctly [configure](#)<sup>[194]</sup> some of your serial port's lines as inputs or outputs through the [io.enabled](#)<sup>[298]</sup> property of the [io](#)<sup>[294]</sup> object. Additionally, you may have the freedom of re-mapping certain serial port lines to different I/O pins of the device if required. For more information, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

### How the serial port sends and receives UART data

The serial port can send and receive the data with no parity, or even, odd, mark, or space parity configuration. Additionally, you can specify the number of bits in each

character (7 or 8). The serial port takes care of parity calculation automatically. When parity bit is enabled, it will automatically calculate parity bit value for each character it transmits. When receiving, the serial port will correctly process incoming characters basing on the specified number of bits and parity mode. Actual parity check is not done. The serial port will receive the parity bit but won't actually check if it is correct.

- ❗ Actual parity check is not done. The serial port will receive the parity bit but won't actually check if it is correct. Parity is mostly kept for compatibility with older devices, so the serial port transmits it correctly.

### How the UART data is stored in the RX and TX buffers of the serial port


When in the UART mode, each data byte in the TX or RX buffer of the serial port represents one character. When the serial port is configured to send and receive 7-bit characters, the most significant bit of each byte in the RX buffer will be 0, and the most significant bit of each byte in the TX buffer will be ignored. Parity bits are not stored in the buffers. For the outgoing data stream, the serial port will calculate and append the parity bit automatically. For the incoming serial data, the serial port will discard the parity bit so the RX buffer will only get "pure" data.

### Full-duplex operation


The full-duplex mode of operation is suitable for communicating with RS232, RS422 devices, 4-line RS485 devices, and most TTL-serial devices. Naturally, external transceiver IC is needed for RS232, RS422, or RS485. TTL serial devices can be connected to the serial port lines directly in most cases.

In the full-duplex mode, the RTS output and CTS input lines can be used for optional flow control. The RTS output is low whenever the serial port is ready to receive the data from "attached" serial device (port is opened and the RX buffer has at least 64 bytes of free space). The RTS line is high whenever the serial port is closed or the RX buffer has less than 64 bytes of free space left. Figure below illustrates RTS operation.

- \* All diagrams show TTL-serial signals. If you are dealing with the lines of the RS232 port you will see all signals in reverse!



The CTS input is used by the serial port to check if attached serial device is able to accept the data. The serial port will only start to send the data when the CTS input is low. The serial port will stop sending the data once the line goes high. Note, that some Tibbo devices have a hardware buffer called "[FIFO<sup>\[196\]</sup>](#)" ("first-in-first-out" if you really need to know ;-). Once the TX data is in the FIFO it will be sent out even if the CTS line goes low. Therefore, after the attached serial device switches the CTS line to low the serial port may still output the number of bytes not exceeding the capacity of the FIFO. For more information, refer to your device's platform documentation (for example, EM1000's is [here<sup>\[143\]</sup>](#)).




When the flow control is enabled, the RTS and CTS lines are controlled by the serial port and cannot be manipulated by your application. When the flow control is off, your application can set and read the state of these lines through the [io<sup>294</sup>](#) object.

**Half-duplex operation**

The half-duplex mode of operation is suitable for communicating with 2-wire RS485 devices. Again, appropriate interface transceiver IC is required to be connected to the serial port.

In the half-duplex mode the RTS output is used to control data transmission direction. You can select the polarity of the direction control signal, i.e. which state will serve as "data in" direction, and which- as "data out" direction (see [Serial Settings<sup>390</sup>](#)).

When the serial port has no data to transmit (the TX buffer is empty), it is always ready to receive the data, so the RTS line is in the "data in" state. When the serial port needs to send out some data (the TX buffer is not empty) it switches the RTS line into the "data out" state, transmits the data, then switches the RTS back into the "data in" state. Assuming "LOWFORINPUT" direction control polarity, direction control looks like this:




The CTS line is not controlled by the serial port when in the half-duplex mode. Your application can manipulate this line through the [io<sup>294</sup>](#) object.

**Wiegand Mode**

In the Wiegand mode the serial port is able to receive the data directly from any Wiegand device, such as card reader and also output the data in the Wiegand format, as if it was a card reader itself. Wiegand interface is popular in the security, access control, and automation industry.

Standard Wiegand data transmission is shown below. There are two data lines- W0 and W1. Negative pulse on the W0 line represents data bit 0. Negative pulse on the W1 line represents data bit 1. There is no standard Wiegand timing, so pulse widths as well as inter-gap widths vary greatly between devices. Averagely, pulse width is usually in the vicinity of 100uS (microseconds), while the inter-pulse gap is usually around 20-100ms (milliseconds).

There is no explicit way to indicate the end of transmission. Receiving device either counts received bits (if it knows how many to expect) or assumes the transmission to be over when the time since the last pulse on the W0 or W1 line exceeds certain threshold, for example, ten times the expected inter-pulse gap.



The serial port outputs Wiegand data through **W0out** and **W1out** lines and receives the data via **W0&1in** and **W1in** lines. "W0&1in" means that the signal on this input must be a logical AND of W0 and W1 output lines of attached Wiegand device (see below for details). Your application *should not* attempt to work with W0out and W1out outputs directly through the [io](#)<sup>[294]</sup> object when the serial port is in the Wiegand mode.

- ! Please, remember that on your platform you may be required to correctly [configure](#)<sup>[194]</sup> some of your serial port's lines as inputs or outputs through the [io.enabled](#)<sup>[298]</sup> property of the [io](#)<sup>[294]</sup> object. Additionally, you may have the freedom of re-mapping certain serial port lines to different I/O pins of the device if required. For more information, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

### How the serial port sends and receives raw Wiegand data

There are many Wiegand data formats currently in use. These formats define how "raw" data bits are processed and converted into actual data. Typically, there are 2 parity bits- one at the beginning, and another one at the end of Wiegand data. Parity calculation, however, varies from format to format. Additionally, the length of Wiegand output is not standardized.

All this makes it impossible for the serial port object to verify incoming Wiegand data, i.e. check the data length and calculate the checksum. Instead, this task is delegated to your application while the serial object only receives raw data. Similarly, before sending out Wiegand data your application needs to prepare this data in the desired format- the serial object itself will output any data stream.

### How the Wiegand data is stored in the RX and TX buffers of the serial port

When in the Wiegand mode, each data byte in the TX or RX buffer of the serial port represents one bit of Wiegand data. This bit is recorded in the least significant bit position of each data byte in the buffer. For your application's convenience, when the serial port receives Wiegand bit stream, it adds an offset of 30Hex to each data bit. Therefore, the data recorded into the RX buffer can only consist of bytes 30H

and 31H. These correspond to ASCII characters '0' and '1'. This way, when your application reads RX buffer contents into a string variable the data will be "readable" without any additional conversion (ASCII characters with codes 0 and 1 would not be "readable").


When the serial port outputs Wiegand data, it only takes bit 0 of each byte in the TX buffer. Other bits can contain any data. You can, for instance, put a string of ASCII characters '0' and '1' into the TX buffer and these will be correctly interpreted as data bits 0 and 1. This, again, is convenient for your BASIC application.

**How the serial port transmits Wiegand data**

Wiegand data output timing is fixed and your application cannot change it. Data pulses are 100uS wide and inter-pulse gaps are 2mS wide.

**How the serial port receives Wiegand data**


You already know that W0&1in input of the serial port must receive a logical AND of W0 and W1 output of attached Wiegand device. A simple AND gate will do the job (figure A below). Actually, NOR-AND gates are more popular and these can be used too (figure B). In case you are building a product that will also accept [clock/data](#)<sup>386</sup> input, you may need to control whether the W0&1in input should receive a logical AND of two lines, or just one of the lines. Schematic diagram C uses an additional I/O line of the device to control this. When the control line is HIGH the W0&1in input receives a logical AND of both W0 and W1 lines, when the control line is LOW, the W0&1in input receives just the signal from the W0 line. Four gates are required for this, so you will get away with using a single 74HC00 IC.



The serial port does not require an incoming Wiegand data stream to adhere to any strict timing. The port is simply registering high-to-low transitions on the W0&1in

line. When such transition is detected, the port checks the state of W1 line. If the line is HIGH, data bit 0 is registered, when the line is low, data bit 1 is registered.

The end of Wiegand transmission is identified by timeout- the serial port has a special property for that, called "intercharacter delay" (see [Serial Settings](#)<sup>[390]</sup>). Another property- "auto-close"- can be used to disable the serial port after the delay has been encountered. This way, when the Wiegand output is over the port will be disabled and no further data will enter the port until you re-enable it.



*\*If the port is configured to auto-close after the gap*

## Clock/Data Mode


In the clock/data mode the serial port is able to receive the data directly from any clock/data or "magstripe interface" device, such as a card reader. The serial port is also able to output the data in the clock/data format, as if it was the card reader itself. Magstripe and clock/data interfaces are popular in the security, access control, automation, and banking industry.

Standard clock/data transmission is shown below. There are two data lines- clock and data. Each negative transition on the clock line marks the beginning of the data bit. The data line carries actual data. When the state of the data line is LOW it means data bit 1, and vice versa. There is no standard clock/data timing and some devices, such as non-motorized magnetic card readers, output the data at variable speeds (depending on how fast the user actually swipes the card).

The magstripe interface only differs from the clock/data interface in that it has a third line- card present. This line goes LOW before the data transmission and goes back to HIGH after the transmission is over. The serial port does not require the card present line for data reception. Just like with [Wiegand data](#)<sup>[383]</sup>, it identifies the end of incoming data by measuring the time since the last negative transition on the clock line. For data transmission, your application can easily use any regular I/O line to serve as card present line.

Compared to Wiegand interface, the data format of clock/data interface is very

standardized and its varieties include standard data formats for different "tracks" of the magnetic card. Most clock/data devices you will actually encounter have nothing to do with magnetic cards but terminology persists.



The serial port outputs clock/data signals through **cout** and **dout** lines and receives the data via **cin** and **din** lines. Your application *should not* attempt to work with cout and dout outputs directly through the [io](#)<sup>[294]</sup> object when the serial port is in the clock/data mode.

**!** Please, remember that on your platform you may be required to correctly [configure](#)<sup>[194]</sup> some of your serial port's lines as inputs or outputs through the [io.enabled](#)<sup>[298]</sup> property of the [io](#)<sup>[294]</sup> object. Additionally, you may have the freedom of re-mapping certain serial port lines to different I/O pins of the device if required. For more information, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

### How the serial port sends and receives raw clock/data data

Clock/data from different "tracks" has different encoding. Encoding defines how "raw" data bits are processed and converted into actual data. To allow maximum flexibility, and also to maintain the data processing style used by the [Wiegand interface](#)<sup>[383]</sup>, the serial port leaves the task of converting between the raw and actual data to your application. The serial port only sends and receives raw data without checking or transforming its contents.

### How the clock/data stream is stored in the RX and TX buffers of the serial port

When in the clock/data mode, each data byte in the TX or RX buffer of the serial port represents one bit of the clock/data stream. This bit is recorded in the least significant bit position of each data byte in the buffer. For your application's convenience, when the serial port receives clock/data bit stream, it adds an offset of 30Hex to each data bit. Therefore, the data recorded into the RX buffer can only consist of bytes 30H and 31H. These correspond to ASCII characters '0' and '1'. This way, when your application reads RX buffer contents into a string variable the

data will be "readable" without any additional conversion (ASCII characters with codes 0 and 1 would not be "readable").

When the serial port outputs clock/data stream, it only takes bit 0 of each byte in the TX buffer. Other bits can contain any data. You can, for instance, put a string of ASCII characters '0' and '1' into the TX buffer and these will be correctly interpreted as data bits 0 and 1. This, again, is convenient for your BASIC application.


### How the serial port transmits clock/data stream

Clock/data output timing is fixed and your application cannot change it. The data is output at a rate of 400us/bit (both LOW and HIGH phases of the clock signal are 200us in length).

### How the serial port receives clock/data stream

The serial port does not require an incoming clock/data stream to adhere to any strict timing. The port is simply registering high-to-low transitions on the clock line. When such transition is detected, the port checks the state of the data line. If the line is HIGH, data bit 0 is registered, when the line is low, data bit 1 is registered.

The end of clock/data transmission is identified by timeout- the serial port has a special property for that, called "intercharacter delay" (see [Serial Settings](#)<sup>[390]</sup>). Another property- "auto-close"- can be used to disable the serial port after the delay has been encountered. This way, when the clock/data output is over the port will be disabled and no further data will enter the port until you re-enable it.



*\*If the port is configured to auto-close after the gap*

## Port Selection

There may be platforms with more than one serial port. You can obtain the number of serial ports available for your platform using the [ser.numofports](#)<sup>[411]</sup> property.

Since there can be multiple ports, you must state which port you are referring to when changing properties or invoking methods. This is done using the [ser.num](#)<sup>[411]</sup> property. For example:

```
ser.numofports
```

```
ser.mode = PL_SER_MODE_WIEGAND
```

Can you tell what serial port the statement above applies to? Neither can the platform. Thus, the correct syntax would be:

```
ser.num = 0  
ser.mode = PL_SER_MODE_WIEGAND
```

Now the platform knows what port you're working with. Once you have set the *port selector* (using `ser.num`), every method and property after that point is taken to refer to that port. Thus:

```
ser.num = 0  
ser.enabled = 1  
ser.baudrate = 1  
ser.bits = 1 ' etc
```

The events generated by the `ser` object are not separate for each port. An event such as [on\\_ser\\_data\\_arrival](#)<sup>[412]</sup> serves all serial ports on your platform. Thus, when an event handler for the serial port object is entered, the port selector is automatically switched to the port number on which the event has occurred:

```
sub on_ser_data_arrival  
  
    dim s as string  
    s = ser.getdata(255) ' Note that you did not have use ser.num before  
    this statement.  
  
end sub
```

As a result of this automatic switching, when an event handler for a serial port event terminates, the `ser.num` property retains its new value (nothing changes it back). You must take this into account when processing other event handlers which make use of the serial port (and are not serial port events). In other words, you should explicitly set the `ser.num` property whenever entering such an event handler, because the property might have been automatically changed prior to this event. To illustrate:

```
sub on_sys_init ' This is always the first event executed.  
  
ser.num = 0 ' Supposedly, this would make all subsequent properties and  
methods refer to this port.  
  
end sub  
  
sub on_ser_data_arrival ' Then, supposing this event executes.  
  
dim s as string  
s = ser.getdata(255) ' However, this event happens on the second port. So
```

```
now ser.num = 1.  
  
end sub  
  
sub on_sock_data_arrival ' And then this socket event executes.  
  
ser.txclear ' You meant to do this for ser.num = 0 (as specified at  
on_sys_init). But now port.num was changed to 1. You did not explicitly  
specify a ser.num here, and now the tx buffer for the wrong port is cleared.  
Oops.  
  
end sub
```

Same precautions should be taken when using [doevents](#)<sup>[73]</sup>. This is because `doevents` will let other events execute and so serial object events will potentially execute and cause the `ser.num` to change.

To recap, only one of two things may change the current `ser.num`: **(1)** Manual change or **(2)** a serial port event. And you cannot assume the number has remained unchanged if you set it somewhere else (because a serial port event might have happened since).



Specifying a port number for a single-port platform may seem redundant, but it makes your program portable. You will have an easier time migrating your program to a multi-port platform in the future.

## Serial Settings

This topic briefly outlines the range of configurable options available on the serial port (this does not include the bulk of data on RX and TX buffers, which are described [here](#)<sup>[393]</sup>).

### Opening and closing the serial port

The `ser.enabled`<sup>[405]</sup> property defines whether the port is opened or closed. The port is closed by default, so you need to open it explicitly. The serial port won't receive or transmit the data when it is closed, but you will still be able to access its RX and TX buffers even at that time.

### Serial port lines remapping

Depending on your platform, you may or may not be allowed to `remap`<sup>[195]</sup> **RTS/W0out/cout** output and **CTS/W0&1in/cin** input, i.e. choose what I/O pins of the device these lines should be on. For more information, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>). If your device supports remapping, you can use `ser.ctsmap`<sup>[403]</sup> and `ser.rtsmap`<sup>[415]</sup> properties to select required mapping. If your device does not support remapping then its platform will not have these properties. You can only perform remapping when the serial port is closed.

### UART, Wiegand, or clock/data mode selection

The `ser.mode`<sup>[409]</sup> property selects `UART`<sup>[380]</sup>, `Wiegand`<sup>[383]</sup>, or `clock/data`<sup>[386]</sup> mode for the serial port. You can only change the mode when the serial port is closed.

## How the incoming data is committed

One important concept you will need to understand is "RX data committing". You already know that the serial port records all incoming data into the RX buffer. New information is that the data recorded into the buffer is not immediately "reported" to your application. Instead, this buffer remains "uncommitted" until certain conditions are met. Uncommitted data is effectively invisible to your application, as if it is not there at all.

For [UART](#)<sup>[380]</sup> mode, the data is committed either when the total amount of uncommitted and committed data in the RX buffer exceeds 1/2 of this buffer's capacity or when the intercharacter gap, defined by the [ser.interchardelay](#)<sup>[408]</sup> property is exceeded. For [Wiegand](#)<sup>[383]</sup> and [clock/data](#)<sup>[386]</sup> modes, the first condition is not monitored, so only the intercharacter gap can commit the data.

The intercharacter gap is the time elapsed since the start of the most recent UART character reception in the UART mode or the most recent falling edge on the W0&1in/cin line in the Wiegand and clock/data modes. The idea is that once the data stops coming in, the serial port starts counting the delay. Once the delay exceeds the time set by the [ser.interchardelay](#) property, the data is committed and becomes visible to your application.

Another property -- [ser.autoclose](#)<sup>[402]</sup> -- defines whether the port will be closed ([ser.enabled](#)<sup>[405]</sup>= NO) once the intercharacter gap reaches [ser.interchardelay](#) value.

For the UART mode, the intercharacter delay allows your application to process the data more efficiently. By keeping the data invisible for a while the serial port can accumulate a large chunk of data that your application will be able to process at once. Imagine, for instance, that the data is flowing into the serial port character by character and your application has to also process this stream character by character. The overhead may be significant and overall performance of your application greatly reduced! Now, if this incoming data is combined into sizeable portions your application won't have to handle it in small chunks, and this will improve performance. Of course, you need to strike a balance here -- attempting to combine the data into blocks that are too large may reduce your application's responsiveness and make your program appear sluggish.

Notice, that the intercharacter gap is not counted when the new data is not being received because the serial port has set the RTS line to LOW (not ready). This could happen when flow control is enabled (more on flow control below).

For the Wiegand and clock/data modes, the intercharacter delay is the way to detect the end of incoming data stream. You are recommended to program the gap to about 10 times the data rate. For example, if you are receiving the Wiegand data at a rate of 1 bit per 20ms, then set the delay to 200 ms and it will serve as a reliable indicator of transmission end. This is when the [ser.autoclose](#) will come handy- once the gap is detected the port will be closed and this will prevent another Wiegand transmission from entering the RX buffer before your application processes the previous one.

## How the outgoing data is committed

Outgoing data uses similar "data committing" concept as the incoming data. The objective is to be able to commit the data for sending once, even if the data was prepared bit by bit. This way your application can avoid sending out data in small chunks. [Buffer Memory Status](#)<sup>[394]</sup> topic details this.

## UART mode settings

Several settings are unique to [UART](#)<sup>[380]</sup> mode. The serial port has all the usual

UART-related communication parameters: [baudrate](#)<sup>[402]</sup>, [parity](#)<sup>[413]</sup>, [7/8 bits](#)<sup>[403]</sup>. There is no property to select the number of stop bits. Second stop bit can be emulated by setting `ser.parity= 3- PL_SER_PR_MARK`.

The baudrate property actually keeps a divisor value. You can set any baudrate you want by providing the correct divisor. There is even a read-only [ser.div9600](#)<sup>[404]</sup> property that allows you to calculate the divisor value in a platform-independent way, by returning the required divisor value (for the current platform) to reach 9600bps.

The actual baudrate is calculated as follows:  $\text{baudrate} = (9600 * \text{ser.div9600}) / \text{ser.baudrate}$ . For example, if we need to achieve 38400bps and `ser.div9600` returns 12, then we need to set `ser.baudrate=3`, because  $(9600 * 12) / 38400 = 3$ . This serves as a platform-independent baudrate calculation, as `ser.div9600` will return different values for different platforms.

For example:

```
function set_baud(baud as integer) as integer
'baud: 0- 1200, 1-2400, 2-4800, 3- 9600, 4-19200, other-38400

select case baud
  case 0: ser.baudrate=ser.div9600*8 '9600/1200=8
  case 1: ser.baudrate=ser.div9600*4 '9600/2400=4
  case 2: ser.baudrate=ser.div9600*2 '9600/4800=2
  case 3: ser.baudrate=ser.div9600    '9600/9600=1
  case 4: ser.baudrate=ser.div9600/2 '19200/9600=2
  case else: ser.baudrate=ser.div9600/4 '38400/9600=4
end function
```

The serial port can be used in full-duplex or half-duplex mode, as determined by the [ser.interface](#)<sup>[408]</sup> property (see [UART Mode](#)<sup>[380]</sup> for details). In the full-duplex mode, the serial port can optionally use the [flow control](#)<sup>[407]</sup>. In the half-duplex mode, you can select the [polarity](#)<sup>[404]</sup> of the direction control signal.

In the UART mode, the serial port can recognize so-called 'escape sequences'. They are defined using the [ser.esctype](#)<sup>[405]</sup> and [ser.escchar](#)<sup>[405]</sup> properties.

When such a sequence is recognized, a special event ([on\\_ser\\_esc](#)<sup>[413]</sup>) is generated and the port is disabled. Of course this can be achieved programmatically, but it would require you to parse all incoming data and really slow things down. Escape sequences were implemented with efficiency and speed in mind.

Escape sequences are rather arbitrary. They follow the style of escape sequences that Tibbo introduced before. However, they are useful for certain things. For example, if your application has a normal mode and serial 'setup' mode, you can use this sequence to switch into setup mode.

Escape sequence will work even if you are using [buffer shorting](#)<sup>[399]</sup>, and that makes them especially powerful. If you are building a device which just routes the data between a serial interface and an Ethernet interface, you will use buffer shorting for performance, but you could still detect the escape sequences to switch into the serial programming mode or perform some other similar task.

## Sending and Receiving Data (TX and RX buffers)

The serial port sends and receives data through TX (transmit) and RX (receive) buffers. Read on and you will know how to allocate memory for buffers, use them, handle overruns, and perform other tasks related to sending and receiving of data.

### Allocating Memory for Buffers

Each buffer has a certain size, i.e, a memory capacity. This capacity is allocated upon request from your program. When the device initially boots, no memory is allocated to buffers at all.

Memory for buffers is allocated in pages. A *page* is 256 bytes of memory. Allocating memory for a buffer is a two-step process: First you have to request for a specific allocation (a number of pages) and then you have to perform the actual allocation. For the RX buffer, request memory using [ser.rxbufreq](#)<sup>[413]</sup>, and for the TX buffer, request it using [ser.txbufreq](#)<sup>[413]</sup>.

The allocation method ([sys.bufalloc](#)<sup>[530]</sup>) applies to all buffers previously specified, in one fell swoop. Hence:

```
dim in, out as byte
out = ser.txbufreq(10) ' Requesting 10 pages for the TX buffer. Out will
then contain how many can actually be allocated.

in = ser.rxbufreq(7) ' Requesting 7 pages for the RX buffer. Will return
number of pages which can actually be allocated.

' .... Allocation requests for buffers of other objects ....

sys.bufalloc ' Performs actual memory allocation, as per previous requests.
```

Actual memory allocation takes up to 100ms, so it is usually done just once, on boot, for all required buffers. If you do not require some buffer, you may choose not to allocate any memory to it. In effect, it will be disabled.

You may not always get the full amount of memory you have requested. Memory is not an infinite resource, and if you have already requested (and received) allocations for 95% of the memory for your platform, your next request will get up to 5% of memory, even if you requested for 10%.

There is a small overhead for each buffer. Meaning, not 100% of the memory allocated to a buffer is actually available for use. 16 bytes of each buffer are reserved for variables needed to administer this buffer, such as various pointers etc.

Thus, if we requested (and received) a buffer with 2 pages (256 \* 2 = 512), we actually have 496 bytes in which to queue data (512 - 16).

- You can only change the size of buffers that belong to serial ports that are closed ([ser.enabled](#)<sup>[405]</sup> = 0) at the moment [sys.bufalloc](#) methods executes. If the port is opened at the time the [sys.bufalloc](#) method executes then buffer capacities for this port will remain unchanged, even if you requested changes through [ser.rxbufreq](#) and [ser.txbufreq](#).

## Using Buffers

Once you have allocated memory for the TX and RX buffers you can start sending and receiving data through them.

### Sending Data (through TX buffer)

Sending data is a two-step process. First, you put the data in the TX buffer using the [ser.setdata](#)<sup>[418]</sup> method, and then you perform the actual sending (commit the data) using the [ser.send](#)<sup>[417]</sup> method. For example:

```
ser.setdata ("Foo") ' Placed our data in the TX buffer - not being sent out
yet.

' ... more code...

ser.setdata ("Bar") ' Added even more data to our buffer, waiting to be
sent.

ser.send ' Now data will actually start going out. Data sent will be
'FooBar'.
```

Since this is a two-step process, you may first prepare a large block of data in the TX buffer and only then commit this data (this may come handy in some applications).

- \* TiOS features *non-blocking operation*. This means that on `ser.send`, for example, the program does not halt and wait until the data is completely sent. In fact, execution resumes immediately, even before the first byte goes out. Your program will not freeze just because you ordered it to send a large chunk of data.

### Receiving Data (through RX buffer)

Receiving data is a one-step process. To extract the data from a buffer, use the [ser.getdata](#)<sup>[407]</sup> method. Data may only be extracted once from a buffer. Once extracted, it is no longer in the buffer. For example:

```
dim whatigot as string
whatigot = ser.getdata(255)
```

The variable `whatigot` now contains up to 255 bytes of data which came from the TX buffer of the serial port.

## Buffer Memory Status

You cannot effectively use a buffer without knowing what its status is. Is it overflowing? Can you add more data? etc. Thus, each of the serial buffers has certain properties which allow you to monitor it:

## The RX buffer

You can check the total capacity of the buffer with the [ser.rxbuffersize](#)<sup>[416]</sup> property. You can also find out how much *committed* data the RX buffer currently contains with the [ser.txlen](#)<sup>[417]</sup> property (see [Serial Settings](#)<sup>[390]</sup> for explanation of what committed data is).

Sometimes you need to clear the RX buffer without actually extracting the data. In such cases the [ser.rxclear](#)<sup>[416]</sup> comes in handy.

## The TX buffer

Similarly to the RX buffer, the TX buffer also has a [ser.txbuffersize](#)<sup>[419]</sup> property which lets you discover its capacity.

Unlike the RX buffer, the TX buffer has two "data length" properties: [ser.txlen](#)<sup>[420]</sup> and [ser.newtxlen](#)<sup>[410]</sup>. The *txlen* property returns the amount of *committed* data waiting to be sent from the buffer (you commit the data by using the [ser.send](#)<sup>[417]</sup> method). The *newtxlen* property returns the amount of data which has entered the buffer, but has not yet been committed for sending.

The TX buffer also has a [ser.txfree](#)<sup>[420]</sup> property, which directly tells you how much space is left in it. This does not take into account uncommitted data in the buffer -- actual free space is `ser.txfree-ser.newtxlen`!



`ser.txlen + ser.txfree = ser.txbuffersize.`

When you want to clear the TX buffer without sending anything, use the [ser.txclear](#)<sup>[420]</sup> method.

An example illustrating the difference between `ser.txlen` and `ser.newtxlen`:

```
sub on_sys_init

dim x,y as word ' declare variables

ser.rxbuffrq(1) ' Request one page for the rx buffer.
ser.txbuffrq(5) ' Request 5 pages for the tx buffer (which we will use).
sys.buffalloc ' Actually allocate the buffers.

ser.setdata("foofoo") ' Set some data to send.
ser.setdata("bar") ' Some more data to send.
ser.send ' Start sending the data (commit).
ser.setdata("baz") ' Some more data to send.
x = ser.txlen ' Check total amount of data in the tx buffer.
y = ser.newtxlen ' Check length of data not yet committed. Should be 3.

end sub 'Set up a breakpoint HERE.
```

Don't step through the code. The sending is fast -- by the time you reach `x` and `y` by stepping one line at a time, the buffer will be empty and `x` and `y` will be 0. Set a breakpoint at the end of the code, and then check the values for the variables (by using the [watch](#)<sup>[331]</sup>).

## Receiving Data

In a typical system, there is a constant need to handle an inflow of data. A simple approach is to use polling. You just poll the buffer in a loop and see if it contains any data, and when fresh data is available, you do something with it. This would look like this:

```
sub on_sys_init

while ser.rxlen = 0
wend ' basically keeps executing again and again as long as ser.rxlen = 0
s = ser.getdata(255) ' once loop is exited, it means data has arrived. We
extract it.

end sub
```

This approach will work, but it will forever keep you in a specific event handler (such as [on\\_sys\\_init](#)<sup>[533]</sup>) and other events will never get a chance to execute. This is an example of *blocking code* which could cause a system to freeze. Of course, you can use the [doevents](#)<sup>[87]</sup> statement, but generally we recommend you to avoid this approach.

Since our platform is event-driven, you should use events to tell you when new data is available. There is an [on\\_ser\\_data\\_arrival](#)<sup>[412]</sup> event which is generated whenever there is data in the rx buffer:

```
sub on_ser_data_arrival

dim s as string
s = ser.getdata(255) ' Extract the data -- but in a non-blocking way.
' .... code to process data ....

end sub
```

This [on\\_ser\\_data\\_arrival](#)<sup>[412]</sup> event is generated whenever there is data in the RX buffer, but only once. There are never two `on_ser_data_arrival` events waiting in the queue. The next event is only generated after the previous one has completed processing, if and when there is any data available in the RX buffer.

This means that when handling this event, you don't have to get *all* the data in the RX buffer. You can simply handle a chunk of data and once you leave the event handler, a new event of the same type will be generated if there is still unprocessed data left.

Here is a correct example of handling arriving serial data through the `on_ser_data_arrival` event. This example implements a data loopback -- whatever is received by the serial port is immediately sent back out.

```
sub on_ser_data_arrival
    ser.setdata(ser.getdata(ser.txfree))
    ser.send
end sub
```

We want to handle this loopback as efficiently as possible, but we must not overrun the TX buffer. Therefore, we cannot simply copy all arriving data from the RX buffer into the TX buffer. We need to check how much free space is available in the TX buffer. The first line of this code implements just that: [Ser.getdata](#)<sup>[407]</sup> method takes as much data from the RX buffer as possible, but not more than [ser.txfree](#)<sup>[420]</sup> (the available room in the TX buffer). The second line just sends the data.

 Actually, this call will handle no more than 255 bytes in one pass. Even though we seemingly copy the data directly from the RX buffer to the TX buffer, this is done via a temporary string variable automatically created for this purpose. In this platform, string variables cannot exceed 255 bytes.

 Polling method of data processing can sometimes be useful. See [Generating Dynamic HTML Pages](#)<sup>[466]</sup>.

## Sending Data

In the previous section, we explained how to handle an incoming stream of data. You could say it was incoming-data driven. Sometimes you need just the opposite -- you need to perform operations based on the sending of data.

For example, supposing that in a certain system, you need to send out a long string of data when a button is pressed. A simple code for this would look like this:

```
sub on_button_pressed
    ser.setdata("This is a long string waiting to be sent. Send me
already!")
    ser.send
end sub
```

The code above *would* work, but *only* if at the moment of code execution the necessary amount of free space was available in the TX buffer (otherwise the data would get truncated). So, obviously, you need to make sure that the TX buffer has the necessary amount of free space before sending. A simple polling solution would look like this:

```
sub on_button_pressed
    dim s as string
    s = "This is a long string waiting to be sent. Send me already!"
    while ser.txfree < len(s) 'we will wait for the necessary amount of
free space to become available
    wend
    ser.setdata(s)
    ser.send
end sub
```

Again, this is not so good, as it would block other event handlers. So, instead of doing that, we would employ a code that uses [on\\_ser\\_data\\_sent](#)<sup>[412]</sup>:

```

dim s as string
s = "This is a long string waiting to be sent. Send me already!"

sub on_button_pressed
    ser.notifysent(ser.txbufsize-len(s)) ' causes the on_ser_data_sent
    event to fire when the tx buffer has space for our string
end sub

sub on_ser_data_sent
    ser.setdata(s) ' put data in tx buffer
    ser.send ' start sending it.
end sub

```

When we press the button, [on\\_button\\_pressed](#)<sup>[234]</sup> event is generated, so now the system knows we have a string to send. Using [ser.notifysent](#)<sup>[410]</sup> we make the system fire the [on\\_ser\\_data\\_sent](#)<sup>[412]</sup> event when the necessary amount of free space becomes available. This event will only be fired once -- and will be fired immediately if there is already enough available space.

Within the `on_ser_data_sent` event handler we put the data in the TX buffer and start sending it.

- Amount of data that will trigger `on_ser_data_sent` does not include uncommitted data in the TX buffer.

## Handling Buffer Overruns

### Handling RX buffer overruns

The [on\\_ser\\_overrun\\_event](#)<sup>[413]</sup> is generated when an RX buffer overrun has occurred. It means the data has been arriving to the UART faster than you were handling it and that some data got lost.

This event is generated just once, no matter how much data is lost. A new event will be generated only after exiting the handler for the previous one. In the UART/full-duplex mode (see [UART Mode](#)<sup>[380]</sup> for details) you can typically prevent this from happening by using the flow control ([ser.flowcontrol](#)<sup>[407]</sup>).

Typically, the user of your system wants to know when an overrun has occurred. For example, you could blink a red LED when this happens.

```

sub on_ser_overrun
    pat.play("R-R-R-R")
end sub

```

### Are TX buffer overruns possible?

TX buffer overruns are not possible. The serial port won't let you overload its TX buffer. If you try to add more data to the TX buffer than the free space in the buffer allows to store then the data you are adding will be truncated.

See [Sending Data](#)<sup>[397]</sup> for explanation on how to TX data correctly.

## Redirecting Buffers

The following example appeared under [Receiving Data](#)<sup>[396]</sup>:

```
sub on_ser_data_arrival
    ser.setdata(ser.getdata(ser.txfree))
    ser.send
end sub
```

This example shows how to send all data incoming to the RX buffer out from the TX buffer, in just two lines of code. However fast, this technique still passes all data through your BASIC code, even though you are not processing (altering, sampling) it in any way.

A much more efficient and advanced way to do this would be using a technique called *buffer redirection* (buffer shorting). With buffer shorting, instead of receiving the data into the RX buffer of your serial port, you are receiving it directly into the TX buffer of another object which is supposed to send out this data. This can be a serial object (the same port or a different one), a socket object, etc.

To use buffer shorting, you invoke the [ser.redir](#)<sup>[414]</sup> method and specify the buffer to which the data is to be redirected. Once this is done, the `on_ser_data_arrival` event won't be generated at all, because the data will be going directly to the TX buffer that you have specified. As soon as the data enters this buffer, it will be automatically committed for sending.

The `ser.redir` method will only work if the serial port is closed ([ser.enabled](#)<sup>[405]</sup> = 0-NO) at the time when this method is executed. Therefore, it makes sense to check the result of `ser.enabled` execution, as in the example below:

```
sub on_sys_init

    if ser.redir(PL_REDIR_SER)= PL_REDIR_SER then
        'redirection succeeded
    else
        'redirection failed (perhaps, the port is opened?)
    end if
end sub
```

The performance advantage of buffer shorting is enormous, due to two factors: first, you are not handling the data programmatically, so the VM isn't involved at all. And second, the data being received is received directly into the TX buffer from which it is transmitted, so there is less copying in memory.

Of course you cannot do anything at all with this data -- you are just pumping it through. However, very often this is precisely what is needed! Additionally, you *can* still catch [escape sequences](#)<sup>[405]</sup>.

To stop redirection, you can use `ser.redir(0)`, which means "receive data into the RX buffer in a normal fashion".

## Sinking Data

Sometimes it is desirable to ignore all incoming data while still maintaining the serial port opened. The [ser.sinkdata](#)<sup>[418]</sup> property allows you to do just that.

Set the `ser.sinkdata` to 1- YES, and all incoming data will be automatically

discarded. This means that the [on\\_ser\\_data\\_arrival](#)<sup>[412]</sup> event will not be generated, reading [ser.rxlen](#)<sup>[417]</sup> will always be returning zero, and so on. No data will be reaching its destination even in case of [buffer redirection](#)<sup>[399]</sup>. [Escape characters](#)<sup>[390]</sup>, however, will still be detected in the incoming data stream.

## Properties, Methods, Events


This section provides an alphabetical list of all properties, methods, and events of the ser object. For your convenience, here is a hierarchical map of the serial port's events, properties and methods.

All properties, methods, and events under [ser.num](#)<sup>[411]</sup> are shown as sub-nodes of this property because they refer to a serial port currently selected by the ser.num. The [\\_on\\_ser\\_data\\_sent](#)<sup>[412]</sup> event is subordinate to the [set.notifysent](#)<sup>[410]</sup> method because this method needs to be called each time you want to receive the `_on_ser_data_sent`.

The [ser.ctsmap](#)<sup>[403]</sup>, [ser.rtsmap](#)<sup>[415]</sup>, [sys.buffalloc](#)<sup>[530]</sup>, [ser.redir](#)<sup>[414]</sup>, and [ser.mode](#)<sup>[409]</sup> are subordinate to ser.enabled because they can be changed (or have effect) only when ser.enabled= 0- NO (the sys.buffalloc method is not a part of the ser object but its use is required for normal serial port operation- this is why it is listed here).

[Ser.baudrate](#)<sup>[402]</sup>, [ser.parity](#)<sup>[413]</sup>, [ser.bits](#)<sup>[403]</sup>, [ser.esctype](#)<sup>[405]</sup>, and [ser.interface](#)<sup>[408]</sup> are only relevant in the UART mode of operation.

[Ser.escchar](#)<sup>[405]</sup> is only relevant when ser.esctype is not DISABLED.



## .Autoclose Property

<b>Function:</b>	For currently selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) specifies whether the port will be disabled once the intercharacter gap expires.
<b>Type:</b>	dis_en (enum, byte)
<b>Value Range:</b>	0- DISABLED ( <b>default</b> ) 1- ENABLED
<b>See Also:</b>	<a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

The serial port is disabled by setting [ser.enabled](#)<sup>[405]</sup>= 0- NO. Intercharacter gap duration is specified by the [ser.interchardelay](#)<sup>[408]</sup> property.

This property offers a way to make sure that no further data is received once the gap of certain length is encountered. This property is especially useful in [Wiegand](#)<sup>[383]</sup> or [clock/data](#)<sup>[386]</sup> mode ([ser.mode](#)<sup>[409]</sup>= 1- PL\_SER\_MODE\_WIEGAND or 2- PL\_SER\_MODE\_CLOCKDATA) where intercharacter gap is the only way to reliably identify the end of one data transmission.

## .Baudrate Property

<b>Function:</b>	Sets/returns the baudrate "divisor value" for the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ).
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, default value is platform dependent, results in <b>9600bps</b> .
<b>See Also:</b>	<a href="#">UART Mode</a> <sup>[380]</sup> , <a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

Actual baudrate is calculated as follows:  $(9600 * \text{ser.div9600}^{\text{[404]}}) / \text{ser.baudrate}$ . The [ser.div9600](#) read-only property returns the value [ser.baudrate](#) must be set to in order to obtain 9600 bps on a particular platform.

For example, if we need to achieve 38400bps and [ser.div9600](#) returns 12, then we need to set [ser.baudrate](#)=3, because  $(9600 * 12) / 38400 = 3$ . This serves as a platform-independent baudrate calculation, as [ser.div9600](#) will return different values for different platforms.

This property is only relevant when the serial port is in the UART mode ([ser.mode](#)<sup>[409]</sup> = 0- PL\_SER\_MODE\_UART).



Technically speaking, this property should be called divisor, not baudrate. We called it *baudrate* so that you could easily find it.

## .Bits Property

<b>Function:</b>	Specifies the number of data bits in a word TXed/RXed by the serial port for the currently selected port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> )
<b>Type:</b>	Enum (pl_ser_bits, byte)
<b>Value Range:</b>	0- PL_SER_BB_7: data word TXed/RXed by the serial port is to contain 7 data bits  1- PL_SER_BB_8 ( <b>default</b> ): data word TXed/RXed by the serial port is to contain 8 data bits.
<b>See Also:</b>	<a href="#">UART Mode</a> <sup>[380]</sup> , <a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

This property is only relevant when the serial port is in the UART mode ([ser.mode](#)<sup>[409]</sup> = 0- PL\_SER\_MODE\_UART).

## .Ctsmap property (Selected Platforms Only)

<b>Function:</b>	Sets/returns the number of the I/O line that will act as <b>CTS/W0&amp;1in/cin</b> input of currently selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ).
<b>Type:</b>	Enum (pl_int_num, byte)
<b>Value Range:</b>	Platform-specific, see the list of pl_int_num constants in the platform specifications.
<b>See Also:</b>	<a href="#">Three modes of the Serial Port</a> <sup>[380]</sup> , <a href="#">Serial Settings</a> <sup>[390]</sup>

### Details



This property is only available on selected platforms. For more information please refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

Default value of this property is different for each serial port. See the list of pl\_int\_num constants in the platform specifications -- it shows default values as well.

Selection can be made only among interrupt lines. Regular, non-interrupt I/O lines cannot be selected. Property value can only be changed when the port is closed ([ser.enabled](#)<sup>[405]</sup>=0- NO).

On certain platforms, you may need to [configure](#)<sup>[194]</sup> the line as input. This is done through the [io.enabled](#)<sup>[298]</sup> property of the [io](#)<sup>[294]</sup> object.

## .Dircontrol Property

<b>Function:</b>	Sets/returns the polarity of the direction control line (RTS) for selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ).
<b>Type:</b>	Enum (pl_ser_dircontrol, byte)
<b>Value Range:</b>	0- PL_SER_DCP_LOWFORINPUT <b>(default)</b> : The RTS output will be LOW when the serial port is ready to RX data and HIGH when the serial port is TXing data. 1- PL_SER_SI_HIGHFORINPUT: The RTS output will be HIGH when the serial port is ready to rx data and LOW when the serial port is txing.
<b>See Also:</b>	<a href="#">UART Mode</a> <sup>[380]</sup> , <a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

This property is only relevant in the UART/half-duplex mode ([ser.mode](#)<sup>[409]</sup>= 0- PL\_SER\_MODE\_UART and [ser.interface](#)<sup>[408]</sup>= 1- PL\_SER\_SI\_HALFDUPLEX).

Note, that HIGH/LOW states specified above are for the TTL-serial interface of the MODULE-level products. If you are dealing with the RS232 port then the states will be in reverse (for example, 1- PL\_SER\_SI\_HIGHFORINPUT will mean "RTS LOW for input, HIGH for output").

Depending on your platform, you may be allowed to [remap](#)<sup>[195]</sup> RTS line to other I/O pins of the device through the [ser.rtsmap](#)<sup>[415]</sup> and [ser.ctsmap](#)<sup>[403]</sup> properties. Also, you may be required to correctly [configure](#)<sup>[194]</sup> RTS line as an input through the [io.enabled](#)<sup>[298]</sup> property of the [io](#)<sup>[294]</sup> object. For more information, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

When the serial port is in the UART/half-duplex mode you can use the CTS line as a regular I/O line of your device.

## .Div9600 R/O Property

<b>Function:</b>	Returns the value to which the <a href="#">ser.baudrate</a> <sup>[402]</sup> property must be set in order to achieve the baudrate of 9600bps on the current device and under present conditions.
<b>Type:</b>	Word
<b>Value Range:</b>	---
<b>See Also:</b>	<a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

"Smart" applications will use this property to set baudrates in a platform-independent fashion. Even for the same device, the value required to achieve 9600bps may be different at different times. For example, some devices have PLLs (see [sys.currentpll](#)<sup>[531]</sup>). Enabling and disabling PLL changes the clock frequency of the device and this affects the value returned by ser.div9600.

## .Enabled Property

<b>Function:</b>	Enables/disables currently selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ).
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO ( <b>default</b> ): not enabled 1- YES: enabled
<b>See Also:</b>	<a href="#">Buffer Memory Status</a> <sup>[394]</sup>

### Details

Enabling/disabling the serial port does not automatically clear its buffers, this is done via [ser.rxclear](#)<sup>[416]</sup> and [ser.txclear](#)<sup>[420]</sup>. Notice that certain properties can only be changed and methods executed when the port is not enabled. These are [ser.rtsmap](#)<sup>[415]</sup>, [ser.ctsmap](#)<sup>[403]</sup>, [ser.mode](#)<sup>[409]</sup>, [ser.redir](#)<sup>[414]</sup>. You also cannot allocate buffer memory for the port (do [sys.bufalloc](#)<sup>[530]</sup>) when the port is enabled.

## .Escchar Property

<b>Function:</b>	For selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) sets/retrieves ASCII code of the escape character used for type1 or type2 serial escape sequences.
<b>Type:</b>	Byte
<b>Value Range:</b>	0-255, <b>default=1</b> (SOH character)
<b>See Also:</b>	<a href="#">UART Mode</a> <sup>[380]</sup> , <a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

Which escape sequence is enabled is defined by the [ser.esctype](#)<sup>[405]</sup> property. This property is irrelevant when ser.esctype= 0- PL\_SER\_ET\_DISABLED or when the serial port is in the [Wiegand](#)<sup>[383]</sup> or [clock/data](#)<sup>[386]</sup> mode (ser.mode= 1- PL\_SER\_MODE\_WIEGAND or ser.mode= 2- PL\_SER\_MODE\_CLOCKDATA) -- serial escape sequences are only recognized in the UART data.

## .Esctype Property

<b>Function:</b>	Defines, for selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ), whether serial escape sequence recognition is enabled and, if yes, what type of escape sequence is to be recognised.
<b>Type:</b>	Enum (pl_ser_esctype, byte)
<b>Value Range:</b>	0- PL_SER_ET_DISABLED ( <b>disabled</b> ): Recognition of serial escape sequences disabled.

- 1- PL\_SER\_ET\_TYPE1: Escape sequences of type 1 are to be recognized.
- 2- PL\_SER\_ET\_TYPE2: Escape sequences of type 2 are to be recognized.

**See Also:** [UART Mode](#)<sup>[380]</sup>, [Serial Settings](#)<sup>[390]</sup>

## Details

Escape sequence is a special occurrence of characters in the incoming data received by the serial port. Escape sequences are only recognized in the [UART](#)<sup>[380]</sup> mode of operation ([ser.mode](#)<sup>[409]</sup>= 0- PL\_SER\_MODE\_UART).

When escape sequence is detected the [on\\_ser\\_esc](#)<sup>[413]</sup> event is generated and the serial port is disabled ([ser.enabled](#)<sup>[405]</sup>= 0- NO). When enabled, serial escape sequence detection works even when the [buffer shorting](#)<sup>[399]</sup> is employed (see [ser.redir](#)<sup>[414]</sup> property).

Follows is the description of two escape sequence types:

**Type 1** Type1 escape sequence consists of three consecutive escape characters (ASCII code of escape character is defined by the [ser.escchar](#)<sup>[405]</sup> property). For the escape sequence to be recognized each of the escape characters must be preceded by a time gap of at least 100ms:

```

...previous  <--100ms-- E.C. <--100ms-- E.C. <--100ms-- E.C.
  data              >                >                >

```

If the time gap before a certain escape character exceeds 100ms then this character is considered to be a part of the escape sequence and is not recorded into the RX buffer. If the time gap before a certain escape character is less than 100ms then this character is considered to be a normal data character and is saved into the RX buffer. Additionally, escape character counter is reset and the escape sequence must be started again. The following example illustrates one important point (escape characters are shown as ■). Supposing the serial port receives the following string:

```
ABC<--100ms-->■ <--100ms-->■ ■ DE
```

First two escape characters in this example had correct time gap before them, so they were counted as a part of the escape sequence and not saved into the buffer. The third escape character did not have a correct time gap so it was interpreted as a data character and saved into the buffer. The following was recorded into the RX buffer:

```
ABC ■ DE
```

The side effect and the point this example illustrates is that first two escape characters were lost -- they neither became a part of a successful escape sequence (because this sequence wasn't completed), nor were saved into the buffer.

**Type 2** Type 2 escape sequence is not based on any timing. Escape sequence consists of escape character (defined by the [ser.escchar](#) property) followed by any character other than escape character. To

receive a *data* character whose ASCII code matches that of escape character the serial port must get this character *twice*. This will result in a single character being recorded into the RX buffer.

The following sequence will be recognized as escape sequence (that is, if current escape character is not 'D'):

**ABC ■ D**

In the sequence below two consecutive escape characters will be interpreted as data (data recorded to the RX buffer will contain only one such character):

**ABC ■ ■**

## .Flowcontrol Property

<b>Function:</b>	Sets/returns flow control mode for currently selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> )
<b>Type:</b>	dis_en (enum, byte)
<b>Value Range:</b>	0- DISABLED ( <b>default</b> ) 1- ENABLED
<b>See Also:</b>	<a href="#">UART Mode</a> <sup>[380]</sup> , <a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

Only relevant when the [ser.mode](#)<sup>[409]</sup>= 0- PL\_SER\_MODE\_UART and [ser.interface](#)<sup>[408]</sup> 0- PL\_SER\_SI\_FULLDUPLEX (full-duplex). Flow control uses two serial port lines- RTS and CTS- to regulate the flow of data between the serial port of your device and another ("attached") serial device.

Depending on your platform, you may be allowed to [remap](#)<sup>[195]</sup> RTS and CTS lines to other I/O pins of the device through the [ser.rtsmap](#)<sup>[415]</sup> and [ser.ctsmap](#)<sup>[403]</sup> properties. Also, you may be required to correctly [configure](#)<sup>[194]</sup> RTS and CTS lines as an input and output through the [io.enabled](#)<sup>[298]</sup> property of the [io](#)<sup>[294]</sup> object. For more information, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

When the flow control is disabled both RTS and CTS lines are not used by the serial port and become regular I/O lines that can be controlled through the [io](#)<sup>[294]</sup> object.

## .Getdata Method

<b>Function:</b>	For the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) returns the string that contains the data extracted from the RX buffer.
<b>Syntax:</b>	<b>ser.getdata(maxinplen as word) as string</b>
<b>Returns:</b>	String containing data extracted from the RX buffer
<b>See Also:</b>	<a href="#">Three Modes of the Serial Port</a> <sup>[380]</sup> , <a href="#">Receiving data</a> <sup>[396]</sup>

Part	Description
maxinplen	Maximum amount of data to return (word).

### Details

Extracted data is permanently deleted from the buffer. Length of extracted data is limited by one of the three factors (whichever is smaller): amount of committed data in the RX buffer itself, capacity of the "receiving" string variable, and the limit set by the maxinplen argument.

In the [UART](#) <sup>[380]</sup> mode ([ser.mode](#) <sup>[409]</sup>= 0- PL\_SER\_MODE\_UART) the data is extracted "as is". For [Wiegand](#) <sup>[383]</sup> and [clock/data](#) <sup>[386]</sup> mode (ser.mode= 1- PL\_SER\_MODE\_WIEGAND and ser.mode= 2- PL\_SER\_MODE\_CLOCKDATA) each character of extracted data represents one data bit and only two characters are possible: '0' or '1'.

## .Interchardelay Property

<b>Function:</b>	Sets/returns maximum intercharacter delay for the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) in 10ms steps.
<b>Type:</b>	Byte
<b>Value Range:</b>	0-255, <b>default</b> = 0 (no delay)
<b>See Also:</b>	<a href="#">Three Modes of the Serial Port</a> <sup>[380]</sup> , <a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

For UART mode ([ser.mode](#) <sup>[409]</sup>= 0- PL\_SER\_MODE\_UART) specifies the time that needs to elapse since the arrival of the most recent serial character into the RX buffer to cause the data to be committed (and [on ser data arrival](#) <sup>[412]</sup> event generated). For Wiegand and clock/data mode (ser.mode= 1- PL\_SER\_MODE\_WIEGAND or 2- PL\_SER\_MODE\_CLOCKDATA) the time since the most recent data bit (high-to-low transition on the **W0&1in/cin** line) is counted.

In the UART mode this property allows you to combine incoming serial data into larger "chunks", which typically improves performance. Notice, that the intercharacter gap is not counted when the new data is not being received because the serial port has set the RTS line to LOW (not ready). For this to happen, the serial port must be in the UART/full-duplex/flow control mode ([ser.mode](#)= 0- PL\_SER\_MODE\_UART, [ser.interface](#) <sup>[408]</sup>= 0- 0- PL\_SER\_SI\_FULLDUPLEX, and [ser.flowcontrol](#) <sup>[407]</sup>= 1- ENABLED) and the RX buffer must be getting nearly full (less than 64 bytes of free space left).

For Wiegand and clock/data modes, counting timeout since the last bit is the only way to determine the end of the data output. Suggested timeout is app. 10 times the bit period of the data output by attached Wiegand or clock/data device.

## .Interface Property

<b>Function:</b>	Chooses full-duplex or half-duplex operating mode for currently selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ).
------------------	---

<b>Type:</b>	Enum (pl_ser_interface, byte)
<b>Value Range:</b>	0- PL_SER_SI_FULLDUPLEX ( <b>default</b> ): full-duplex mode. 1- PL_SER_SI_HALFDUPLEX: half-duplex mode.
<b>See Also:</b>	<a href="#">UART Mode</a> <sup>[380]</sup> , <a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

Full-duplex mode is suitable for RS232, RS422, or four-wire RS485 communications. RTS output (together with CTS input) can be used for optional hardware flow control ([ser.flowcontrol](#)<sup>[407]</sup>).

Half-duplex mode is suitable for two-wire RS485 communications. RTS line is used for direction control. Hardware flow control is not possible, so [ser.flowcontrol](#) value is irrelevant. Direction control polarity can be set through [ser.dircontrol](#)<sup>[404]</sup>.

This property is only relevant when the port is in the UART mode ([ser.mode](#)<sup>[408]</sup> = 0- PL\_SER\_MODE\_UART).

Depending on your platform, you may be allowed to [remap](#)<sup>[195]</sup> RTS and CTS lines to other I/O pins of the device through the [ser.rtsmap](#)<sup>[415]</sup> and [ser.ctsmap](#)<sup>[403]</sup> properties. Also, you may be required to correctly [configure](#)<sup>[194]</sup> RTS and CTS lines as an input and output through the [io.enabled](#)<sup>[298]</sup> property of the [io](#)<sup>[294]</sup> object. For more information, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

## .Mode Property

<b>Function:</b>	Sets operating mode for the currently selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ).
<b>Type:</b>	Enum (pl_ser_mode, byte)
<b>Value Range:</b>	0- PL_SER_MODE_UART ( <b>default</b> ): UART mode. 1- PL_SER_MODE_WIEGAND: Wiegand mode. 2- PL_SER_MODE_CLOCKDATA: clock/data (magstripe interface) mode.
<b>See Also:</b>	<a href="#">Three Modes of the Serial Port</a> <sup>[380]</sup> , <a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

Follows is a short introduction of three operating modes of the serial port:

<b>UART mode</b>	Suitable for RS232, RS422, RS485, etc. communications in full-duplex or half-duplex mode (see <a href="#">ser.interface</a> <sup>[408]</sup> ). Data is transmitted through the <b>TX</b> pin and received through the <b>RX</b> pin. Optionally, <b>RTS</b> (output) and <b>CTS</b> (input) lines are used for flow control (see <a href="#">ser.flowcontrol</a> <sup>[407]</sup> ) in the full-duplex mode. Additionally, RTS can be used for direction control in the half-duplex mode.
------------------	--

- Wiegand mode** Suitable for sending to or receiving data from any standard Wiegand device. Data transmission is through pins **W0out** and **W1out**, reception- through **W0&1in** and **W1in**. "W0&1in" means that a logical AND of W0 and W1 signals must be applied to this input. Therefore, external logical gate is needed in order to receive Wiegand data.
- Clock/data mode** Suitable for sending to or receiving data from any standard clock/data (or magstripe) device. Data transmission is through pins **cout** and **dout**, reception- through **cin** and **din**. Third line of the magstripe interface- card present- is not required for data reception. For transmission, any I/O line can be used as card present output (under software control).

Changing port mode is only possible when the port is closed ([ser.enabled](#)<sup>[405]</sup>= 0-NO). Depending on your platform, you may be allowed to [remap](#)<sup>[195]</sup> RTS/W1out/cout and CTS/W0&1in/cin lines to other I/O pins of the device through the [ser.rtsmap](#)<sup>[415]</sup> and [ser.ctsmap](#)<sup>[403]</sup> properties. Also, depending on selected mode and your platform you may be required to correctly [configure](#)<sup>[194]</sup> some of your serial port's lines as inputs or outputs through the [io.enabled](#)<sup>[298]</sup> property of the [io](#)<sup>[294]</sup> object. For more information, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).



We understand that it would be much more logical to call this property "interface", not "mode". Problem is, this property was added later, when [ser.interface](#) already came to mean something [else](#)<sup>[408]</sup>. So, we had no choice but to choose unused term.

## .Newtxlen R/O Property

- Function:** For the selected serial port (selection is made through [ser.num](#)<sup>[411]</sup>) returns the amount of uncommitted TX data in bytes.
- Type:** Word
- Value Range:** 0-65535, **default**= 0 (bytes)
- See Also:** [Sending \(Transmitting\) Data](#)<sup>[397]</sup>, [ser.txlen](#)<sup>[420]</sup>, [ser.txfree](#)<sup>[420]</sup>

### Details

Uncommitted data is the one that was added to the TX buffer with the [ser.setdata](#)<sup>[418]</sup> method but not yet committed using the [ser.send](#)<sup>[417]</sup> method.

## .Notifysent Method

- Function:** Using this method for the selected serial port (selection is made through [ser.num](#)<sup>[411]</sup>) will cause the [on\\_ser\\_data\\_sent](#)<sup>[412]</sup> event to be generated when the amount of committed data in the TX buffer is found to be below "threshold" number of bytes.

**Syntax:** `notifysent(threshold as word)`

**Returns:** ---

**See Also:** [Sending \(Transmitting\) Data](#)<sup>[397]</sup>

Part	Description
threshold	Amount of bytes in the TX buffer below which the event it so be generated.

### Details

Only one `on_ser_data_sent` event will be generated each time after the `ser.notifysent` method is invoked. This method, together with the `on_ser_data_sent` event provides a way to handle data sending asynchronously.

Just like with [ser.txfree](#)<sup>[420]</sup>, the trigger you set won't take into account any uncommitted data in the TX buffer.

## .Num Property

**Function:** Sets/returns the number of currently selected serial port (ports are enumerated from 0).

**Type:** Byte

**Value Range:** The value of this property won't exceed [ser.numofports](#)<sup>[411]</sup> - 1 (even if you attempt to set higher value). **Default= 0** (port #0 selected)

**See Also:** ---

### Details

All other properties and methods of this object relate to the serial port selected through this property. Note that serial port-related events such as [on\\_ser\\_data\\_arrival](#)<sup>[412]</sup> change currently selected port!

## .Numofports R/O Property

**Function:** Returns total number of serial ports found on the current platform.

**Type:** Byte

**Value Range:** platform-dependent

**See Also:** [ser.num](#)<sup>[411]</sup>

### Details

---

## On\_ser\_data\_arrival Event

- Function:** Generated when at least one data byte is present in the RX buffer of the serial port (i.e. for this port the [ser.rxlens](#)<sup>[417]</sup>>0).
- Declaration:** `on_ser_data_arrival`
- See Also:** [Buffer Memory Status](#)<sup>[394]</sup>
- 

### Details

When the event handler for this event is entered the [ser.num](#)<sup>[411]</sup> property is automatically switched to the port for which this event was generated. Another [on\\_ser\\_data\\_arrival](#)<sup>[412]</sup> event on a particular port is never generated until the previous one is processed. Use [ser.getdata](#)<sup>[407]</sup> method to extract the data from the RX buffer.

You don't have to process all data in the RX buffer at once. If you exit the `on_ser_data_arrival` event handler while there is still some unprocessed data in the RX buffer another `on_ser_data_arrival` event will be generated immediately.

This event is not generated for a particular port when buffer redirection is set for this port through the [ser.redir](#)<sup>[414]</sup> method.

## On\_ser\_data\_sent Event

- Function:** Generated after the total amount of *committed* data in the TX buffer of the serial port ([ser.txlen](#)<sup>[420]</sup>) is found to be less than the threshold that was preset through the [ser.notifysent](#)<sup>[410]</sup> method.
- Declaration:** `on_ser_data_sent`
- See Also:** [Sending \(Transmitting\) Data](#)<sup>[397]</sup>
- 

### Details

This event may be generated only after the `ser.notifysent` method was used. Your application needs to use the `ser.notifysent` method EACH TIME it wants to cause the `on_ser_data_sent` event generation for a particular port. When the event handler for this event is entered the [ser.num](#)<sup>[411]</sup> is automatically switched to the port on which this event was generated.

Please, remember that uncommitted data in the TX buffer is not taken into account for `on_ser_data_sent` event generation.

## On\_ser\_esc Event

<b>Function:</b>	Generated when currently enabled escape sequence is detected in the RX data stream.
<b>Declaration:</b>	<b>on_ser_esc</b>
<b>See Also:</b>	<a href="#">Serial Settings</a> <sup>[390]</sup>

### Details

Once the serial escape sequence is detected on a certain serial port this port is automatically disabled (ser.enabled= 0- NO).

When event handler for this event is entered the [ser.num](#)<sup>[411]</sup> property is automatically switched to the port on which this event was generated.

Whether or not escape sequence detection is enabled and what kind of escape sequence is expected is defined by the [ser.esctype](#)<sup>[405]</sup> property. Escape sequence detection works even when buffer redirection is set for the serial port using the [ser.redir](#)<sup>[414]</sup> method.

## On\_ser\_overflow Event

<b>Function:</b>	Generated when data overrun has occurred in the RX buffer of the serial port.
<b>Declaration:</b>	<b>on_ser_overflow</b>
<b>See Also:</b>	<a href="#">Handling Buffer Overruns</a> <sup>[398]</sup>

### Details

Another on\_ser\_overflow event for a particular port is never generated until the previous one is processed. When the event handler for this event is entered the [ser.num](#)<sup>[411]</sup> property is automatically switched to the port on which this event was generated.

Data overruns are a common occurrence on serial lines. The overrun happens when the serial data is arriving into the RX buffer faster than your application is able to extract it, the buffer runs out of space and "misses" some incoming data.

Data overruns are typically prevented through the use of RTS/CTS flow control (see the [ser.flowcontrol](#)<sup>[407]</sup> property).

## .Parity Property

<b>Function:</b>	Sets/returns parity mode for the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> )
<b>Type:</b>	Enum (pl_ser_parity, byte)
<b>Value Range:</b>	0- PL_SER_PR_NONE: no parity bit to be transmitted. 1- PL_SER_PR_EVEN: even parity. 2- PL_SER_PR_ODD: odd parity.

- 3- PL\_SER\_PR\_MARK: parity bit always at "1".
- 4- PL\_SER\_PR\_SPACE: parity bit always at "0".

**See Also:** [UART Mode](#)<sup>[380]</sup>, [Serial Settings](#)<sup>[390]</sup>

### Details

Mark parity is equivalent to having a second stop-bit (there is no separate property to explicitly select the number of stop bits).

This property is only relevant when the serial port is in the UART mode ([ser.mode](#)<sup>[409]</sup> = 0- PL\_SER\_MODE\_UART).

## .Redir Method

- Function:** For the selected serial port (selection is made through [ser.num](#)<sup>[411]</sup>) redirects the data being RXed to the TX buffer of the same serial port, different serial port, or another object that supports compatible buffers.
- Syntax:** **ser.redir(redir as pl\_redir) as pl\_redir**
- Returns:** Returns 0- PL\_REDIR\_NONE if redirection failed or the same value as was passed in the redir argument.
- See Also:** [Redirecting Buffers \(Shorting\)](#)<sup>[399]</sup>

Part	Description
redir	Platform-specific. See the list of pl_redir constants in the platform specifications.

### Details

Data redirection (sometimes referred to as "buffer shorting") allows to arrange efficient data exchange between ports, sockets, etc. in cases where no data alteration or parsing is necessary, while achieving maximum possible throughput is important.

The redir argument, as well as the value returned by this method are of "enum pl\_redir" type. The pl\_redir defines a set of platform inter-object constants that include all possible redirections for this platform. Specifying redir value of 0- PL\_REDIR\_NONE cancels redirection. When the redirection is enabled for a particular serial port, the [on\\_ser\\_data\\_arrival](#)<sup>[412]</sup> event is not generated for this port.

Once the RX buffer is redirected certain properties and methods related to the RX buffer will actually return the data for the TX buffer to which this RX buffer was redirected:

- [Ser.rxbuffsize](#)<sup>[416]</sup> will actually be returning the size of the TX buffer.
- [Ser.rxclear](#)<sup>[416]</sup> method will actually be clearing the TX buffer.
- [Ser.rxlent](#)<sup>[417]</sup> method will be showing the amount of data in the TX buffer.

**!** If the redirection is being done on a serial port that is currently opened ([ser.enabled](#)<sup>[405]</sup>= 1- YES) then this port will be closed automatically.

### .Rtsmap Property (Selected Platforms Only)

**Function:** Sets/returns the number of the I/O line that will act as **RTS/W0out/cout** output of currently selected serial port (selection is made through [ser.num](#)<sup>[411]</sup>).

**Type:** Enum (pl\_io\_num, byte)

**Value Range:** Platform-specific, see the list of pl\_io\_num constants in the platform specifications.

**See Also:** [Three modes of the Serial Port](#)<sup>[380]</sup>, [Serial Settings](#)<sup>[390]</sup>

#### Details

**!** This property is only available on selected platforms. For more information, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

Default value of this property is different for each serial port. See the list of pl\_int\_num constants in the platform specifications -- it shows default values as well.

Absolutely any I/O line can be selected by this property, as long as this line is not occupied by some other function. Property value can only be changed when the port is closed ([ser.enabled](#)<sup>[405]</sup>= 0- NO).

On certain platforms, you may need to [configure](#)<sup>[194]</sup> the line as output. This is done through the [io.enabled](#)<sup>[298]</sup> property of the [io](#)<sup>[294]</sup> object.

### .Rxbuffrq Method

**Function:** For the selected serial port (selection is made through [ser.num](#)<sup>[411]</sup>) pre-requests "numpages" number of buffer pages (1 page= 256 bytes) for the RX buffer of the serial port.

**Syntax:** **ser.rxbuffrq(numpages as byte) as byte**

**Returns:** Actual number of pages that can be allocated (byte)

**See Also:** [Allocating Memory for Buffers](#)<sup>[393]</sup>, [ser.txbuffrq](#)<sup>[419]</sup>

Part	Description
numpages	Requested numbers of buffer pages to allocate.

### Details

Returns actual number of pages that can be allocated. Actual allocation happens when the [sys.bufalloc](#)<sup>[530]</sup> method is used. The serial port is unable to RX data if its RX buffer has 0 capacity. Actual current buffer capacity can be checked through the [ser.rxbuffersize](#)<sup>[416]</sup> which returns buffer capacity in bytes.

Relationship between the two is as follows:  $\text{ser.rxbuffersize} = \text{num\_pages} * 256 - 16$  (or  $= 0$  when  $\text{num\_pages} = 0$ ), where "num\_pages" is the number of buffer pages that was GRANTED through the `ser.rxbuffrq`. "-16" is because 16 bytes are needed for internal buffer variables.

Buffer allocation will not work if the serial port to which this buffer belongs is opened ([ser.enabled](#)<sup>[405]</sup> = 1- YES) at the time when `sys.bufalloc` executes. You can only change buffer sizes of ports that are closed.

## **.Rxbuffersize R/O Property**

<b>Function:</b>	For the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) returns current RX buffer capacity in bytes.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535
<b>See Also:</b>	<a href="#">Buffer Memory Status</a> <sup>[394]</sup>

### Details

Buffer capacity can be changed through the [ser.rxbuffrq](#)<sup>[415]</sup> method followed by the [sys.bufalloc](#)<sup>[530]</sup> method.

The `ser.rxbuffrq` requests buffer size in 256-byte pages whereas this property returns buffer size in bytes. Relationship between the two is as follows:  $\text{ser.rxbuffersize} = \text{num\_pages} * 256 - 16$  (or  $= 0$  when  $\text{num\_pages} = 0$ ), where "num\_pages" is the number of buffer pages that was GRANTED through the `ser.rxbuffrq`. "-16" is because 16 bytes are needed for internal buffer variables. The serial port cannot RX data when the RX buffer has zero capacity.

## **.Rxclear Method**

<b>Function:</b>	For the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) clears (deletes all data from) the RX buffer.
<b>Syntax:</b>	<b>ser.rxclear</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Buffer Memory Status</a> <sup>[394]</sup>

## Details

---

### **.Rxlen R/O Property**

<b>Function:</b>	For the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) returns total number of committed bytes currently waiting in the RX buffer to be extracted and processed by your application.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535
<b>See Also:</b>	<a href="#">Serial Settings</a> <sup>[390]</sup> , <a href="#">Buffer Memory Status</a> <sup>[394]</sup>

## Details

The [on\\_ser\\_data\\_arrival](#)<sup>[412]</sup> event is generated once the RX buffer is not empty, i.e. there is data to process. There may be only one on\_ser\_data\_arrival event for each port waiting to be processed in the event queue. Another on\_serial\_data\_arrival event for the same port may be generated only after the previous one is handled.

If, during the on\_ser\_data\_arrival event handler execution, not all data is extracted from the RX buffer, another on\_ser\_data\_arrival event is generated immediately after the on\_ser\_data\_arrival event handler is exited.

Notice that the RX buffer of the serial port employs "data committing" based on the amount of data in the buffer and intercharacter delay ([ser.interchardelay](#)<sup>[408]</sup>). Data in the RX buffer may not be committed yet. Uncommitted data is not visible to your application and is not included in the count returned by the ser.rxlen.

### **.Send Method**

<b>Function:</b>	For the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) commits (allows sending) the data that was previously saved into the TX buffer using the <a href="#">ser.setdata</a> <sup>[418]</sup> method.
<b>Syntax:</b>	<b>ser.send</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Serial Settings</a> <sup>[390]</sup>

## Details

You can monitor the sending progress by checking the [ser.txlen](#)<sup>[420]</sup> property or using the [ser.notifysent](#)<sup>[410]</sup> method and the [on\\_ser\\_data\\_sent](#)<sup>[412]</sup> event.

## .Setdata Method

<b>Function:</b>	For the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) adds the data passed in the txdata argument to the contents of the TX buffer.
<b>Syntax:</b>	<b>ser.setdata(byref txdata as string)</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Three Modes of the Serial Port</a> <sup>[380]</sup> , <a href="#">Sending Data</a> <sup>[397]</sup> , <a href="#">ser.txlen</a> <sup>[420]</sup> , <a href="#">ser.txfree</a> <sup>[420]</sup> ,

Part	Description
txdata	The data to send.

### Details

In the [UART](#)<sup>[380]</sup> mode ([ser.mode](#)<sup>[409]</sup>= 0- PL\_SER\_MODE\_UART) the data is added "as is". For [Wiegand](#)<sup>[383]</sup> and [clock/data](#)<sup>[386]</sup> mode (ser.mode= 1- PL\_SER\_MODE\_WIEGAND and ser.mode= 2- PL\_SER\_MODE\_CLOCKDATA) each data character represents one data bit and only bit0 (least significant bit) of each character is relevant (therefore, adding "0101" will result in the 0101 sequence of data bits).

If the buffer doesn't have enough space to accommodate the data being added then this data will be truncated. Newly saved data is not sent out immediately. This only happens after the [ser.send](#)<sup>[417]</sup> method is used to commit the data. This allows your application to prepare large amounts of data before sending it out.

Total amount of newly added (uncommitted) data in the buffer can be checked through the [ser.newtxlen](#)<sup>[410]</sup> setting.

## .Sinkdata Property

<b>Function:</b>	For the currently selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) specifies whether the incoming data should be discarded.
<b>Type:</b>	Enum (yes_no, byte)
<b>Value Range:</b>	0- NO ( <b>default</b> ): normal data processing. 1- YES: discard incoming data.
<b>See Also:</b>	<a href="#">Sinking Data</a> <sup>[399]</sup>

### Details

Setting this property to 1- YES causes the serial port to automatically discard all incoming data without passing it to your application. The [on\\_ser\\_data\\_arrival](#)<sup>[412]</sup> event will not be generated, reading [ser.rxlen](#)<sup>[417]</sup> will always return zero, and so on. No data will be reaching its destination even in case of [buffer redirection](#)<sup>[399]</sup>. [Escape characters](#)<sup>[390]</sup>, however, will still be detected in the incoming data stream.

## .Txbuffrq Method

- Function:** For the selected serial port (selection is made through [ser.num](#)<sup>[411]</sup>) pre-requests "numpages" number of buffer pages (1 page= 256 bytes) for the TX buffer of the serial port.
- Syntax:** **ser.txbuffrq(numpages as byte) as byte**
- Returns:** Actual number of pages that can be allocated (byte).
- See Also:** [Allocating Memory for Buffers](#)<sup>[393]</sup>, [ser.rxbuffrq](#)<sup>[415]</sup>

Part	Description
numpages	Requested numbers of buffer pages to allocate.

### Details

Returns actual number of pages that can be allocated. Actual allocation happens when the [sys.buffalloc](#)<sup>[530]</sup> method is used. The serial port is unable to TX data if its TX buffer has 0 capacity. Actual current buffer capacity can be checked through the [ser.txbuffsize](#)<sup>[419]</sup> which returns buffer capacity in bytes.

Relationship between the two is as follows:  $ser.txbuffsize = num\_pages * 256 - 16$  (or  $= 0$  when  $num\_pages = 0$ ), where "num\_pages" is the number of buffer pages that was GRANTED through the ser.txbuffrq. "-16" is because 16 bytes are needed for internal buffer variables.

Buffer allocation will not work if the serial port to which this buffer belongs is opened ([ser.enabled](#)<sup>[405]</sup> = 1- YES) at the time when sys.buffalloc executes. You can only change buffer sizes of ports that are closed.

## .Txbuffsize R/O Property

- Function:** For the selected serial port (selection is made through [ser.num](#)<sup>[411]</sup>) returns current TX buffer capacity in bytes.
- Type:** Word
- Value Range:** 0-65535
- See Also:** [Buffer Memory Status](#)<sup>[394]</sup>

### Details

Buffer capacity can be changed through the [ser.txbuffrq](#)<sup>[419]</sup> method followed by the [sys.buffalloc](#)<sup>[530]</sup> method.

The ser.txbuffrq requests buffer size in 256-byte pages whereas this property returns buffer size in bytes. Relationship between the two is as follows:  $ser.txbuffsize = num\_pages * 256 - 16$  (or  $= 0$  when  $num\_pages = 0$ ), where "num\_pages" is the number of buffer pages that was GRANTED through the ser.txbuffrq. "-16" is

because 16 bytes are needed for internal buffer variables. The serial port cannot TX data when the TX buffer has zero capacity.

## .Txclear Method

<b>Function:</b>	For the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) clears (deletes all data from) the TX buffer.
<b>Syntax:</b>	<b>ser.txclear</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Buffer Memory Status</a> <sup>[394]</sup>

---

### Details

This method will **only** work when the port is closed ([Ser.Enabled Property](#)<sup>[405]</sup> = NO). You cannot clear the TX buffers while the port is open.

## .Txfree R/O Property

<b>Function:</b>	For the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) returns the amount of free space in the TX buffer in bytes.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535
<b>See Also:</b>	<a href="#">Buffer Memory Status</a> <sup>[394]</sup>

---

### Details

Notice, that the amount of free space returned by this property does not take into account any uncommitted data that might reside in the buffer (this can be checked via [ser.newtxlen](#)<sup>[410]</sup>). Therefore, actual free space in the buffer is `ser.txfree-ser.newtxlen`. Your application will not be able to store more data than this amount. To achieve asynchronous data processing, use the [ser.notifysent](#)<sup>[410]</sup> method to get [on\\_ser\\_data\\_sent](#)<sup>[412]</sup> event once the TX buffer gains required amount of free space.

## .Txlen R/O Property

<b>Function:</b>	For the selected serial port (selection is made through <a href="#">ser.num</a> <sup>[411]</sup> ) returns total number of <i>committed</i> bytes currently found in the TX buffer.
------------------	---

---

<b>Type:</b>	Word
<b>Value Range:</b>	0-65535
<b>See Also:</b>	<a href="#">Serial Settings</a> <sup>[390]</sup> , <a href="#">Buffer Memory Status</a> <sup>[394]</sup> , <a href="#">ser.newtxlen</a> <sup>[410]</sup>

---

### Details

The data in the TX buffer does not become committed until you use the [ser.send](#)<sup>[417]</sup> method.

Your application may use the [ser.notifysent](#)<sup>[410]</sup> method to get [on\\_ser\\_data\\_sent](#)<sup>[412]</sup> event once the total number of committed bytes in the TX buffer drops below the level defined by the [ser.notifysent](#) method.

## Sock Object



This is the sockets object. It allows you to maintain up to 16 simultaneous UDP or TCP ("normal" or HTTP) connections (actual number supported by the platform may be lower, due to memory constraints).

Very commonly, each connection is called a "socket". This is the term we will use as well. On other programming systems, sockets are often dynamic, created and destroyed as needed. With TiOS, you receive a preset number of sockets which have already been created for you, and just use them. A socket may be idle, but it will still be there.

Individual sockets have all the traditional settings you would expect to find, such as destination port number, protocol, etc. At the same time, their functionality goes significantly beyond what you usually find, and includes a lot of additional features that significantly lower the amount of code you need to write. For example, you can restrict incoming connections to your device, automatically filter out certain messages within the TCP data stream, etc.

The sockets object also implements webserver (HTTP) functionality. Each socket can carry a "normal" data connection or be in the HTTP mode.

- Currently, the socket object can only access first 65534 bytes of each HTML file, even if the actual file is larger! Make sure that all HTML files in your project are not larger than 65534 bytes. This is not to be confused with the size of HTTP output generated by the file. A very large output can be generated by a small HTML file (due to dynamic data)- and that is OK. What's important is that the size of each HTML file in your project does not exceed 65534 bytes.

The sock object should not be confused with objects used to represent actual network interfaces, such as the [net](#)<sup>[358]</sup> object which represents the Ethernet interface. The socket object is responsible for actual IP (TCP or UDP) communications -- it doesn't matter which interface these communications are

effected through. Therefore, this is not the right place to look for a property such as 'IP address'. This is an attribute of a particular network interface.

Follows is the list of features offered by each socket of the sock object:

- Support for UDP, TCP and HTTP protocols (this is a submode of TCP).
- An extensive set of properties that define which hosts can connect to the socket, whether broadcasts are supported, which listening ports are associated with the socket, etc.
- Support for automatic processing of inband commands-- messages that are passed within the TCP data stream.
- Detailed socket state reporting with 30 different states supported!
- Fully asynchronous operation with separate "data arrival" and "data sent" events.
- Automatic data overrun detection on the RX buffer.
- Adjustable receive (RX), transmit (TX), and other buffer sizes for optimal RAM utilization.
- Buffer shorting feature for fast data exchange between the sock object and other objects (such as the [ser](#)<sup>[378]</sup> object) that support standard Tibbo Basic data buffers.

## Overview, 14.1

This section covers the socket object in detail. Here you will find:

- [Anatomy of a socket](#)<sup>[422]</sup>
- [Socket selection](#)<sup>[423]</sup>
- [Handling Network Connection](#)<sup>[424]</sup>
- [Send and Receiving Data](#)<sup>[444]</sup>
- [Working With Inband Commands](#)<sup>[456]</sup>
- [Using HTTP](#)<sup>[461]</sup>

### Anatomy of a Socket

A socket is composed of a send/receive logic that actually handles UDP, TCP (including HTTP) communications, and of 6 buffers. Each socket is capable of maintaining one connection with another node (host) on a network.

The socket object contains properties, methods and events which relate both to the buffers and the send/receive logic.

The *buffers* available are:

- The **RX** buffer, which stores data incoming from the host on the other side of a connection (this buffer doesn't have to be used for [HTTP connections](#)<sup>[461]</sup>).
- The **TX** buffer, which stores data which is due for sending to the host on the other side of a connection (for HTTP connection, this buffer can store both the request and the reply).
- The **TX2** buffer, which is used internally, and only when [inband commands](#)<sup>[456]</sup> are enabled.

- The **CMD** buffer, which is used to store incoming inband commands (messages). It is used only when inband commands are enabled.
- The **RPL** buffer, which is used to store outgoing inband replies (messages). It is used only when inband commands are enabled.
- The **VAR** buffer, which is used to store [HTTP](#) request string. It is needed only when the socket is in the HTTP mode.

## Socket Selection

TiOS supports up to 16 sockets, but there may be platforms with less than 16 sockets available. You can obtain the number of sockets available for your platform using the [sock.numofsock](#) property.

Since there can be multiple sockets, you must state which socket are you referring to when changing properties or invoking methods. This is done using the [sock.num](#) property. For example:

```
sock.protocol = 1
```

Can you tell what socket the statement above applies to? Neither can the platform. Thus, the correct syntax would be:

```
sock.num = 0  
sock.protocol = 1
```

Now the platform knows which socket you're working with. Once you have set the *socket selector* (using `sock.num`), every socket-specific method and property after that point is taken to refer to that socket. Thus:

```
sock.num = 0  
sock.protocol = 1  
sock.connectiontimeout = 10  
sock.httpmode = 1 ' etc
```

The events for this object are not separate for each socket. An event such as [on\\_sock\\_data\\_arrival](#) serves all sockets on your platform. Thus, when an event handler for the socket object is entered, the socket selector is automatically switched to the socket number on which the event occurred:

```
sub on_sock_data_arrival  
    dim s as string  
    s = sock.getdata(255) ' Note that you did not have to specify any  
    sock.num preceding this statement.  
end sub
```

As a result of this automatic switching, when an event handler for a socket event terminates, the `sock.num` property retains its new value (nothing changes it back).

You must take this into account when processing other event handlers which make use of a socket (and are not socket events). In other words, you should explicitly set the `sock.num` property whenever entering such an event handler, because the property might have been automatically changed prior to this event. To illustrate:

```
sub on_sys_init ' This is always the first event executed.
    sock.num = 0 ' Supposedly, this would make all subsequent properties
and methods refer to this socket.
end sub

sub on_sock_data_arrival ' Then, supposing this event executes.
    dim s as string
    s = sock.getdata(255) ' However, this event happens on the second
socket. So now sock.num = 1.
end sub

sub on_ser_data_arrival ' And then this serial port event executes.
    sock.txclear ' You meant to do this for sock.num = 0 (as specified at
on_sys_init). But now sock.num was changed to 1! Oops...
end sub
```

To recap, only one of two things may change the current `sock.num`: **(1)** manual change or **(2)** a socket event. You cannot assume the number has remained unchanged if you set it somewhere else (because a socket event might have happened since).

## Handling Network Connections

The whole purpose of socket's existence is to engage in network connections with other network hosts. Each socket can maintain a single connection using a UDP/IP or TCP/IP *transport* protocol. Which of the two is used is defined by the [sock.protocol](#)<sup>[492]</sup> property.

Sockets are also capable of working with HTTP. HTTP is not a transport protocol, rather, it is based on the TCP. Therefore, when your socket is using TCP it may be for "plain data transmission" or for HTTP.

## TCP connection basics

### What is TCP

The TCP is the most widely used transmission protocol. It is the backbone of all Internet traffic. The idea behind the TCP is to provide two communicating points (we can call them host A and host B) with a reliable, stream-oriented data link. "Stream-oriented" means that neither the host A, nor the host B have to worry about how the data travels across the connection. A just puts the stream of bytes in and B receives exactly the same stream of bytes on its side. It is the responsibility of the TCP to split the data into packets for transmission through the network, retransmit lost packets, make sure there are no data overruns, etc.

The TCP is strictly a "point-to-point" protocol: only two parties can engage in a connection and no third party can "join in".

### TCP connections

Before any data can be transmitted one of the hosts has to establish a connection to another host. This is similar to placing a telephone call: one of the parties has to call the other end.

The host that takes initiative to establish a connection is said to be opening an "outgoing connection" or "performing an active open". This is like dialing a telephone number of the desired party, only the number is the IP address of another host.

The host that accepts the "call" is said to be accepting an "incoming connection" or "performing a passive open". This is similar to picking up the phone when it starts ringing.

Once connection has been established, both parties can "say something" (send data) at any time and the TCP will make sure that all data sent on one end arrives to the other end.

TCP connections are expected to be closed (terminated) properly- there is a special exchange of messages between the host to let each other know that connection is being terminated. This is called "graceful disconnect". There is also a "reset" (abort) which is much simpler and is akin to hanging up abruptly. Finally, there is a "discard" way to end the connection in which the host simply "forgets" that there was a connection.

The TCP connection can be closed purposefully, or it can [timeout](#)<sup>[437]</sup>.

A TCP connection in progress is fully defined by 4 parameters: IP address and the port number on host A and the IP address and port number on host B. When the host is performing an active open, it has to "dial" not just the IP address of the target host, but also the port number on this host. Ports are not physical- they are just logical subdivisions of the IP address (65536 ports per IP). If the IP is a telephone number of the whole office then the port is an extension. The "calling" host is also calling not just from its IP address but also from specific port.

## UDP "connection" basics

### What is UDP

In many aspects, the UDP protocol is the opposite of the TCP protocol. Whereas the TCP provides a reliable, stream-oriented transport, the UDP offers a way to send data as separate packets or "UDP datagrams". This is similar to "paging" (as in, sending a message with a "pager" -- remember those?). What is sent is a packet containing some data. There is no guarantee that the other side will receive the packet and the sender won't know whether the packet was received or not.

Each UDP datagram lives its own life and you are responsible for dividing your data into chunks of reasonable size and sending it in separate datagrams. There is no connection establishment or termination on UDP- the datagram can be sent instantly, without any preparation.

Unlike TCP, the UDP is not point-to-point. For example, several hosts can send the datagrams to the same socket of your device- and all of them can be accepted- a situation that is impossible with TCP. There is also an option to broadcast the datagram to all hosts connected to the same network segment- something that is also impossible with TCP.

### And now to UDP "connections"...

This said, it should come as a bit of a surprise that we will now turn 180 degrees and start talking about UDP "connections". Didn't we just say that there is no such thing? Well, yes and no. On the physical network there is, indeed, no such thing. However, on our socket object level we have deliberately made UDP

communications look more like TCP connections. And, since the UDP "connection" is nothing more than our sock object's abstraction, we use the word "connection" in quotation marks.

We consider an active open to have been performed when our host has sent the first UDP datagram to the destination. A passive open is when we have received the first incoming UDP datagram from another host (provided that this datagram was accepted- more on that in [Handling Incoming Connections](#)<sup>[426]</sup>).

There is no graceful disconnect for UDP connections. The connection can only be discarded (our host "forgets" about it). The UDP connection can also [timeout](#)<sup>[437]</sup>.

## Accepting Incoming Connections

### Master switch for incoming connections

It is possible to globally enable or disable acceptance of incoming connections on all sockets, irregardless of the setup of individual sockets. This is done using the [sock.inconenabledmaster](#)<sup>[484]</sup> property. By default, this property is set to 1- YES.

### Defining who can connect to your socket

The [sock.inconmode](#)<sup>[485]</sup> ("incoming connections mode") property allows you to define whether incoming connections will be accepted and, if yes, from who. By default (0- PL\_SOCK\_INCONMODE\_NONE), incoming connections are not allowed at all. For TCP this means that incoming connection requests will be rejected. For UDP, incoming datagrams will simply be ignored.

If you don't mind to accept an incoming connection from any host/port then set the [sock.inconmode](#)<sup>[485]</sup> = 3- PL\_SOCK\_INCONMODE\_ANY\_IP\_ANY\_PORT. This way, whoever wants to connect to your socket will be able to do so as long as this party is using correct transport protocol (you define this through the [sock.protocol](#)<sup>[492]</sup> property) and is connecting to the right port number (more on this below).

If you are only interested in accepting connections from a particular host on the network then set [sock.inconmode](#)<sup>[485]</sup> = 2- PL\_SOCK\_INCONMODE\_SPECIFIC\_IP\_ANY\_PORT. This way, only the host with IP matching the one defined by the [sock.targetip](#)<sup>[506]</sup> property will be able to connect to your socket.

You can restrict things further and demand that not only the IP of the other host must match the one you set in [sock.targetip](#)<sup>[506]</sup> property, but also the port from which the connection is being originated must match the port defined by the [sock.targetport](#)<sup>[507]</sup> property. To achieve this, set the [sock.inconmode](#)<sup>[485]</sup> = 1- PL\_SOCK\_INCONMODE\_SPECIFIC\_IPPORT.

Here is an example of how to only accept incoming TCP connections from host 192.168.100.40 and port 1000:

```
sock.protocol= PL_SOCK_PROTOCOL_TCP
sock.inconmode= PL_SOCK_INCONMODE_SPECIFIC_IPPORT
sock.targetip= "192.168.1.40"
sock.targetport= 1000
```

The sock object rejects an incoming connection by sending out a reset TCP packet. This way, the other host is instantly notified of the rejection. There is an exception to this -- see [Socket Behavior in the HTTP Mode](#)<sup>[465]</sup>.

## Listening ports

Ports on which your socket will accept an incoming connection are called "listening ports". These are defined by two properties: the [sock.localportlist](#)<sup>[486]</sup> and the [sock.httpportlist](#)<sup>[483]</sup>. Notice that both properties are of string type, so each one can accept a list of ports.

For example, to accept a normal data connection either on port 1001, port 2000, or port 3000, set the `sock.localportlist="1001,2000,3000"`. Once the connection is in progress, you can check which of the socket's local ports is actually engaged in this connection. This is done through the [sock.localport](#)<sup>[485]</sup> read-only property.

For UDP connections, the `sock.localportlist` is all there is. For TCP, which can be used for "plain vanilla data connections" or for HTTP, you have another property-`sock.httpportlist`. To be accepted by your socket, an incoming TCP connection has to target either one of the ports on the `sock.localportlist`, or one of the ports on the `sock.httpportlist`. The socket will automatically switch into the HTTP mode if the connection is accepted on one of the ports from the `sock.httpportlist`.

Here is an example:

```
sock.localportlist = "1001,2000"  
sock.httpportlist = "80"
```

The above means that any incoming TCP connection that targets either port 1001 or port 2000 will be interpreted as a regular data connection. If connection target port 80 it will be accepted as an HTTP connection.

And what if the same port is listed both under the `sock.localportlist` and `sock.httpportlist`?

```
sock.localportlist = "1001,2000,80"  
sock.httpportlist = "80"
```

In this example, if there is an incoming connection targeting "our" port 80 and the protocol is TCP then the mode will be HTTP- the `sock.httpportlist` has priority over `sock.localportlist`. Of course, for UDP the `sock.httpportlist` won't matter since the HTTP is only possible on TCP!

## Setting allowed interfaces

The socket object is interface-independent and supports communications over more than one interface. The [sock.allowedinterfaces](#)<sup>[474]</sup> property defines the list of interfaces on which the current socket will accept incoming connections. The list is different and depends on the platform. To find out what interfaces are available, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

The [sock.allowedinterfaces](#)<sup>[474]</sup> property stores the string that lists all interfaces that the socket will listen on:

```
sock.allowedinterfaces = "NET,WLN" 'listen on Ethernet and Wi-Fi interfaces'
```

## Connections accepted even when the VM is paused

Once the socket has been setup it will accept an incoming connection even when the VM is paused (for example, has stopped on your breakpoint). All communications are handled by the [master process](#)<sup>[7]</sup>, so the socket does not need the VM to accept an incoming connection (or, for that matter, receive and send the data).

## Accepting UDP broadcasts

UDP datagrams can be sent as broadcasts. Broadcast, instead of specifying a particular network host as a destination, targets a group of hosts on the network.



The sock object supports link-level broadcasts. Such broadcast packets have their destination MAC address set to 255.255.255.255.255. Link-level broadcasts are received by all network hosts connected to the current network segment. Link-level broadcasts cannot penetrate routers, bridges, etc.

For the socket to accept incoming UDP broadcasts, the [sock.acceptbcast](#)<sup>[474]</sup> property must be set to 1- YES. In every other aspect working with incoming broadcast UDP datagrams is like working with regular incoming datagrams.

## Understanding TCP Reconnects

The sock object has a unique feature- support for "reconnects". To simplify the explanation, let us start from a description of a real-life problem first.

### When reconnects save the day

Supposing, you have a host on the network that is engaged in a TCP connection with one of the sockets of the socket object. The data is sent across this connection from the host to our socket. For a while, everything is fine and then the host momentarily loses power and reboots. Our socket doesn't know anything about this- from its point of view, the TCP connection is still OK. Just because no data is arriving from the host does not mean that there is a problem!

Meanwhile, the host reboots and attempts to establish a new connection to the socket- and gets rejected! This is because the socket thinks it is already engaged in a TCP connection- the one that has been left hanging since the host went down! This stagnant connection will remain in place until it times out- if timeouts are enabled at all through the [sock.connectiontout](#)<sup>[477]</sup> property.

Reconnects are a nifty way out of this situation. You enable reconnects through the [sock.reconmode](#)<sup>[492]</sup> (reconnection mode) property. For the above example, you typically set the sock.reconmode= 2- PL\_SOCKET\_RECONMODE\_2. This mode means, that if the socket is already engaged in a connection, and then there is an incoming connection attempt that originated from the same host (and any port), then the socket will forget everything about the original connection and accept the new one.

For our example case, this is the solution- after rebooting the host tries to establish

a new connection to our socket. The socket then "realizes" that this new connection is being attempted from the same host as the connection already in progress, discards the original connection and accepts the new one!

### **Reconnects must target the same port and interface!**

Even when the socket has more than one listening port (i.e. `sock.localportlist`<sup>[486]</sup>="1000,1001") the reconnect will only be accepted if it targets the same local port of the socket as the one already engaged in the current connection being "replaced". In other words, to be successful, the reconnect must target the port that is currently returned by the `sock.localport`<sup>[485]</sup> read-only property.

The interface must also be the same. The host can't make an original connection through Ethernet, and then reconnect through Wi-Fi.

### **Which mode to choose?**

As you can see, the `sock.reconmode` property gives you several "strictness levels" of dealing with reconnects. Which one to choose? Let us explain why the choice of `sock.reconmode=2-PL_SOCKET_RECONMODE_2` is the most common. Typically, when the host is establishing an outgoing connection it does so from the ever changing port number. Basically, there is a "pool" of ports for this purpose and each new connection the host needs to establish will be made from the next port in the pool.

Each time the host connects to our socket the port on the host could be different. This is why it makes sense to accept reconnects from the same IP but any port. Disadvantage? Any connection originating from this host will essentially be treated as the same and the only connection!

Some programs (few!) establish connections from a specific, preset port. This may be done for a variety of reasons- no time to go into this here- just let us say, sometimes this is the case. If you are dealing with such a case then you can safely set `sock.reconmode=1-PL_SOCKET_RECONMODE_1`. This way, reconnects will only be accepted from the same IP and the same port as the original connection.

### **Total promiscuity -- mode 3!**

Finally, there is a mode (`3-PL_SOCKET_RECONMODE_3`) when the socket will accept a reconnect from any host or port. Basically, this means, that whatever connection is in progress, it will be interrupted and replaced by any other incoming connection.

### **Do not use reconnects for HTTP sockets!**

Reconnects and HTTP do not play nicely together. When you request an HTML page, several simultaneous HTTP requests may be generated (one for the page itself, several -- for pictures on this page, etc.). All these requests will use a separate TCP socket, so multiple sockets will be opened (almost) at the same time. Now, what will happen if even just one of your application's "HTML" sockets has reconnects enabled? This single socket will intercept all HTML requests. So, if loading the HTML page needed 3 separate requests and TCP sessions, this socket will get them all -- and each next session opening will discard the previous one. Result won't be pretty!

## **Understanding UDP Reconnects and Port Switchover**

For UDP "connections", there is also such a thing as reconnects. Due to a very different nature of UDP (compared to TCP), reconnects for UDP must be explained separately. Additionally, we need to introduce something called "port switchover".

## Port switchover explained

With TCP, each side of the connection uses a single port both to send and receive data. With UDP, this doesn't have to be the case. The sock object, when it is engaged in a connection, can receive the data from one port but send the data to a different port!

When port switchover is disabled, the socket always addresses its outgoing UDP datagrams to the port, specified by the `sock.targetport`<sup>[507]</sup> property. When port switchover is enabled, the socket will address its outgoing datagrams to the port from which the most recent incoming datagram was received!

Notice, that we did not say anything about the IP switchover- so far we have only discussed ports.

## UDP reconnects

Just like with TCP, the `sock.reconmode`<sup>[492]</sup> property defines, for UDP, what kind of incoming UDP datagram will be able to make the socket forget about its previous "connection" and switch to the new one. You have two choices: either define that reconnects are only accepted from a specific IP but any port or choose reconnects to be accepted from any IP and any port. Combine this with two options for port switchover and you have four combinations- four options for the `sock.reconmode` property. All this is best understood on the example.

### Example: PL\_SOCK\_RECONMODE\_0

Setup:

```
sock.protocol= PL_SOCK_PROTOCOL_UDP 'we are dealing with UDP
sock.inconmode= PL_SOCK_INCONMODE_ANY_IPPORT
sock.reconmode= PL_SOCK_RECONMODE_0 'reconnects accepted from the same IP,
any port, port switchover off
sock.localportlist= "3000"
sock.targetport= "900"
```

Two hosts are sending us datagrams and here is how the socket will react:

#### Incoming datagram

192.168.100.40:1000 sends UDP datagram to the port 3000 of our device

192.168.100.44:1001 sends UDP datagram to the port 3000 of our device

192.168.100.40:1100 sends UDP datagram to the port 3000 of our device

#### Socket reaction

Datagram accepted, UDP "connection" is now in progress, the socket will be sending all further outgoing datagrams to 192.168.100.40:900.

Datagram ignored- it came from a different IP. The socket will still be sending its outgoing datagrams to 192.168.100.40:900.

Reconnection accepted (so datagram is accepted), but the socket will still be sending all further outgoing datagrams to 192.168.100.40:900 (because port switchover is off).

### Example: PL\_SOCK\_RECONMODE\_1

Setup:

```
sock.protocol= PL_SOCKET_PROTOCOL_UDP 'we are dealing with UDP
sock.inconmode= PL_SOCKET_INCONMODE_ANY_IPPORT
sock.reconmode= PL_SOCKET_RECONMODE_1 'reconnects accepted from any IP/port,
port switchover off
sock.localportlist= "3000"
sock.targetport= "900"
```

Two hosts are sending us datagrams and here is how the socket will react:

#### Incoming datagram

192.168.100.40:1000 sends UDP datagram to the port 3000 of our device

192.168.100.44:1001 sends UDP datagram to the port 3000 of our device

#### Socket reaction

Datagram accepted, UDP "connection" is now in progress, the socket will be sending all further outgoing datagrams to 192.168.100.40:900.

Reconnection accepted, the socket will be sending all further outgoing datagrams to 192.168.100.44:900.

### Example: PL\_SOCKET\_RECONMODE\_2

Setup:

```
sock.protocol= PL_SOCKET_PROTOCOL_UDP 'we are dealing with UDP
sock.inconmode= PL_SOCKET_INCONMODE_ANY_IPPORT
sock.reconmode= PL_SOCKET_RECONMODE_2 'reconnects accepted from the same IP,
any port, port switchover on
sock.localportlist= "3000"
sock.targetport= "900"
```

Two hosts are sending us datagrams and here is how the socket will react:

#### Incoming datagram

192.168.100.40:1000 sends UDP datagram to the port 3000 of our device

192.168.100.44:1001 sends UDP datagram to the port 3000 of our device

192.168.100.40:1100 sends UDP datagram to the port 3000 of our device

#### Socket reaction

Datagram accepted, UDP "connection" is now in progress, the socket will be sending all further outgoing datagrams to 192.168.100.40:1000.

Datagram ignored- it came from a different IP. The socket will still be sending its outgoing datagrams to 192.168.100.40:1000.

Reconnection accepted, the socket will be sending all further outgoing datagrams to 192.168.100.40:1100.

### Example: PL\_SOCKET\_RECONMODE\_3

Setup:

```
sock.protocol= PL_SOCKET_PROTOCOL_UDP 'we are dealing with UDP
sock.inconmode= PL_SOCKET_INCONMODE_ANY_IPPORT
sock.reconmode= PL_SOCKET_RECONMODE_3 'reconnects accepted from any IP/port,
port switchover on
sock.localportlist= "3000"
sock.targetport= "900"
```

Now, two hosts are sending us datagrams and here is how the socket will react:

#### Incoming datagram

192.168.100.40:1000 sends UDP datagram to the port 3000 of our device

192.168.100.44:1001 sends UDP datagram to the port 3000 of our device

#### Socket reaction

Datagram accepted, UDP "connection" is now in progress, the socket will be sending all further outgoing datagrams to 192.168.100.40:1000.

Reconnection accepted, the socket will be sending all further outgoing datagrams to 192.168.100.44:1001.

## Incoming Connections on Multiple Sockets

So far, we have been talking about all kinds of incoming connections applied to a single socket. The fact is, the sock object supports up to 16 sockets which all can have a different setup. Just because an incoming connection is rejected or ignored on one socket does not mean that it won't be connected on another!

When the network packet is received by the sock object the latter attempts to find a socket for which this newly arrived packet is acceptable.

First, the sock object checks if the packet can be considered a part of any existing connection or a reconnection attempt for an existing connection. All sockets that are currently engaged in a connection are checked, starting from socket 0, then sock 1, 2, and up to `sock.numofsock` - 1.

If it turns out that some socket can accept the packet as a part of current connection or an acceptable reconnection attempt then the search is over and the packet is "pronounced" to belong to this socket.

If it turns out that no socket currently engaged in a connection can accept the packet then the socket object checks all currently idle sockets to see if any of these sockets can accept this packet as a new incoming connection. Again, all idle

sockets are checked, starting from socket 0, and up to sock.numofsock-1.

For TCP, a packet that can start such a new connection is a special "SYN" packet. For UDP, any incoming datagram that can be accepted by the socket (which depends on the socket setup) can start the new connection.

If the packet cannot be construed as a part of any existing connection, reconnect, or new incoming connection then this packet is discarded.

### Example

Supposing, we have the following setup:

```
sock.num= 0
sock.protocol= PL_SOCKET_PROTOCOL_TCP
sock.inconmode= PL_SOCKET_INCONMODE_SPECIFIC_IP_ANY_PORT
sock.targetip="192.168.100.40"
sock.reconmode= PL_SOCKET_RECONMODE_2
sock.localportlist= "1001"

sock.num=1
sock.protocol= PL_SOCKET_PROTOCOL_TCP
sock.inconmode= PL_SOCKET_INCONMODE_ANY_IPPORT
sock.localportlist= "1001"

sock.num=2
sock.protocol= PL_SOCKET_PROTOCOL_UDP
sock.inconmode= PL_SOCKET_INCONMODE_ANY_IPPORT
sock.localportlist= "2000"
```

Here is a sample sequence of incoming connections and how the setup above would handle them:

#### Incoming datagram

Incoming TCP connection to port 1001  
from host 192.168.100.40:29600

Incoming TCP connection to port 1001  
from host 192.168.100.40:29601

Incoming TCP connection to port 1001  
from host 192.168.100.41:900

Incoming UDP datagram to port 2000  
from host 192.168.100.40:320

#### Socket reaction

Connection will be accepted on socket 0 since this socket lists 1001 as one of the listening ports and this incoming connection request is from "correct" host.

This will be taken as a reconnect on socket 0: this incoming connection is from the same host as the previous one and it targets the same port 1001.

Connection will be accepted on socket 1, because socket 0 is already engaged in a connection and this new connection request cannot be interpreted as a reconnect (different host).

This datagram will be accepted on socket 2 and "connection" will be opened.

## Establishing Outgoing Connections

### Performing active opens

Now that we know how to setup the sockets to accept incoming TCP connections and UDP "connections" we move on to learning about establishing connections of our own, or, as is often said, performing "active opens".

Establishing an outgoing connection is always an explicit action- you use the [sock.connect](#)<sup>[477]</sup> method *to attempt* to do this. Once you do this the socket will try to perform an active open to the IP and port specified by the [sock.targetip](#)<sup>[506]</sup> and [sock.targetport](#)<sup>[507]</sup> properties. There is also a [sock.targetinterface](#)<sup>[506]</sup> property -- this one defines which network interface the new connection will be passing through.



As you can see, the `sock.targetip` and `sock.targetport` properties perform a double-duty: for incoming connections they define (if required by the [sock.inconmode](#)<sup>[485]</sup>) who will be able to connect to the socket. For outgoing connections this pair defines IP and host to which the socket will attempt to connect.

Notice, that your `sock.connect` invocation will only work if you do this while the socket is in the "closed" state (see [Checking Connection Status](#)<sup>[439]</sup>).

### Active opens for TCP

Once you tell a "TCP" socket to connect, the socket will do the following:

- Resolve the IP address of the target using the ARP protocol.
- Attempt to engage the target in a standard TCP connection sequence (SYN-SYN-ACK).
- Connection will be either established, or this will fail. Your program has a way to monitor this- see [Checking Connection Status](#)<sup>[439]</sup>.



If what we've just said doesn't ring any bell for you, don't worry. These, indeed, are very technical things and you don't have to understand them fully to be able to use the sock object.

### "Active opens" for UDP

When you tell an "UDP" socket to connect, the latter will just resolve the IP address of the target and consider "connection" established.

### Do not forget: connection handling is fully asynchronous!

Keep in mind that the sock object handles communications asynchronously. When the VM executes the [sock.connect](#)<sup>[477]</sup> method it does not mean that the connection is established by the time the VM gets to the next program statement. Executing `sock.connect` merely instructs the master process to start establishing the connection (more on master process and the VM in the [System Components](#)<sup>[7]</sup> topic). Connection establishment can take some time and your application doesn't have to wait for that to complete. [Checking Connection Status](#)<sup>[439]</sup> topic explains how to find out actual connection status at any time (see [sock.state](#)<sup>[502]</sup> and

[sock.statesimple](#)<sup>[505]</sup> R/O properties).

- Asynchronous nature of the sock object has some interesting implications. [More On the Socket's Asynchronous Nature](#)<sup>[447]</sup> topic contains important information on the subject, so make sure you read it!

## Sending UDP broadcasts

### How to send UDP broadcasts

UDP datagrams can be sent as broadcasts. Broadcast, instead of specifying a particular network host as a destination, targets a group of hosts on the network.



The sock object supports link-level broadcasts. Such broadcast packets have their destination MAC address set to 255.255.255.255.255. Link-level broadcasts are received by all network hosts connected to the current network segment. Link-level broadcasts cannot penetrate routers, bridges, etc.

To make the socket send its outgoing UDP datagrams as broadcasts, set the [sock.targetbcast](#)<sup>[505]</sup> property to 1- YES:

```
...
sock.targetbcast= YES
sock.setdata("ABC") 'this is explained in 'Working With Buffers' section
sock.send 'this is explained in 'Working With Buffers' section
sock.connect 'broadcast UDP datagram with string 'ABC' will be sent out at
this point
...
```

There is one difference to grasp regarding the socket that is sending its outgoing packets as broadcasts: no incoming UDP packet that would have normally be interpreted as a re-connect will cause the socket to "switchover" to the source IP-address of the packet.

Let's evaluate two examples.

### Example 1: regular UDP communications

Here is a sample setup for the UDP socket:

```
sock.protocol= PL_SOCKET_PROTOCOL_UDP
sock.inconmode= PL_SOCKET_INCONMODE_ANY_IP_ANY_PORT
sock.reconmode= PL_SOCKET_RECONMODE_3
sock.targetip= "192.168.100.40"
sock.targetport= 1000
sock.localportlist= "2000"
sock.setdata("ABC")
sock.send
```

```
sock.connect
```

And here is a hypothetical sequence of events:

#### Incoming/outgoing datagram

Datagram with contents "ABC" sent to 192.168.100.40:1000 as soon as sock.connect method is invoked

Incoming UDP datagram from 192.168.100.41:20.

Socket sends out another datagram- this time to 192.168.100.41:20!

#### Comment

We now have the UDP "connection" with 192.168.100.40:1000

This will be taken as a reconnect- the socket is now engaged in a connection with 192.168.100.41:20.

Complete switchover happened- the socket is now transmitting data to the IP and port of the sender of the previous incoming datagram

### Example 2: regular UDP communications

Here is another setup for the UDP socket:

```
sock.protocol= PL_SOCKET_PROTOCOL_UDP
sock.inconmode= PL_SOCKET_INCONMODE_ANY_IP_ANY_PORT
sock.reconmode= PL_SOCKET_RECONMODE_3
sock.targetbcast= YES
sock.targetport=1000
sock.localportlist= "2000"
sock.setdata("ABC")
sock.send
sock.connect
```

Sequence of events:

#### Incoming/outgoing datagram

Datagram with contents "ABC" sent as broadcast to all stations on the network segment

Incoming UDP datagram from 192.168.100.41:20.

Socket sends out another datagram- still as a broadcast but this time to port 20.

#### Comment

We now have the UDP "connection" with... err... everybody on the segment

This is still a reconnect, but the socket won't switch over to the IP-address of the sender. Only port switchover will take place!

Port switchover happened because it is allowed by the [sock.reconmode](#)<sup>492</sup>.

## Closing Connections

### Passive TCP connection termination

When your socket is engaged in a TCP connection with another host on the network, this host may choose to terminate the connection. This can be done through a "graceful disconnect" sequence ("FIN-ACK-FIN-ACK") or through a reset ("RST" packet).

In both cases the socket will handle connection closing automatically, without any help from your Tibbo BASIC program or the VM. In fact, the socket will accept connection termination even when the VM is stopped (for example, it was paused on your breakpoint). All communications are handled by the [master process](#)<sup>[7]</sup>, so the socket does not need the VM to terminate the connection.

There is one intricate detail in the connection termination process that you will have to understand clearly. When the VM is not running, the socket can [accept an incoming connection](#)<sup>[426]</sup> (active open) and can accept an active close. However, the socket won't be able to accept another (next) incoming connection until the VM has had a chance to run and execute the [on\\_sock\\_event](#)<sup>[490]</sup> event handler (see [Checking Connection Status](#)<sup>[439]</sup>).

Here is why. In many cases there is a need to perform certain actions (like, maybe, clear some buffers, initialize variables, etc.) after the previous connection ends and before the new one begins. Not letting the socket accept next connection before your program has a chance to respond to connection termination is a way to achieve this!

### Actively closing TCP connections

A TCP connection can be closed, reset (aborted), or discarded using three different methods- [sock.close](#)<sup>[475]</sup>, [sock.reset](#)<sup>[495]</sup>, and [sock.discard](#)<sup>[478]</sup>.

The recommended (and polite!) way of closing a TCP connection is through the `sock.close` method. This will initiate a proper closing sequence ("FIN-ACK-FIN-ACK"), known as a "graceful disconnect".

Connection reset is slightly more "rude"- your socket will simply tell the other end that "it is all over" (by sending the "RST" packet).

Finally, the `sock.discard` method simply makes your socket forget about the connection- the other side is not notified at all.

Just like with connection establishment, you can monitor the progress of connection termination- see [Checking Connection Status](#)<sup>[439]</sup>.



Notice, that depending on the socket state at the moment of `sock.close` method invocation, the socket may need to resort to a simple connection closing option- reset or discard. Similarly, when you use the `sock.reset`, it may sometimes result in discard. For more information read the [sock.close](#)<sup>[475]</sup>, [sock.reset](#)<sup>[495]</sup>, and [sock.discard](#)<sup>[478]</sup> topics.

### Actively closing UDP connections

For UDP, no matter what method you use to close the "connection", result will still be as if the `sock.discard` was invoked. This is because in reality there is no such thing as a proper UDP connection termination so simply "forgetting" about the connection is the only option the socket has.

### **Do not forget: connection handling is fully asynchronous!**

Keep in mind that the sock object handles communications asynchronously. When the VM executes the [sock.close](#)<sup>[475]</sup> ([sock.reset](#)<sup>[495]</sup>, [sock.discard](#)<sup>[478]</sup>) method it does not mean that the connection is done with by the time the VM gets to the next program statement. Executing these methods merely instructs the master process to terminate the connection. Connection termination can take some time and your application doesn't have to wait for that to complete. [Checking Connection Status](#)<sup>[439]</sup> topic explains how to find out actual connection status at any time (see [sock.state](#)<sup>[502]</sup> and [sock.statesimple](#)<sup>[505]</sup> read-only properties).

- Asynchronous nature of the sock object has some interesting implications. [More On the Socket's Asynchronous Nature](#)<sup>[441]</sup> topic contains important information on the subject, so make sure you read it!

### **Socket re-use after connection closing**

When the socket connection terminates, the socket is ready to accept another incoming connection or establish a new outgoing connection (if so configured) -- with one little caveat! There is a special built-in mechanism that ensures that your application has a chance to react after the previous connection terminates and before the next one is established.

For example, you might need to clean some buffers before each new incoming TCP connection. Naturally, you want this to happen before the new connection is actually accepted.

Typically, your program achieves this by executing code placed in the [on\\_sock\\_event](#)<sup>[490]</sup> event handler (this event is explained in [Checking Connection Status](#)<sup>[439]</sup> topic). The socket will not be able to engage in the new connection until the `on_sock_event` has a chance to execute. There is an interesting example on this in the [More On the Socket's Asynchronous Nature](#)<sup>[441]</sup> topic.

### **Connection timeouts**

The [sock.connectiontout](#)<sup>[477]</sup> provides a way to automatically terminate a connection across which no data was exchanged for a predefined period of time. For TCP, reset (abort) is used, while UDP "connections" are simply discarded. Connection timeout is a useful way to exit "hanged" connections (this happens a lot with TCP on large networks).

The [sock.toutcounter](#)<sup>[507]</sup> R/O property informs your application of the time passed since the data was last exchanged across the connection. Each time there is some data sent or received the `sock.toutcounter` is reset to zero. The property increments at 0.5 second intervals while no data is moving through this socket.

If the `sock.connectiontout` is not at 0, the `sock.toutcounter` increments until it reaches the value of the `sock.connectiontout` and the connection is terminated. The `sock.toutcounter` then stays at the value of `sock.connectiontout`.

If the `sock.connectiontout` is at 0, the maximum value that the `sock.toutcounter` can reach is 1. That is, the `sock.toutcounter` will be at 0 after the data exchange, and at 1 if at least 0.5 seconds have passed since the last data exchange.

### **Normally, HTTP connections close automatically**

There is one case where your socket will perform an active graceful disconnect without you using the `sock.close` method. This is the case when the socket is running in the TCP-HTTP mode.

In [Accepting Incoming Connections](#)<sup>[426]</sup> we have already explained that the socket automatically switches into the HTTP mode if a TCP connection is accepted on one of the ports from the [sock.httpportlist](#)<sup>[483]</sup> list. The socket can also be switched into the HTTP mode programmatically, through the [sock.httpmode](#)<sup>[481]</sup> property.

Default HTTP functionality requires that the TCP connection is closed once the HTTP server has finished sending out its "response" (i.e. HTML page or another file that has been requested). In this situation the socket won't need the `sock.close` from your program- the connection will be terminated automatically. In fact, when the socket is in the HTTP mode, your [sock.close](#)<sup>[475]</sup>, [sock.reset](#)<sup>[495]</sup>, and [sock.discard](#)<sup>[478]</sup> will simply be ignored. There is a [sock.httpnoclose](#)<sup>[482]</sup> property alters the standard socket behavior in the HTTP mode. Set this property to 1- YES and the connection will be kept opened even after the socket has sent all of the HTTP reply out.

Just like in all other cases, a new connection on the socket won't be accepted until your program has had a chance to respond- this was explained above.

## Checking Connection Status

### Simplified and detailed socket states

The `sock` object features several properties that provide complete information on what the socket is doing, which IP and port it is engaged in the connection with, etc.

The most important of all this data is the socket state. Two state groups are supported- "simplified" and "detailed". Simplified state tells you, generally, what condition the socket is in. Detailed state additionally tells you how this condition came to be.

For example, the "simplified" `PL_SSTS_CLOSED` state means that connection is closed (socket is idle). It doesn't tell you, however, why it is closed. "Detailed" state `PL_SST_CL_ARESET_CMD` tells you that connection is closed because there was an active close as a result of the [sock.close](#)<sup>[475]</sup> method invocation from your program!

### On\_sock\_event and sock.event, sock.eventsimple read-only properties

Each time the socket state changes an [on\\_sock\\_event](#)<sup>[490]</sup> event is generated. Unlike many other events, this one can be generated again and again before the `on_sock_event` handler is invoked, so event queue can contain multiple such events. A separate event is generated for each new state the socket enters.

The `on_sock_event` "brings" two arguments with it -- one is called "newstate", another one -- "newstatesimple". These arguments contains the state of the socket at the moment when the `on_sock_event` was generated.

Newstate and newstatesimple arguments have been introduced in Tibbo Basic **V2.0**. Before, their role was played by two read-only properties -- [sock.event](#)<sup>[480]</sup> and [sock.eventsimple](#)<sup>[480]</sup>. These properties are no longer available.

Here is one example of how `on_sock_event` can be used. Supposing, when connection is established we need to open the serial port and when it is no longer established close the serial port and clear the data from its TX and RX buffers:

```
sub on_sock_event(newstate as pl_sock_state,newstatesimple as
pl_sock_state_simple)
  if newstatesimple= PL_SSTS_EST then
    ser.enabled= YES 'connection has been established- open port
```

```

else
  if ser.enabled= YES then 'connection is NOT established? Close and
clear the port if it is opened!
    ser.enabled= NO
    ser.txclear
    ser.rxclear
  end if
end if
end sub

```

### Sock.state and sock.statesimple read-only properties

There is also a pair of read-only properties- [sock.state](#)<sup>[502]</sup> and [sock.statesimple](#)<sup>[505]</sup> that allows you to check current socket state (as opposed to the state that was at the moment of on\_sock\_event generation).

Here is an example of how you can use this. Supposing, you want to "play" an LED pattern that depends on the current state of the socket. Here is how you do this:

```

sub on_pat
'this event is generated each time a pattern finishes playing
  select case sock.statesimple
  case PL_SSTS_EST: 'connection is established- Green LED on
    pat.set("GGGGGGGGGGGGGGGG",NO)
  case PL_SSTS_ARP: 'ARP in progress- Green LED blinks
    pat.set("G-G-G-G-G-G-G-G",NO)
  case PL_SSTS_PO: 'connection is being established- green LED goes
'blink-blink-blink'
    pat.set("-----G-G-G-",NO)
  case PL_SSTS_AO: 'connection is being established- green LED goes
'blink-blink-blink'
    pat.set("-----G-G-G-",NO)
  case else: 'connection is closed or being closed- green LED is 'blink-
blink'
    pat.set("-----G-G-",NO)
  end select
end sub

```

### Understanding who you are talking to

Whenever the socket is engaged in the connection you can check the parameters of the other side through three read-only properties- [sock.remotemac](#)<sup>[495]</sup>, [sock.remoteip](#)<sup>[494]</sup>, and [sock.remoteport](#)<sup>[495]</sup>. For UDP, you can also check if the datagram you have received was sent to your device exclusively or it was a broadcast- the [sock.bcast](#)<sup>[475]</sup> will tell you that. For TCP, you can additionally check if the socket is in the "regular data" or HTTP mode- just check the [sock.httpmode](#)<sup>[481]</sup> property.

There is an intricate detail to understand about the sock.remotemac, sock.remoteip, sock.remoteport, and sock.bcast properties when you are using the UDP protocol.

With UDP, your socket may be accepting datagrams from several different hosts. As will be explained in [Receiving Data in UDP Mode](#)<sup>[450]</sup>, the most common way to handle the incoming data is through the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event. You will get one such event for each UDP datagram that the socket will receive. If you check the sock.remotemac, sock.remoteip, sock.remoteport, or sock.bcast from within the

on\_sock\_data\_arrival event handler you will get the sender's data for the UDP datagram *currently* being processed.

On the contrary, using sock.remotemac, sock.remoteip, sock.remoteport, or sock.bcast property outside of the on\_sock\_data\_arrival event handler will give you the data for the *most recent* UDP datagram received into the RX buffer of the socket. This is not the same as the *next* UDP datagram to be extracted from the RX buffer and processed by your application!

### Checking current interface

Starting from **V1.2**, the sock object provides an additional property, [sock.currentinterface](#)<sup>[478]</sup>, which tells you which network interface the network connection is going through.

## More On the Socket's Asynchronous Nature

In [Establishing Outgoing Connections](#)<sup>[434]</sup> and [Closing Connections](#)<sup>[437]</sup> topics we have already touched on the subject of the sock object's asynchronous nature. This topic offers further details on what that means for your application.

Executing [sock.connect](#)<sup>[477]</sup>, [sock.close](#)<sup>[475]</sup>, [sock.reset](#)<sup>[495]</sup>, or [sock.discard](#)<sup>[478]</sup> method does not mean that your connection gets established or terminated by the time your program reaches the next statement. Executing these statements merely instructs the Master Process what to do with the connection (more on the Master Process in the [System Components](#)<sup>[7]</sup> topic). Connection establishment/termination can take some time and your application doesn't have to wait for that to complete. [Checking Connection Status](#)<sup>[439]</sup> topic explained how to find out actual connection status at any time (see [sock.state](#)<sup>[502]</sup> and [sock.statesimple](#)<sup>[505]</sup> read-only properties)

There are certain situations when your program has to take the above into account. Here is one example. Supposing, we want to know the MAC address of a remote device to which we are establishing an outgoing connection. Naturally, we can do it this way:

```
'Correct code -- on startup we order the connection to be established and in
the on_sock_event event handler we record the MAC address of the 'other
side'

Sub On_sys_init
...
sock.targetip="192.168.100.40" 'we prepare for the connection
sock.targetport=2000
sock.connect 'and now we connect
End Sub

'-----
-----

Sub On_sock_event(newstate As pl_sock_state,newstatesimple As
pl_sock_state_simple)
Dim s As String
If newstatesimple=PL_SSTS_EST Then
```

```

    'OK, so connection is established, let's get this MAC!
    s=sock.remotemac
  End If
End Sub

```

The above is a good example of event-driven programming. Sometimes, however, you need to establish a connection and "follow-up" on it in the same event handler. So, how do we do this? Here is a simple, and WRONG code:

```

'!!! BAD EXAMPLE !!!

Dim s As String
...
...

sock.targetip="192.168.100.40"  'we prepare for the connection
sock.targetport=2000
sock.connect                    'and now we connect
s=sock.remotemac                'and now we try to check the MAC. WRONG! Connection
may not be established yet!

...

```

And here is the correct way to handle this. For clarity, this example assumes that connection will definitely be established.

```

'Correct, but simplified example (we do not handle possible connection
failure).

Dim s As String
...
...

sock.targetip="192.168.100.40"  'we prepare for the connection
sock.targetport=2000
sock.connect                    'and now we connect
While sock.statesimple<>PL_SSTS_EST 'we wait here until the connection is
actually established
Wend
s=sock.remotemac                'Get the MAC!

...

```

Here is even more interesting example. Supposing, you want to close and reestablish a TCP connection right within the same event handler. Here is a wrong way of doing this:

```

'!!! BAD EXAMPLE !!! -- this just won't work!
...
...

sock.close
sock.connect

```

```
...
```

You see, executing `sock.close` doesn't really close the connection -- it only issues the instruction (to the Master Process) to close the connection. So, by the time program execution gets to the `sock.connect` method your previous connection is still on!

Correct way is to wait for the connection to actually be closed before executing `sock.connect`. Here is another example -- not quite correct either -- but closer to the truth.

```
'!!! 'BETTER' CODING !!! -- still not totally OK!
...
...

sock.close
  While sock.statesimple<>PL_SSTS_CLOSED 'here we wait for the connection
to be closed
  Wend
sock.connect
...
```

OK, this is better. One final correction and the code is complete. In the [Closing Connections](#)<sup>[437]</sup> topic ("Socket re-use after connection closing" section) we have already explained that the OS makes sure that the `on_sock_event` has a chance to execute after the old connection is closed and before the new one is established. In the above example both `sock.close` and `sock.connect` are in the same event handler -- the `on_sock_event` won't squeeze in between them unless you use the [doevents](#)<sup>[73]</sup> statement! Here is the correct code:

```
'100% CORRECT!
...
...

sock.close
  While sock.statesimple<>PL_SSTS_CLOSED 'here we wait for the connection
to be closed
  Wend
  doevents ' Absolutely essential for this particular case!
sock.connect
...
```

Notice how `doevents` is placed after the while-wend loop. It is absolutely essential that you do it this way! Of course, now that you have at least one `doevents` in the event handler you might as well add `doevents` in all "places of waiting" -- just to let other events execute sooner.

```
'Even better code!
...
...

sock.close
  While sock.statesimple<>PL_SSTS_CLOSED 'here we wait for the connection
```

```

to be closed
  doevents 'Not necessary but useful -- lets other events execute
Wend
  doevents ' Absolutely essential for this particular case!
sock.connect
...

```

- You have to place `doevents` after the `while-wend` loop and you have to do this even if you don't actually have a handler for the [on sock event](#)<sup>[490]</sup> event in your application!

## Sending and Receiving data

Once a network connection has been established the socket is ready to send and receive the data. This is done through two buffers- the TX buffer and the RX buffer. Read on and you will know how to allocate memory for buffers, use them, handle overruns, and perform other tasks related to sending and receiving of data.

## Allocating Memory for Buffers

Each buffer has a certain size, i.e, a memory capacity. This capacity is allocated upon request from your program. When the device initially boots, no memory is allocated to buffers at all.

Memory for buffers is allocated in pages. A *page* is 256 bytes of memory. Allocating memory for a buffer is a two-step process: first you have to request for a specific allocation (a number of pages) and then you have to perform the actual allocation.

For the socket object to be able to send and receive the data, you have to give its TX and RX buffers some memory. This is done through the [sock.txbufreq](#)<sup>[509]</sup> and [sock.rxbufreq](#)<sup>[497]</sup> methods.

The allocation method ([sys.buffalloc](#)<sup>[530]</sup>) applies to all buffers previously specified, in one fell swoop.

Hence:

```

dim in, out as byte
out = sock.txbufreq(10) ' Requesting 10 pages for the TX buffer. Out will
then contain how many can actually be allocated.

in = sock.rxbufreq(7) ' Requesting 7 pages for the RX buffer. Will return
number of pages which can actually be allocated.

' ... Allocation requests for other buffers...

sys.buffalloc ' Performs actual memory allocation, as per previous requests.

```

Actual memory allocation takes up to 100ms, so it is usually done just once, on boot, for all required buffers. If you do not require some buffer, you may choose not to allocate any memory to it. In effect, it will be disabled.

You may not always get the full amount of memory you have requested. Memory is not an infinite resource, and if you have already requested (and received) allocations for 95% of the memory for your platform, your next request will get up to 5% of memory, even if you requested for 10%.

There is a small overhead for each buffer. Meaning, not 100% of the memory

allocated to a buffer is actually available for use. 16 bytes of each buffer are reserved for variables needed to administer this buffer, such as various pointers etc.

Thus, if we requested (and received) a buffer with 2 pages ( $256 * 2 = 512$ ), we actually have 496 bytes in which to store data ( $512 - 16$ ).

- If you are *changing* the size of any buffer for a socket using `sys.buffalloc`, and this socket is not closed (`sock.statesimple`<sup>[505]</sup> is not `PL_SSTS_CLOSED`), the socket will be automatically closed. Whatever connection you had in progress will be discarded. The socket will not be closed if its buffer sizes remain unchanged.

## Using Buffers in TCP Mode

Once you have allocated memory for the TX and RX buffers you can start sending and receiving data through them. Since TCP is a stream-oriented protocol this is what buffers store- a stream of data being sent and received, without any separation into individual packets. Even for the outgoing data, you have no control over how it will be split into packets for transmission over the network.

### Sending Data

Sending data a two-step process. First, you put the data in the TX buffer using the `sock.setdata`<sup>[500]</sup> method, and then you perform the actual sending (commit the data) using the `sock.send`<sup>[500]</sup> method. For example:

```
sock.setdata ("Foo") ' Placed our data in the TX buffer - not being sent out
yet.
' ... more code...
sock.setdata ("Bar") ' Added even more data to the TX buffer, waiting to be
sent.
sock.send ' Now data will actually start going out. Data sent will be
'FooBar'.
```

Since this is a two-step process, you may gradually fill the buffer to capacity, and only then send its contents.

- \* TiOS features *non-blocking operation*. This means that on `sock.send`, for example, the program does not halt and wait until the data is completely sent. In fact, execution resumes immediately, even before the first byte goes out. Your program will not freeze just because you ordered it to send a large chunk of data.

The data can be stored in the TX buffer at any time but it will only be sent out if and when the `network connection`<sup>[424]</sup> is established. Storing the data in the TX buffer won't cause the socket to establish any connection automatically.

### Receiving Data

Receiving data is a one-step process. To extract the data from the RX buffer, use the `sock.getdata`<sup>[480]</sup> method. Data may only be extracted once from the buffer. Once extracted, it is no longer in the buffer. For example:

```
dim whatigot as string
whatigot = sock.getdata(255)
```

The string `whatigot` now contains up to 255 bytes of data which came from the RX buffer of the socket.

Discussion of TCP data RXing continues in [Receiving Data in TCP mode](#)<sup>[446]</sup>.

## Using Buffers in UDP Mode

UDP is a packet-based protocol (as opposed to TCP, which is stream-based). In UDP you usually care what data belongs to what datagram (packet). The sockets object gives you complete control over the individual datagrams you receive and transmit.

Sending and receiving UDP data is still effected through the TX and RX buffers. The difference is that the subdivision into datagrams is preserved within the buffers.

Each datagram in the buffer has its own header:

- For the TX buffer, headers contain datagram length as well as the destination MAC, IP, port, and broadcast flag (indicating whether to send the datagram as a broadcast).
- For the RX buffer, headers contain datagram length plus the sender's MAC, IP, port, and broadcast flag (indicating whether the datagram is a broadcast).

### Sending Data

Just like with TCP, sending data through the TX buffer in UDP mode is a two-step process; first you put the data in the buffer using the [sock.setdata](#)<sup>[500]</sup> method, and then you close a datagram and perform the actual sending (commit the data) using the [sock.send](#)<sup>[500]</sup> method.

The datagrams will never be mixed with one another. Once you invoke `sock.send`, the datagram is closed and sent (as soon as possible). Any new data added to the TX buffer will belong to a new datagram. For example:

```
sock.setdata ("Foo") ' Placed our data in the tx buffer - not being sent out
yet.

' ... more code...

sock.setdata ("Bar") ' Added even more data to the same datagram, waiting to
be sent.
sock.send ' A datagram containing 'FooBar' will now be closed and committed
for sending.
sock.setdata ("Baf") ' This new data will go into a new datagram.
sock.send ' Closes the datagram with only 'Baf' in it and commits it for
sending.
sock.send ' sends an empty UDP datagram!
```

Notice that in the example above we were able to send out an empty datagram by using `sock.send` without `sock.setdata`!

Keep in mind that there is a limitation for the maximum length of data in the UDP

datagram- 1536 bytes.

## Receiving Data

Receiving data in UDP mode requires you to be within an event handler for incoming socket data, or to explicitly move to the next UDP datagram in the buffer.

To extract the data from a buffer, use the [sock.getdata](#)<sup>[480]</sup> method. This method only accesses a single datagram on the buffer, unless you use the [sock.nextpacket](#)<sup>[487]</sup> method. If you have several incoming datagrams waiting, you will have to process them one by one, moving from one to the next. This is good because this way you know where one datagram ends and another one begins.

Here is an example:

```
sub on_sock_data_arrival
  dim whatigot as string
  whatigot = sock.getdata(255) 'will only extract the contents of a
  single datagram. Reenter the on_sock_data_arrival to get the next datagram
end sub
```

Data may only be extracted once from a buffer. Once extracted, it is no longer in the buffer. Discussion of UDP data RXing continues in [Receiving Data in UDP mode](#)<sup>[450]</sup>.

## TX and RX Buffer Memory Status

You cannot effectively use a buffer without knowing what is its status. Is it overflowing? Can you add more data? etc. Thus, each of the socket buffers has certain properties which allow you to monitor it:

### The RX buffer

You can check the total capacity of the buffer with the [sock.rxbuffersize](#)<sup>[498]</sup> property. You can also find out how much data the RX buffer currently contains with the [sock.rxlens](#)<sup>[499]</sup> property. From these two data, you can easily deduce how much free space you have in the RX buffer -- even though this isn't such a useful datum (that's one of the reasons there is no explicit property for it).

Note that `sock.rxlens` returns the *gross* current size of data in the RX buffer. In TCP mode, this is equivalent to the actual amount of data in the buffer. However, in UDP mode, this value includes the headers preceding each datagram within the RX buffer -- the amount of actual data in the buffer is smaller than that. A separate property -- [sock.rxpacketlen](#)<sup>[499]</sup> returns the length of actual data in the UDP datagram you are currently processing.

Sometimes you need to clear the RX buffer without actually extracting the data. In such cases the [sock.rxclear](#)<sup>[498]</sup> comes in handy.

### The TX buffer

Similarly to the RX buffer, the TX buffer also has a [sock.txbuffersize](#)<sup>[509]</sup> property which lets you discover its capacity.

The TX buffer has two "data length" properties: [sock.txlen](#)<sup>[510]</sup> and [sock.newtxlen](#)<sup>[486]</sup>. The `txlen` property returns the amount of *committed* data waiting to be sent from the buffer (you commit the data by using the [sock.send](#)<sup>[500]</sup> method). The `newtxlen` property returns the amount of data which has entered the buffer, but has not yet

been committed for sending. For UDP, this is basically the length of UDP datagram being created.

The TX buffer also has a [sock.txfree](#)<sup>[510]</sup> property, which directly tells you how much space is left in it. This does not take into account uncommitted data in the buffer -- actual free space is `sock.txfree-sock.newtxlen`!



`ser.txlen + ser.txfree = ser.txbuffersize.`

When you want to clear the TX buffer without sending anything, use the [sock.txclear](#)<sup>[510]</sup> method. Notice, however, that this will only work when the network connection is closed ([sock.statesimple](#)<sup>[505]</sup>= PL\_SSTS\_CLOSED).

An example illustrating the difference between `sock.txlen` and `sock.newtxlen`:

```
sub on_sys_init

dim x,y as word ' declare variables

sock.rxbufferq(1) ' Request one page for the RX buffer.
sock.txbufferq(5) ' Request 5 pages for the TX buffer (which we will use).
sys.buffalloc ' Actually allocate the buffers.

sock.setdata("foofoo") ' Set some data to send.
sock.setdata("bar") ' Some more data to send.
sock.send ' Start sending the data (commit).
sock.setdata("baz") ' Some more data to send.
x = sock.txlen ' Check total amount of data in the TX buffer.
y = sock.newtxlen ' Check length of data not yet committed.

end sub 'Set up a breakpoint HERE.
```

Don't step through the code. The sending is fast -- by the time you reach `x` and `y` by stepping one line at a time, the buffer will be empty and `x` and `y` will be 0. Set a breakpoint at the end of the code, and then check the values for the variables (by using the [watch](#)<sup>[33]</sup>).

## Receiving Data in TCP Mode

We have already explained that RX and TX buffers operate differently in the [TCP](#)<sup>[445]</sup> and [UDP](#)<sup>[446]</sup> mode. This section explains how to receive data when the TCP protocol is used by the socket.

In a typical system, there is a constant need to handle an inflow of data. A simple approach is to use polling. You just poll the buffer in a loop and see if it contains any fresh data, and when fresh data is available, you do something with it. This would look like this:

```
sub on_sys_init

while sock.rxlen = 0
wend ' basically keeps executing again and again as long as sock.rxlen = 0
s = sock.getdata(255) ' once loop is exited, it means data has arrived. We
extract it.

end sub
```

This approach will work, but it will forever keep you in a specific event handler (such as [on\\_sys\\_init](#)<sup>[533]</sup>) and other events will never get a chance to execute. This is an example of *blocking code* which could cause a system to freeze. Of course, you can use the [doevents](#)<sup>[87]</sup> statement, but generally we recommend you to avoid this blocking approach.

Since our platform is event-driven, you should use events to tell you when new data is available. There is an [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event which is generated whenever there is data in the RX buffer:

```
sub on_sock_data_arrival

dim s as string
s = sock.getdata(255) ' Extract the data -- but in a non-blocking way.
' .... code to process data ....
end sub
```

The `on_sock_data_arrival` event is generated whenever there is data in the RX buffer, but only once. There are never two `on_sock_data_arrival` events (for the same socket) waiting in the queue. The next event is only generated after the previous one has completed processing, if and when there is any data available in the RX buffer.

This means that when handling this event, you don't have to get *all* the data in the RX buffer. You can simply handle a chunk of data and once you leave the event handler, a new event of the same type will be generated.

Here is a correct example of handling arriving socket data through the `on_sock_data_arrival` event. This example implements a data loopback -- whatever is received by the socket is immediately sent back out.

```
dim rx_tcp_packet_len as word 'to keep the size of the next incoming TCP
packet

sub on_sys_init
end sub
```

We want to handle this loopback as efficiently as possible, but we must not overrun the TX buffer. Therefore, we cannot simply copy all arriving data from the RX buffer into the TX buffer. We need to check how much free space is available in the TX buffer. The first line of this code implements just that: `sock.getdata` takes as much data from the RX buffer as possible, but not more than `sock.txfree` (the available room in the TX buffer). The second line just sends the data.



Actually, this call will handle no more than 255 bytes in one pass. Even though we seemingly copy the data directly from the RX buffer to the TX buffer, this is done via a temporary string variable automatically created for this purpose. In this platform, string variables cannot exceed 255 bytes.

## Receiving Data in UDP Mode

In the [previous section](#)<sup>[448]</sup> we have already explained how to handle data reception when the socket is in the TCP mode. This section provides explanation for receiving data with UDP.

### Using on\_sock\_data\_arrival event

With UDP, you still (typically) process incoming data basing on the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event. Two differences apply:

- Each time the on\_sock\_data\_arrival event handler is entered you only get to process a single UDP datagram waiting in the RX buffer. Unless you use a special method (see below), you won't be able to get the data from the next datagram, even if this datagram is already available in the RX buffer.
- If, while within the on\_sock\_data\_arrival event handler, you don't read out entire contents of the "current" datagram and exit the event handler, then the unread portion of the datagram is discarded.

Here is an example: supposing, two datagrams are waiting in the RX buffer and their contents are "ABC" and "123". The following code will then execute twice:

```
sub on_sock_data_arrival
dim s as string(2)
s = sock.getdata(255) ' will get 2 bytes as this is the capacity of s
end sub
```

Since s has a maximum capacity of 2 the first time s=sock.getdata(255) executes you will get "AB". When the event handler is exited the rest of the first UDP datagram will be discarded, so next time you will get "12"!

### Using sock.nextpacket method

Using on\_sock\_data\_arrival event is a preferred method of handling an incoming data stream. Still, in selected cases you may need to process RX data in a loop, without leaving the event handler.

The [sock.nextpacket](#)<sup>[487]</sup> method exists for just such a case. The result of this method execution is equivalent to exiting/(re)entering the on\_sock\_data\_arrival event handler: the unread portion of the previous UDP datagram is discarded and we move to the next UDP datagram (if any).

Here is a code example where we handle all incoming UDP data without exiting event handler:

```
dim s as string
...
l1:
while sock.rxlens = 0
doevents 'good practice: let other events execute while we are waiting
wend

sock.nextpacket 'Now we know that we do have data, 'move to' the next UDP
datagram. This is like entering the on_sock_data_arrival.
```

```
s = sock.getdata(255) 'get data
goto l1
...

```

## Sending TCP and UDP Data

In the previous sections, we have explained how to handle an incoming stream of data. You could say it was incoming-data driven. Sometimes you need just the opposite -- you need to perform operations based on the sending of data.

### Sending data with `on_sock_data_sent` event

Supposing that in a certain system, you need to send out a long string of data when a button is pressed. A simple code for this would look like this:

```
sub on_button_pressed
    sock.setdata("This is a long string waiting to be sent. Send me
already!")
    sock.send
end sub

```

The code above *would* work, but *only* if at the moment of code execution the necessary amount of free space was available in the TX buffer (otherwise the data would get truncated). So, obviously, you need to make sure that the TX buffer has the necessary amount of free space before sending. A simple polling solution would look like this:

```
sub on_button_pressed
    dim s as string
    s = "This is a long string waiting to be sent. Send me already!"
    while sock.txfree < len(s)
    wend
    sock.setdata(s)
    sock.send
end sub

```

Again, this is not so good, as it would block other event handlers. So, instead of doing that, we would employ a code that uses [on\\_sock\\_data\\_sent](#)<sup>[489]</sup>:

```
dim s as string
s = "This is a long string waiting to be sent. Send me already!"

sub on_button_pressed
    sock.notifysent(sock.txbufsize-len(s)) ' causes the on_sock_data_sent
event to fire when the TX buffer has space for our string
end sub

sub on_sock_data_sent
    sock.setdata(s) ' put data in TX buffer
    sock.send ' start sending it.

```

```
end sub
```

When we press the button, [on button pressed](#)<sup>[234]</sup> event is generated, so now the system knows we have a string to send. Using [sock.notifysent](#)<sup>[487]</sup> we make the system fire the `on_ser_data_sent` event when the necessary amount of free space becomes available. This event will only be fired once -- and will be fired immediately if there is already enough available space.

Within the event handler for this event, we put the data in the TX buffer and start sending it.

- Amount of data that will trigger `on_sock_data_sent` does not include uncommitted data in the TX buffer.

### UDP datagrams are generated as you create them

In [Using Buffers in TCP Mode](#)<sup>[446]</sup> we have already explained that for UDP you have a complete control over how the data you are sending is divided into the UDP datagrams. Each time you use the `sock.send` method you draw the boundary between the datagrams- the previous one is "closed" and the new one "begins". You can even send out an empty UDP datagram by executing [sock.send](#)<sup>[500]</sup> without using the [sock.setdata](#)<sup>[500]</sup> first.

### Correctly responding to the sender of each UDP datagram

With UDP, your socket may be receiving UDP datagrams from several different hosts. When the `on_sock_data_arrival` event handler is entered (see [Receiving Data in UDP mode](#)<sup>[450]</sup>) the following properties automatically reflect the source of the current datagram- [sock.remotemac](#)<sup>[495]</sup>, [sock.remoteip](#)<sup>[494]</sup>, and [sock.remoteport](#)<sup>[495]</sup>. Additionally, the [sock.bcast](#)<sup>[475]</sup> property will tell you whether the datagram was a regular or a broadcast one (this material has already been covered in [Checking Connection Status](#)<sup>[439]</sup>).

Additionally, any datagram that was generated and sent from within the `on_sock_data_arrival` event handler will be send to the sender of the datagram for processing of which the `on_sock_data_arrival` event handler was entered.

The point is that if you are sending out a datagram from within the `on_sock_data_arrival` event handler you are automatically replying to the sender of the datagram being processed. The following example sends back "GOT DATAGRAM FROM xxx.xxx.xxx.xxx" string in response to any datagram received by the socket:

```
sub on_sock_data_arrival
  sock.setdata("GOT DATAGRAM FROM " + sock.remoteip)
  sock.send
end sub
```

For the above example, even if several hosts send the datagrams to the socket at the same time each one of these hosts will get a correct reply back!

Now consider this example: each time the button is pressed the same message is generated:

```
sub on_button_pressed
    sock.setdata("GOT DATAGRAM FROM " + sock.remoteip)
    sock.send
end sub
```

The difference is that when you press the button the datagram will be sent to the destination, from which the most recent incoming UDP datagram was received (and accepted) by the socket!

## "Split Packet" Mode of TCP Data Processing

Though our customer's feedback we have learned that sometimes it may be necessary to know the size of individual TCP packets. For example, as it turns out, some data encryption methods work on a packet level. Erase the border between TCP packets -- and you can't decrypt the data.

Introduced in Tibbo Basic V2.0, new [sock.splittcppackets](#)<sup>[501]</sup> property and [on\\_sock\\_tcp\\_packet\\_arrival](#)<sup>[491]</sup> event allow you to process incoming TCP data packet by packet. To achieve this, set the `sock.splittcppacket=1` - YES. After that, the `on_sock_tcp_packet_arrival` will be generated for each incoming TCP packet carrying any new data (i.e., not a retransmission data). Here is an example of use:

```
dim rx_tcp_packet_len as word 'to keep the size of the next incoming TCP
packet

sub on_sys_init
    ...
    rx_tcp_packet_len=0
    sock.splittcppackets=YES
end sub

sub on_sock_tcp_packet_arrival(len as word)
    rx_tcp_packet_len=len 'we get the size of the next packet we are going to
process
end sub

sub on_sock_data_arrival
    dim s as string
    'take exactly the contents of one packet (we assume that it can fit in
the string!)
    s=sock.getdata(rx_tcp_packet_len)
    rx_tcp_packet_len=0 'very important!
end sub
```

Naturally, you may also need to control the size of outgoing TCP packets. This is done in a different way. With `sock.splittcppackets`<sup>[501]</sup>=1- YES, when you put some data into the TX buffer and execute `sock.send`<sup>[500]</sup>, the socket won't send this data out unless entire contents of the TX buffer can be sent out in a single TCP packet. Here is an example of how you can use that:

```
sock.splittcppackets=YES
...
...
sock.setdata("ABCDEFGH1234567890")
sock.send
```

```
while sock.txlen>0
  doevents
wend
```

Notice that this method has its disadvantage -- your data throughput is diminished because your program is seeking an acknowledgement for each TCP packet being sent. On the other hand, this is a bulletproof way of making sure that the outgoing TCP packet contains exactly the data you intended.

Be careful not to try to send more data than the RX buffer size on the other end. Since in this mode the socket won't send that data unless it can send all of it, your TCP connection will get stuck!

Also, attempting to send the packet with size exceeding the "maximum segment size" (MSS) as specified by the other end will lead to data fragmentation! The socket will never send any TCP packet with the amount of data exceeding MSS.

## Handling Buffer Overruns

### Handling RX buffer overruns

The [on\\_sock\\_overrun event](#)<sup>[497]</sup> is generated when an RX buffer overrun has occurred. It means the data has been arriving to the RX buffer faster than you were handling it and that some data got lost.

This event is generated just once, no matter how much data is lost. A new event will be generated only after exiting the handler for the previous one.

Normally, data overruns will not occur when the TCP transport protocol is used. This is because the TCP is intelligent enough to regulate the flow of data between the sender and the receiver and, hence, avoid overruns. The UDP protocol does not have a "flow control" mechanism and RX buffer overruns can and will happen.

Typically, the user of your system wants to know when an overrun has occurred. For example, you could blink a red LED when this happens.

```
sub on_ser_overrun
  pat.play("R-R-R-R")
end sub
```

### Are TX buffer overruns possible?

TX buffer overruns are not possible. The socket won't let you overload its TX buffer. If you try to add more data to the TX buffer than the free space in the buffer allows to store then the data you are adding will be truncated.

See [Sending Data](#)<sup>[451]</sup> for explanation on how to TX data correctly.

## Redirecting Buffers

The following example appeared under [Receiving Data in TCP Mode](#)<sup>[448]</sup>:

```
sub on_sock_data_arrival
  sock.setdata(sock.getdata(sock.txfree))
  sock.send
end sub
```

This example shows how to send all data incoming to the RX buffer out from the TX buffer, in just two lines of code. However fast, this technique still passes all data through your BASIC code, even though you are not processing (altering, sampling) it in any way.

A much more efficient and advanced way to do this would be using a technique called *buffer redirection* (buffer shorting). With buffer shorting, instead of receiving the data into the RX buffer of your socket, you are receiving it directly into the TX buffer of another object which is supposed to send out this data. This can be a socket (same or different one), a serial port object, etc.

To use buffer shorting, you invoke the [sock.redir](#)<sup>[493]</sup> method and specify the buffer to which the data is to be redirected. Once this is done, the `on_sock_data_arrival` event won't be generated at all, because the data will be going directly to the TX buffer that you have specified. As soon as the data enters this buffer, it will be automatically committed for sending. Here is an example:

```
sub on_sys_init
  sock.num=0
  sock.redir(PL_REDIR_SOCKET) ' This is a loopback for socket 0.
end sub
```

The performance advantage here is enormous, due to two factors: first, you are not handling the data programmatically, so the VM isn't involved at all. And second, the data being received is received directly into the TX buffer from which it is transmitted, so there is less copying in memory.

Of course you cannot do anything at all with this data -- you are just pumping it through. However, very often this is precisely what is needed! Additionally, you *can* still process [inband commands/replies](#)<sup>[456]</sup> (messages).

To stop redirection, you can use `sock.redir(0)`, which means "receive data into the RX buffer of the socket in a normal fashion".

## Redirection and UDP

[Using Buffers in UDP Mode](#)<sup>[446]</sup> explained that the sock object preserves buffer boundaries when storing UDP datagrams in RX and TX buffer. To achieve this, the sock object uses special datagram headers that are also stored in these buffers. This means that the buffers contain not only data, but also an additional "service" information.

When an RX buffer of a "UDP socket" (i.e. a socket running in the UDP mode) is redirected to a TX buffer of another UDP socket, datagram boundaries are preserved. The receiving socket will still send out the data subdivided into the original datagrams.

When an RX buffer of a UDP socket is redirected to a TX buffer of a TCP socket or serial port, the service information is removed and datagram boundaries are dissolved. To the receiving TCP socket or serial port, the data appears to be a stream.

## Sinking Data

Sometimes it is desirable to ignore all incoming data while still maintaining the connection opened. The [sock.sinkdata](#)<sup>[501]</sup> property allows you to do just that.

Set the sock.sinkdata to 1- YES, and all incoming data will be automatically discarded. This means that the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event will not be generated, reading [sock.rxlent](#)<sup>[499]</sup> will always be returning zero, and so on. No data will be reaching its destination even in case of [buffer redirection](#)<sup>[454]</sup>. [Inband commands](#)<sup>[456]</sup>, however, will still be extracted from the incoming data stream and processed. [Sock.connectionout](#)<sup>[477]</sup> and [sock.toutcounter](#)<sup>[507]</sup> will work correctly as well.

## Working With Inband Commands

Inband commands (replies) are messages embedded within the TCP data stream. Each inband message has a specific formatting that allows the socket to recognize it in the data stream being received.

Inband messages have many uses. For example, in a network-to-serial converter, you typically pass all serial data through a single TCP connection. At the same time, you often need to send some control commands to the device, i.e. for setup, etc. This can be done in two ways: through a separate network connection ("out-of-band" respective to the main data connection) or by embedding those commands inside the serial data stream ("inband" way). The second method is sometimes better, since very often you want to avoid or cannot have another network connection to your device.

Of course, you could just write a BASIC code that would be separating inband commands from the data but this would affect the performance (data throughput) of your device considerably. The sock object natively supports inband commands to avoid this performance penalty. In fact, inband commands will work even when the [buffer redirection](#)<sup>[454]</sup> is enabled!



Inband messages are only possible with TCP transport protocol. You cannot use inband messages with UDP!

## Inband Message Format

Inband message passing is enabled through the [sock.inbandcommands](#)<sup>[484]</sup> property.

Each inband message has to start with a special escape character whose ASCII code is specified by the [sock.escchar](#)<sup>[479]</sup> property. The next character after the escape character can have any ASCII code *except* for the code of the escape character itself.

Following that is the body of the inband message. The last character in the message is a so-called end character, specified by the [sock.endchar](#)<sup>[479]</sup> property. It signals the end of the inband message and return to the "regular" data.

There are no specific limitations on how long the inband message can be. The length is only limited by how much space you allocate for the [CMD and RPL buffers](#)<sup>[457]</sup> that store incoming and outgoing inband messages.

And what if the data stream itself contains a character(s) with the ASCII code of the escape character you have set? Wouldn't this confuse the socket into thinking that this is the beginning of inband command? To avoid this situation, the *data* character with code of escape character is transmitted as two identical characters with the same ASCII code.

Example: supposing you have the following setup:

```
...
sock.inbandcommands= YES
sock.escchar=`$`
sock.endchar=`%`
...
```

Now, you have the following data stream coming into the socket:

**ABCD\$#inband commqand%EFG\$\$123**

The socket will interpret this stream as including one inband command: "\$#inband command%". Regular data, placed into the RX buffer of the socket will be "ABCDEFGF\$123". The first '\$' character is interpreted as the beginning of the inband message because this character is followed by some other character ('#'). The second occurrence of the '\$' character is interpreted as data, since this character is followed by another 'S' character. Resulting data stream contains only a single '\$' character- the socket takes care of removing the second one automatically.

When sending data from the TX buffer, the socket also automatically doubles all data characters with the ASCII code of the escape character. So, if you want to send this string: "Outbound\$!" what will actually be sent is:

**Outbound\$\$!**



Inband messages are not our invention. Many programs, such as the HyperTerminal, treat the character with code 255 as an escape character.

## Inband-related Buffers (CMD, RPL, and TX2)

Three buffers are required for inband message processing. On startup, these buffers are not allocated any memory, so you have to do it if you are planning to send and receive inband messages.

- The CMD buffer- used to store incoming inband messages (we call them "inband commands"). Use the [sock.cmdbuffrq](#)<sup>[476]</sup> method to allocate memory for this buffer. Usually, inband commands are not very long so allocating a minimum space of 1 page is typically sufficient.
- The RPL buffer- used to store outgoing inband messages (we call them "inband replies"). Use the [sock.rplbuffrq](#)<sup>[496]</sup> method to allocate memory for this buffer. again, inband commands are usually not very long so allocating a minimum space of 1 page will probably be sufficient.
- The TX2 buffer- used internally by the socket when inband commands are enabled. You don't have to do anything with this buffer other than allocate memory for it. We recommend allocating as much space as you did for the TX buffer. Allocation is requested through the [sock.tx2buffrq](#)<sup>[508]</sup> method.

Actual memory allocation is done through the [sys.buffalloc](#)<sup>[530]</sup> method which applies to all buffers previously specified. Here is an example:

```

dim b1, b2, b3, b4, b5 as byte

...
'setup for other objects, sockets, etc.

b1= sock.txbufreq(5) 'you need this buffer to send regular data
b2= sock.rxbufreq(5) 'you need this buffer to receive regular data
b3= sock.cmdbufreq(1) 'buffer for incoming inband commands
b4= sock.rplbufreq(1) 'buffer for outgoing inband replies
b5= sock.tx2bufreq(5) 'same buffer size as for the TX buffer

....

sys.buffalloc ' Performs actual memory allocation, as per previous requests

```

Actual memory allocation takes up to 100ms, so it is usually done just once, on boot, for all required buffers.

You may not always get the full amount of memory you have requested. Memory is not an infinite resource, and if you have already requested (and received) allocations for 95% of the memory for your platform, your next request will get up to 5% of memory, even if you requested for 10%.

There is a small overhead for each buffer. Meaning, not 100% of the memory allocated to a buffer is actually available for use. 16 bytes of each buffer are reserved for variables needed to administer this buffer, such as various pointers etc.

Thus, if we requested (and received) a buffer with 2 pages ( $256 * 2 = 512$ ), we actually have 496 bytes in which to store data ( $512 - 16$ ).

- If you are *changing* the size of any buffer for a socket using `sys.buffalloc`, and this socket is not closed ([sock.statesimple](#)<sup>[505]</sup> is not `PL_SSTS_CLOSED`), the socket will be automatically closed. Whatever connection you had in progress will be discarded. The socket will not be closed if its buffer sizes remain unchanged.

## Processing Inband Commands

### What goes into the CMD buffer

All incoming inband commands are stored into the CMD buffer. At any given time the buffer may contain more than one command. Each inband message in the buffer already has its escape character and the character after the escape character removed. The end character, however, is not removed and can be used by your program to separate inband messages from each other.

Here is an example. Supposing, you have the following setup:

```

...
sock.inbandcommands= YES
sock.escchar=`@`
sock.endchar=`&`
...

```

Here is a sample data stream:

**Data@command1&Moredata@!command2&Evenmoredata**

This incoming data stream will have the following effect:

- The RX buffer will receive this data: "DataMoredataEvenmoredata".
- The CMD buffer will receive: "ommand1&command2&"

Notice, that the first inband command is missing the first character- this is because when the inband command is being processed both its escape character and the character following the escape character are removed. End characters of both inband commands are preserved so you can tell where each one ends.

### Extracting the data from the CMD buffer

Extracting data from the CMD buffer is similar to extracting data from the RX buffer. A dedicated method- [sock.getinband](#)<sup>[481]</sup>- does the job. This method is just like the [sock.getdata](#)<sup>[480]</sup>, minus the maxlen argument. Total amount of data in the CMD buffer can be checked through the [sock.cmdlen](#)<sup>[477]</sup> property.

Once extracted, the data is no longer in the buffer. You can use the [sock.cmdlen](#)<sup>[477]</sup> property to check how much data is waiting in the CMD buffer. There is no dedicated property to tell you the buffer capacity- just remember what the [sock.cmdbuffrq](#)<sup>[476]</sup> method returned if you have to know this!

The [on\\_sock\\_inband](#)<sup>[490]</sup> event is generated whenever there is some data in the CMD buffer, but only once. There are never two on\_sock\_inband events waiting in the queue. The next event is only generated after the previous one has completed processing, if and when there is any data available in the CMD buffer.

Inband commands only appear in the CMD buffer in their entirety. That is, if the buffer was previously empty and you get the on\_sock\_inband event then you are guaranteed that the buffer will contain a full command (or several full commands).

Here is an example:

```
sub on_sock_inband
  dim s as string 'we will keep the data from the CMD buffer here
  dim s2 as string 'this will keep individual inband commands
  dim x as byte

  s=sock.getinband 'we get entire CMD buffer contents into the s
  x=instr(1,s,chr(sock.endchar))
  while x<>0
    s2=left(s,x-1) 's2 now contains a single inband command
    s=right(s,len(s)-x) 'cut out this command

    'process inband command in the s2 as needed
    ...
    ...

    'any more inband commands to process now?
    x=instr(1,s,chr(sock.endchar))
  wend
end sub
```

- For the above example to work well, the size of the CMD buffer must not exceed the capacity of string variable s. This way whatever is extracted from the CMD buffer will always fit in s. A slightly more complex processing is needed if the buffer is larger than the capacity of s.

### Are CMD buffer overruns possible?

CMD buffer overruns are not possible. If the socket receives an inband command that cannot be saved into the CMD buffer in its entirety, then the socket will discard the whole command (your program won't be notified of this in any way). Therefore, you are guaranteed to always receive complete inband commands, or nothing at all.

### Incomplete inband commands

Take a look at this datastream:

```
Data@!comma@!command2&Moredata
```

What we have here is an inband command that is incomplete- a new inband command starts before the previous one ends. Such incomplete commands are discarded and not recorded into the CMD buffer.

## Sending Inband Replies

### How to generate inband reply correctly

Inband replies are sent from the RPL buffer. Unlike the process of sending "regular" TX data that requires you to use [sock.setdata](#)<sup>[500]</sup> and [sock.send](#)<sup>[500]</sup> methods, the process of sending an inband reply only takes one step. You set and send (commit) the data with a single method- [sock.setsendinband](#)<sup>[500]</sup>.

The [sock.setsendinband](#) method puts the data into the RPL buffer and immediately commits it for sending. The socket does not add necessary encapsulation automatically: it is the responsibility of your application to add the escape character, some other character after the escape, and the end character.

Your inband reply will only be stored into the RPL buffer if the latter has enough space to store your entire message. If there is not enough free space then *nothing* will be stored. This is different from the TX buffer, for which *whatever can fit* is stored. You can check the free space in the RPL buffer by using the [sock.rplfree](#)<sup>[497]</sup> property. Amount of unsent data in the RPL buffer can be checked through the [sock.rpllen](#)<sup>[497]</sup> property.

You must not split your inband reply- it must be placed in the RPL buffer with a single invocation of [sock.setsendinband](#). In the example below we reply back "OK" to each inband command we receive:

```
sub on_sock_inband
  dim s as string 'we will keep the data from the CMD buffer here
  dim s2 as string 'this will keep individual inband commands
  dim x as byte
```

```

s=sock.getinband 'we get entire CMD buffer contents into the s
x=instr(1,s,chr(sock.endchar))
while x<>0
    s2=left(s,x-1) 's2 now contains a single inband command
    s=right(s,len(s)-x) 'cut out this command

    'reply back with OK
    sock.setsendinband(chr(sock.escchar)+" OK"+chr(sock.endchar))

    'any more inband commands to process now?
    x=instr(1,s,chr(sock.endchar))
wend
end sub

```

And this would be an incorrect way- *do not* split inband replies!

```

...
sock.setsendinband(chr(sock.escchar)) 'WRONG!
sock.setsendinband(" OK") 'WRONG!
sock.setsendinband(chr(sock.endchar)) 'WRONG!
...

```

- For the above example to work well, the size of the CMD buffer must not exceed the capacity of string variable s. This way whatever is extracted from the CMD buffer will always fit in s. A slightly more complex processing is needed if the buffer is larger than the capacity of s.
- Notice how we have created a character after the escape character- by adding a space in front of our "OK" reply, like this: " OK". This will work fine as long as our escape character is not space!

## Using HTTP

The sock object can function as a HTTP server. This means that when certain conditions are met, individual sockets will switch into the HTTP mode and output the data in a style, consistent with the HTTP server functionality.

Certain BASIC information about the HTTP server has already been provided in [Working with HTML](#)<sup>[79]</sup> and [Embedding Code Within an HTML File](#)<sup>[80]</sup>.

When the socket is in the HTTP mode your program has no control over the received data (HTTP requests) and only *sometimes* has control over the transmitted data (HTTP reply).

In the simplest case the file returned to the web browser is static- a "fixed" HTML page, a graphic, or some other file. Processing of such a static file requires no intervention from your program whatsoever. Just setup the socket(s) to be able to accept HTTP requests and the sock object will take care of the rest.

More often than not, however, you have to create a dynamic HTML page. Dynamic pages include fragments of BASIC code. When the sock object encounters such a fragment in the file being sent to the browser, it executes the code. This code, in turn, performs some action, for example, generates and sends some dynamic data to the browser or jumps to the other place in the HTML file.

The HTTP server built into the sock object understands two request types- GET and POST. Both can carry "HTTP variables" that the server will extract and pass to the BASIC code.

At the moment, the following file types are explicitly supported:

- HTML- can be static or include BASIC code.
- TXT- plain text, no BASIC code can be included.
- JPG and GIF- graphic files.
- SWF flash files.

All files other than HTML files are static and are sent to the browser "as is". There is, however, a method of programmatic generation of such files -- see [URL Substitution](#)<sup>[468]</sup>.

All other file types are handled as binary files.

- Currently, the socket object can only access first 65534 bytes of each file, even if the actual file is larger! Make sure that all HTML files (and other files that will be returned by the built in server of your device) are not larger than 65534 bytes. This is not to be confused with the size of HTTP output generated by HTTP file. A very large output can be generated by a small HTML file (due to dynamic data generation)- and that is OK.  
65534 is actually the size limitation for the *compiled* HTML file. When compiling your project, the TIDE will separate the static portion of the file from the Tibbo Basic code fragments. Only the compiled file size matters.

## HTTP-related Buffers

For the HTTP to work, you need to allocate some memory to the following buffers:

- RX buffer. This buffer will be receiving HTTP requests from the client (browser). Buffer allocation request is done through the [sock.rxbufferq](#)<sup>[497]</sup> method. It is possible to avoid spending memory on the RX buffer by [redirecting](#)<sup>[454]</sup> this buffer to the TX buffer of the same socket. This will work because the web server operation is strictly sequential -- receive a request, then generate a reply. Requests and replies do not have to be stored concurrently, so one buffer is sufficient and you will save some memory!
- TX buffer. This buffer will be handling web server replies. If you enable redirection it will also receive HTTP requests. Buffer allocation request is done through the [sock.txbufferq](#)<sup>[509]</sup> method. Practical experience shows that allocating just one page for this buffer makes HTTP request handling somewhat slow. At three or four pages, there is a significant performance improvement. Additional buffer pages do not lead to any dramatic improvements in performance.
- VAR buffer. Dynamic HTML pages include snippets of BASIC code and this code may need to know variable passed to the HTTP server using GET or POST methods. The VAR buffer stores those variables. Do the allocation with the [sock.varbufferq](#)<sup>[517]</sup> method. Buffer size of one page is usually OK. If the application is to handle large amounts of variable data, such as in the case of file uploads, you can improve the performance by allocating more pages.

Actual memory allocation is done through the [sys.buffalloc](#)<sup>[530]</sup> method which applies to all buffers previously specified. Here is an example:

```
Dim f As Byte
```

```
...
'setup for other objects, sockets, etc.

'setup buffers of sockets 8-15 (will be used for HTTP)
For f=8 To 15
    sock.num=f
    sock.txbufreq(1) 'you need this buffer for HTTP requests and replies
    sock.varbufreq(1) 'you need this buffer to get HTTP variables
    sock.redir(PL_REDIR_SOCKET0 + sock.num) 'this will allow us to avoid
wasting memory on the RX buffer
Next f

....

sys.buffalloc ' Performs actual memory allocation, as per previous requests.
```

Memory allocation takes up to 100ms, so it is usually done just once, on boot, for all required buffers.

You may not always get the full amount of memory you have requested. Memory is not an infinite resource, and if you have already requested (and received) allocations for 95% of the memory for your platform, your next request will get up to 5% of memory, even if you requested for 10%.

There is a small overhead for each buffer. Meaning, not 100% of the memory allocated to a buffer is actually available for use. 16 bytes of each buffer are reserved for variables needed to administer this buffer, such as various pointers etc.

Thus, if we requested (and received) a buffer with 2 pages ( $256 * 2 = 512$ ), we actually have 496 bytes in which to store data ( $512 - 16$ ).

- If you are *changing* the size of any buffer for a socket using `sys.buffalloc`, and this socket is not closed (`sock.statesimple`<sup>[505]</sup> is not `PL_SSTS_CLOSED`), the socket will be automatically closed. Whatever connection you had in progress will be discarded. The socket will not be closed if its buffer sizes remain unchanged.
- Notice, that in most cases you will need to reserve more than one socket for HTTP. The HTTP server may need to service multiple requests from different computers at the same time. Even for a single computer and a single HTML page, more than one socket may be needed. For example, if your HTML page contains a picture, the browser will establish two parallel connections to the sock object- one to get the HTML page itself, another one- to get the picture. We recommend that you reserve 4-8 sockets for the HTTP. It is better to have less buffer memory for each HTTP sockets than to have fewer HTTP sockets!

## Setting the Socket for HTTP

### How to set the socket for HTTP

Apart from assigning some memory to the TX, RX, and VAR buffers, the following needs to be done to make the socket work in HTTP mode:

- The protocol must be TCP (`sock.protocol`<sup>[492]</sup> = 1- `PL_SOCKET_PROTOCOL_TCP`).
- The socket must be open for incoming connections (typically, from anybody: `sock.inconmode`<sup>[485]</sup> = 3- `PL_SOCKET_INCONMODE_ANY_IP_ANY_PORT`).

- Reconnects should not be enabled- this is counter-productive for HTTP (`sock.reconmode`<sup>[492]</sup>= 0- PL\_SOCK\_RECONMODE\_0). Reconnects are disabled by default so just leave it this way.
- Correct listening HTTP port must be set. Default HTTP port on all servers is 80 (`sock.httpportlist`<sup>[483]</sup>="80").

In the previous topic, we have already explained that your system should reserve *several* HTTP sockets. Here is a possible initialization example:

```
dim f as byte
...
'setup for other sockets, etc.

'setup sockets 8-15 for HTTP
for f=8 to 15
    sock.num=f
    sock.protocol= PL_SOCK_PROTOCOL_TCP
    sock.inconmode= PL_SOCK_INCONMODE_ANY_IP_ANY_PORT
    sock.httpportlist="80"
next f
....
```

To make sure that the HTTP is working you can create and add to the project a simple static HTTP file. Call this file <index.html>- this is a default file that will be called if no specific file is requested by GET or POST. Here is a static file example:

```
<!DOCTYPE HTML PUBLIC "-//W3C//DTD W3 HTML//EN">
<HTML>
<BODY>
    HELLO WORLD!<br>
</BODY>
</HTML>
```

Launch the browser, type the IP-address of your device, for example: "http://192.168.1.95" and you will get the output "HELLO WORLD!".

- Don't forget to give your device an IP address. For example, if you are working through a regular wired Ethernet, you should assign an IP address through the `net.ip`<sup>[360]</sup> property.

### Double-duty: non-HTTP and HTTP processing on the same socket

Your HTTP sockets don't have to be *exclusively* HTTP. You can have them behave differently depending on which listening port the TCP connection is being made to. Here is an example: supposing the setup of your device needs to be effected in two ways- via TELNET or via HTTP. Standard TELNET port is 23, standard HTTP port is 80. Setup your socket like this:

```
sock.num=f
```

```
sock.protocol= PL_SOCKET_PROTOCOL_TCP
sock.inconmode= PL_SOCKET_INCONMODE_ANY_IP_ANY_PORT
sock.localportlist="23"
sock.httpportlist="80"
....
```

The socket will now be accepting connections both on port 23 and port 80. When connection is made to port 23, the socket will work as a regular data socket, as was described in previous sections. When connection is made to port 80, the socket will automatically switch into the HTTP mode!

There is a property- [sock.httpmode](#)<sup>[481]</sup>- that tells you which mode the socket is in- regular data mode or HTTP. You can even "forcefully" switch any TCP connection into the HTTP mode by setting `sock.httpmode= 1- YES`. You cannot, however, switch this connection back to the data mode, it will remain in the HTTP mode until termination.

## Socket Behavior in the HTTP Mode

When in the HTTP mode, the socket is behaving differently compared to the normal data mode.

### Incoming connection rejection

As was explained in [Accepting Incoming Connections](#)<sup>[426]</sup>, if your device "decides" to reject an incoming TCP connection, it will send out a reset TCP packet. This way, the other host is instantly notified of the rejection. Rules are different for HTTP sockets:

- If there is an incoming TCP connection to the web server of the device (incoming HTTP connection request), and if your application has one or more sockets that are configured to accept this connection, and if all such sockets are already occupied, then the system will not reply to the requesting host *at all*.
- If there is an incoming HTTP connection request, and if your application has no HTTP sockets configured to accept this connection, then the system will still respond with a reset.

This behavior allows your application to get away with fewer HTTP sockets. Here is why. If all HTTP sockets are busy and your application sends out a reset, the browser will show a "connection reset" message. If, however, your device does not reply at all, the browser will wait, and resend its request later. Browsers are "patient" -- they will typically try several times before giving up. If any HTTP sockets are freed-up during this wait, the repeat request will be accepted and the browser will get its page. Therefore, very few HTTP sockets can handle a large number of page requests in a sequential manner and with few rejections.

### Other differences

- All incoming data is still stored in the TX buffer (yes, TX buffer). This data, however, is not passed to your program but, instead, is interpreted as HTTP request. This HTTP request must be properly formatted. The sock object supports GET and POST commands.
- The RX buffer is [not used](#)<sup>[462]</sup> at all and does not have be allocated any memory.
- GET and POST commands can optionally contain "request variables". These are stored into the VAR buffer from which your program can read them out later.
- No [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event is generated when the HTTP request string is

- received into the RX buffer.
- Once entire request has been received the socket prepares and starts to output the reply. Your program has no control over this output until a BASIC code fragment is encountered in the HTTP file. The [on\\_sock\\_data\\_sent](#)<sup>[489]</sup> event cannot be used as well.
  - When code fragment is encountered in the HTTP file control is passed to it and then your program can perform desired action, i.e. generate some dynamic HTML content, etc. When this fragment is entered, the [sock.num](#)<sup>[488]</sup> is automatically set to the correct socket number.
  - Once HTTP reply has been sent to the client the socket will automatically close the connection, as is a normal socket behavior for HTTP. A special property- [sock.httpnoclose](#)<sup>[482]</sup>- allows you to change this default behavior and leave the connection opened.

## Including BASIC Code in HTTP Files

To create dynamic HTML pages, you include BASIC statements directly into the HTML file. A fragment of BASIC code is included within "<? ?>" encapsulation, as shown in the example below (for more info see [Working with HTML](#)<sup>[79]</sup>):

```
<!DOCTYPE HTML public "-//W3C//DTD W3 HTML//EN">
<HTML>
<BODY>
  HELLO HTML WORLD!<br>
  <?
      'This is a BASIC code snippet. We can, for instance, send
something to the serial port
      ser.num=0
      ser.setdata("HELLO SERIAL WORLD TOO!")
      ser.send
  ?>
</BODY>
</HTML>
```

Each time this HTML page will be requested by the browser, the "HELLO SERIAL WORLD TOO!" string will be sent out of the serial port.

## Generating Dynamic HTML Pages

### How to "print" dynamic HTML data

In most cases the BASIC code included into the HTML page is used to generate dynamic HTML content, i.e. to send some dynamically generated data to the browser. This is done in a way, similar to sending out data in a regular data mode: you first set the data you want to send with the [sock.setdata](#)<sup>[500]</sup> method, then commit this data for sending using [sock.send](#)<sup>[500]</sup> method.

Here is an example HTML page that checks the state of one of the inputs of the I/O object and reports this state on the HTML page:

```

<!DOCTYPE HTML public "-//W3C//DTD W3 HTML//EN">
<HTML>
<BODY>
  The state of line 0 is:!  
<?
    'This is a BASIC code fragment. Get the state of the line.
    io.num=0
    if io.state= LOW then
      sock.setdata("LOW")
    else
      sock.setdata("HIGH")
    end if
    sock.send
  ?>
</BODY>
</HTML>

```

- Notice how we did not have to use [sock.num](#)<sup>[488]</sup> it is set automatically when control is passed to BASIC!

### Be careful not to get your data truncated!

The above example is seemingly correct and in this particular case will work fine- because there is not much static data preceding the point where we generate dynamic content and not much dynamic content is generated as well. Generally speaking, you cannot expect that the TX buffer will have enough space when you need to put some data into it! If you are not careful the dynamic data you want to generate may get truncated!

To avoid this situation always check if the necessary amount of free space is available before attempting to put it into the TX buffer. This statement is true for the normal data mode as well, not just for the HTTP processing- we have already touched on this subject in [Sending Data](#)<sup>[451]</sup>. What is different for HTTP is that you cannot use the [on\\_sock\\_data\\_sent](#)<sup>[489]</sup> event to "call you back" when the TX buffer frees up!

The only solution in case of HTTP is to wait, in a loop, for the desired amount of space to become available. Naturally, we don't want to be blocking the whole device, so "polite" waiting shall include a [doevents](#)<sup>[87]</sup> statement:

```

<?
  dim s as string(4)
?>

<!DOCTYPE HTML public "-//W3C//DTD W3 HTML//EN">
<HTML>
<BODY>
  The state of line 0 is:!  
<?
    'This is a BASIC code snippet. Get the state of the line.
    io.num=0
    if io.state= LOW then
      s="LOW"
    else
      s=HIGH
    end if

```

```

        'and now we wait till the TX buffer has enough free space
        while sock.txfree<len(s)
            doevents
        wend

        'OK, so necessary space is now available!
        sock.setdata(s)
        sock.send

    ?>
</BODY>
</HTML>

```

Now we have a bullet-proof dynamic content generation *and* non-blocking operation! As you get more experience with HTML, you will see that the `doevents` statement has to be used quite often.

### Special case: `doevents` and concurrent request of the same file

With HTTP it is entirely possible that two computers (browsers) will request the same HTML file. If you have allocated more than one socket for HTTP it is also possible that both of those requests will be processed at the same time. Of course, the BASIC VM is a single-process system, so when it comes to processing dynamic part of the files, one of the requests will be first.

It is also entirely possible, that when executing the BASIC procedure from the first "instance" of the file, execution arrives at `doevents` and the second instance of the same file will start to process. After all, `doevents` allows other events to execute, so this can include activity in other sockets.

Now, if the same BASIC procedure was allowed to execute again this would cause recursion: an attempt to execute a portion of code while it is already executing! [Recursion is not allowed](#)<sup>[466]</sup>, so the VM will not re-enter the code immediately. Instead, the second instance of HTML page will be "on hold" until the first instance finishes running the procedure in question. After that, the same procedure will be executed for the second instance. This behavior has been introduced in **V1.2** of TiOS. In the previous release, procedure execution for the second instance of the HTML page was simply skipped and not executed at all, which is wrong!

Once again, for this to occur the following conditions must be met: the HTML procedure in question must use `doevents` statement, and the same file (HTML page) must be requested simultaneously from several browsers.

### Avoiding illegal characters

HTTP restricts the use of some characters- you cannot freely send any code from the ASCII table. When you use the `sock.setdata` and `sock.send`, you are "printing" data directly to the browser. It is your program's responsibility to avoid illegal characters and use "%xx" instead.

## URL Substitution

HTML files can [include BASIC code](#)<sup>[466]</sup> and thus be [dynamic](#)<sup>[466]</sup>. Actual HTML contents received by the browser may partially be generated by your Tibbo BASIC application. Files of other types -- plain text, graphics, etc. -- cannot include executable code and are static in nature. These files are sent to the browser "as is".

So, what if you need to generate such a non-HTTP file dynamically? For example, what if you want to generate a BMP file? The answer is in using "URL substitution". The [sock.urlsubstitutes](#)<sup>[511]</sup> property allows you to do this.

The property stores a list of comma-separated file names (with extensions). When the web server receives a request for a non-HTML file from the browser (say, "pix.bmp"), it first tries to find this file among the HTML and resource files of your project. Failing this, the web server looks at defined substitutions. If the requested file is not on the list, the web server returns the "404 error".

If the file is on the list of defined substitutions, the browser looks for the file with the same name but ".html" extension ("pix.html"). If there is no such file, the "404 error" is, again, the answer. If this HTML file exists the server outputs this file, but makes it look like it was a file of the original type (server processes "pix.html", browser gets "pix.bmp").

Since the actual behind-the-scenes output is done for the HTML file you can put your own code into that file and generate content dynamically. The following example shows how we generate the file "pix.bmp" dynamically. For this to work, we need to set `sock.urlsubstitutes="pix.bmp"` somewhere in the initialization section of the project. Here is what we have in "pix.html" file:

```
<?
  Dim x As Byte
  Dim s As String

  romfile.open("source.bmp")
  Do
    x=sock.txfree
    s=romfile.getdata(x)
    sock.setdata(s)
    sock.send
  Loop While Len(s)=x
?>
```

In this example we simply read and output the contents of another bmp file called "source.bmp". No value is added -- we could just access that graphical file directly. Your code, however, is free to do anything and substitution opens up the way to create your picture on the fly, or dynamically generate the content for other "static" files.

## Working with HTTP Variables

HTML pages often pass "variables" to each other. For example, if you have an HTML form to fill on page "form.html" you may want to have the data input by the user on page "result.html".

The explanation of HTTP variables is divided into three sections:

- [Simple case](#)<sup>[470]</sup> -- the amount of HTTP variable data does not exceed 255 bytes;
- [Complex case](#)<sup>[471]</sup> -- the amount of HTTP variable data exceeds 255 bytes (can easily happen, especially with file uploads);
- [Details](#)<sup>[473]</sup> on how the variable data actually looks to your application depending on the method used (HTTP GET or POST).

In most cases the client will send a fairly small amount of variable data, so it all will fit in 255 bytes. Use the [sock.httprqstring](#)<sup>[483]</sup> R/O property, as shown in the following example. Say, you have a login to perform. The user enters his/her name and password on page "index.html". Actual login is processed on page "login.html". The data is passed between these two pages "invisibly", using the HTTP POST method.

Here is the file "index.html":

```
<html> <body>
  <form action="form_get.html" method="post" enctype="multipart/form-
data">
    username: <Input Type="text" name="user"><br>
    password: <Input Type="password" name="pwd"><br>
    <Input Type="submit" value="send">
  </form>
</body> </html>
```

And here is "login.html":


```
<html><body>
  <?
    dim s as string
    s=sock.httprqstring
    'actual processing here, s now contains the variable string
  ?>
</body></html>
```

[Details on Variable Data](#)<sup>[473]</sup> explains what exactly you get from the [sock.httprqstring](#)<sup>[483]</sup> property.

The advantage of using the sock.httprqstring is that the variable data is always there, no matter how many times you read it. Be forewarned, though...

- If you are using the sock.httprqstring, and if the client sends more data than can fit in the VAR buffer, the execution of the HTTP request processing will be stalled indefinitely. See [Complex Case \(Large Amount of Variable Data\)](#)<sup>[471]</sup> for a method of handling this correctly.

Let's talk a bit about why the socket may get stuck. The following diagram details the flow of HTTP request and response processing:




As you can see from the diagram, the socket will automatically extract the variable data and store it into the VAR buffer. The code example above will access the buffer during the reply phase -- from within the "login.html" page. Problem is, processing may never get that far. If the VAR buffer becomes full in the request processing phase, the socket will simply keep waiting, and the reply phase will never start! This is true no matter what HTTP method you use -- GET or POST. [Read on](#)<sup>[471]</sup> and we will tell you how to avoid this.

To avoid a problem situation described in the [previous](#)<sup>[470]</sup> topic use a more complex, but very reliable way of handling large HTTP variable data.

The [on\\_sock\\_postdata](#)<sup>[491]</sup> event is generated when there is data in the VAR buffer. In this regard, the event is similar in nature to the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event which is generated when the RX buffer of the socket has data. Unlike the [on\\_sock\\_data\\_arrival](#) event, the [on\\_sock\\_postdata](#) will first be generated only after the VAR buffer becomes full. That is, you won't be bothered by this event unless the HTTP request processing simply can't continue without it.

OK, so now you have a chance to access and process the HTTP variable data as it arrives and before the reply phase even starts. The [sock.gethttpprqstring](#)<sup>[480]</sup> method, unlike the [sock.httpprqstring](#)<sup>[483]</sup> R/O property, actually removes the data from the VAR buffer, thus freeing up the buffer space. Diagram below illustrates the process:



Here is a modified login example:

In the event handler for the `on_sock_postdata` event we extract available HTTP variable data and process it. The event will be called as many times as necessary. For example, we may save the data into a file:

```

Sub On_sock_postdata ()
    fd.setdata(sock.gethttprqstring(255)) 'very simplified, but illustrates
the point
End Sub
  
```

Then, in the HTML file. It is necessary to remember that a portion of the HTTP variable data may still be unhandled by the time you get here:

```

<html><body>
  <?
    While sock.httprqstring<>" 'extract the remaining part of the
variable data
      fd.setdata(sock.gethttprqstring(255))
    Wend
  ?>
</body></html>
  
```

It is unlikely that user login will require such careful handling. User name and

password will comfortably fit in 255 bytes, unless you users are paranoid and have humongous passwords. Still, there are many situation when you need to send large variable data. For example, HTTP POST methods are routinely used to upload files to the web server and your device will be able to handle this, too.

So far we haven't touched on the subject of actual data that you will read using [sock.httprqstring](#)<sup>[483]</sup> and [sock.gethttprqstring](#)<sup>[480]</sup>. In other words, we haven't discussed the contents of the VAR buffer. It is time to clear this.

We have already explained that the above R/O property and method will return the same data, with the only difference that the sock.httprqstring will not actually remove the data from the VAR buffer and will not be able to access past the first 255 bytes of such data.

Data format in the VAR buffer depends on the method used.

#### **VAR buffer contents -- HTTP GET method**

Supposing the client has sent the following request:

```
GET /form_get.html?user=CHUCKY&pwd=THEEVILDOLL HTTP/1.1
Host: 127.0.0.1:1000
User-Agent: Mozilla/5.0 (and so on)
```

The VAR buffer will get everything past the URL and until the first CR/LF. The part is highlighted in **blue**. There are two variables -- user and pwd. They are equal to "CHUCKY" and "THEEVILDOLL". Your application can just ignore the "HTTP/1.1" part.

#### **VAR buffer contents -- HTTP POST method**

Here is a sample client request:

```
POST /form_get.html HTTP/1.1
Host: 127.0.0.1:1000
User-Agent: Mozilla/5.0
(lots of stuff skipped)
Content-Type: multipart/form-data; boundary=-----
21724139663430
Content-Length: 257
```

```
-----21724139663430
Content-Disposition: form-data; name="user"
```

```
CHUCKY
```

```
-----21724139663430
Content-Disposition: form-data; name="pwd"
```

```
THEEVILDOLL
```

-----21724139663430--

You will get everything shown in **blue**.

## Properties, Methods, and Events

This section provides an alphabetical list of all properties, methods, and events of the sock object.

### .Acceptbcast Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) specifies whether the socket will accept incoming broadcast UDP datagrams.
<b>Type:</b>	Enum (yes_no, byte)
<b>Value Range:</b>	0- NO ( <b>default</b> ): will not accept broadcasts. 1- YES: will accept broadcasts.
<b>See Also:</b>	---

---

#### Details

This property is irrelevant for TCP communications ([sock.protocol](#)<sup>[492]</sup> = PL\_SOCK\_PROTOCOL\_TCP).

### .Allowedinterfaces Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) defines the list of network interfaces on which this socket will accept incoming connections.
<b>Type:</b>	String
<b>Value Range:</b>	Platform-specific. Refer to your device's platform documentation (for example, EM1000's is <a href="#">here</a> <sup>[143]</sup> ).
<b>See Also:</b>	<a href="#">Accepting Incoming Connections</a> <sup>[426]</sup>

---

#### Details

Interfaces that can be on the list are: "NET" (Ethernet), "WLN" (Wi-Fi), "PPP", and "PPPoE". The list of allowed interfaces is comma-delimited, i.e, "WLN,NET".

Note that reading back the value of this property will return the same list, but not necessarily in the same order. For example, the application may write "WLN,NET" into this property, yet read "NET,WLN" back. Unsupported interface names will be dropped from the list automatically.

The list of interfaces supported by your platform can be checked through [sock.availableinterfaces](#)<sup>[475]</sup>. Only interfaces from this list can be specified as "allowed". Trying to allow an unsupported interface will not work.

The socket will not accept a connection on the interface which is not on the `sock.allowedinterfaces` list, even if all other connection parameters such as protocol, port, etc. are correct.

## .Availableinterfaces R/O Property

<b>Function:</b>	Returns a comma-delimited list of network interfaces available on this platform.
<b>Type:</b>	String
<b>Value Range:</b>	Platform-specific. Refer to your device's platform documentation (for example, EM1000's is <a href="#">here</a> <sup>[143]</sup> ).
<b>See Also:</b>	<a href="#">sock.targetinterface</a> <sup>[506]</sup> , <a href="#">sock.currentinterface</a> <sup>[478]</sup> , <a href="#">sock.allowedinterfaces</a> <sup>[474]</sup>

---

### Details

---

## .Bcast R/O Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) reports whether the current or most recently received UDP datagram was a broadcast one.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO ( <b>default</b> ): the UDP datagram is not a broadcast one. 1- YES: the UDP datagram is a broadcast one.
<b>See Also:</b>	<a href="#">sock.remotemac</a> <sup>[495]</sup> , <a href="#">sock.remoteip</a> <sup>[494]</sup> , <a href="#">sock.remoteport</a> <sup>[495]</sup>

---

### Details

When the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event handler is entered, the `sock.bcast` will contain the broadcast status for the current datagram being processed. Outside of the `on_sock_data_arrival` event handler, the property will return the broadcast status of the most recent datagram received by the socket.

## .Close Method

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) causes the socket to close the connection with the other host.
<b>Syntax:</b>	<b>sock.close</b>
<b>Returns:</b>	---

**See Also:****Details**

For established TCP connections this will be a "graceful disconnect", if the TCP connection was in the "connection opening" or "connection closing" state this will be a reset (just like when the [sock.reset](#)<sup>[495]</sup> method is used). If connection was in the ARP phase or the transport protocol was UDP ([sock.protocol](#)<sup>[492]</sup>= 0- 0- PL\_SOCK\_PROTOCOL\_UDP) the connection will be discarded (just like when the [sock.discard](#)<sup>[478]</sup> method is used). Method invocation will have NO effect if connection was closed at the time when the method was called ([sock.state](#)<sup>[502]</sup> in one of PL\_SST\_CLOSED states).

This method will be ignored when called from within an HTML page. HTML sockets are handled automatically and your application is not at freedom to close HTML sockets arbitrarily.

**.Cmdbuffrq Method**

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) pre-requests "numpages" number of buffer pages (1 page= 256 bytes) for the CMD buffer of the socket.
<b>Syntax:</b>	<b>sock.cmdbuffrq(numpages as byte) as byte</b>
<b>Returns:</b>	Actual number of pages that can be allocated (byte)
<b>See Also:</b>	<a href="#">sock.rplbuffrq</a> <sup>[496]</sup>

Part	Description
numpages	Requested numbers of buffer pages to allocate.

**Details**

The CMD buffer is the buffer that accumulates incoming inband commands (messages). This method returns actual number of pages that can be allocated. Actual allocation happens when the sys.buffalloc method is used. The socket is unable to receive inband commands if its CMD buffer has 0 capacity. Unlike for TX or RX buffers there is no property to read out actual CMD buffer capacity in bytes. This capacity can be calculated as num\_pages\*256-16 (or =0 when num\_pages=0), where "num\_pages" is the number of buffer pages that was GRANTED through the [sock.cmdbuffrq](#)<sup>[476]</sup> method. "-16" is because 16 bytes are needed for internal buffer variables.

Buffer allocation will not work if the socket port to which this buffer belongs is not idle ([sock.statesimple](#)<sup>[505]</sup> is not at 0- PL\_SSTS\_CLOSED) at the time when sys.buffalloc executes. You can only change buffer sizes of sockets that are idle.

The CMD buffer is only required when inband commands are enabled ([sock.inbandcommands](#)<sup>[484]</sup>= 1-YES).

## .Cmdlen R/O Property

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the length of data (in bytes) waiting to be processed in the CMD buffer.
<b>Type:</b>	Word
<b>Value Range:</b>	<b>Default</b> = 0 (0 bytes)
<b>See Also:</b>	<a href="#">sock.rplen</a> <sup>[497]</sup> , <a href="#">sock.inbandcommands</a> <sup>[484]</sup>

### Details

The CMD buffer accumulates incoming inband commands (messages) and may contain more than one such command. Use [sock.getinband](#)<sup>[481]</sup> method to extract the data from the CMD buffer.

## .Connect Method

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) causes the socket to attempt to connect to the target host.
<b>Syntax:</b>	<b>sock.connect</b>
<b>Returns:</b>	---
<b>See Also:</b>	

### Details

The target is specified by the [sock.targetport](#)<sup>[507]</sup> and [sock.targetip](#)<sup>[506]</sup> (unless, for UDP, the socket is to broadcast the data- see the [sock.targetbcast](#)<sup>[505]</sup> property). Outgoing connection will be attempted through the network interface defined by the [sock.targetinterface](#)<sup>[506]</sup> property.

Method invocation will have effect only if connection was closed at the time when the method was called ([sock.state](#)<sup>[502]</sup> in one of PL\_SST\_CLOSED states).

## .Connectiontout Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) sets/returns connection timeout threshold for the socket in half-second increments.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535 (0-32767.5 seconds, 0 means "no timeout"), <b>default</b> = 0 (no timeout)
<b>See Also:</b>	<a href="#">Closing Connections</a> <sup>[437]</sup>

### Details

When no data is exchanged across the connection for `sock.connectiontout/2` number of seconds this connection is aborted (in the same way as if the [`sock.reset`](#) <sup>[495]</sup> method was used). Connection timeout of 0 means "no timeout".

Actual time elapsed since the last data exchange across the socket can be obtained through the [`sock.toutcounter`](#) <sup>[507]</sup> R/O property.

## **.Currentinterface R/O Property**

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#"><code>sock.num</code></a> <sup>[488]</sup> ) returns the network interface this socket is currently communicating through.
<b>Type:</b>	Enum ( <code>pl_sock_interfaces</code> , byte)
<b>Value Range:</b>	Platform-specific. See the list of <code>pl_sock_interfaces</code> constants in the platform specifications (for example, EM1000's is <a href="#">here</a> <sup>[143]</sup> ).
<b>See Also:</b>	<a href="#">Checking Connection Status</a> <sup>[439]</sup>

---

### Details

The value of this property is only valid when the socket is not idle, i.e. `sock.statesimple<> 0- PL_SSTS_CLOSED`.

## **.Discard Method**

<b>Function:</b>	For the selected socket (selection is made through <a href="#"><code>sock.num</code></a> <sup>[488]</sup> ) causes the socket to discard the connection with the other host.
<b>Syntax:</b>	<b><code>sock.discard</code></b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#"><code>sock.close</code></a> <sup>[475]</sup> , <a href="#"><code>sock.reset</code></a> <sup>[495]</sup>

---

### Details

Discarding the connection means simply forgetting about it without notifying the other side of the connection in any way.

This method will be ignored when called from within an HTML page. HTML sockets are handled automatically and your application is not at freedom to discard HTML sockets arbitrarily.

## .Endchar Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) specifies the ASCII code of the character that will end inband command (message).
<b>Type:</b>	Byte
<b>Value Range:</b>	0-255, <b>default</b> = 13 (CR)
<b>See Also:</b>	<a href="#">sock.escchar</a> <sup>[479]</sup>

---

### Details

Each inband message has to end with the end character, which will mark a return to the "regular" data stream of the TCP connection.

This property is irrelevant when inband commands are disabled ([sock.inbandcommands](#)<sup>[484]</sup>= 0- NO). The program won't be able to change the value of this property when the socket is not idle ([sock.statesimple](#)<sup>[505]</sup><> 0- PL\_SSTS\_CLOSED).

## .Escchar Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) specifies the ASCII code of the character that will be used as an escape character for inband commands (messages).
<b>Type:</b>	Byte
<b>Value Range:</b>	0-255, <b>default</b> = 255
<b>See Also:</b>	<a href="#">sock.endchar</a> <sup>[479]</sup>

---

### Details

Each inband message starts with "EC OC", where "EC" is the escape character defined by the sock.escchar property and "OC" is any character other than "EC". With inband commands enabled, data characters with code matching that of the escape character is transmitted as "EC EC" (that is, two identical characters are needed to transmit a single data character with code matching that of escape character).

This property is irrelevant when inband commands are disabled ([sock.inbandcommands](#)<sup>[484]</sup>= 0- NO). The program won't be able to change the value of this property when the socket is not idle ([sock.statesimple](#)<sup>[505]</sup><> 0- PL\_SSTS\_CLOSED).

### .Event R/O Property (Obsolete)

This property is no longer available. Instead, the [on\\_sock\\_event](#)<sup>[490]</sup> property has a newstate argument that carries the state of the socket at the time of event generation.

### .Eventsimple R/O Property (Obsolete)

This property is no longer available. Instead, the [on\\_sock\\_event](#)<sup>[490]</sup> property has a newstatesimple argument that carries the simplified state of the socket at the time of event generation.

### .GetData Method

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the string that contains the data extracted from the RX buffer.
<b>Syntax:</b>	<b>ser.getdata(maxinplen as word) as string</b>
<b>Returns:</b>	String containing data extracted from the RX buffer
<b>See Also:</b>	

Part	Description
maxinplen	Maximum amount of data to return (word).

#### Details

Extracted data is permanently deleted from the buffer. Length of extracted data is limited by one of the three factors (whichever is smaller): amount of data in the RX buffer itself, capacity of the "receiving" string variable, and the limit set by the maxinplen argument.

Additionally, if this socket uses UDP transport protocol ([sock.protocol](#)<sup>[492]</sup>= 1-PL\_SOCKET\_PROTOCOL\_TCP) the length of data that will be extracted is limited to the UDP datagram being processed. Additional conditions apply to UDP datagram processing; see [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event and [sock.nextpacket](#)<sup>[487]</sup> method.

### .Gethttprqstring Method

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) extracts up to 255 bytes of the HTTP request string from the VAR buffer.
<b>Syntax:</b>	<b>ser.gethttprqstring(maxinplen as word) as string</b>
<b>Returns:</b>	String containing data extracted from the VAR buffer.
<b>See Also:</b>	<a href="#">Working with HTTP Variables</a> <sup>[469]</sup> , <a href="#">Sock.httprqstring</a> <sup>[483]</sup>

Part	Description
maxinplen	Maximum amount of data to return (word).

### Details

Extracted data is permanently deleted from the VAR buffer. VAR buffer contents are explained in [Details on Variable Data](#)<sup>[473]</sup>.

Length of extracted data is limited by one of the three factors (whichever is smaller): amount of data in the buffer itself, capacity of the "receiving" string variable, and the limit set by the maxinplen argument.

This method is only relevant when the socket is in the HTTP mode ([sock.httpmode](#)<sup>[481]</sup> = 1- YES). Use it from within an HTML page or [on\\_sock\\_postdata](#)<sup>[491]</sup> event handler.

## **.Getinband Method**

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the string that contains the data extracted from the CMD buffer.
<b>Syntax:</b>	<b>sock.getinband as string</b>
<b>Returns:</b>	String containing data from the CMD buffer
<b>See Also:</b>	

Part	Description
------	-------------

### Details

The CMD buffer is the buffer that accumulates inband commands. Extracted data is permanently deleted from the CMD buffer. Length of extracted data is limited by one of the two factors (whichever is smaller): amount of data in the CMD buffer itself, and the capacity of the "receiving" buffer variable. Several inband commands may be waiting in the CMD buffer. Each command will always be complete, i.e. there will be no situation when you will extract a portion of the command because the end of this command hasn't arrived yet. Inband commands stored in the CMD buffer will have escape character (see [sock.escchar](#)<sup>[479]</sup> property) and the character after the escape character already cut off, but the end character (see [sock.endchar](#)<sup>[479]</sup> property) will still be present. Therefore, your application can separate inband command from each other by finding the end characters.

## **.Httpmode Property**

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) specifies whether this socket is in the HTTP mode.
------------------	---

---

<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO <b>(default)</b> : "regular" TCP connection. 1- YES: - HTTP connection.
<b>See Also:</b>	---

---

### Details

This property is irrelevant when the [sock.protocol](#)<sup>[492]</sup>= PL SOCK\_PROTOCOL\_UDP (UDP). If you do not set this property directly, its value will be:

0- NO: for all outgoing connections (active opens) of the socket.

0- NO: for incoming connections received on one of the ports from the [sock.localportlist](#)<sup>[486]</sup> list.

1- YES: for incoming connections received on one of the ports from the [sock.httpportlist](#)<sup>[483]</sup> list.

You can manually switch any TCP connection at any time after it has been established from "regular" to HTTP by setting sock.httpmode= 1. However, this operation is "sticky"- once you have converted the TCP connection into the HTTP mode you cannot convert it back into the regular mode- trying to set sock.httpmode=0 won't have any effect- the TCP connection will remain in the HTTP mode until this connection is closed.

## **.Httpnoclose Property**

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) sets/returns whether TCP HTTP connection will be kept opened after the HTTP request has been processed and the HTML page has been sent out
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO <b>(default)</b> : connection will be closed (standard HTML server behavior) 1- YES: will be kept opened, special string will be used as a separator.
<b>See Also:</b>	---

---

### Details

Normally, the end of HTML output is indicated by closing the TCP connection. When this property is set to 1- YES, connection is not closed at the end of HTML output. As a substitute, the end of HTML page output is marked by the following string: "<tibbo\_linkserver\_http\_proxy\_end\_of\_output>".

## .Httpportlist Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) sets/returns the list of listening ports on any of which this socket will accept an incoming HTTP connection.
<b>Type:</b>	String
<b>Value Range:</b>	0-32 characters, <b>default</b> = ""
<b>See Also:</b>	<a href="#">sock.localport</a> <sup>[485]</sup> , <a href="#">sock.httpmode</a> <sup>[481]</sup>

### Details

This property is only relevant when incoming connections are allowed by the [sock.inconmode](#)<sup>[485]</sup> property and the the [sock.protocol](#)<sup>[492]</sup>= 1- PL\_SOCKET\_PROTOCOL\_TCP (HTML output cannot be done through the UDP).

This property is of string type and the list of ports is a comma-separated string, i.e. "80,81" (to accept HTTP connections on either port 80 or 81). Max string length for this property is 32 bytes.

Notice, that there is also the [sock.localportlist](#)<sup>[486]</sup> property that defines a list of listening ports for UDP and non-HTTP TCP connections. When a particular port is listed both under the [sock.localportlist](#) and the [sock.httpportlist](#), and the protocol for this socket is TCP then [sock.httpportlist](#) has precedence (incoming TCP connection on the port in question will be interpreted as HTTP).

For example, if the [sock.httpportlist](#)= "80,81", the [sock.localportlist](#)="3000,80", the [sock.protocol](#)= 1- PL\_SOCKET\_PROTOCOL\_TCP, and there is an incoming TCP connection request on port 80 then this connection will be interpreted as HTTP one.

## .Httprqstring R/O Property

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns up to 255 bytes of the HTTP request string stored in the VAR buffer.
<b>Type:</b>	String
<b>Value Range:</b>	<b>Default</b> = ""
<b>See Also:</b>	<a href="#">Sock.varbuffrq</a> <sup>[511]</sup>

### Details

The [sock.httprqstring](#) is a property; it can be invoked several times and will return the same data (when this property is used the data is not deleted from the VAR buffer). VAR buffer contents are explained in [Details on Variable Data](#)<sup>[473]</sup>.

This property is only relevant when the socket is in the HTTP mode ([sock.httpmode](#)<sup>[481]</sup>= 1- YES). Use it from within an HTML page or [on sock\\_postdata](#)<sup>[491]</sup> event handler. Maximum length of data that can be obtained through this property is 255

bytes, since this is the maximum possible capacity of a string variable that will accept the value of the sock.httprqstring.

HTTP requests can be much longer than 255 bytes and can even include entire files being uploaded from the client to your device. Rely on the on\_sock\_postdata event and the [sock.gethttprqstring](#)<sup>[480]</sup> method to handle large amounts of HTTP variable data correctly.

- If you are using the sock.httprqstring, and if the client sends more data than can fit in the VAR buffer, the execution of the HTTP request will be stalled indefinitely. To avoid this, reply on the on\_sock\_postdata event and the sock.gethttprqstring method, as explained in [Complex Case \(Large Amount of Variable Data\)](#)<sup>[471]</sup>.

## .Inbandcommands Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) specifies whether inband command passing is allowed.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO <b>(default)</b> : inband commands are not allowed. 1- YES: inband commands are allowed.
<b>See Also:</b>	---

---

### Details

Inband commands are messages passed within the TCP data stream. Each message has to be formatted in a specific way- see the [sock.escchar](#)<sup>[479]</sup> and [sock.endchar](#)<sup>[479]</sup> properties.

Inband commands are not possible for UDP communications so this setting is irrelevant when the [sock.protocol](#)<sup>[492]</sup>= 1- PL\_SOCKET\_PROTOCOL\_UDP. Inband messaging will work even when redirection (buffer shorting) is enabled for the socket (see the [sock.redir](#)<sup>[493]</sup> method). The program won't be able to change the value of this property when the socket is not idle ([sock.statesimple](#)<sup>[505]</sup><> 0- PL\_SSTS\_CLOSED).

## .Inconenabledmaster Property

<b>Function:</b>	A master switch that globally disables incoming connection acceptance on all sockets, irregardless of each socket's individual setup.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO: No socket will be allowed to accept an incoming connection. 1- YES <b>(default)</b> : Incoming connections are globally enabled. Individual socket's behavior and whether it will accept or reject a particular incoming connection depends

on the setup of this socket.

**See Also:** [sock.inconmode](#)<sup>[485]</sup>, [sock.localportlist](#)<sup>[486]</sup>, [sock.httpportlist](#)<sup>[483]</sup>

### Details

This property can be used to temporarily disable incoming connection acceptance on all sockets without changing individual setup of each socket.

## **.Inconmode Property**

**Function:** For the currently selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) specifies whether incoming connections (passive opens) will be accepted and, if yes, from which sources.

**Type:** Enum (pl\_sock\_inconmode, byte)

**Value Range:**

- 0- PL\_SOCKET\_INCONMODE\_NONE (**default**): The socket does not accept any incoming connections.
- 1- PL\_SOCKET\_INCONMODE\_SPECIFIC\_IPPORT: The socket will only accept an incoming connection from specific IP (matching [sock.targetip](#)<sup>[506]</sup>) and specific port (matching [sock.targetport](#)<sup>[507]</sup>)
- 2- PL\_SOCKET\_INCONMODE\_SPECIFIC\_IP\_ANY\_PORT: The socket will only accept an incoming connection from specific IP (matching sock.targetip), but any port.
- 3- PL\_SOCKET\_INCONMODE\_ANY\_IP\_ANY\_PORT: The socket will accept an incoming connection from any IP and any port.

**See Also:** [sock.reconmode](#)<sup>[492]</sup>, [sock.localportlist](#)<sup>[486]</sup>, [sock.httpportlist](#)<sup>[483]</sup>

### Details

---

## **.Localport R/O Property**

**Function:** For the currently selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) returns current local port of the socket.

**Type:** Word

**Value Range:** 0-65535, default= 0

**See Also:** ---

### Details

Your application cannot set the local port directly. Instead, a list of ports on which the socket is allowed to accept an incoming connection (passive open) is supplied via the [sock.localportlist](#)<sup>[486]</sup> and [sock.httpportlist](#)<sup>[483]</sup> properties.

An incoming connection is accepted on any port from those two lists. The sock.localport property reflects current or the most recent local port on which connection was accepted.

## **.Localportlist Property**

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) sets/returns the list of listening ports on any of which this socket will accept an incoming UDP or TCP connection.
<b>Type:</b>	String
<b>Value Range:</b>	0-32 characters, <b>default</b> = ""
<b>See Also:</b>	<a href="#">sock.localport</a> <sup>[485]</sup>

---

### Details

The socket will only accept an incoming connection when such connections are allowed by the [sock.inconmode](#)<sup>[485]</sup> property. Whether the socket will accept UDP or TCP connections is defined by the [sock.protocol](#)<sup>[492]</sup> property. Additionally, the [sock.allowedinterfaces](#)<sup>[474]</sup> property defines network interfaces on which the socket will accept an incoming connection.

This property is of string type and the list of ports is a comma-separated string, i.e. "1001,3000" (to accept connections on either port 1001 or 3000). Max string length for this property is 32 bytes. Notice, that there is also a [sock.httpportlist](#)<sup>[483]</sup> property that defines a list of listening ports for HTTP TCP connections.

## **.Newtxlen R/O Property**

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the amount of uncommitted TX data in bytes.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default</b> = 0 (0 bytes)
<b>See Also:</b>	---

---

### Details

Uncommitted data is the one that was added to the TX buffer with the

[sock.setdata](#)<sup>[500]</sup> method but not yet committed using the [sock.send](#)<sup>[500]</sup> method.

## .Nextpacket Method

**Function:** For the selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) in the UDP mode ([sock.protocol](#)<sup>[492]</sup>= 0-PL\_SOCKET\_PROTOCOL\_UDP) closes processing of current UDP datagram and moves to the next datagram.

**Syntax:** **sock.nextpacket**

**Returns:** ---

**See Also:** ---

### Details

For UDP, the [sock.getdata](#)<sup>[486]</sup> method only extracts the data from a single UDP datagram even if several datagrams are stored in the RX buffer. When incoming UDP datagram processing is based on the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event the use of the sock.nextpacket method is not required since each invocation of the on\_sock\_data\_arrival event handler "moves" processing to the next UDP datagram.

The method is useful when it is necessary to move to the next datagram without re-entering on\_sock\_data\_arrival event handler. Therefore, sock.nextpacket is only necessary when the application needs to process several incoming UDP packets at once and within a single event handler.

## .Notifysent Method

**Function:** Using this method for the selected socket (selection is made through sock.num) will cause the [on\\_sock\\_data\\_sent](#)<sup>[489]</sup> event to be generated when the amount of committed data in the TX buffer is found to be below "threshold" number of bytes.

**Syntax:** **notifysent(threshold as word)**

**Returns:** ---

**See Also:**

Part	Description
threshold	Amount of bytes in the TX buffer below which the event it so be generated.

### Details

Only one on\_sock\_data\_sent event will be generated each time after the sock.notifysent is invoked. This method, together with the on\_sock\_data\_sent event provides a way to handle data sending asynchronously.

Just like with [sock.txfree](#)<sup>[510]</sup>, the trigger you set won't take into account any

uncommitted data in the TX buffer.

## .Num Property

<b>Function:</b>	Sets/returns the number of currently selected socket.
<b>Type:</b>	Byte
<b>Value Range:</b>	The value of this property won't exceed <a href="#">sock.numofsock</a> <sup>[488]</sup> -1 (even if you attempt to set higher value). <b>Default</b> = 0 (socket #0 selected).
<b>See Also:</b>	---

---

### Details

Sockets are enumerated from 0. Most other properties and methods of this object relate to the socket selected through this property. Note that socket-related events such as [on\\_sock\\_data\\_arrival](#)<sup>[488]</sup> change currently selected socket!

## .Numofsock R/O Property

<b>Function:</b>	Returns total number of sockets available on the current platform.
<b>Type:</b>	Byte
<b>Value Range:</b>	platform-dependent
<b>See Also:</b>	<a href="#">sock.num</a> <sup>[488]</sup>

---

### Details

---

## .Outputport Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) sets/returns the number of the port that will be used by the socket to establish outgoing connections.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default</b> = 0
<b>See Also:</b>	---

---

## Details

If this property is set to 0 then the socket will use "automatic" port numbers: for the first connection since the powerup the port number will be selected randomly, for all subsequent outgoing connections the port number will increase by one. Actual local port of a connection can be queried through the [sock.localport](#)<sup>[485]</sup> read-only property.

If this property is not at zero then the port it specifies will be used for all outgoing connections from this socket.

## On\_sock\_data\_arrival Event

**Function:** Generated when at least one data byte is present in the RX buffer of the socket (i.e. for this socket the [sock.rxlens](#)<sup>[499]</sup>>0).

**Declaration:** `on_sock_data_arrival`

**See Also:** [sock.nextudpdatagram](#)<sup>[487]</sup>

## Details

When the event handler for this event is entered the [sock.num](#)<sup>[488]</sup> property is automatically switched to the socket for which this event was generated. Another [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event on a particular socket is never generated until the previous one is processed.

Use the [sock.getdata](#)<sup>[480]</sup> method to extract the data from the RX buffer.

For TCP protocol ([sock.protocol](#)<sup>[492]</sup>= 1- PL\_SOCKET\_PROTOCOL\_TCP), there is no separation into individual packets and you get all arriving data as a "stream". You don't have to process all data in the RX buffer at once. If you exit the `on_sock_data_arrival` event handler while there is still some unprocessed data in the RX buffer another `on_sock_data_arrival` event will be generated immediately.

For UDP protocol ([sock.protocol](#)= 0- PL\_SOCKET\_PROTOCOL\_UDP), the RX buffer preserves datagram boundaries. Each time you enter the `on_sock_data_arrival` event handler you get to process next UDP datagram. If you do not process entire datagram contents the unread portion of the datagram is discarded once you exit the event handler.

This event is not generated for a particular socket when buffer redirection is set for this socket through the [sock.redir](#)<sup>[493]</sup> method.

## On\_sock\_data\_sent Event

**Function:** Generated after the total amount of *committed* data in the TX buffer of the socket (`sock.txlen`) is found to be less than the threshold that was preset through the [sock.notifysent](#)<sup>[487]</sup> method.

**Declaration:** `on_sock_data_sent`

**See Also:** ---

### Details

To cause generation of the `on_sock_data_sent` event, the application needs to use `sock.notifysent` each time. When the event handler is entered the `sock.num`<sup>[488]</sup> is automatically switched to the socket on which this event was generated.

Please, remember that uncommitted data in the TX buffer is not taken into account for `on_sock_data_sent` event generation.

## On\_sock\_event Event

**Function:** Notifies your program that the socket state has changed.

**Declaration:** `on_sock_event(newstate as pl_sock_state, newstatesimple as pl_sock_state_simple)`

**See Also:** ---

Part	Description
<code>newstate</code>	"Detailed" state of the socket at the time of event generation.
<code>newstatesimple</code>	"Simplified" state of the socket at the time of event generation.

### Details

The `newstate` and `newstatesimple` arguments carry the state as it was at the moment of event generation. This is different from `sock.state`<sup>[502]</sup> and `sock.statesimple`<sup>[505]</sup> R/O properties that return *current* socket state). The `newstate` argument uses the same set of constants as the `sock.state`. The `newstatesimple` argument uses the same set of constants as the `sock.statesimple`. See `sock.state`<sup>[502]</sup> and `sock.statesimple`<sup>[505]</sup> for detailed description of reported socket states.

`Newstate` and `Newstatesimple` arguments of the `on_sock_event` have been introduced in the Tibbo Basic release **2.0**. They replace `sock.event`<sup>[480]</sup> and `sock.eventsimple`<sup>[480]</sup> R/O properties which are no longer available.

## On\_sock\_inband Event

**Function:** At least one data byte is present in the CMD buffer (`sock.cmdlen`<sup>[477]</sup>>0).

**Declaration:** `on_sock_inband`

**See Also:** ---

### Details

Use the `sock.getinband`<sup>[481]</sup> method to extract the data from the CMD buffer. Another `on_inband_command` event on a particular socket is never generated until

the previous one is processed. When the event handler is entered the `sock.num` is automatically switched to the socket on which this event was generated.

## On\_sock\_overrun Event

<b>Function:</b>	Data overrun has occurred in the RX buffer of the socket.
<b>Declaration:</b>	<code>on_sock_overrun</code>
<b>See Also:</b>	---

---

### Details

Normally, overruns can only happen for UDP communications as UDP has no "data flow control" and, hence, data overruns are normal. Another `on_sock_overrun` event on a particular socket is never generated until the previous one is processed. When the event handler for this event is entered the [`sock.num`](#)<sup>[488]</sup> is automatically switched to the socket on which this event was generated.

## On\_sock\_postdata

<b>Function:</b>	Generated when at least one data byte is present in the VAR buffer of the socket, but only after the VAR buffer has become full at least once in the cause of the current HTTP request processing.
<b>Declaration:</b>	<code>on_sock_postdata</code>
<b>See Also:</b>	<a href="#"><code>Sock.varbuffrq</code></a> <sup>[511]</sup>

---

### Details

HTTP requests can contain large amount of HTTP variable data, which is stored into the VAR buffer. The amount of such data can exceed the VAR buffer capacity. If this is not handled properly, the HTTP request execution may stall indefinitely -- see [Working with HTTP Variables](#)<sup>[469]</sup>.

After the socket accepts an HTTP connection, this event is not generated (for this particular connection) until the VAR buffer becomes full. Once this happened, the event is generated even if there is a single byte waiting to be processed in the buffer. Two same-socket `on_sock_postdata` events never wait in the queue -- the next event can only be generated after the previous one is processed.

When the event handler for this event is entered the [`sock.num`](#)<sup>[488]</sup> property is automatically switched to the socket for which this event was generated.

Use the [`sock.gethttpprqstring`](#)<sup>[480]</sup> method or [`sock.httpprqstring`](#)<sup>[483]</sup> property to work with the VAR buffer's data.

## On\_sock\_tcp\_packet\_arrival Event

<b>Function:</b>	Notifies your program that the TCP packet of a certain size has arrived.
------------------	--

**Syntax:** `on_sock_tcp_packet_arrival(len as word)`

**See Also:** ["Split Packet" Mode of TCP Data Processing](#)<sup>[453]</sup>

Part	Description
len	Length of the new data in the RXed TCP packet.

### Details

This event is only generated when [sock.splittcppackets](#)<sup>[501]</sup>= 1- YES and [sock.inbandcommands](#)<sup>[484]</sup>= 0- DISABLED. Notice that only new data, never transmitted before, is counted. If the packet is a retransmission then this event won't be generated. Also, if some part of packet's data is a retransmission and some part is new then only the length of the new data will be reported. This way your program can maintain correct relationship between data lengths reported by this event and actual data in the RX buffer.

The `on_sock_tcp_packet_arrival` event is always generated before the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> for any incoming TCP data (packet).

## .Protocol Property

**Function:** For the currently selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) selects the transport protocol.

**Type:** Enum (pl\_sock\_protocol, byte)

**Value Range:** 0- PL\_SOCKET\_PROTOCOL\_UDP (**default**): UDP transport protocol.  
1- PL\_SOCKET\_PROTOCOL\_TCP: TCP transport protocol.

**See Also:** ---

### Details

Notice, that there is no "HTTP" selection, as HTTP is not a transport protocol (TCP is the transport protocol required by the HTTP). You make the socket accept HTTP connections by specifying the list of HTTP listening ports using the [sock.httpportlist](#)<sup>[483]</sup> property or using the [sock.httpmode](#)<sup>[481]</sup> property.

The program won't be able to change the value of this property when the socket is not idle ([sock.statesimple](#)<sup>[505]</sup><> 0- PL\_SSTS\_CLOSED).

## .Reconmode Property

**Function:** For the currently selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) whether the socket accepts reconnects, and, if yes, from which sources.

**Type:** Enum (pl\_sock\_reconmode, byte)

**Value Range:** 0- PL\_SOCKET\_RECONMODE\_0 (default): For UDP: Reconnects accepted only from the same IP as the one

already engaged in the current connection with this socket, but any port; port switchover will not happen. TCP: reconnects are not accepted at all.

1- PL\_SOCK\_RECONMODE\_1: For UDP: Reconnects accepted from any IP, any port; port switchover will not happen. TCP: reconnects accepted only from the same IP and port as the ones already engaged in the current connection with this socket.

2- PL\_SOCK\_RECONMODE\_2: For UDP: Reconnects accepted only from the same IP as the one already engaged in the current connection with this socket, but any port; port switchover will happen. TCP: reconnects accepted only from the same IP as the one already engaged in the current connection with this socket, but any port.

3- PL\_SOCK\_RECONMODE\_3: For UDP: Reconnects accepted from any IP, any port; port switchover will happen. TCP: reconnects accepted from any IP, any port.

**See Also:** ---

---

## Details

Reconnect situation is when a passive open and resulting connection replace, for the same socket, the connection that was already in progress. For UDP, this property additionally defines whether a "port switchover" will occur as a result of an incoming connection (passive open) or a reconnect. Port switchover is when the socket starts sending its outgoing UDP datagrams to the port from which the most recent UDP datagram was received, rather than the port specified by the [sock.targetport](#)<sup>[507]</sup> property.

DO NOT enable reconnects on sockets that are used to handle HTML requests. This will interfere with HTML operation, as explained in the [Understanding TCP Reconnects](#)<sup>[428]</sup> topic.

## **.Redir Method**

**Function:** For the selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) redirects the data being RXed to the TX buffer of the same socket, different socket, or another object that supports compatible buffers.

**Syntax:** **sock.redir(redir as pl\_redir) as pl\_redir**

**Returns:** Returns 0- PL\_REDIR\_NONE if redirection failed or the same value as was passed in the redir argument.

**See Also:**

---

Part	Description
------	-------------

redir Platform-specific. See the list of pl\_redir constants in the platform specifications.

### Details

Data redirection (sometimes referred to as "buffer shorting") allows to arrange efficient data exchange between ports, sockets, etc. in cases where no data alteration or parsing is necessary, while achieving maximum possible throughput is important.

The redir argument, as well as the value returned by this method are of "enum pl\_redir" type. The pl\_redir defines a set of platform inter-object constants that include all possible redirections for this platform. Specifying redir value of 0-PL\_REDIR\_NONE cancels redirection. When the redirection is enabled for a particular socket, the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event is not generated for this port.

Once the RX buffer is redirected certain properties and methods related to the RX buffer will actually return the data for the TX buffer to which this RX buffer was redirected:

- [sock.rxbuffsize](#)<sup>[498]</sup> will actually be returning the size of the TX buffer.
- [sock.rxclear](#)<sup>[498]</sup> method will actually be clearing the TX buffer.
- [sock.rxlent](#)<sup>[499]</sup> method will be showing the amount of data in the TX buffer.

## **.Remoteip R/O Property**

**Function:** For the currently selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) returns the IP address of the host with which this socket had the most recent or currently has a connection.

**Type:** String

**Value Range:** **Default=** "0.0.0.0"

**See Also:** [sock.remotemac](#)<sup>[495]</sup>, [sock.remoteport](#)<sup>[495]</sup>, [sock.bcast](#)<sup>[475]</sup>

### Details

The application cannot directly change this property, it can only specify the target IP address for active opens through the [sock.targetip](#)<sup>[506]</sup> property.

For UDP connections, when the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event handler is entered, the sock.remoteip will contain the IP address of the sender of the current datagram being processed. Outside of the on\_sock\_data\_arrival event handler, the property will return the source IP address of the most recent datagram received by the socket.

## .Remotemac R/O Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the MAC address of the host with which this socket had the most recent or currently has a connection.
<b>Type:</b>	String
<b>Value Range:</b>	<b>Default=</b> "0.0.0.0.0.0"
<b>See Also:</b>	<a href="#">sock.remoteip</a> <sup>[494]</sup> , <a href="#">sock.remoteport</a> <sup>[495]</sup> , <a href="#">sock.bcast</a> <sup>[475]</sup>

### Details

For UDP connections, when the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event handler is entered, the sock.remotemac will contain the MAC address of the sender of the current UDP datagram being processed. Outside of the on\_sock\_data\_arrival event handler, the property will return the source MAC address of the most recent datagram received by the socket.

## .Remoteport R/O Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the port number of the host with which this socket had the most recent or currently has a connection.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default=</b> 0
<b>See Also:</b>	<a href="#">sock.remotemac</a> <sup>[495]</sup> , <a href="#">sock.remoteip</a> <sup>[494]</sup> , <a href="#">sock.bcast</a> <sup>[475]</sup>

### Details

The application cannot directly change this property, it can only specify the target port for active opens through the [sock.targetport](#)<sup>[507]</sup> property.

For UDP connections, when the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event handler is entered, the sock.remoteport will contain the port number of the sender of the current datagram being processed. Outside of the on\_sock\_data\_arrival event handler, the property will return the source port of the most recent datagram received by the socket.

## .Reset Method

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) causes the socket to abort the connection with the other host.
------------------	---

**Syntax:** `sock.reset`

**Returns:** ---

**See Also:** [sock.close](#)<sup>[475]</sup>

### Details

For TCP connections that were established, being opened, or being closed this will be a reset (RST will be sent to the other end of the connection). If connection was in the ARP phase or the transport protocol was UDP ([sock.protocol](#)<sup>[492]</sup>= 0- PL\_SOCK\_PROTOCOL\_UDP) the connection will be discarded (just like when the [sock.discard](#)<sup>[478]</sup> method is used).

Method invocation will have NO effect if connection was closed at the time when the method was called ([sock.state](#)<sup>[502]</sup> in one of PL\_SST\_CLOSED states).

This method will be ignored when called from within an HTML page. HTML sockets are handled automatically and your application is not at freedom to reset HTML sockets arbitrarily.

## **.Rplbuffrq Method**

**Function:** For the selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) pre-requests "numpages" number of buffer pages (1 page= 256 bytes) for the RPL buffer of the socket.

**Syntax:** `sock.cmdbuffrq(numpages as byte) as byte`

**Returns:** Actual number of pages that can be allocated (Byte).

**See Also:** [sock.cmdbuffrq](#)<sup>[476]</sup>

Part	Description
numpages	Requested numbers of buffer pages to allocate.

### Details

The RPL buffer is the the buffer that stores outgoing inband replies (messages). Actual allocation happens when the [sys.buffalloc](#)<sup>[530]</sup> method is used. The socket is unable to send inband replies if its RPL buffer has 0 capacity.

Unlike for TX or RX buffers there is no property to read out actual RPL buffer capacity in bytes. This capacity can be calculated as num\_pages\*256-16 (or =0 when num\_pages=0), where "num\_pages" is the number of buffer pages that was GRANTED through the sock.rplbuffrq. "-16" is because 16 bytes are needed for internal buffer variables.

Buffer allocation will not work if the socket port to which this buffer belongs is not idle ([sock.statesimple](#)<sup>[505]</sup> is not at 0- PL\_SSTS\_CLOSED) at the time when sys.buffalloc executes. You can only change buffer sizes of sockets that are idle.

The RPL buffer is only required when inband commands are enabled ([sock.inbandcommands](#)<sup>[484]</sup>= 1- YES).

## .Rplfree R/O Property

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the free space (in bytes) available in the RPL buffer
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default</b> = 0 (0 bytes)
<b>See Also:</b>	<a href="#">sock.cmdlen</a> <sup>[477]</sup> , <a href="#">sock.rpllen</a> <sup>[497]</sup> , <a href="#">sock.inbandcommands</a> <sup>[484]</sup>

---

### Details

The RPL buffer is the buffer that keeps outgoing inband replies (messages). Your application adds inband replies to the RPL buffer with the [sock.setsendinband](#)<sup>[500]</sup> method. Several inband replies may be waiting in the RPL buffer.

## .Rpllen R/O Property

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the length of data (in bytes) waiting to be send out from the RPL buffer.
<b>Type:</b>	Word
<b>Value Range:</b>	
<b>See Also:</b>	<a href="#">sock.cmdlen</a> <sup>[477]</sup> , <a href="#">sock.rplfree</a> <sup>[497]</sup> , <a href="#">sock.inbandcommands</a> <sup>[484]</sup>

---

### Details

Your application adds inband replies to the RPL buffer with the [sock.setsendinband](#)<sup>[500]</sup> method. Several inband replies may be waiting in the RPL buffer.

## .Rxbufferq Method

<b>Function:</b>	For the selected socket (selection is made through sock.num) pre-requests "numpages" number of buffer pages (1 page= 256 bytes) for the RX buffer of the socket.
<b>Syntax:</b>	<b>sock.rxbufferq(numpages as byte) as byte</b>
<b>Returns:</b>	Actual number of pages that can be allocated (Byte).
<b>See Also:</b>	<a href="#">sock.txbufferq</a> <sup>[509]</sup>

Part	Description
numpages	Requested numbers of buffer pages to allocate.

### Details

Returns actual number of pages that can be allocated. Actual allocation happens when the [sys.buffalloc](#)<sup>[530]</sup> method is used. The socket is unable to RX data if its RX buffer has 0 capacity. Actual current buffer capacity can be checked through the [sock.rxbuffsize](#)<sup>[498]</sup> which returns buffer capacity in bytes.

Relationship between the two is as follows:  $\text{sock.rxbuffsize} = \text{num\_pages} * 256 - 16$  (or  $=0$  when  $\text{num\_pages} = 0$ ), where "num\_pages" is the number of buffer pages that was GRANTED through the [sock.rxbuffrq](#). "- 16" is because 16 bytes are needed for internal buffer variables.

Buffer allocation will not work if the socket port to which this buffer belongs is not idle ([sock.statesimple](#)<sup>[505]</sup> is not at 0- PL\_SSTS\_CLOSED) at the time when [sys.buffalloc](#) executes. You can only change buffer sizes of sockets that are idle.

## **.Rxbuffsize R/O Property**

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns current RX buffer capacity in bytes.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535
<b>See Also:</b>	---

### Details

Buffer capacity can be changed through the [sock.rxbuffrq](#)<sup>[497]</sup>. The [sock.rxbuffrq](#) requests buffer size in 256-byte pages whereas this property returns buffer size in bytes.

Relationship between the two is as follows:  $\text{sock.rxbuffsize} = \text{num\_pages} * 256 - 16$  (or  $=0$  when  $\text{num\_pages} = 0$ ), where "num\_pages" is the number of buffer pages that was GRANTED through the [sock.rxbuffrq](#). "- 16" is because 16 bytes are needed for internal buffer variables. The socket cannot RX data when the RX buffer has zero capacity.

## **.Rxclear Method**

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) clears (deletes all data from) the RX buffer.
<b>Syntax:</b>	<b>sock.rxclear</b>
<b>Returns:</b>	---

**See Also:** ---

---

### Details

Invoking this method will have no effect when the socket is in the HTTP mode ([sock.httpmode](#)<sup>[487]</sup>= 1- YES).

## **.Rxpacketlen R/O Property**

**Function:** For the selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) returns the length (in bytes) of the UDP datagram being extracted from the RX buffer.

**Type:** Word

**Value Range:** 0-1536, **default**= 0

**See Also:** [sock.rhlen](#)<sup>[499]</sup>

---

### Details

This property is only relevant when the [sock.protocol](#)<sup>[492]</sup>= 1- PL\_SOCKET\_PROTOCOL\_TCP. Correct way of using this property is within the [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event or in conjunction with the [sock.nextpacket](#)<sup>[487]</sup> method.

## **.Rxlen R/O Property**

**Function:** For the selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) returns total number of bytes currently waiting in the RX buffer to be extracted and processed by your application.

**Type:** Word

**Value Range:** 0-65535, **default**= 0

**See Also:** ---

---

### Details

The [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event is generated once the RX buffer is not empty, i.e. there is data to process. There may be only one on\_ser\_data\_arrival event for each socket waiting to be processed in the event queue. Another on\_sock\_data\_arrival event for the same socket may be generated only after the previous one is handled.

If, during the on\_sock\_data\_arrival event handler execution, not all data is extracted from the RX buffer, another on\_sock\_data\_arrival event is generated immediately after the on\_sock\_data\_arrival event handler is exited.

## .Send Method

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) commits (allows sending) the data that was previously saved into the TX buffer using the <a href="#">sock.setdata</a> <sup>[500]</sup> method.
<b>Syntax:</b>	<b>sock.rxbuffrq</b>
<b>Returns:</b>	---
<b>See Also:</b>	---

### Details

You can monitor the sending progress by checking the [sock.txlen](#)<sup>[510]</sup> property or using the [sock.notifysent](#)<sup>[487]</sup> method and the [on sock data sent](#)<sup>[489]</sup> event.

## .Setdata Method

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) adds the data passed in the txdata argument to the contents of the TX buffer.
<b>Syntax:</b>	<b>ser.setdata(byref txdata as string)</b>
<b>Returns:</b>	---
<b>See Also:</b>	---

Part	Description
txdata	The data to send; this data will be added to the contents of the TX buffer.

### Details

If the buffer doesn't have enough space to accommodate the data being added then this data will be truncated. Newly saved data is not sent out immediately. This only happens after the [sock.send](#)<sup>[500]</sup> method is used to commit the data. This allows your application to prepare large amounts of data before sending it out.

Total amount of newly added (uncommitted) data in the buffer can be checked through the [sock.newtxlen](#)<sup>[486]</sup> setting.

## .Setsendinband Method

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) puts the data into the RPL buffer. This method also commits the data.
<b>Syntax:</b>	<b>sock.setsendinband(byref data as string)</b>

**Returns:** ---  
**See Also:** ---

Part	Description
data	The data to send (String).

### Details

This method is different from the TX buffer for which two separate methods- [sock.setdata](#)<sup>[500]</sup> and [sock.send](#)<sup>[500]</sup>- are used to store and commit the data. For the RPL buffer you store and commit the data with a single [sock.setsendinband](#) method.

It is the responsibility of your application to properly encapsulate outgoing messages with escape sequence ("EC OC", see the [sock.escchar](#)<sup>[479]</sup> property) and the end character (see the [sock.endchar](#)<sup>[479]</sup> property). When adding the data to the RPL buffer make sure you are adding entire inband message at once- you are not allowed to do this "in portions"!

## Sinkdata Property

**Function:** For the currently selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) specifies whether the incoming data should be discarded.

**Type:** Enum (yes\_no, byte)

**Value Range:** 0- NO (**default**): normal data processing.  
1- YES: discard incoming data.

**See Also:** [Sinking Data](#)<sup>[456]</sup>

### Details

Setting this property to 1- YES causes the socket to automatically discard all incoming data without passing it to your application. The [on\\_sock\\_data\\_arrival](#)<sup>[489]</sup> event will not be generated, reading [sock.rhlen](#)<sup>[499]</sup> will always return zero, and so on. No data will be reaching its destination even in case of [buffer redirection](#)<sup>[454]</sup>. [Inband commands](#)<sup>[456]</sup>, however, will still be extracted from the incoming data stream and processed. [Sock.connectiontout](#)<sup>[477]</sup> and [sock.toutcounter](#)<sup>[507]</sup> will work correctly as well.

## .Splittcp packets Property

**Function:** For the currently selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) specifies whether the program will have additional control over the size of TCP packets being received and transmitted.

**Type:** Enum (no\_yes, byte)

**Value Range:** 0- NO (**default**): regular processing of TCP data in which your program does not care about the size of individual TCP data packets being transmitted and received.  
1- YES: Additional features are enabled that allow your program to know the size of each incoming TCP packet and also control the size of each outgoing TCP packet.

**See Also:** ["Split Packet" Mode of TCP Data Processing](#)<sup>[453]</sup>

---

### Details

When this property is set to 1- YES your program gets an additional degree of control over TCP. For incoming TCP data, the program can know the size of individual incoming packets (this will be reported by the [on sock tcp packet arrival](#)<sup>[491]</sup> event).

For outgoing TCP data, no packet will be sent out at all unless entire contents of the TX buffer can be sent. Therefore, by executing [sock.send](#)<sup>[500]</sup> and waiting for [sock.txlen](#)<sup>[510]</sup>=0 your program can make sure that the packet sent will have exactly the size you needed.

The property is only relevant when the [sock.inbandcommands](#)<sup>[484]</sup>= 0- NO. With inband commands enabled, the socket will always behave as if the [sock.splittcppackets](#)= 0- NO. The program won't be able to change the value of this property when the socket is not idle ([sock.statesimple](#)<sup>[503]</sup><> 0- PL\_SSTS\_CLOSED).

Notice, that sending out TCP data and waiting for the [sock.txlen](#)<sup>[510]</sup>=0 significantly diminishes your TX data throughput. This is because each send will be waiting for the other end to confirm the reception of data.

Also, with [sock.splittcppackets](#)= 1= YES make sure that you are not sending more data than the size of the RX buffer on the other end. If this happens, no data will ever get through because your side will be waiting for the chance to send out all TX data at once, and the other end won't be able to receive this much data in one piece.

Also, attempting to send the packet with size exceeding the "maximum segment size" (MSS) as specified by the other end will lead to data fragmentation! The socket will never send any TCP packet with the amount of data exceeding MSS.

### **.State R/O Property**

**Function:** For the currently selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) returns "detailed" current socket state.

**Type:** Enum (pl\_sock\_state, byte)

**Value Range:** 0- PL\_SST\_CLOSED (**default**): Connection is closed (and haven't been opened yet, it is a post-powerup state). Applied both to UDP and TCP.  
1- PL\_SST\_CL\_PCLOSED: Connection is closed (it was a passive close). Applies only to TCP.  
2- PL\_SST\_CL\_ACLOSED: Connection is closed (it was an active close by the application). Applies only to TCP.

- 3- PL\_SST\_CL\_PRESET\_POPENING: Connection is closed (it was a passive reset during a passive open). Applies only to TCP.
- 4- PL\_SST\_CL\_PRESET\_AOPENING: Connection is closed (it was a passive reset during an active open). Applies only to TCP.
- 5- PL\_SST\_CL\_PRESET\_EST: Connection is closed (it was a passive reset while in "connection established" state). Applies only to TCP.
- 6- PL\_SST\_CL\_PRESET\_PCLOSING: Connection is closed (it was a passive reset while performing a passive close). Applies only to TCP.
- 7- PL\_SST\_CL\_PRESET\_ACLOSING: Connection is closed (it was a passive reset while performing an active close). Applies only to TCP.
- 8- PL\_SST\_CL\_PRESET\_STRANGE: Connection is closed (it was a passive reset, no further details available). Applies only to TCP.
- 9- PL\_SST\_CL\_ARESET\_CMD: Connection is closed (it was an active reset issued by the application). Applies only to TCP.
- 10- PL\_SST\_CL\_ARESET\_RE\_PO: Connection is closed (it was an active reset issued because of excessive retransmission attempts during a passive open). Applies only to TCP.
- 11- PL\_SST\_CL\_ARESET\_RE\_AO: Connection is closed (it was an active reset issued because of excessive retransmission attempts during an active open). Applies only to TCP.
- 12- PL\_SST\_CL\_ARESET\_RE\_EST: Connection is closed (it was an active reset issued because of excessive retransmission attempts while in "connection established" state). Applies only to TCP.
- 13- PL\_SST\_CL\_ARESET\_RE\_PCL: Connection is closed (it was an active reset issued because of excessive retransmission attempts during a passive close). Applies only to TCP.
- 14- PL\_SST\_CL\_ARESET\_RE\_AC: Connection is closed (it was an active reset issued because of excessive retransmission attempts during a passive open). Applies only to TCP.
- 15- PL\_SST\_CL\_ARESET\_TOUT: Connection is closed (it was an active reset caused by connection timeout, i.e. no data was exchanged for sock.connectiontimeout number of seconds). Applies only to TCP.
- 16- PL\_SST\_CL\_ARESET\_DERR: Connection is closed (it was an active reset caused by a data exchange error). Applies only to TCP.
- 17- PL\_SST\_CL\_DISCARDED\_CMD: Connection is closed (it was discarded by the application). Applies both to UDP and TCP.

18- PL\_SST\_CL\_DISCARDED\_PO\_WCS: Connection is closed (it was discarded because an error in connection sequence was detected during a passive open). Applies only to TCP.

19- PL\_SST\_CL\_DISCARDED\_AO\_WCS: Connection is closed (it was discarded because an error in connection sequence was detected during an active open). Applies only to TCP.

20- PL\_SST\_CL\_DISCARDED\_ARPFL: Connection is closed (it was discarded because the device has failed to resolve the IP address of the destination during an active open, i.e. there was no reply to ARP requests). Applies both to UDP and TCP.

21- PL\_SST\_CL\_DISCARDED\_TOUT: Connection is closed (it was discarded because connection has timed out, i.e. no data was exchanged for sock.connectiontout number of seconds). Applies only to UDP.

32- PL\_SST\_ARP: ARP resolution is an progress (it is an active open). Applied both to UDP and TCP.

64- PL\_SST\_PO: Connection is being established (it is a passive open). Applies only to TCP.

96- PL\_SST\_AO: Connection is being established (it is an active open). Applies only to TCP.

128- PL\_SST\_EST: Connection is established (generic, includes both passive and active open). Applies both to UDP and TCP.

128- PL\_SST\_EST\_POPENED: Connection is established (it was a passive open). Applies both to UDP and TCP.

129- PL\_SST\_EST\_AOPENED: Connection is established (it was an active open). Applies both to UDP and TCP.

160- PL\_SST\_PC: Connection is being closed (it is a passive close). Applies only to TCP.

192- PL\_SST\_AC: Connection is being closed (it is an active close). Applies only to TCP.

**See Also:** ---

---

### Details

This property tells the "detailed" current state of the socket, as opposed to the [sock.event](#)<sup>[480]</sup> property that returns the "detailed" state at the moment of the [on\\_sock\\_event](#)<sup>[490]</sup> event generation.

Another set of read-only properties- [sock.eventsimple](#)<sup>[480]</sup> and [sock.statesimple](#)<sup>[505]</sup>- return "simplified" socket states.

## .Statesimple R/O Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns "simplified" current socket state.
<b>Type:</b>	Enum (pl_sock_state_simple, byte)
<b>Value Range:</b>	0- PL_SSTS_CLOSED ( <b>default</b> ): Connection is closed. Applies both to UDP and TCP. 1- PL_SSTS_ARP: ARP resolution is an progress (it is an active open). Applies both to UDP and TCP. 2- PL_SSTS_PO: Connection is being established (it is a passive open). Applies only to TCP. 3- PL_SSTS_AO: Connection is being established (it is an active open). Applies only to TCP. 4- PL_SSTS_EST: Connection is established. Applies both to UDP and TCP. 5- PL_SSTS_PC: Connection is being closed (it is a passive close). Applies only to TCP. 6- PL_SSTS_AC: Connection is being closed (it is an active close). Applies only to TCP.
<b>See Also:</b>	---

---

### Details

This property tells the current "simplified" state of the socket, as opposed to the [sock.eventsimple](#)<sup>[480]</sup> property that returns the "simplified" state at the moment of the [on\\_sock\\_event](#)<sup>[490]</sup> event generation.

Another set of read-only properties- [sock.event](#)<sup>[480]</sup> and [sock.state](#)<sup>[502]</sup>- return "detailed" socket states.

## .Targetbcast Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) specifies whether this port will be sending its outgoing UDP datagrams as link-level broadcasts.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO: UDP datagrams will be sent as "normal" packets 1- YES: UDP datagrams will be sent out as link-level broadcast packets
<b>See Also:</b>	---

---

### Details

This property is only relevant for UDP communications ([sock.protocol](#)<sup>[492]</sup>= PL\_SOCK\_PROTOCOL\_UDP). When this property is set to 1- YES the socket will be

sending out all UDP datagrams as broadcasts and incoming datagrams won't cause port switchover, even if the latter is enabled through the [sock.reconmode](#)<sup>[492]</sup> property.

## .Targetinterface Property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) selects the network interface through which an outgoing network connection will be established.
<b>Type:</b>	Enum (pl_sock_interfaces, byte)
<b>Value Range:</b>	Platform-specific. See the list of pl_sock_interfaces constants in the platform specifications (for example, EM1000's is <a href="#">here</a> <sup>[143]</sup> ).
<b>See Also:</b>	<a href="#">Establishing Outgoing Connections</a> <sup>[434]</sup>

---

### Details

--

## .Targetip Property

<b>Function:</b>	For active opens on the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) specifies the target IP to which the socket will attempt to connect to. For passive opens specifies, in certain cases, the only IP address from which an incoming connection will be accepted.
<b>Type:</b>	String.
<b>Value Range:</b>	Any valid IP address, i.e. "192.168.100.40". Default="0.0.0.0"
<b>See Also:</b>	<a href="#">sock.targetport</a> <sup>[507]</sup> , <a href="#">sock.remoteport</a> <sup>[495]</sup>

---

### Details

For active opens, this property is only relevant at the moment of connection establishment.

For incoming connections, whether this property will matter or not is defined by the [sock.inconmode](#)<sup>[485]</sup> property. When the sock.inconmode= 1- PL\_SOCKET\_INCONMODE\_SPECIFIC\_IPPORT or 2- PL\_SOCKET\_INCONMODE\_SPECIFIC\_IP\_ANY\_PORT only the host with IP matching the one set in the sock.targetip property will be able to connect to the socket.

Current IP on the "other side" of the connection can always be checked through the [sock.remoteip](#)<sup>[494]</sup> read-only property.

## .Targetport Property

<b>Function:</b>	For active opens on the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) specifies the target port to which the socket will attempt to connect to. For passive opens specifies, in certain cases, the only port from which an incoming connection will be accepted.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default</b> = 0
<b>See Also:</b>	<a href="#">sock.targetip</a> <sup>[506]</sup> , <a href="#">sock.remoteip</a> <sup>[494]</sup>

---

### Details

For active opens, this property is only relevant at the moment of connection establishment.

For incoming connections, whether this property will matter or not is defined by the [sock.inconmode](#)<sup>[485]</sup> property. When the sock.inconmode= 1-PL\_SOCKET\_INCONMODE\_SPECIFIC\_IPPORT an incoming connection will only be accepted from the port matching the one set in the sock.targetport property.

Current port on the "other side" of the connection can always be checked through the [sock.remoteport](#)<sup>[495]</sup> read-only property.

## .Toutcounter R/O property

<b>Function:</b>	For the currently selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the time, in 0.5 second intervals, elapsed since the data was last send or received on this socket.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default</b> = 0
<b>See Also:</b>	<a href="#">Closing Connections</a> <sup>[437]</sup>

---

### Details

This property is reset to 0 each time there is some data exchanged across the socket connection. The property increments at 0.5 second intervals while no data is moving through this socket.

If the [sock.connectiontout](#)<sup>[477]</sup> is not at 0, this property increments until it reaches the value of the sock.connectiontout and the connection is terminated. The sock.toutcounter then stays at the value of sock.connectiontout.

If the sock.connectiontout is at 0, the maximum value that the sock.toutcounter can reach is 1. That is, the sock.toutcounter will be at 0 after the data exchange, and at 1 if at least 0.5 seconds have passed since the last data exchange.

## .Tx2buffrq Method

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) pre-requests "numpages" number of buffer pages (1 page= 256 bytes) for the TX2 buffer of the socket.
<b>Syntax:</b>	<b>sock.tx2buffrq(numpages as byte) as byte</b>
<b>Returns:</b>	Actual number of pages that can be allocated (Byte).
<b>See Also:</b>	<a href="#">sock.txbuffrq</a> <sup>[509]</sup>

Part	Description
numpages	Requested numbers of buffer pages to allocate.

### Details

The TX2 buffer is required when inband commands are enabled ([sock.inbandcommands](#)<sup>[484]</sup>= 1- YES), without it the socket won't be able to TX data. Returns actual number of pages that can be allocated. Actual allocation happens when the [sys.buffalloc](#)<sup>[530]</sup> method is used. Unlike for TX or RX buffers there is no property to read out actual TX2 buffer capacity in bytes. This capacity can be calculated as num\_pages\*256-16 (or =0 when num\_pages=0), where "num\_pages" is the number of buffer pages that was GRANTED through the sock.tx2buffrq. "-16" is because 16 bytes are needed for internal buffer variables.

Buffer allocation will not work if the socket port to which this buffer belongs is not idle ([sock.statesimple](#)<sup>[505]</sup> is not at 0- PL\_SSTS\_CLOSED) at the time when sys.buffalloc executes. You can only change buffer sizes of sockets that are idle.

## .Tx2len R/O Property

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the amount of data waiting to be sent out in the TX2 buffer.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default</b> = 0 (0 bytes)
<b>See Also:</b>	<a href="#">sock.txlen</a> <sup>[510]</sup>

### Details

The TX2 buffer is needed to transmit outgoing TCP data when inband commands (messages) are enabled ([sock.inbandcommands](#)<sup>[484]</sup>= 1- YES). If your application needs to make sure that all data is actually sent out from the socket then it must verify that both TX and TX2 buffers are empty.

## .Txbuffrq Method

- Function:** For the selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) pre-requests "numpages" number of buffer pages (1 page= 256 bytes) for the TX buffer of the socket.
- Syntax:** **sock.txbuffrq(numpages as byte) as byte**
- Returns:** Actual number of pages that can be allocated (Byte).
- See Also:** [sock.tx2buffrq](#)<sup>[508]</sup>

Part	Description
numpages	Requested numbers of buffer pages to allocate.

### Details

Actual allocation happens when the [sys.buffalloc](#)<sup>[530]</sup> method is used. The socket is unable to TX data if its TX buffer has 0 capacity. Actual current buffer capacity can be checked through the [sock.txbuffsize](#)<sup>[509]</sup> which returns buffer capacity in bytes. Relationship between the two is as follows:

sock.txbuffsize=num\_pages\*256-16 (or =0 when num\_pages=0), where "num\_pages" is the number of buffer pages that was GRANTED through the sock.txbuffrq. "-16" is because 16 bytes are needed for internal buffer variables.

Buffer allocation will not work if the socket port to which this buffer belongs is not idle ([sock.statesimple](#)<sup>[505]</sup> is not at 0- PL\_SSTS\_CLOSED) at the time when sys.buffalloc executes. You can only change buffer sizes of sockets that are idle.

## .Txbuffsize R/O Property

- Function:** For the currently selected socket (selection is made through [sock.num](#)<sup>[488]</sup>) returns current TX buffer capacity in bytes.
- Type:** Word
- Value Range:** 0-65535, **default**= 0 (0 bytes).
- See Also:** ---

### Details

Buffer capacity can be changed through the [sock.txbuffrq](#)<sup>[509]</sup> method followed by the [sys.buffalloc](#)<sup>[530]</sup> method.

The sock.txbuffrq requests buffer size in 256-byte pages whereas this property returns buffer size in bytes. Relationship between the two is as follows: sock.txbuffsize=num\_pages\*256-16 (or =0 when num\_pages=0), where "num\_pages" is the number of buffer pages that was GRANTED through the sock.txbuffrq. "-16" is because 16 bytes are needed for internal buffer variables.

The socket cannot TX data when the TX buffer has zero capacity.

## .Txclear Method

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) clears (deletes all data from) the TX buffer.
<b>Syntax:</b>	<b>sock.rxclear</b>
<b>Returns:</b>	---
<b>See Also:</b>	---

---

### Details

Invoking this method will have no effect when the socket is not closed ([sock.statesimple](#)<sup>[505]</sup><> 0- PL\_SSTS\_CLOSED).

## .Txfree R/O Property

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns the amount of free space in the TX buffer in bytes.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default</b> = 0 (0 bytes).
<b>See Also:</b>	---

---

### Details

Notice, that the amount of free space returned by this property does not take into account any uncommitted data that might reside in the buffer (this can be checked via [sock.newtxlen](#)<sup>[486]</sup>). Therefore, actual free space in the buffer is sock.txfree-sock.newtxlen. Your application will not be able to store more data than this amount.

To achieve asynchronous data processing, use the [sock.notifysent](#)<sup>[487]</sup> method to get [on\\_sock\\_data\\_sent](#)<sup>[489]</sup> event once the TX buffer gains required amount of free space.

## .Txlen R/O Property

<b>Function:</b>	For the selected socket (selection is made through <a href="#">sock.num</a> <sup>[488]</sup> ) returns <i>total number of committed bytes currently found in the TX buffer.</i>
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535, <b>default</b> = 0 (0 bytes).
<b>See Also:</b>	---

**Details**

The data in the TX buffer does not become committed until you use the [sock.send](#) method.

Your application may use the [sock.notifysent](#) method to get [on\\_sock\\_data\\_sent](#) event once the total number of committed bytes in the TX buffer drops below the level defined by the sock.notifysent method.

**.Urlsubstitutes**

- Function:** A comma-separated list of filenames whose extensions will be automatically substituted for ".html" by the internal webserver of your device.
- Type:** String
- Value Range:** 0-40 characters, **default= ""**
- See Also:** [URL Substitution](#)

**Details**

The substitution will be used only if the resource file with the requested file name is not included in the project directly.

For example, setting this property to "pix1.bmp" will force the webserver to actually process "pix1.html", but only if the file "pix1.bmp" is not found. Data output by the webserver to the browser will still look like a ".bmp" file. For this to work, the "pix1.html" must exist in the project.

This property allows programmatic generation of non-HTML files. In the above example it is possible to generate the BMP file through a BASIC code. There is no other way to do this, since only HTML files are parsed for BASIC code inclusions.

**.Varbuffrq Method**

- Function:** For the selected socket (selection is made through [sock.num](#)) pre-requests "numpages" number of buffer pages (1 page= 256 bytes) for the VAR buffer of the socket.
- Syntax:** **sock.varbuffrq(numpages as byte) as byte**
- Returns:** Actual number of pages that can be allocated (Byte).
- See Also:** ---

Part	Description
numpages	Requested numbers of buffer pages to allocate.

## Details

The VAR buffer is the buffer that stores the HTTP request string. The socket is unable to process HTTP requests if its VAR buffer has 0 capacity.

Actual allocation happens when the [sys.buffalloc](#)<sup>[530]</sup> method is used. Unlike for TX or RX buffers there is no property to read out actual VAR buffer capacity in bytes. This capacity can be calculated as  $\text{num\_pages} * 256 - 16$  (or  $=0$  when  $\text{num\_pages}=0$ ), where "num\_pages" is the number of buffer pages that was GRANTED through the sock.varbuffrq. "-16" is because 16 bytes are needed for internal buffer variables.

Buffer allocation will not work if the socket port to which this buffer belongs is not idle ([sock.statesimple](#)<sup>[505]</sup> is not at 0- PL\_SSTS\_CLOSED) at the time when sys.buffalloc executes. You can only change buffer sizes of sockets that are idle.

The VAR buffer is only required when you plan to use this socket in the HTTP mode- see [sock.httpmode](#)<sup>[481]</sup> property, also [sock.httpportlist](#)<sup>[483]</sup>.

## Ssi Object



The ssi. object implements up to four serial synchronous interface (SSI) channels on the general-purpose I/O lines of your BASIC-programmable device. Examples of such interfaces are:

- [I2C](#)<sup>[516]</sup> (<http://en.wikipedia.org/wiki/I2C>), and YES, ssi. object can handle the acknowledgement bit automatically.
- SPI ([http://en.wikipedia.org/wiki/Serial\\_peripheral\\_interface](http://en.wikipedia.org/wiki/Serial_peripheral_interface)).
- Clock/data (example: goto <http://www.maxim-ic.com> and search for MAX7219 display driver IC);
- Numerous variations on the above.

You can typically get all the necessary data from the IC you want to interface to. Note that some interface designs may not be free to use (i.e. they are patented, etc.).

The common denominator among these interfaces is the presence of the clock line that "paces" data transmission on the data line(s) -- with each clock cycle on the clock line, one bit of data can be transmitted over the data line(s). In contrast, UARTs (managed by the [ser.](#)<sup>[378]</sup> object) are not synchronous -- there is no clock line to synchronize two devices and this is why there is an "A" ("asynchronous") in "UART".

SSI interface links have masters and slaves. The master's role is to generate the clock pulses that slaves will use to synchronize themselves to the master. Only one device can be the master at any given time. **The ssi. object can only work as the master.** That is, it generates the clock for others to use.

Of course, it is possible to communicate with SSI devices by manipulating general-purpose I/O lines of your device directly. This is known as "bit-banging" or "bit-blasting". The advantage of the SSI object is in speed -- the same data exchange will often compete *hundreds of times faster* compared with bit-banging.

A particular channel to work with is selected through the [ssi.channel](#)<sup>[518]</sup> property.

All other properties and methods apply to the currently selected channel.

The [ssi.enabled](#)<sup>[520]</sup> property defines if the channel is disabled or enabled. Necessary [configuration](#)<sup>[513]</sup> of the communication channel can only be performed when ssi.enabled= 0- NO. Actual [data exchange](#)<sup>[515]</sup> is possible only when ssi.enabled= 1- YES.



If you are going to talk to an I2C device, be sure to check out [More on I2C](#)<sup>[516]</sup> topic.

## Configuring SSI Channel

In this section:

- [CLK, DO, and DI lines](#)<sup>[513]</sup>
- [Baudrate](#)<sup>[514]</sup>
- [SSI modes](#)<sup>[514]</sup>
- [Direction](#)<sup>[515]</sup>

### CLK, DO, and DI Lines

Each communication channel comprises a clock line (CLK), data out (DO) line (a.k.a. "master out, slave in" -- MOSI), and data in (DI) line ("master in, slave out" -- MISO). [Ssi.clkmap](#)<sup>[518]</sup>, [ssi.dimap](#)<sup>[519]</sup>, and [ssi.domap](#)<sup>[519]</sup> properties define which three general-purpose I/O lines of your device are assigned to serve as the CLK, DI, and DO of the selected channel.

Some interfaces, notably, [I2C](#)<sup>[516]</sup>, use a single physical line for moving data in both directions (slave-to-master and master-to-slave). With such interfaces, ssi.dimap and ssi.domap must point to the same physical I/O line. Furthermore, [ssi.zmode](#)<sup>[522]</sup> property must be set to 1- PL\_SSI\_ZMODE\_ENABLED\_ON\_ZERO and there may be a need for a "pull-up resistor" on the data line (in the I2C world this joint line is called "SDA" and the pull-up resistor is directly specified by relevant datasheets).

Many interfaces require additional interface lines. For example, there is a chip select (CS) line in SPI. The ssi. object does not control such lines -- handle them directly using the [io.](#)<sup>[294]</sup> object.

On devices with [unidirectional I/O lines](#)<sup>[194]</sup>, the I/O lines forming your SSI channels must be properly configured (see [io.enabled](#)<sup>[298]</sup>): CLK and DO lines must be set as outputs, and the DI line must be set as input. To find out the type of GPIO lines on your device, refer to its platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

## Baudrate

The `ssi.baudrate` property defines the speed at which the CLK line will be toggled. The term baudrate is a bit of a misnomer because it may lead one to believe that the baudrate in the ssi object is something stable and precise. In reality, SSI baudrate only crudely defines the clock speed. The baudrate is also device-specific. Here is the formula for T1000-based devices such as the EM1000:


- When the PLL is enabled (`sys.currentpll = 1 - PL_ON`) the clock period can be calculated as  $0.8\mu\text{s} + \text{ssi.baudrate} * 0.112\mu\text{s}$ .
- With the PLL disabled the period will be 8 times longer.

## SSI Modes

The `ssi.mode` property defines one of the four possible modes for the CLK line. These modes directly correspond to the SPI modes as described here: [http://en.wikipedia.org/wiki/Serial\\_peripheral\\_interface](http://en.wikipedia.org/wiki/Serial_peripheral_interface).

SSI mode combines two independent parameters -- CPOL (clock polarity), and CPHA (clock phase):

- Mode 0: CPOL=0, CPHA=0;
- Mode 1: CPOL=0, CPHA=1;
- Mode 2: CPOL=1, CPHA=0;
- Mode 3: CPOL=1, CPHA=1.



Here is a brief description of modes -- some "preparedness" is required to comprehend this:

- CPOL=0: clock line is LOW when idle:
  - CPHA=0: data bits are captured on the CLK's rising edge (LOW-to-HIGH transition) and data bits are propagated on the CLK's falling edge (HIGH-to-LOW transition).
  - CPHA=1: data bits are captured on the CLK's falling edge and data bits are propagated on the CLK's rising edge.
- CPOL=1: clock line is HIGH when idle:

- CPHA=0: data bits are captured on the CLK's falling edge and data bits are propagated on the CLK's rising edge.
- CPHA=1: data bits are captured on the CLK's rising edge and data bits are propagated on the CLK's falling edge.

Note also that there is an additional difference:

- In SSI modes 1 and 3, the first data bit (in either direction) will be present on the DO (DI) line *after* the first transition on the CLK line.
- In SSI modes 0 and 2, the first data bit (in either direction) will be present on the DO (DI) line *before* transitions on the CLK line start.

## Direction

The [ssi.direction](#)<sup>[519]</sup> property defines whether the SSI channel will output (input) the data least significant bit first (ssi.direction= 0- PL\_SSI\_DIRECTION\_RIGHT) or most significant bit first (ssi.direction= 1- PL\_SSI\_DIRECTION\_LEFT).

## Sending and Receiving Data

Those familiar only with [serial](#)<sup>[378]</sup> ("UART") communications will find this surprising: there are no separate send and receive operations for the ssi. object. When you are sending something out you are also receiving something in at the same time (and vice versa). On the ssi. object's level, these two operations are simultaneous -- with each clock pulse generated on the CLK line, one data bit will be output onto the DO line, and one bit will be recorded from the DI line. The same is true when DO and DI lines are merged.

Of course, on the *operational* level, interactions with a slave SSI device usually consist of sending something (command or data) to the slave device first and then receiving something (data) from it later. Typically, when your device is sending a command, the slave side won't be sending anything meaningful back at the same time, but the SSI channel will still record the data on the DI line. It is your application that should know how to interpret the data received from the slave device.

In the similar matter, whenever you are receiving from the slave device, you are also sending something. Normally, when the slave device is sending you data it will ignore everything you are sending to it.

There are two ways to send and receive data: word-by-word, or as a "string".

For "word-by-word transactions", use [ssi.value](#)<sup>[521]</sup> method. It will simultaneously clock out and clock in up to 16 bits of data. If you are sending less than 16 bits, then the specified number of the rightmost bits will be sent and received.

```
Dim x As word
...
ssi.value(&hCA5A,14) 'When we want to send something out, we can ignore the
"data" we get back
```

```
x=ssi.value(&hFFFF,14) 'When we are expecting to receive data, we send out
'all 1s' (good practice)
x=ssi.value(&hCA5A,14) 'Of course we can do both at the same time
```

For "string transactions", use [ssi.str](#)<sup>[520]</sup> method. String transactions are more sophisticated: you can send (and receive) a string consisting of multiple bytes. These bytes may be handled as "pure" 8-bit words or 9-bit words consisting of eight data bits plus one acknowledgement bit, as required for [I2C communications](#)<sup>[515]</sup> (<http://en.wikipedia.org/wiki/I2C>). For each byte it outputs, the ssi. object will check for the slave's acknowledgement. Data output will not continue if there was no acknowledgement. You can detect this by comparing the length of the returned string and the length of the string you were trying to send -- if they do not match, then the data exchange ended prematurely.

```
Dim Input_String, Output_String As String
...
Output_String="\x40\x12\xff"
Input_String=ssi.str(Output_String,1) 'output data, with acknowledgements
enabled
If Len(Output_String) <> Len(Input_String) Then
    'something went wrong
End If
...
```



If you are going to talk to an I2C device, be sure to check out [More on I2C](#)<sup>[516]</sup> topic.

## More on I2C 5.3

This topic a continuation of the discussion started in [Sending and Receiving Data](#)<sup>[515]</sup>.

I2C (and many existing variations on it) relies on a single data line (called "SDA") for data transmission in both directions. DO and DI lines of the SSI channel must be joined together. On devices with [unidirectional I/O lines](#)<sup>[194]</sup>, the [ssi.zmode](#)<sup>[522]</sup> property must be set to 1- PL\_SSI\_ZMODE\_ENABLED\_ON\_ZERO (not required on devices with bidirectional I/O lines). The DO line will then operate in the following manner:

- To set the DO line HIGH, your device will disable the output buffer. The line will then float HIGH (because of "weak pull-ups" in the device). In this state, the slave SSI device can safely output its own data onto the SDA.
- To set the DO line LOW, your device will enable the output buffer and set the output to LOW.

It follows then, that if your DO and DI lines are joined together, and you want to receive data from the slave device, you should keep your own output at "all 1s" while the slave device is supposed to send data, like this:

```
...
ssi.str("\x40\x12\xff",1) 'we anticipate that the slave device will reply
```

```

after we output two bytes of our own data
...

```

Each I2C transaction requires so-called start and stop sequences -- the ssi. object won't handle this so you need to implement this in code. Below is a snippet from a real application. Notice how necessary transitions on the SDA line are performed by setting the DO line LOW and then enabling/disabling its output buffer.

```

...
i2c_start()
ssi.str("\x40\x12\xff",1)      'output data, with acknowledgements enabled
i2c_stop()
...

'-----
Sub i2c_start()
  io.lineset(SSI_CLK,HIGH)
  io.num=SSI_DO                'set SDA to HIGH first so we can have HIGH-
>LOW transition
  io.state=LOW                'we are manipulating data line through the
OE register
  io.enabled=NO
  io.enabled=YES              'this will set the data output to LOW
End Sub

'-----
Sub i2c_stop()
  io.lineset(SSI_CLK,LOW)     'this will remove the ack bit
  io.num=SSI_DO               'set SDA to LOW first so we can have LOW-
>HIGH transition
  io.state=LOW                'we are manipulating data line through the
OE register
  io.enabled=YES
  io.lineset(SSI_CLK,HIGH)   'this will set the data output to HIGH
End Sub

```

## Properties, Methods

Properties, methods, and events of the ssi object.

### .Baudrate Property

<b>Function:</b>	For the currently selected SSI channel (see <a href="#">ssi.channel</a> <sup>518</sup> ) sets/returns the clock rate on the CLK line.
<b>Type:</b>	Byte
<b>Value Range:</b>	1-255, the fastest rate is achieved at 1, the slowest rate -- at 255. <b>Default</b> = 1 (the fastest rate possible).

**See Also:** [ssi.direction](#)<sup>[519]</sup>, [ssi.mode](#)<sup>[520]</sup>, [ssi.zmode](#)<sup>[522]</sup>

---

### Details

Actual clock rate is device-dependent. See [Baudrate](#)<sup>[514]</sup> topic for details.

This property can only be changed when [ssi.enabled](#)<sup>[520]</sup>= 0- NO.

It is actually permissible to set the property to 0 -- this will be like setting it to 256 (slowest possible clock rate).

## **.Channel Property**

**Function:** Sets/returns the number of the currently selected SSI channel (channels are enumerated from 0).

**Type:** Byte

**Value Range:** 0-3. **Default**= 0 (channel #0 selected)

**See Also:** [Ssi Object](#)<sup>[512]</sup>

---

### Details

All other properties and methods of this object relate to the channel selected through this property.

## **.Clkmap Property**

**Function:** For the currently selected SSI channel (see [ssi.channel](#)<sup>[518]</sup>) sets/returns the number of the general-purpose I/O line to serve as the clock (CLK) line of this channel.

**Type:** Enum (pl\_io\_num, byte)

**Value Range:** Platform-specific. See the list of pl\_io\_num constants in the platform specifications. **Default**= PL\_IO\_NULL (NULL line).

**See Also:** [CLK, DO, and DI Lines](#)<sup>[513]</sup>,  
[ssi.dimap](#)<sup>[519]</sup>, [ssi.domap](#)<sup>[519]</sup>

---

### Details

This property can only be changed when [ssi.enabled](#)<sup>[520]</sup>= 0- NO.

On devices with unidirectional I/O lines, the CLK line must be "manually" configured as output (see [io.enabled](#)<sup>[298]</sup>= 1- YES).

## .Dimap Property

<b>Function:</b>	For the currently selected SSI channel (see <a href="#">ssi.channel</a> <sup>[518]</sup> ) sets/returns the number of the general-purpose I/O line to serve as the data in (DI) line of this channel.
<b>Type:</b>	Enum (pl_io_num, byte)
<b>Value Range:</b>	Platform-specific. See the list of pl_io_num constants in the platform specifications. <b>Default</b> = PL_IO_NULL (NULL line).
<b>See Also:</b>	<a href="#">CLK, DO, and DI Lines</a> <sup>[513]</sup> , <a href="#">ssi.clkmap</a> <sup>[518]</sup> , <a href="#">ssi.domap</a> <sup>[519]</sup>

### Details

This property can only be changed when [ssi.enabled](#)<sup>[520]</sup>= 0- NO.

On devices with unidirectional I/O lines, the DI line must be "manually" configured as input (see [io.enabled](#)<sup>[298]</sup>= 0- NO).

## .Direction Property

<b>Function:</b>	For the currently selected SSI channel (see <a href="#">ssi.channel</a> <sup>[518]</sup> ) sets/returns the direction of data input and output (least significant bit first or most significant bit first).
<b>Type:</b>	Enum (pl_ssi_direction_options , byte)
<b>Value Range:</b>	0- PL_SSI_DIRECTION_RIGHT ( <b>default</b> ): data input/output least significant bit first 1- PL_SSI_DIRECTION_LEFT: data input/output most significant bit first
<b>See Also:</b>	<a href="#">Direction</a> <sup>[515]</sup>

### Details

This property can only be changed when [ssi.enabled](#)<sup>[520]</sup>= 0- NO.

## .Domap Property

<b>Function:</b>	For the currently selected SSI channel (see <a href="#">ssi.channel</a> <sup>[518]</sup> ) sets/returns the number of the general-purpose I/O line to serve as the data out (DO) line of this channel.
<b>Type:</b>	Enum (pl_io_num, byte)
<b>Value Range:</b>	Platform-specific. See the list of pl_io_num constants in the platform specifications. <b>Default</b> = PL_IO_NULL (NULL line).
<b>See Also:</b>	<a href="#">CLK, DO, and DI Lines</a> <sup>[513]</sup> , <a href="#">ssi.clkmap</a> <sup>[518]</sup> , <a href="#">ssi.dimap</a> <sup>[519]</sup>

### Details

This property can only be changed when [ssi.enabled](#)<sup>[520]</sup> = 0- NO.

On devices with unidirectional I/O lines, the DO line must be "manually" configured as output (see [io.enabled](#)<sup>[298]</sup> = 1- YES).

### **.Enabled Property**

<b>Function:</b>	Enables/disables the currently selected SSI channel (see <a href="#">ssi.channel</a> <sup>[518]</sup> ).
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO ( <b>default</b> ): disabled 1- YES: enabled
<b>See Also:</b>	<a href="#">Ssi Object</a> <sup>[512]</sup>

### Details

SSI channel's operating parameters ([ssi.baudrate](#)<sup>[517]</sup>, [ssi.mode](#)<sup>[520]</sup>, etc.) can only be changed when the channel is disabled.

You can only send and receive the data ([ssi.value](#)<sup>[521]</sup>, [ssi.str](#)<sup>[520]</sup>) when the channel is enabled.

### **.Mode Property**

<b>Function:</b>	For the currently selected SSI channel (see <a href="#">ssi.channel</a> <sup>[518]</sup> ) sets/returns the clock mode.
<b>Type:</b>	Enum (pl_ssi_modes , byte)
<b>Value Range:</b>	0- PL_SSI_MODE_0 ( <b>default</b> ) 1- PL_SSI_MODE_1 2- PL_SSI_MODE_2 3- PL_SSI_MODE_3
<b>See Also:</b>	<a href="#">ssi.baudrate</a> <sup>[517]</sup> , <a href="#">ssi.direction</a> <sup>[519]</sup> , <a href="#">ssi.zmode</a> <sup>[522]</sup>

### Details

This property can only be changed when [ssi.enabled](#)<sup>[520]</sup> = 0- NO. For detailed explanation of clock modes see [SSI Modes](#)<sup>[514]</sup>.

### **.Str Method**

<b>Function:</b>	For the currently selected SSI channel (see <a href="#">ssi.channel</a> <sup>[518]</sup> ) outputs a string of byte data to the slave device and simultaneously inputs the same amount of data from the
------------------	---

slave device.

**Syntax:** **ssi.str(byref txdata as string, ack\_bit as no\_yes) as string**

**Returns:** A string of the same length as txdata or less if the transmission ended prematurely due to the acknowledgement error.

**See Also:** [Sending and Receiving Data](#)<sup>[515]</sup>,  
[ssi.value](#)<sup>[521]</sup>

Part	Description
txdata	The string to send to the slave device.
ack_bit	0- NO: transmit/receive byte data as 8-bit words, without the use of the acknowledgement bit. 1- YES: transmit/receive byte data as 9-bit words comprising 8 bits of data and the acknowledgement bit.

### Details

This method can be invoked only when [ssi.enabled](#)<sup>[520]</sup>= 1- YES.

## **.Value Method**

**Function:** For the currently selected SSI channel (see [ssi.channel](#)<sup>[518]</sup>) outputs a data word of up to 16 bits and simultaneously inputs a data word of the same length.

**Syntax:** **ssi.value(txdata as word, len as byte) as word**

**Returns:** 16-bit value containing the data received from the slave device, the number of bits received from the slave device will be equal to the len argument, and these data bits will be right-aligned within the returned 16-bit word.

**See Also:** [Sending and Receiving Data](#)<sup>[515]</sup>,  
[ssi.str](#)<sup>[520]</sup>

Part	Description
txdata	Data to output to the slave device. The number of rightmost bits equal to the len argument will be sent.
len	Number of data bits to send to and receive from the slave device.

### Details

Data input/output direction (least significant bit first or most significant bit first) is defined by the [ssi.direction](#)<sup>[519]</sup> property.

This method can be invoked only when [ssi.enabled](#)<sup>[520]</sup>= 1- YES.

## .Zmode Property

<b>Function:</b>	For the currently selected SSI channel (see <a href="#">ssi.channel</a> <sup>[518]</sup> ) sets/returns the mode of the data out (DO) line.
<b>Type:</b>	Enum (pl_ssi_zmodes , byte)
<b>Value Range:</b>	0- PL_SSI_ZMODE_ALWAYS_ENABLED ( <b>default</b> ): the DO line toggles normally by setting the output buffer to LOW or HIGH. 1- PL_SSI_ZMODE_ENABLED_ON_ZERO: for HIGH state, the output buffer of the DO line is turned off, for LOW state, the output buffer is turned on and the line is set to LOW.
<b>See Also:</b>	<a href="#">ssi.baudrate</a> <sup>[517]</sup> , <a href="#">ssi.direction</a> <sup>[519]</sup> , <a href="#">ssi.mode</a> <sup>[520]</sup>

### Details

This property is only useful on devices with [unidirectional I/O lines](#)<sup>[194]</sup> and in case the DO and DI lines are joined together, as necessary for the I2C and similar interfaces. See [More on I2C](#)<sup>[516]</sup> for more details.

This property can only be changed when [ssi.enabled](#)<sup>[520]</sup>= 0- NO.

## Stor Object



The stor object provides access to the non-volatile (EEPROM) memory in which your application can store data that must not be lost when the device is switched off.

The [stor.size](#)<sup>[525]</sup> read-only property tells you the amount of EEPROM memory offered by the stor object. The [stor.set](#)<sup>[524]</sup> is used to write the data to the EEPROM, while the [stor.get](#)<sup>[523]</sup> method is used to read the data from the EEPROM.

Here is a simple example how to save the IP address of your device in the EEPROM:

```
dim s as string
dim x as byte

s=ddval(net.ip) 'this way it will take less space in the EEPROM (only 4
bytes needed)
x= stor.set(s,0) 'write EEPROM

'check result
if x<>len(s) then
    'EEPROM write failure- do something about this!
end if
```

And here is how you read this data back from the EEPROM:

```
net.ip=ddstr(stor.get(0,4))
```

Notice, that with the stor object addresses are counted from 1, not 0. That is, the first memory location has address 1.

### Special configuration area

The EEPROM IC of the device is also used to store certain [configuration information](#) <sup>[197]</sup> required by the device. Memory available to your application equals the capacity of the IC minus the size of the special configuration area.

By default, when you access the first byte of the EEPROM you are actually accessing the first memory location above the special configuration area. One property -- [stor.base](#) <sup>[523]</sup> -- returns the size of this offset. On startup, stor.base is equal to the size of the special configuration area, so your program can only access the memory above this area.

You can change the stor.base and access configuration area when you need. For example, you can change the MAC address this way- next time the device boots up it will start using newly set address.

## .Base Property

<b>Function:</b>	Sets/returns the base address of the EEPROM from which the area available to your application starts.
<b>Type:</b>	Word
<b>Value Range:</b>	1- <actual memory capacity>, <b>default</b> = <size of special configuration area>+1
<b>See Also:</b>	<a href="#">Stor Object</a> <sup>[522]</sup> , <a href="#">stor.size</a> <sup>[525]</sup>

### Details

By default, the value returned by this property is the address of the first EEPROM location just above the [special configuration area](#) <sup>[197]</sup>. For example, if the size of the special configuration area on your platform is 28 bytes then stor.base will return 29 by default.

This Default value makes sure that your application won't overwrite MAC or password. When you are accessing EEPROM memory using [stor.set](#) <sup>[524]</sup> or [stor.get](#) <sup>[523]</sup> methods, you specify the start address. Actual physical address you access is start\_address+stor.base-1.

If your application needs to change some parameters in the configuration area you can set the stor.base to 1- this way you will have access to the entire memory.

## .Getdata Method (previously .Get)

<b>Function:</b>	Reads data from the EEPROM.
<b>Syntax:</b>	<b>stor.getdata(startaddr as word, len as byte) as string</b>
<b>Returns:</b>	String contains the data read out from the EEPROM.

**See Also:** [Stor Object](#)<sup>[522]</sup>, [stor.set](#)<sup>[524]</sup>

Part	Description
startaddr	The starting address in the EEPROM memory (addresses are counted from 1, if you set this parameter to 0 it will be interpreted as 1).
len	Maximum number of bytes to read.

### Details

The len parameter defines the *maximum* number of bytes to read from the EEPROM. Actual amount of extracted data is also limited by the capacity of the receiving variable and the starting address (in relation to the memory capacity of the EEPROM). Memory capacity can be checked through the [stor.size](#)<sup>[525]</sup> read-only property. Notice that when the stor.getdata executes, an offset equal to the value of [stor.base](#)<sup>[523]</sup> is added to the startaddr. For example, if the stor.base returns 9 and you do stor.getdata(1,3) then you will actually be reading the data starting from physical EEPROM location 9. If you set the stor.base to 1 you will be able to access the EEPROM right from the physical address 1.

By default, the stor.base is set in such a way as to allow access to the EEPROM starting from the address just above the [special configuration area](#)<sup>[197]</sup> of your device -- for details on what this area actually stores see your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>). By setting the stor.base to 1 you are allowing access to the special configuration area.



With Tibbo Basic release **V2**, this method had to be renamed from .get to .getdata. This is because the period (".") separating "stor" from "getdata" is now a "true" part of the language, i.e. it is recognized as a syntax unit, not just part of identifier. Hence, Tibbo Basic sees "stor" and "get" as separate entities and "get" is a reserved word that can't be used.

## .Setdata Method (previously .Set)

<b>Function:</b>	Writes data into the EEPROM.
<b>Syntax:</b>	<b>stor.setdata</b> (byref datatset <b>as string</b> , startaddr <b>as word</b> ) <b>as byte</b>
<b>Returns:</b>	Actual number of bytes written into the EEPROM.
<b>See Also:</b>	<a href="#">Stor Object</a> <sup>[522]</sup> , <a href="#">stor.get</a> <sup>[523]</sup> , <a href="#">stor.size</a> <sup>[525]</sup>

Part	Description
datatset	Data to write into the EEPROM.
startaddr	Starting address in the EEPROM from which the data will be stored (addresses are counted from 1, if you set this parameter to 0 it will be interpreted as 1).

## Details

The operation has completed successfully if the value returned by this method equaled the length of the dataset string. If this is not the case then the write has (partially) failed and there may be two reasons for this: physical EEPROM failure or invalid startaddr (too close to the end of memory to save the entire string).

Notice that when the stor.setdata executes, an offset equal to the value of [stor.base](#)<sup>[523]</sup> is added to the startaddr. For example, if the stor.base returns 9 and you do stor.setdata("ABC",1) then you will actually be reading the data starting from physical EEPROM location 9. If you set the stor.base to 1 you will be able to access the EEPROM right from the physical address 1.

By default, the stor.base is set in such a way as to allow access to the EEPROM starting from the address just above the [special configuration area](#)<sup>[197]</sup> of your device -- for details on what this area actually stores see your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>). By setting the stor.base to 1 you are allowing access to the special configuration area.



With Tibbo Basic release **V2**, this method had to be renamed from .set to .setdata. This is because the period (".") separating "stor" from "setdata" is now a "true" part of the language, i.e. it is recognized as a syntax unit, not just part of identifier. Hence, Tibbo Basic sees "stor" and "set" as separate entities and "set" is a reserved word that can't be used.

## .Size R/O Property

<b>Function:</b>	Returns total EEPROM memory capacity (in bytes) for the current device.
<b>Type:</b>	Word
<b>Value Range:</b>	Platform-dependent
<b>See Also:</b>	<a href="#">Stor Object</a> <sup>[522]</sup>

---

## Details

Certain amount of EEPROM memory is occupied by the [special configuration section](#)<sup>[197]</sup> -- for details on what this area actually stores see your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

By default, special configuration area is not accessible to the application and is excluded from memory capacity reported by the stor.size. For example, if the EEPROM IC used by this platform has 2048 bytes of data, and the size of the special configuration memory is 8 bytes, then the stor.size will return 2040 by default. At the same time, the default value of [stor.base](#)<sup>[523]</sup> property will be 9, which means that the EEPROM locations 1-8 are occupied by the special configuration area.

If you set the stor.base to 1 (for instance, to edit the MAC address), the stor.size will show the capacity of 2048. In other words, the number this property returns is actual\_EEPROM\_capacity-stor.base+1.

## Sys Object



This is the system object that loosely combines "general system" stuff such as initialization (boot) event, buffer management, system timer, PLL mode, and some other miscellaneous properties and methods.

### Overview, 17.1

Here you will find:

- [On\\_sys\\_init \(boot\) event](#)<sup>[526]</sup>
- [Buffer Management](#)<sup>[526]</sup>
- [System Timer](#)<sup>[528]</sup>
- [PLL Management](#)<sup>[529]</sup>
- [Serial Number](#)<sup>[530]</sup>
- [Miscellaneous stuff](#)<sup>[530]</sup> such as how to halt execution, reboot, check firmware version.

### On\_sys\_init Event

The sys object provides a very important event- [on\\_sys\\_init](#)<sup>[533]</sup>. This event is guaranteed to be generated first when your device starts running. Therefore, you should put all your initialization code for sockets, ports, .etc into the event handler for this event:

```
sub on_sys_init
  net.ip="192.168.1.95"
  sock.num=0
  sock.targetip= "192.168.1.96"
  '...and everything else that you may need!
end sub
```

### Buffer Management

#### How to allocate buffer memory

Some objects, such as the [sock](#)<sup>[421]</sup> or [ser](#)<sup>[378]</sup>, rely on buffers for storing the data being sent and received. For example, each serial port of the ser object has two buffers- RX and TX, while each socket of the sock object has 6 different buffers.

By default, all buffers have no memory allocated for them, which basically means that they cannot store any data. For related objects to work, these buffers need to be given memory.

Memory is allocated in pages. Each page equals 256 bytes. There is a small overhead for each buffer- 16 bytes are used for internal buffer housekeeping (variables, pointers, etc.). Therefore, if you have allocated 2 pages for a particular buffer, then this buffer's actual capacity will be  $2 * 256 - 16 = 496$  bytes.

Buffer memory allocation is a two-step process. First, you request certain number of pages for each port, socket, etc. that you plan to use. This is done through

methods of corresponding objects. For example, the [ser.rxbufreq](#)<sup>[415]</sup> method requests buffer memory for the RX buffer of one of the serial ports. Similar methods exist for all other buffers of all objects that require buffer memory. Note, that actual memory allocation does not happen at this stage- only your "requests" are collected.

After all requests have been made actual memory allocation is performed by using the [sys.bufalloc](#)<sup>[530]</sup> method. This allocates memory, as per previous requests, for all buffers of all objects. Here is an example:

```
'allocate memory for RX and TX buffers of serial port 0 and socket 0

'make requests
ser.num= 0
ser.rxbufreq= 5
ser.txbufreq= 5
sock.num=0
sock.rxbufreq= 4
sock.txbufreq= 4

'and now actual allocation
sys.bufalloc
```

Typically, buffer memory allocation is done in the `on_sys_init` event handler but you don't have to do it this way. In fact, your application can re-allocate buffer memory space according to the changes in the operating mode or other conditions.

`sys.bufalloc` could take up to several hundred milliseconds to execute, so it makes sense to use it as little as possible. Hence, request all necessary buffer allocations first, then use the `sys.bufalloc` once to finish the job.

Buffer (re)allocation for a specific object will only work if the corresponding object or part of the object to which this buffer belongs is idle. "Part" refers to a particular serial port of the `ser` object, or particular socket of the `sock` object, etc. to which the buffer you are trying to change belongs. "Idle" means different things for different objects: [ser.enabled](#)<sup>[405]</sup>= 0- NO for the serial port, [sock.statesimple](#)<sup>[505]</sup>= 0- `PL_SSTS_CLOSED` for the socket, etc.

### Intelligent memory allocation basing on what's available

Memory is not an infinite resource and you will not always get as much memory as you have requested. Methods such as the [ser.rxbufreq](#)<sup>[415]</sup> actually return the amount of memory that can be allocated:

```
dim x as byte
x=ser.rxbufreq(5) 'x could get less than 5, which means that you got less
memory than you have asked for
```

Two properties of the `sock` object were implemented to help you allocate memory intelligently, basing on what is available.

The [sys.totalbufpages](#)<sup>[536]</sup> read-only property tells you how many buffer pages are there on your system in total. This is defined by the amount of physical variable memory (RAM) available minus memory required to store your project's variables

(so, as your project grows available buffer memory shrinks).

The [sys.freebuffpages](#)<sup>[531]</sup> read-only property tells you the amount of free (not yet allocated) buffer pages.

Here is an example in which we allocate memory equally between the TX and RX buffers of four serial ports and four sockets:

```
dim x, f as byte

x=sys.totalbuffpages/16 'will work correctly if we haven't allocated
anything yet

for f=0 to 3
  ser.num= f
  ser.rxbuffrq(x)
  ser.txbuffrq(x)
  sock.num= f
  sock.rxbuffrq(x)
  sock.txbuffrq(x)
next f
```

In the above example we do not check what individual buffer requests return because we have already calculated each buffer's size basing on the total number of buffer pages available.

## System Timer

The system object provides a timer event- [on\\_sys\\_timer](#)<sup>[533]</sup>- that is generated periodically. The period depends on the platform. If the platform doesn't have a [sys.onsystimerperiod](#)<sup>[533]</sup> property, then this period is fixed at 0.5 seconds. If the platform supports this property, then 0.5 second is the default period and the property allows your program to adjust it.

If your software has some periodic tasks you can put the code into the `on_sys_timer` event handler. Notice that when generated, this event goes into the queue and waits in line to be processed, just like all other events. Therefore, you cannot expect great accuracy in the period at which the `on_sys_timer` event handler is entered. You can just expect that *on average* you will be getting this event every 0.5 seconds.

There is also a [sys.timercount](#)<sup>[536]</sup> read-only property. Timer counter is a free-running counter that is initialized to 0 when your device is powered up and increments every 0.5 seconds. The `sys.timercount` is useful in determining elapsed time, for instance, when you are waiting for something.

Here is an example. Supposing, you are supposed to wait for the serial data to arrive, but you are not willing to wait more than 10 seconds:

```
dim w as word
...
...
```

```
w=sys.timecount 'memorize time count at the beginning of waiting for serial
data
while ser.rxlen=0
  'nope, no data yet, do we still have time?
  if sys.timercount-w>20 then goto enough_waiting 'we quit after 10
seconds
  doevents 'polite waiting includes this
wend

...
...
```



The above example does not represent best coding style. Generally speaking, this is not a great programming but sometimes you just have to wait in a cycle.

## PLL Management

PLL is a module of the device that transforms the clock generated by onboard crystal into higher frequency (x8 of the base for Tibbo devices). When the PLL is on, the device runs at 8 times the base frequency, when the PLL is off, the device runs at a "native" frequency of the crystal. Naturally, the device is 8 times faster (and consumes almost as much more power) when the PLL is on.

Not all Tibbo devices have PLLs- to find out if yours does, refer to its platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

When a certain platform supports PLL, it will have a [sys.currentpll](#)<sup>[531]</sup> read-only property and [sys.newpll](#)<sup>[532]</sup> method to control the PLL. Due to the nature of PLL operation it is impossible to switch it on and off while the CPU is executing the firmware. The PLL needs time to "stabilize" its output frequency and it is not safe to let this happen when the CPU is running. Instead, the PLL is toggled when the CPU is in the reset state.

To change PLL mode, request new state through the [sys.newpll](#) method, then self-reset the device through the [sys.reboot](#)<sup>[534]</sup> method. After the reboot the device emerges from reset with new PLL state (and PLL frequency already stabilized).

Here is a code example that makes sure that your device is running with PLL off:

```
sub on_sys_init
  if sys.currentpll=YES then
    sys.newpll(OFF)
    sys.reboot
  end if
end sub
```

External resets- power-up and RST pin reset (reset button reset)- set the PLL to default state (typically ON). On some devices there is a hardware jumper that defines the post-external reset state of the PLL.



Notice that PLL mode affects other objects- for example, baudrates of [serial ports](#)<sup>[378]</sup> (this is why there is a [ser.div9600](#)<sup>[404]</sup> property) and frequency generated by the [beep](#)<sup>[232]</sup> object.

## Serial Number

Most Tibbo devices feature unique serial numbers. The length and contents of serial numbers are device-dependent. For more information refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

## Miscellaneous

The [sys.version](#)<sup>[536]</sup> property returns the version of the TiOS (firmware) running on your device.

The [sys.halt](#)<sup>[532]</sup> method can be used to halt the execution of your program. For example, you can use this to halt the program when the Ethernet interface failure is detected:

```
...
if net.failure= YES then
    sys.halt
end if
...
```

The [sys.reboot](#)<sup>[534]</sup> method causes the device to reboot. This may be needed, for instance, to change the mode of the [PLL](#)<sup>[529]</sup>.

The [sys.runmode](#)<sup>[534]</sup> read-only property informs whether the device is running in the release or debug mode. This data can be used by the program to exhibit different behavior- for example report all errors in the debug mode and try to "manage on its own" in the release mode (for more info see [Two Modes of Target Execution](#)<sup>[27]</sup>).

The [sys.resettype](#)<sup>[535]</sup> read-only property tells you what caused the most recent reset experienced by your device.

## Properties, Methods, Events

This section provides an alphabetical list of all properties, methods, and events of the sys object.

### .Buffalloc Method

<b>Function:</b>	Allocates buffer memory as previously requested by "buffrq" methods of individual objects (such as <a href="#">ser.rxbuffrq</a> <sup>[415]</sup> ).
<b>Syntax:</b>	<b>sys.buffalloc</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">sys.totalbuffpages</a> <sup>[536]</sup> , <a href="#">sys.freebuffpages</a> <sup>[531]</sup>

### Details

Call this method after requesting all buffers you need through methods like

[ser.txbufreq](#)<sup>[419]</sup> and [sock.cmdbufreq](#)<sup>[476]</sup>.

This method takes significant amount of time (100s of milliseconds) to execute, during which time the device cannot receive network packets, serial data, etc. For certain interfaces like serial ports some incoming data could be lost.

Buffer (re)allocation for a specific object will only work if the corresponding object or part of the object to which this buffer belongs is idle. "Part" refers to a particular serial port of the [ser](#)<sup>[378]</sup> object, or particular socket of the [sock](#)<sup>[427]</sup> object, etc. to which the buffer you are trying to change belongs. "Idle" means different things for different objects: [ser.enabled](#)<sup>[405]</sup>= 0- NO for the serial port, [sock.statesimple](#)<sup>[505]</sup>= 0- PL\_SSTS\_CLOSED for the socket, etc.

## .Currentpll R/O Property (Selected Platforms Only)

<b>Function:</b>	Returns current PLL mode of the device
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO: PLL is off, the device runs at low speed with reduced power consumption.  1- YES: PLL is on, the device runs at maximum speed, x8 faster than low speed.
<b>See Also:</b>	<a href="#">sys.newpll</a> <sup>[532]</sup>

---

### Details

After the external reset the device typically boots with PLL on. You can switch PLL off and on programmatically by using the [sys.newpll](#)<sup>[532]</sup> method and then "self-resetting" the device using the [sys.reboot](#)<sup>[534]</sup> method.

Actual PLL mode change only takes place after you "self-reset" the device using [sys.reboot](#)<sup>[534]</sup> method or the device self-resets due to some other reason (for instance, there is a self reset after a new BASIC application upload, or when you hit "restart" button in TIDE). External resets- power-up and RST pin reset (reset button reset)- set the PLL to default state (typically ON). On some devices there is a hardware jumper that defines the post-external reset state of the PLL.

Not all Tibbo devices have PLL- to find out if yours does, refer to its platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

## .Freebufpages R/O Property

<b>Function:</b>	Returns the number of free (not yet allocated) buffer pages (one page= 256 bytes).
<b>Type:</b>	Byte
<b>Value Range:</b>	0-255
<b>See Also:</b>	<a href="#">sys.totalbufpages</a> <sup>[536]</sup>

---

### Details

Only changes after the [sys.buffalloc](#)<sup>[530]</sup> method is used. "Preparatory" methods like [ser.rxbufferq](#)<sup>[415]</sup> do not influence what this property returns.

## **.Halt Method**

**Function:** Stops your program execution (halts VM).

**Syntax:** **sys.halt**

**Returns:** ---

**See Also:** [sys.reboot](#)<sup>[534]</sup>

### Details

Causes the same result as when you press PAUSE in [TIDE](#)<sup>[15]</sup> during the debug session. Once this method has been used, there is no way for your device to resume execution without your help.

## **.Newpll Method (Selected Platforms Only)**

**Function:** Sets new state of the PLL.

**Syntax:** **sys.newpll(newpllstate as off\_on)**

**Returns:** ---

**See Also:** [sys.currentpll](#)<sup>[531]</sup>

Part	Description
newpllstate	Specifies what state the PLL will be in after the device emerges from internal reset: 0- OFF: PLL will be off, the device will emerge from reset at low speed with reduced power consumption 1- ON: PLL will be on, the device will emerge from reset at maximum speed, x8 faster than low speed

### Details

Actual PLL mode change only takes place after you "self-reset" the device using [sys.reboot](#)<sup>[534]</sup> method or the device self-resets due to some other reason (for instance, there is a self reset after a new BASIC application upload, or when you hit "restart" button in TIDE). External resets- power-up and RST pin reset (reset button reset)- set the PLL to default state (typically ON). On some devices there is a hardware jumper that defines the post-external reset state of the PLL.

Not all Tibbo devices have PLL- to find out if yours does, refer to its platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

**!** Notice that PLL mode affects other objects- for example, baudrates of [serial\\_ports](#)<sup>[378]</sup> (this is why there is a [ser.div9600](#)<sup>[404]</sup> property) and frequency generated by the [beep](#)<sup>[232]</sup> object.

## On\_sys\_init Event

**Function:** First event to be generated when your device boots up.  
**Declaration:** `on_sys_init`  
**See Also:** ---

---

### Details

Typically, initialization code for you application is placed here.

## On\_sys\_timer Event

**Function:** Periodic event.  
**Declaration:** `on_sys_timer`  
**See Also:** [sys.timercount](#)<sup>[536]</sup>

---

### Details

Multiple `on_sys_timer` events may be waiting in the event queue. `On_sys_timer` event is not generated when the program execution is PAUSED (in [debug mode](#)<sup>[27]</sup>).  
 New in **V1.2**. If the platform does not support the [sys.onsystimerperiod](#)<sup>[533]</sup> property, then the interval of this event generation is fixed at 0.5 seconds. If the platform does support this property, then the period is adjustable.

## .Onsystimerperiod Property (Selected Platforms Only)

**Function:** New in **V1.2**. Sets/returns the period for the [on\\_sys\\_timer](#)<sup>[533]</sup> event generation expressed in 10ms intervals.  
**Type:** Byte  
**Value Range:** 0-255. **Default**= 50 (500ms).  
**See Also:** ---

---

### Details

Defines, in 10ms increments, the period at which the [on\\_sys\\_timer](#)<sup>[533]</sup> event will be generated. Platforms that do not support this property have the period fixed at 0.5

seconds.

## .Reboot Method

<b>Function:</b>	Causes your device to reboot.
<b>Syntax:</b>	<b>sys.reboot</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">sys.currentpll</a> <sup>[531]</sup> , <a href="#">sys.runmode</a> <sup>[534]</sup> , <a href="#">sys.resettype</a> <sup>[535]</sup> , and <a href="#">sys.halt</a> <sup>[532]</sup>

### Details

After the device reboots it will behave as after any other reboot: enter PAUSE mode if your program was compiled for debugging, or start execution if the program was compiled for release (see [Two Modes of Target Execution](#)<sup>[27]</sup>).

The PLL mode will change after the reboot if you requested the changed through [sys.newpll](#)<sup>[532]</sup> method.

## .Runmode R/O Property

<b>Function:</b>	Returns current run (execution) mode.
<b>Type:</b>	Enum (pl_sys_mode, byte)
<b>Value Range:</b>	<p>0- PL_SYS_MODE_RELEASE: debugging is not possible, application execution starts immediately after device powers up. Severe errors such as "division by zero" are ignored and do not stop execution.</p> <p>1- PL_SYS_MODE_DEBUG: debug mode in which it is possible to cross-debug the application (under the control of <a href="#">TIDE</a><sup>[15]</sup> software). Application execution is not started automatically after the power up. Severe errors such as "division by zero" halt execution.</p>
<b>See Also:</b>	<a href="#">sys.currentpll</a> <sup>[531]</sup> , <a href="#">sys.newpll</a> <sup>[532]</sup> , <a href="#">sys.resettype</a> <sup>[535]</sup> , and <a href="#">sys.halt</a> <sup>[532]</sup>

### Details

For some programs, it may be useful to know if the program is currently executing in Debug Mode or Release Mode( see [Two Modes of Target Execution](#)<sup>[27]</sup>).

## Serialnum R/O Property (Selected Platforms Only)

<b>Function:</b>	Returns a string containing the serial number of the device.
<b>Type:</b>	String

**Value Range:** Platform-dependent  
**See Also:** [Serial Number](#)<sup>[530]</sup>

### Details

To find out if there is a serial number, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

## Setserialnum Method (Selected Platforms Only)

**Function:** Sets the serial number of the device.  
**Syntax:** `sys.setserialnum(byref str as string) as ok_ng`  
**Returns:** 0- OK: The serial number was set successfully.  
 1- NG: Serial number programming failed.  
**See Also:** [Serial Number](#)<sup>[535]</sup>

### Details

To find out if there is a serial number, refer to your device's platform documentation (for example, EM1000's is [here](#)<sup>[143]</sup>).

## .Resettype R/O Property

**Function:** Returns the type of the most recent hardware reset.  
**Type:** Enum (pl\_sys\_reset\_type, byte)  
**Value Range:** 0- PL\_SYS\_RESET\_TYPE\_INTERNAL: The most recent reset was generated internally.  
 1- PL\_SYS\_RESET\_TYPE\_EXTERNAL: The most recent reset was generated externally.  
**See Also:** [sys.currentpll](#)<sup>[531]</sup>, [sys.runmode](#)<sup>[534]</sup>, [sys.reboot](#)<sup>[534]</sup>, and [sys.halt](#)<sup>[532]</sup>

### Details

Internal resets are generated when the device self-reboots. This can be caused by the execution of [sys.reboot](#)<sup>[534]</sup> in your application, or command from TIDE.

External resets are the ones that are caused by power-cycling (turning the device off and back on) or applying a reset pulse to the RTS line of the device (pushing reset button).

### .Timercount R/O Property

<b>Function:</b>	Returns the time (in half-second intervals) elapsed since the device powered up.
<b>Type:</b>	Word
<b>Value Range:</b>	0-65535
<b>See Also:</b>	<a href="#">on_sys_timer</a> <sup>533</sup>

---

#### Details

Once this timer reaches 65535 it rolls over to 0.

### .Totalbuffpages R/O Property

<b>Function:</b>	Returns the total amount of memory pages available for buffers (one page= 256 bytes).
<b>Type:</b>	Byte
<b>Value Range:</b>	0-255
<b>See Also:</b>	<a href="#">sys.buffalloc</a> <sup>530</sup> , <a href="#">sys.freebuffpages</a> <sup>531</sup>

---

#### Details

Calculated as total available variable memory (RAM) in pages minus number of pages required to store variables of the current project.

### .Version R/O Property

<b>Function:</b>	Returns firmware (TiOS) version string.
<b>Type:</b>	String
<b>Value Range:</b>	Whatever is set in firmware, for example "<EM202-1.00.00>"
<b>See Also:</b>	---

---

#### Details

---

## Wln Object



The wln. object represents the Wi-Fi interface of your device. It is through this

object that you find available Wi-Fi networks and select the one to associate with. You can also create an ad-hoc network of your own and have other stations connect to it.

The `wln.` object is not responsible for actual data communications over the Wi-Fi -- this is the job of the [sock.](#)<sup>[421]</sup> object.

On platforms with Wi-Fi support, you will find Wi-Fi interface listed or available on the following `sock.` object's properties:

- [Sock.availableinterfaces](#)<sup>[475]</sup>
- [Sock.allowedinterfaces](#)<sup>[474]</sup>
- [Sock.currentinterface](#)<sup>[478]</sup>
- [Sock.targetinterface](#)<sup>[506]</sup>

In the task it performs, the `wln.` object is similar to the [net](#)<sup>[358]</sup> object, which controls another interface -- the Ethernet. In comparison, the `wln.` object is *much* more complex.



You can avoid dealing with the complexity of Wi-Fi by using our [WLN library](#)<sup>[703]</sup>. The library handles the tasks of bringing up the Wi-Fi interface, finding the specified access point, and associating with it using selected security protocol. The library also offers other convenient "services".

The `wln` object allows you to:

- Scan for available networks and obtain their parameters such as name, channel, mode, etc. "Hidden networks" (those that do not broadcast their SSID) can also be found.
- Set WEP, WPA-PSK, or WPA2-PSK security modes and related keys. Part of required WPA/WPA2 functionality is implemented in the [WLN library](#)<sup>[703]</sup>. That is, the `wln.` object and WLN library work together to achieve WPA-PSK and WPA2-PSK support.
- Associate with one of the networks (at a time) or form your own "ad-hoc" network on a desired channel.
- Monitor received signal strength.
- Detect disassociation from the network.
- Detect Wi-Fi interface power-down or malfunction.

The `wln.` object works with dedicated hardware -- the GA1000 add-on module. This add-on hardware is described in our Programmable Hardware Manual.

## Overview, 18.1

If you are new to Wi-Fi communications, then we recommend you to read the [Wi-Fi Parlance Primer](#)<sup>[538]</sup> that will introduce you to some important Wi-Fi lingo.

[Wln Tasks](#)<sup>[539]</sup> topic explains the basics of interaction with the `wln.` object.

The rest of the manual follows the natural sequence of steps that you usually take when working with and through the Wi-Fi interface ([Wln State Transitions](#)<sup>[542]</sup> topic expands on the subject). The steps are as follows:

- [Brining up Wi-Fi interface](#) <sup>543</sup>
- [Scanning for Wi-Fi networks](#) <sup>550</sup>
- [Setting WEP or WPA security](#) <sup>552</sup>
- [Associating with selected network](#) <sup>554</sup> (or [creating own ad-hoc network](#) <sup>555</sup>)
- [Communicating via Wi-Fi interface](#) <sup>555</sup>
- [Disassociating from the network](#) <sup>556</sup> (or [terminating own ad-hoc network](#) <sup>556</sup>)
- [Detecting disassociation or offline state](#) <sup>556</sup>

## Wi-Fi Parlance Primer

If you are new to Wi-Fi networking, this section will give you a bit of knowledge on the highly specialized jargon used in the Wi-Fi world. We also provided useful links that will lead you to a lot more info on the subject.

Here are the abbreviations and terms that are used in the Wi-Fi world:

- **BSS** stands for Basic Service Set (ah, now it is clear!). In simple words, this is a wireless network created by a single access point ([http://en.wikipedia.org/wiki/Wireless\\_access\\_point](http://en.wikipedia.org/wiki/Wireless_access_point)), but not always. It all depends on the...
- **BSS mode**. Wi-Fi networks can operate in either the infrastructure mode, or ad-hoc mode. In the infrastructure mode, a wireless access point is used to create, control and regulate the network. In the ad-hoc mode, there is no access point and wireless devices communicate directly with each other. This is called "IBSS" (Independent Basic Service Set), more on this here: [http://en.wikipedia.org/wiki/Independent\\_Basic\\_Service\\_Set](http://en.wikipedia.org/wiki/Independent_Basic_Service_Set).
- **SSID** stands for Service Set Identifier. In simple words, the SSID is a name of the wireless network. In case of the infrastructure network, this name is preset on the access point during its configuration. You can read more on SSIDs here: [http://en.wikipedia.org/wiki/BSSID#Service\\_set\\_identifier\\_.28SSID.29](http://en.wikipedia.org/wiki/BSSID#Service_set_identifier_.28SSID.29).
- **BSSID** stands for Basic Service Set Identifier. This is the "MAC address of the wireless network". When your network is built on the access point, this is the MAC address of this access point. For ad-hoc networks the BSSID is selected with certain randomness built in. More on this here: [http://en.wikipedia.org/wiki/BSSID#Basic\\_service\\_set\\_identifier](http://en.wikipedia.org/wiki/BSSID#Basic_service_set_identifier).
- **Channel**. Wi-Fi devices operate on one of 14 preset frequencies. Channel refers to the channel number, not the actual frequency used. Depending on the locale, you can be restricted to fewer channels: [http://en.wikipedia.org/wiki/List\\_of\\_WLAN\\_channels](http://en.wikipedia.org/wiki/List_of_WLAN_channels)
- **RSSI**. Stands for Received Signal Strength Indication. This is a measure of the quality of RF signal received from the wireless network (or peer). More on this here: <http://en.wikipedia.org/wiki/Rssi>
- **WEP** stands for Wired Equivalent Privacy, a widely used method of protecting Wi-Fi networks from eavesdropping and unauthorized access. The name carries a bit of a wishful thinking, as it has been clearly demonstrated that WEP is rather weak

and can be easily defeated. Read on here: [http://en.wikipedia.org/wiki/Wired\\_Equivalent\\_Privacy](http://en.wikipedia.org/wiki/Wired_Equivalent_Privacy).

- **WPA** means Wi-Fi Protected Access. This is a security protocol that exists in two versions -- WPA and WPA2. WPA was developed in response to serious weaknesses discovered in the WEP standard. Tibbo devices support "personal" WPA protocols WPA-PSK and WPA2-PSK. Read about WPA here: [http://en.wikipedia.org/wiki/Wi-Fi\\_Protected\\_Access](http://en.wikipedia.org/wiki/Wi-Fi_Protected_Access).

## Wln Tasks

True to the [non-blocking operation philosophy](#)<sup>[4]</sup> of the entire system, the wln object does not stall the entire Tibbo Basic application execution to wait for the Wi-Fi interface to complete required operation ("task"). You program gives the wln object a task to perform, and then it is free to go and do other things.

There are nine wln. tasks:

- [Setting TX power](#)<sup>[550]</sup> (initiated by [wln.settxpower](#)<sup>[570]</sup> method). This is an "immediate" task.
- [Passively Scanning for Wi-Fi networks](#)<sup>[550]</sup> (initiated by [wln.scan](#)<sup>[567]</sup> method).
- [Actively Scanning for Wi-Fi networks](#)<sup>[550]</sup> (initiated by [wln.activescan](#)<sup>[556]</sup> method).
- [Setting WEP mode and key](#)<sup>[553]</sup> (initiated by [wln.setwep](#)<sup>[570]</sup> method). This is an "immediate" task.
- [Setting WPA/WPA2 mode and key](#)<sup>[553]</sup> (initiated by [wln.setwpa](#)<sup>[571]</sup> method). This is an "immediate" task.
- [Associating with selected network](#)<sup>[554]</sup> (initiated [wln.associate](#)<sup>[557]</sup> by method).
- [Creating own ad-hoc network](#)<sup>[555]</sup> (initiated by [wln.networkstart](#)<sup>[564]</sup> method).
- [Disassociating from the network](#)<sup>[556]</sup> (initiated by [wln.disassociate](#)<sup>[561]</sup> method).
- [Terminating own ad-hoc network](#)<sup>[556]</sup> (initiated by [wln.networkstop](#)<sup>[564]</sup> method).

Three tasks on the list -- [wln.settxpower](#)<sup>[570]</sup>, [wln.setwep](#)<sup>[570]</sup>, and [wln.setwpa](#)<sup>[571]</sup> -- are so-called immediate tasks. They complete as soon as they are started. If the execution advances to the next statement in the program then you know that these tasks are done with.

All remaining tasks take time to complete, and they complete asynchronously with respect to the program execution. The following example shows a wrong way of tasking:

```
'THIS WON'T WORK!
...
wln.scan("NET1")
wln.associate(wln.scanresultbssid,"NET1",wln.scanresultchannel,
wln.scanresultbssmode) 'this task will be skipped over!
```

Here is how you should do this: use the [wln.task](#)<sup>[572]</sup> read-only property and wait until the previous task is completed.

```
'A BETTER WAY
...
wln.scan("NET1")
```

```

while wln.task<>PL_WLN_TASK_IDLE 'waiting for the task to complete...
wend
...
wln.associate(wln.scanresultbssid,"NET1",wln.scanresultchannel,
wln.scanresultbssmode)
while wln.task<>PL_WLN_TASK_IDLE 'waiting for the task to complete...
wend
...

```

The above approach still needs some refinement. Just making sure that the previous task has completed will not guarantee that your next task will be accepted. This is because some tasks can only be accepted under certain conditions. For example, you can't associate while you are already associated. Try this, and [wln.associate](#) <sup>557</sup> will return 1- REJECTED.

```

'GOOD PROGRAMMING MEANS ANTICIPATING PROBLEMS
While wln.task<>PL_WLN_TASK_IDLE 'waiting for the previous task to
complete...
Wend
...
If wln.associate(wln.scanresultbssid,"NET1",wln.scanresultchannel,
wln.scanresultbssmode)<>ACCEPTED Then
    'We already made sure that the previous task was completed.
    'Hence, there is a more 'fundamental' reason for the rejection!
End If

```

Now, this is still not all. "Task completed" is not equal to "task completed successfully". In the above example, we were trying to associate with the "NET1" network. Now, have we actually succeeded? Find out by testing the value of [wln.associationstate](#) <sup>558</sup>! For every task that may result in failure there is a way to know if the execution was successful or not.

```

'MORE CHECKING
While wln.task<>PL_WLN_TASK_IDLE 'waiting for the previous task to
complete...
Wend
...
If wln.associate(wln.scanresultbssid,"NET1",wln.scanresultchannel,
wln.scanresultbssmode)<>ACCEPTED Then
    'Handle this...
End If
While wln.task<>PL_WLN_TASK_IDLE 'waiting for association to complete...
Wend
'did we succeed?
If wln.associationstate<>PL_WLN_ASSOCIATED Then
    'something went wrong...
End If
...

```

One problem with the code in the above examples is that it is, essentially, blocking. Your application is not doing anything useful while the Wi-Fi interface is associating.

To take advantage of the event-driven nature of the system, you can base your execution flow on the [on\\_wln\\_task\\_complete](#)<sup>565</sup> event which is generated each time a task is completed. Completed\_task argument of the event handler carries the code of the event that has been completed. Therefore, you can advance through steps in this manner:

```
'THIS CODE TAKES FULL ADVANTAGE OF THE EVENT-DRIVEN NATURE OF THE SYSTEM
'-----
Sub On_sys_init
  ...
  wln.scan("CISCO1") 'start the task and don't wait
End Sub

'-----
Sub On_wln_task_complete(completed_task As pl_wln_tasks)
  Select Case completed_task

    Case PL_WLN_TASK_SCAN:
      'wln.scan() completed
      If wln.scanresultssid="" Then
        'passive scan failed to reveal the network, let's try active
        scanning
        wln.activescan("CISCO1")
      Else
        'network discovered
        goto associate_now
      End If

    Case PL_WLN_TASK_ACTIVESCAN:
      'wln.activescan() completed
      If wln.scanresultssid="" Then
        'network still not found -- handle this
        ...
      End If
  associate_now:
    wln.associate(wln.scanresultbssid,"CISCO1",wln.scanresultchannel,
wln.scanresultbssmode)

    Case PL_WLN_TASK_ASSOCIATE:
      'wln.associate() completed, proceed in this manner...
      ...
  End Select
End Sub

'-----
Sub On_wln_event(wln_event As pl_wln_events)
  'here we catch hardware problems and disassociations -- also
  asynchronously
End Sub
```


Notice the [on\\_wln\\_event](#)<sup>565</sup> in the code above. It allows us to catch "problems".

## Wln State Transitions

The Wi-Fi hardware may be in one of the following states:

- Uninitialized state (`wln.enabled`<sup>[562]</sup>= 0- NO).
- Booted and idle (`wln.enabled`= 1- YES and `wln.associationstate`<sup>[558]</sup>= 0- PL\_WLN\_NOT\_ASSOCIATED).
- Booted and associated with a network (`wln.enabled`= 1- YES and `wln.associationstate`= 1- PL\_WLN\_ASSOCIATED).
- Booted and running its own ad-hoc network (`wln.enabled`= 1- YES and `wln.associationstate`= 2- PL\_WLN\_OWN\_NETWORK).

The following diagram details possible state transitions.



The only way to advance from the uninitialized state into the booted state is through a successful boot. The process is described in [Bringing Up Wi-Fi Interface](#)<sup>[543]</sup>. The key method for the process is `wln.boot`<sup>[558]</sup>.

There is no special method for powering down. Your application can only [hardware-reset](#)<sup>[546]</sup> the GA1000, after which the boot process can be repeated. The `on_wln_event`<sup>[565]</sup> is generated when the GA1000 goes offline, either as a result of a deliberate reset, or in case the Wi-Fi hardware malfunctions or gets disconnected.

Transition between the idle and associated states happens as a result of successful association. This is detailed in [Associating With Selected Network](#)<sup>[564]</sup>. The key method is `wln.associate`<sup>[557]</sup>.

The `wln.disassociate`<sup>[561]</sup> method can be used to force disassociation. The wln object also detects the loss of association automatically, i.e. when the network in

question "disappears". In both cases, the [on\\_wln\\_event](#)<sup>[565]</sup> event is generated.

The Wi-Fi interface can also [create its own ad-hoc network](#)<sup>[555]</sup>, which is achieved through the [wln.networkstart](#)<sup>[564]</sup> method. [Terminating Own Ad-hoc Network](#)<sup>[556]</sup> explains how to end this (in short, use [wln.networkstop](#)<sup>[564]</sup>).

Notice that you cannot be associated and run your own network at the same time. These states are mutually exclusive.

## Brining Up Wi-Fi Interface

The easiest way to make the Wi-Fi interface work is by calling [wln\\_start\(\)](#)<sup>[724]</sup> of the [WLN library](#)<sup>[703]</sup>. This will save you a ton of effort, seriously!

If you can't or won't use the library, here is the sequence of steps that you just have to take in order to bring up the Wi-Fi interface:

- [Configure interface lines](#)<sup>[545]</sup>
- [Reset Wi-Fi module](#)<sup>[546]</sup>
- [Select the domain](#)<sup>[547]</sup>
- [Allocate buffer memory](#)<sup>[547]</sup>
- [Set MAC address \(optional\)](#)<sup>[548]</sup>
- [Boot up the GA1000 add-on module](#)<sup>[549]</sup>
- [Set the IP, gateway IP, and netmask](#)<sup>[549]</sup>
- [Set TX power \(really optional\)](#)<sup>[550]</sup>

The following is a simplified sample code that demonstrates the process. Typically, it would be called from the [on\\_sys\\_init](#)<sup>[533]</sup> event handler, but you can actually call it from anywhere in your application. You can also call this code repeatedly and even after the Wi-Fi interface has already been running. We call the code simplified because it does not check for any error conditions.

```
'BRINGING UP THE WI-FI MODULE (SIMPLIFIED)

#If PLATFORM_ID=EM500W
    #define WLN_RESET_MODE 1 'reset is controlled by the combination of CS
and CLK
    'there is no need to map CS, DI, DO, and CLK lines because they are
fixed
#elif PLATFORM_ID=EM1206W
    #define WLN_RESET_MODE 0 'there is a dedicated reset line
    #define WLN_RST PL_IO_NUM_11
    #define WLN_CS PL_IO_NUM_15
    #define WLN_DI PL_IO_NUM_12
    #define WLN_DO PL_IO_NUM_13
    #define WLN_CLK PL_IO_NUM_14
#else
    #define WLN_RESET_MODE 0 'there is a dedicated reset line
    #define WLN_RST PL_IO_NUM_51
    #define WLN_CS PL_IO_NUM_49
    #define WLN_DI PL_IO_NUM_52
    #define WLN_Do PL_IO_NUM_50
    #define WLN_CLK PL_IO_NUM_53
#endif
```

```

'-----
-

'----- configure interface lines -----
' (on platforms with fixed mapping this will have no effect and do no
harm)
wln.csmmap=WLN_CS
io.num=WLN_CS
io.enabled=YES
wln.dimap=WLN_DI
wln.domap=WLN_DO
io.num=WLN_DO
io.enabled=YES
wln.clkmap=WLN_CLK
io.num=WLN_CLK
io.enabled=YES
io.num=WLN_RST
io.enabled=YES

'----- reset Wi-Fi module -----
#If WLN_RESET_MODE
    'reset is controlled by the combination of CS and CLK
    io.lineset(wln.csmmap,HIGH)
    io.lineset(wln.clkmap,LOW)
    io.lineset(wln.clkmap,HIGH)
#Else
    'there is a dedicated reset line
    io.num=WLN_RST
    io.state=LOW
    io.state=HIGH
#endif

'in case we called wln_init() after it has already been up and running
While wln.enabled=YES
Wend

'----- set the domain -----
wln.domain=PL_WLN_DOMAIN_FCC

'----- allocate buffers -----
wln.buffrq(5)
sys.buffalloc

'----- set MAC address (optional) -----
wln.mac="0.100.110.120.130.140"

'----- boot up the GA1000 -----
romfile.open("ga1000fw.bin")
wln.boot(romfile.offset)

'----- setup the IP, gateway, netmask -----
wln.ip="192.168.1.86"
wln.gatewayip="192.168.1.1"
wln.netmask="255.255.255.0"

'----- set TX power (REALLY optional) -----
wln.settxpower(15)
while wln.task<>PL_WLN_TASK_IDLE
wend

```

## Configuring Interface Lines

The GA1000 add-on interacts with your BASIC-programmable device through an SPI interface. The SPI interface has four signals: chip select (CS), clock (CLK), data in (DI), and data out (DO). On the [EM500](#)<sup>[138]</sup>, DI and DO are combined together (this saves one GPIO line on a module that has very few of them). [Connecting GA1000](#)<sup>[201]</sup> shows related schematic diagrams.

All Tibbo devices except the EM500 allow remapping of SPI lines. That is, any four GPIO lines of your device can be chosen to control the GA1000. [Wln.csmmap](#)<sup>[560]</sup>, [wln.clkmap](#)<sup>[560]</sup>, [wln.dimap](#)<sup>[560]</sup>, and [wln.domap](#)<sup>[562]</sup> properties exist for the purpose. There is no remapping on the EM500 and manipulating these properties makes no difference for it.

The GA1000 also has a reset (RST) line. As [Connecting GA1000](#)<sup>[201]</sup> explains, the RST line can be driven by a dedicated GPIO line of your device, or through a "joint effort" of CLK and DO, which, again, spares one GPIO pin of your device. There isn't any property to remap the RST line. This is because the RST is supposed to be controlled by your application directly. It exists outside of the wln. object's realm, so choose any GPIO to control it.

This said, some Tibbo hardware has all the choices made for you already. We are talking about the NB1000 board (part of DS100x) and the EM1206EV board. On these boards, all the necessary hardware connections to the GA1000 are already there, so your mapping just has to follow them. With the exception of the EM500, you have a complete freedom to map any way you want on all other devices, but why would you? We recommend you to follow this scheme:

```
#If PLATFORM_ID=EM500W
    #define WLN_RESET_MODE 1 'reset is controlled by the combination of CS
and CLK
    'there is no need to map CS, DI, DO, and CLK lines because they are
fixed
#elif PLATFORM_ID=EM1206W or PLATFORM_ID=DS1101W or PLATFORM_ID=DS1102W
'also applies to EM1206EV board
    #define WLN_RESET_MODE 0 'there is a dedicated reset line
    #define WLN_RST PL_IO_NUM_11
    #define WLN_CS PL_IO_NUM_15
    #define WLN_DI PL_IO_NUM_12
    #define WLN_Do PL_IO_NUM_13
    #define WLN_CLK PL_IO_NUM_14
#Else 'for all other devices including NB1010
    #define WLN_RESET_MODE 0 'there is a dedicated reset line
    #define WLN_RST PL_IO_NUM_51
    #define WLN_CS PL_IO_NUM_49
    #define WLN_DI PL_IO_NUM_52
    #define WLN_Do PL_IO_NUM_50
    #define WLN_CLK PL_IO_NUM_53
#endif
```

The above sets three schemes: one for the [EM500](#)<sup>[138]</sup> module and related devices, the second one for the [EM1206](#)<sup>[158]</sup>, [DS1101](#)<sup>[168]</sup>, [DS1102](#)<sup>[174]</sup>, and related devices, and the third one for all other devices including the [EM1000](#)<sup>[143]</sup>, [EM1202](#)<sup>[151]</sup>, etc.

Here is the code snippet that prepares GPIO lines:

```
'----- configure interface lines -----
```

```

    '(on platforms with fixed mapping this will have no effect and do no
    harm)
    wln.csmmap=WLN_CS
    io.num=WLN_CS
    io.enabled=YES
    wln.dimmap=WLN_DI
    wln.domap=WLN_DO
    io.num=WLN_DO
    io.enabled=YES
    wln.clkmap=WLN_CLK
    io.num=WLN_CLK
    io.enabled=YES
    io.num=WLN_RST
    io.enabled=YES

```

Note that mapping can't be changed when the Wi-Fi hardware is already [booted](#)<sup>[549]</sup> (i.e. [wln.enabled](#)<sup>[562]</sup>= 1- YES).

## Applying Reset

Once the RST line has been [properly configured](#)<sup>[545]</sup>, you can hardware-reset the GA1000 at any time by executing the following simple code. Note that the GA1000 *has* to be reset after the power up of your device. Proper hardware reset is *not* optional!

If your design has no GPIO line to spare, the reset signal can be derived from the combination of CS and CLK line signals (check [Connecting GA1000](#)<sup>[201]</sup>, diagram B). When there is a dedicated RST line, this line is manipulated directly.

Notice also the *while...wend* loop. It is there for proper GA1000 reset after it has already been up and running. When the hardware reset is applied, the GA1000 will go offline, and the wln. object will detect this in a matter of milliseconds. Your program should not try to work with the wln. object again until the [wln.enabled](#)<sup>[562]</sup> property goes to 0- NO in response to the hardware reset. Your code can stay and wait for this (as shown below) or rely on the [on wln event](#)<sup>[565]</sup>. Once the event is triggered, you are free to repeat the whole process of [bringing up Wi-Fi interface](#)<sup>[543]</sup>.

```

'----- reset Wi-Fi module -----
#If WLN_RESET_MODE
    'reset is controlled by the combination of CS and CLK
    io.lineset(wln.csmmap,HIGH)
    io.lineset(wln.clkmap,LOW)
    io.lineset(wln.clkmap,HIGH)
#Else
    'there is a dedicated reset line
    io.num=WLN_RST
    io.state=LOW
    io.state=HIGH
#endif

'in case we called wln_init() after it has already been up and running
While wln.enabled=YES
Wend

```

## Selecting Domain

Wireless communications and channels are tightly regulated in every country on Earth, and this applies to Wi-Fi networks as well. Not every one of 14 pre-defined Wi-Fi frequencies is allowed to be used in every country. It is your responsibility to set a correct "domain" for your Wi-Fi device. This is done through the [wln.domain](#) property. Supported domains are US (FCC), EU, JAPAN, and "OTHER", which mimics US channel set.

Selected domain restricts available channels for [wln.activescan](#) and [wln.associate](#) methods. These are methods that cause the GA1000 to transmit data. [Wln.scan](#) is not restricted by the selected domain in any way, because it only listens for incoming Wi-Fi signals, without actually transmitting anything.

One side effect of the above is that you may be able to discover the network with [wln.scan](#), yet unable to associate with it because this network is operating on a channel which is disallowed in a currently selected domain!

## Allocating Buffer Memory

The [wln](#) object requires a single buffer. This buffer is used to form outgoing packets and is necessary for correct operation. You never have to deal with this buffer directly -- it is handled internally by the [wln](#) object itself.

Buffer memory is allocated in pages. A page is 256 bytes of memory. Allocating memory for a buffer is a two-step process: First you have to request for a specific allocation (a number of pages) and then you have to perform the actual allocation. Request the size you need in pages using the [wln.buffrq](#) method.

The allocation method ([sys.buffalloc](#)) applies to all buffers previously specified, in one fell swoop:

```
Dim x As Byte
x = wln.buffrq(5) ' request 5 pages for the wln buffer. X will then contain
                 ' how many can actually be allocated
                 ' .... Allocation requests for buffers of other objects...
sys.buffalloc 'perform actual memory allocation, as per previous requests
```

You may not always get the full amount of memory you have requested. Memory is not an infinite resource, and if you have already requested (and received) allocations for 95% of the memory for your platform, your next request will get up to 5% of memory, even if you requested for 10%.

Current [wln](#) buffer size in bytes can always be checked with the [wln.buffsize](#) read-only property.

Note that [wln](#) buffer size can't be changed when the Wi-Fi hardware is already [booted](#) ([wln.enabled](#) = 1- YES).

### How many pages should the [wln](#) buffer get?

The size of the [wln](#) buffer directly dictates the maximum size of network packets that the [wln](#) object will be able to send (this buffer has nothing to do with incoming packets). Up to 100 bytes of the buffer space are required for various packet headers, and the rest is available to packet payload. For example, if you have allocated 2 pages for the buffer, then the buffer size is 512 bytes. Hence, maximum

payload size cannot exceed 412 bytes. That is, every TCP, UDP, etc. packet sent, including its protocol headers, will not exceed 412 bytes.

For TCP communications, the size of individual packets is not that critical. The beauty of TCP is that it can work with practically any buffer space available. In theory, the bigger the buffer, the better the TCP throughput is. In reality, you will stop feeling any improvement in TCP performance once your wln. buffer size exceeds ~3 pages. UDP is another matter entirely. If you want to be able to send UDP datagrams of a certain size, then you must make sure that you have created an adequate wln. buffer.

In any case, TiOS does not send out TCP or UDP packets with payloads exceeding 1024 bytes (4 pages). This is the internal limitation of TiOS itself. Add to this TCP/UDP and Wi-Fi headers, and you are still within 5 pages. Therefore, there is no point in setting the wln. buffer to more than 5 pages.

### Setting MAC Address (Optional)

Every network interface needs its own MAC, and the Wi-Fi port is no exception. The `wln.mac`<sup>[563]</sup> property exists for this purpose. Your Wi-Fi module already carries a MAC address onboard -- it is preset during manufacturing, so you don't actually have to take care of the MAC. Leave the wln.mac at its default pre-boot value of "0.0.0.0.0.0", `boot_up`<sup>[549]</sup> the Wi-Fi interface (`wln.boot`<sup>[558]</sup>), and the wln.mac will be updated with the pre-assigned address that is stored inside the Wi-Fi module.

You can use another MAC if you want, too. Set the desired MAC address *before* booting up the Wi-Fi, and this MAC will be used instead of the pre-assigned one. That is, if wln.mac is set to anything but "0.0.0.0.0.0" and then wln.boot is called, then "your" MAC will be used instead.

```
'set the mac address
wln.mac="0.1.2.3.100.200" 'override pre-assigned MAC with another address
...
romfile.open("ga1000fw.bin")
wln.boot(romfile.offset) 'the hardware will start using your MAC
```

The pre-assigned MAC inside the Wi-Fi module will not be altered. It is always there and can be called up by leaving the wln.mac at "all zeroes", then booting the Wi-Fi hardware.

### A bit of info on MACs

The MAC address can be either "globally unique" or "locally administered". There is also a provision for "unicast" and "multicast" addressing. You can find more information on this here: [http://en.wikipedia.org/wiki/Mac\\_address](http://en.wikipedia.org/wiki/Mac_address).

Your organization can purchase a block of globally unique addresses, or choose to assign random locally administered addresses. In the latter case, set the most significant byte of the address to 2, and choose random values for the remaining 5 bytes (`random`<sup>[222]</sup> function will help). Note that each device you are using should have a unique MAC address. It is a good idea to generate the MAC once, and store it in the EEPROM memory (see the `stor.`<sup>[522]</sup> object). The MAC can then be retrieved on each boot and written into the `wln.mac`<sup>[563]</sup> property.

Note that the MAC address of the Wi-Fi interface can't be set when the hardware is already booted (`wln.enabled`<sup>[562]</sup>= 1- YES).

## Booting Up the Hardware

Booting up the GA1000 hardware is done through the [wln.boot](#)<sup>[558]</sup> method. The GA1000 does not have a ROM or flash memory and its internal processor executes the firmware from RAM. Before the GA1000 module can start working, you need to upload this firmware into it, and this is what `wln.boot` really does.

The firmware file is called "ga1000fw.bin" (the file can be downloaded from Tibbo website). The file must be [added](#)<sup>[132]</sup> to your Tibbo Basic project as a binary [resource file](#)<sup>[20]</sup>.

Access to resource files is through the [romfile](#)<sup>[370]</sup> object. First, you open the "ga1000fw.bin" file with the [romfile.open](#)<sup>[374]</sup> method, then pass the pointer to this file (value of the [romfile.offset](#)<sup>[373]</sup> R/O property) to the `wln.boot` method:

```
'boot it up
romfile.open("ga1000fw.bin")
If wln.boot(romfile.offset) Then
    'something is wrong, react to this
    ...
End If
```

The boot takes 1-3 seconds to complete. The method will return 0- OK if the boot was completed successfully. At that moment, [wln.enabled](#)<sup>[562]</sup> will become 1- YES.

The boot will fail (return 1- NG) if:

- The Wi-Fi hardware is not powered, not [properly reset](#)<sup>[546]</sup>, [mapped incorrectly](#)<sup>[545]</sup>, or malfunctions.
- The offset to the firmware file is incorrect or the file is not included in your project.
- The Wi-Fi hardware is already booted and operational.

## Setting IP, Gateway, and Netmask

The Wi-Fi is a separate network interface and so it has its own IP address, which is set using the [wln.ip](#)<sup>[563]</sup> property. This address is different from the IP address of the Ethernet interface (see [net.ip](#)<sup>[360]</sup>). We noticed that many people find it "unusual" that Tibbo hardware device would turn out to have two IP addresses. In fact, this is completely normal. On the PC, every network interface has the IP of its own as well.

Technically speaking, IP address configuration can be done at any time. This topic has been placed into this section to remind you that the IP of the `wln` object has to be set, if not right after the [boot](#)<sup>[549]</sup>, then at some later point. If your application uses a static IP, then setting it in the boot section of your code is a good idea. If the application obtains the IP address through DHCP, then the IP can only be set after communicating with the DHCP server, and this will only be possible after successful [association](#)<sup>[554]</sup>. You may even need to set the IP address repeatedly if your product switches between different networks (access points).

There are also [wln.gatewayip](#)<sup>[562]</sup> and [wln.netmask](#)<sup>[564]</sup> properties that may need to

be set along with the IP address. This is optional and is only required if your device will have to establish outgoing connections to the network hosts outside of your LAN.

Note that IP, gateway IP, and netmask of the Wi-Fi interface can't be set when there is at least one open socket in your system ([sock.statesimple](#)<sup>[505]</sup><> 0- PL\_SSTS\_CLOSED) that operates on the Wi-Fi interface ([sock.currentinterface](#)<sup>[478]</sup>= 2- PL\_SOCKET\_INTERFACE\_WLN).



A very useful [DHCP library](#)<sup>[618]</sup> can handle IP, gateway IP, and netmask configuration both for the Ethernet ([net.](#)<sup>[358]</sup>) and Wi-Fi (wln.) interfaces of your device. Use it and save yourself a ton of work!

### Setting TX Power (Optional)

The output power of the Wi-Fi hardware can be adjusted in 12 steps. The [wln.settxpower](#)<sup>[570]</sup> method is provided for that purpose. The power value roughly corresponds to dB. The lowest output power is set with `wln.settxpower(4)` and the highest power is set with `wln.settxpower(15)`. Lower power reduces the current consumption of the Wi-Fi module, but not by much. We recommend that you do not touch this.

Note that setting TX power is an **"immediate" wln task**<sup>[539]</sup> and there is a certain correct way of handling tasks. "Immediate" means you don't have to wait for the task to complete -- it is finished as soon as `wln.settxpower` is done executing.

### Scanning for Wi-Fi Networks

Scanning allows you to discover all networks in your device's range and also learn about their operating parameters, such as the name, RF channel, signal strength, etc. Two methods -- [wln.scan](#)<sup>[567]</sup> and [wln.activescan](#)<sup>[566]</sup> -- are provided for this purpose. Both methods are **wln tasks**<sup>[539]</sup> and there is a certain correct way of handling tasks.

`Wln.scan` performs a passive detection of networks. During the passive detection, the hardware listens for "beacons" transmitted by wireless networks and extracts network information from these beacon packets. This method can't collect the network information of "hidden" wireless networks that do not broadcast their SSIDs (names).

Passive scanning is performed on all 14 frequency channels, regardless of the value of [wln.domain](#)<sup>[561]</sup>. This is not in violation of any regulations because the passive scanning does not involve transmitting any data out of the device (the transmitter stays silent).

`Wln.activescan` actively "probes" the environment around the device by sending -- you guessed it -- "probe" packets. This method can find all the wireless networks that `wln.scan` would find, plus it can discover a hidden network, but only if you knew this network's name in advance.

Active scanning (sending "probe" packets) is only performed on "allowed" channels. The list of allowed channels depends on the selected domain ([wln.domain](#)<sup>[561]</sup>).

Scanning can be performed at any time, even when the Wi-Fi interface is in the associated state ([wln.associationstate](#)<sup>[558]</sup> 1- PL\_WLN\_ASSOCIATED) or running its own ad-hoc network (`wln.associationstate`= 2- PL\_WLN\_OWN\_NETWORK). Keep in mind, however, that scanning temporarily disrupts communications between the device and the access point. This is because scanning involves checking for available access points on all (allowed) frequencies. Obviously, the radio can't keep

communicating with the "current" access point while jumping from channel to channel.

Both `wln.scan` and `wln.activescan` accept a single argument of string type. Presence or absence of this argument defines the "operating mode" of these methods. You can either [discover all wireless networks](#)<sup>[551]</sup> in range, or try to [collect information about the specific network](#)<sup>[551]</sup>.

Also read about what happens when [several access points have the same name](#)<sup>[552]</sup>.

## Discovering All Wireless Networks

When called with an empty string argument, `wln.scan`<sup>[567]</sup> and `wln.activescan`<sup>[556]</sup> will attempt to find all wireless networks in range. After the task completes, the `wln.scanresultssid`<sup>[569]</sup> R/O property will contain a comma-separated list of network names.

```
'scan for available network
Dim s As String
...
wln.scan("") 'you could use wln.activescan(') instead
While wln.task<>PL_WLN_TASK_IDLE
Wend
s=wln.scanresultssid 'the list of networks will be copied into s
```

After the execution of the above, the `s` string may contain something like this: "TIBBO,c1100\_1,.....,WNET2". Notice "....." -- these are five bytes with ASCII code 0. They represent a hidden network (i.e. the network that does not broadcast its SSID). Naturally, the name of this network is not revealed to your device. This will be the case regardless of whether you used `wln.scan` or `wln.activescan`.

## Collecting Data About Specific Network

When called with the argument `set` to the name of a particular network, the `wln.scan`<sup>[567]</sup> and `wln.activescan`<sup>[556]</sup> methods will attempt to find this wireless network and obtain its operational parameters:

```
'scan for a specific network
wln.activescan("Tibbo1") 'you could use wln.scan('), unless you are
expecting to be dealing with a hidden network
While wln.task<>PL_WLN_TASK_IDLE
Wend
If wln.scanresultssid<>"" Then
    'network found!
    ...
End If
```

After the scan...

- [Wln.scanresultssid](#)<sup>[569]</sup> R/O property will contain the name of the specified network, or nothing if the network wasn't found. If the network was found, the following five properties will also be updated:
- [Wln.scanresultbssid](#)<sup>[567]</sup> R/O property will contain the BSSID ("MAC address") of the specified network.
- [Wln.scanresultbssmode](#)<sup>[568]</sup> R/O property will contain the BSS mode of the network (infrastructure or ad-hoc).
- [Wln.scanresultchannel](#)<sup>[568]</sup> R/O property will return the number of the RF channel on which the network operates.
- [Wln.scanresultrssi](#)<sup>[569]</sup> R/O property will contain the strength of the RF signal received from the specified network.
- [Wln.scanresultwpainfo](#)<sup>[569]</sup> R/O property will contain the data necessary for [WPA/WPA2 protocols](#)<sup>[553]</sup>. This is not a human-readable data. Better let our [WLN library](#)<sup>[703]</sup> interpret it.

Both `wln.scan` and `wln.activescan` will collect exactly the same data about the specified network. The only difference is that `wln.scan` won't be able to do the job if this wireless network does not broadcast its SSID. `Wln.activescan`, on the contrary, will get this done. So, if you need to work with a hidden network, then you need to know this network's name, and you need to use `wln.activescan` to obtain this network's data.

## Multiple Access Points With the Same Name

Many installations have several access points with the same SSID (name). These may be viewed as a single wireless network consisting of multiple access points, or several networks that use the same SSID. What happens when you do [wln.scan](#)<sup>[567]</sup> or [wln.activescan](#)<sup>[556]</sup> in this environment?

Let's assume you have five access points in range: "CISCO1", "Net10", and three access points named "tibbo\_net".

If you are [discovering all wireless networks](#)<sup>[551]</sup> in range, i.e. do `wln.scan("")` or `wln.activescan("")`, then after the scanning task is complete, [wln.scanresultssid](#)<sup>[569]</sup> will contain several identical entries, like this: "CISCO1,tibbo\_net,tibbo\_net,Net10,tibbo\_net". You can't really distinguish one "tibbo\_net" from another!

If you are [collecting data about specific network](#)<sup>[551]</sup>, i.e. do `wln.scan("tibbo_net")` or `wln.activescan("tibbo_net")`, then `wln.scanresultssid` will end up containing a single entry: "tibbo\_net". Question is, which one of the three "tibbo\_net" access points does this entry represent? The answer: it is the one with the strongest signal (the highest [wln.scanresultrssi](#)<sup>[569]</sup>)! All other "wln.scanresult..." R/O properties will then contain values pertaining to this access point. Thus, when given a choice, the `wln.` object automatically selects the best access point to work with.

## Setting Wi-Fi Security

The `wln.` object supports two types of Wi-Fi security:

- [WEP64 and WEP128](#)<sup>[553]</sup> -- a weak and old form of Wi-Fi protection.
- [WPA-PSK and WPA2-PSK](#)<sup>[553]</sup> -- two modern forms of Wi-Fi security (use WPA2 whenever possible). These security modes require the [WLN library](#)<sup>[703]</sup> (or a lot of coding effort) to work correctly.

WEP and WPA security must be set before [associating](#)<sup>[554]</sup> with the selected network or creating own [ad-hoc network](#)<sup>[555]</sup>.

## Setting WEP Mode and Key

The [wln.setwep](#)<sup>[570]</sup> method allows you to specify the WEP mode and key. Note that `wln.setwep` is an "immediate" [wln task](#)<sup>[539]</sup> and there is a certain correct way of handling tasks. "Immediate" means you don't have to wait for the task to complete -- it is finished as soon as `wln.setwep` is done executing.

The mode can be either DISABLED, WEP64, or WEP128. WEP key is entered as a HEX string, not ASCII string. Each character in a string represents one HEX digit: 0..9 or A..F (a..f). The key has a fixed length: 10 HEX digits for WEP-64 or 26 HEX digits for WEP-128. If your key is too short it will be padded with zeroes. If the key is too long it will be truncated.

Here is the code example that sets the Wi-Fi to WEP128 mode:

```
'set WEP128
wln.setwep("11111111111111111111111111111111", PL_WLN_WEP_MODE_128) 'we love to
choose difficult keys
```

Wi-Fi devices routinely define four WEP keys, but Tibbo hardware only uses a single key (key 1).

Note that the WEP mode and key can't be changed while the Wi-Fi interface is in the associated state ([wln.associationstate](#)<sup>[558]</sup> 1- PL\_WLN\_ASSOCIATED) or is running its own network (`wln.associationstate`= 2- PL\_WLN\_OWN\_NETWORK).



You need to call `wln.setwep` *every time* before [associating](#)<sup>[554]</sup> with the access point or [starting](#)<sup>[555]</sup> own network. If you are switching from an access point using WEP security to another access point with no security or [WPA security](#)<sup>[553]</sup>, you still need to execute `wln.setwep("", PL_WLN_WEP_MODE_DISABLED)`!

## Setting WPA Mode and Key

The [wln.setwpa](#)<sup>[571]</sup> method allows you to specify the WPA mode and key. Looks easy, similar to [WEP](#)<sup>[553]</sup>, but the reality is that doing WPA is a hard hard job! It is, in fact, so hard and involves so many steps that we are not even going to attempt to explain how this is done. Use the [WLN library](#)<sup>[703]</sup> whenever you have to deal with WPA/WPA2. This is the way of doing this, really!

Tibbo devices only support "personal" WPA modes WPA-PSK and WPA2-PSK.



If you are switching from an access point using WPA security to another access point with no security or [WEP security](#)<sup>[553]</sup>, you still need to execute `wln.setwpa(PL_WLN_WPA_DISABLED,0,"",0)`!

## Associating With Selected Network

Association is a process by which your Wi-Fi device establishes a link with an access point or another wireless station running an ad-hoc network.

The association process is initiated using the [wln.associate](#) method. Association is a required step before you will be able to send and receive the data over the Wi-Fi. Note that `wln.associate` is a [wln task](#) and there is a certain correct way of handling tasks.

`Wln.associate` will be rejected (return 1- REJECTED) if:

- Another task is currently in progress.
- GA1000 add-on module is not online (`wln.enabled` = 0- NO).
- The Wi-Fi interface is already in the non-idle state (`wln.associationstate` <> 0- PL\_WLN\_NOT\_ASSOCIATED). That is, you can't try to associate when you are already associated or running [own ad-hoc network](#).

The method will return 0- ACCEPTED if the task is accepted for processing.

Prior to associating, you need to set the [WEP](#) or [WPA](#) security (if required). You also need to know several key parameters about the network you are associating with:

- SSID (the name) of this network;
- BSSID ("MAC") of this network;
- Channel on which this network operates;
- BSS mode of this network (whether the network is infrastructure or ad-hoc).

Normally, the SSID is known, but BSSID, channel, and BSS mode require some digging. The easiest way to sniff out correct values of these parameters is through [scanning](#). [Wln.scan](#) or [wln.activescan](#) will fill out [wln.scanresultbssid](#), [wln.scanresultchannel](#), and [wln.scanresultbssmode](#) R/O properties. You only need to put them to good use, as shown in the example below.

Before you look at the example, consider this: you may be able to discover the network with `wln.scan`, yet unable to associate with it because this network is operating on a channel which is disallowed in a currently selected [domain](#).

```
'connect to the access point named TIBBO.
wln.scan("TIBBO") 'scanning for a specific network will give us necessary
parameters (you can also use wln.activescan)
While wln.task<>PL_WLN_TASK_IDLE
Wend
If wln.scanresultssid<>" " Then
    'wireless network not found
End If

'now can associate: 'wln.scanresult...' properties contain necessary data
after the scanning
wln.associate(wln.scanresultbssid, wln.scanresultssid,
wln.scanresultchannel, wln.scanresultbssmode)
While wln.task<>PL_WLN_TASK_IDLE
Wend
If wln.associationstate=PL_WLN_ASSOCIATED Then
    'successful association!
    ...
End If
```

After the association task is completed you have to check the association result. Mere task completion does not indicate success! The [wln.associationstate](#)<sup>[558]</sup> will provide the indication.

If you are running with no security or [WEP security](#)<sup>[553]</sup>, you can start [communicating](#)<sup>[555]</sup> over the Wi-Fi interface as soon as you are done associating. If it is WPA you are dealing with, completing `wln.associate` is really just a first step. There is a lengthy and laborious message exchange to follow. It is best to delegate this to our [WLN library](#)<sup>[703]</sup>!

When the `wln` object is in the associated state, [wln.rssi](#)<sup>[566]</sup> read-only property is constantly updated with the strength of the signal coming from the access point. Do not confuse this with the [wln.scanresultrssi](#)<sup>[569]</sup> property which returns the signal strength of a particular network obtained during [scanning](#)<sup>[550]</sup>.

## Creating Own Ad-hoc Network

Rather than [associating](#)<sup>[554]</sup> with somebody else's network, the Wi-Fi interface can create an ad-hoc network of its own and have other devices associate with it. This is done by using [wln.networkstart](#)<sup>[564]</sup>. Note that `wln.networkstart` is a [wln task](#)<sup>[539]</sup> and there is a certain correct way of handling tasks.

`wln.networkstart` will be rejected (return 1- REJECTED) if:

- Another task is currently in progress.
- GA1000 add-on module is not online ([wln.enabled](#)<sup>[562]</sup>= 0- NO).
- The Wi-Fi interface is already in the non-idle state ([wln.associationstate](#)<sup>[558]</sup><>0- PL\_WLN\_NOT\_ASSOCIATED). That is, you can't start a network when you are already associated or running a network.

The method will return 0- ACCEPTED if the task is accepted for processing.

To start a network, you only need to make up your mind regarding its name and operating channel:

```
'take control and run your own network
wln.networkstart ("VOICEOFREBELS", 6)
While wln.task<>PL_WLN_TASK_IDLE
Wend
```

## Communicating via Wln Interface

Actual data exchange over the Wi-Fi interface falls outside the responsibilities of the `wln` object. This is the task of the [sock](#)<sup>[421]</sup> object. This object has a set of properties that define whether a particular socket will be listening on the Wi-Fi interface ([sock.allowedinterfaces](#)<sup>[474]</sup> property), establish an outgoing connection through the Wi-Fi interface ([sock.targetinterface](#)<sup>[506]</sup> property). See also: [sock.currentinterface](#)<sup>[478]</sup> read-only property.

## Disassociating From the Network

To disassociate from the network, use the [wln.disassociate](#)<sup>[561]</sup> method. Note that wln.disassociate is a [wln task](#)<sup>[539]</sup> and there is a certain correct way of handling tasks.

```
'disassociate now
wln.disassociate
While wln.task<>PL_WLN_TASK_IDLE
Wend
```

Disassociation can be forced by the access point. Disassociation will also happen if the access point goes offline or out of range, or if the Wi-Fi hardware is powered down, reset, disconnected, or malfunctions. This will be [detected](#)<sup>[566]</sup> by the wln object.

## Terminating Own Ad-hoc Network

Use [wln.networkstop](#)<sup>[564]</sup> to terminate your ad-hoc network. We are talking about the network your hardware has created -- you can't terminate an ad-hoc network of someone else. Note that wln.networkstop is a [wln task](#)<sup>[539]</sup> and there is a certain correct way of handling tasks.

## Detecting Disassociation or Offline State

The wln. object automatically detects disassociation from the wireless network and powering-off of or reset of the GA1000. [On wln event](#)<sup>[565]</sup> event is fired up if either condition is detected. In response to this event, your application can re-initialize the Wi-Fi hardware and/or re-associate with the wireless network.

## Properties, Methods, Events

Properties, methods, and events of the wln object.

### .Activescan Method

<b>Function:</b>	Causes the Wi-Fi interface to commence either the active detection of available wireless networks or obtainment of an additional information about a particular network specified by its SSID (name).
<b>Syntax:</b>	<b>wln.activescan(byref ssid as string) as accepted_rejected</b>
<b>Returns:</b>	One of accepted_rejected constants: 0- ACCEPTED. 1- REJECTED.
<b>See Also:</b>	<a href="#">Scanning for Wi-Fi Networks</a> <sup>[550]</sup> , <a href="#">Wln Tasks</a> <sup>[539]</sup> , <a href="#">wln.scan</a> <sup>[567]</sup>

Part	Description
------	-------------

ssid Network name. Leave empty to detect all available networks -- after the scan, the comma-delimited list of networks will be in [wln.scanresultssid](#)<sup>[569]</sup>. Alternatively, specify the network name. If the network is detected, its parameters will be available through [wln.scanresultssid](#)<sup>[569]</sup>, [wln.scanresultbssid](#)<sup>[567]</sup>, [wln.scanresultbssmode](#)<sup>[568]</sup>, [wln.scanresultchannel](#)<sup>[568]</sup>, [wln.scanresultrssi](#)<sup>[569]</sup>, [wln.scanresultwpainfo](#)<sup>[569]</sup>.

**Details**

Active scanning process is a task and there is a certain [correct way](#)<sup>[539]</sup> of handling tasks.

Scanning while the Wi-Fi interface is in the associated state ([wln.associationstate=](#)<sup>[558]</sup> 1- PL\_WLN\_ASSOCIATED) or running its own ad-hoc network (wln.associationstate= 2- PL\_WLN\_OWN\_NETWORK) will temporarily disrupt communications between the device and the "current" access point.

Active detection of networks is performed only on allowed channels, as determined by the [wln.domain](#)<sup>[561]</sup> property. This is because an active "probe" signal is transmitted during the active scanning.

Active scanning can detect a networks that doesn't broadcast its SSID, but you still need to know this network's name in advance.

**.Associate Method**

**Function:** Causes the Wi-Fi interface to attempt association with the specified wireless network.

**Syntax:** **wln.associate(byref bssid as string, byref ssid as string, channel as byte, bssmode as pl\_wln\_bss\_modes) as accepted\_rejected**

**Returns:** One of accepted\_rejected constants:  
 0- ACCEPTED.  
 1- REJECTED.

**See Also:** [Associating With Selected Network](#)<sup>[554]</sup>, [Setting Wi-Fi Security](#)<sup>[552]</sup>, [Wln Tasks](#)<sup>[539]</sup>  
[wln.disassociate](#)<sup>[561]</sup>

Part	Description
bssid	The BSSID ("MAC address") of the network with which to associate.
ssid	The name of the target network with which to associate.
channel	Channel on which the target network is operating.
bssmode	Network mode:
ode	0- PL_WLN_BSS_MODE_INFRASTRUCTURE: This is an infrastructure network (access point). 1- PL_WLN_BSS_MODE_ADHOC: This is an ad-hoc (device-to-device) network.

## Details

The association process is a task and there is a certain [correct way](#)<sup>[539]</sup> of handling tasks. Task completion does not imply success -- association result has to be verified by reading the state of the [wln.associationstate](#)<sup>[558]</sup> read-only property after the task is completed.

### **.Associationstate R/O Property**

<b>Function:</b>	Indicates whether the Wi-Fi interface is idle, associated with another network, or running its own ad-hoc network.
<b>Type:</b>	Enum (pl_wln_association_states, byte)
<b>Value Range:</b>	0- PL_WLN_NOT_ASSOCIATED ( <b>default</b> ): The Wi-Fi interface is idle. 1- PL_WLN_ASSOCIATED: The Wi-Fi interface is associated with a wireless network. 2- PL_WLN_OWN_NETWORK: The Wi-Fi interface is running its own ad-hoc network.
<b>See Also:</b>	<a href="#">Associating With Selected Network</a> <sup>[554]</sup> , <a href="#">Disassociating From the Network</a> <sup>[556]</sup> , <a href="#">Creating Own Ad-hoc Network</a> <sup>[555]</sup> , <a href="#">Terminating Own Ad-hoc Network</a> <sup>[556]</sup> , <a href="#">Detecting Disassociation or Offline State</a> <sup>[556]</sup>

---

## Details

After the successful association, which is initiated through the [wln.associate](#)<sup>[557]</sup> method, the value of this property changes to 1- PL\_WLN\_ASSOCIATED. The value is reset back to 0- PL\_WLN\_NOT\_ASSOCIATED if disassociation occurs ([on\\_wln\\_event](#)<sup>[565]</sup> will be generated too).

Disassociation can be induced through the [wln.disassociate](#)<sup>[561]</sup> method or forced by the access point. Disassociation will also happen if the access point goes offline or out of range, or if the GA1000 is powered down, reset, disconnected, or malfunctions.

After the Wi-Fi interface succeeds in creating its own ad-hoc network (see [wln.networkstart](#)<sup>[564]</sup>), the value of this property becomes 2- PL\_WLN\_OWN\_NETWORK. The value is reset back to 0- PL\_WLN\_NOT\_ASSOCIATED when the ad-hoc network is terminated with [wln.networkstop](#)<sup>[564]</sup>.

### **.Boot Method**

<b>Function:</b>	Boots up the Wi-Fi interface, which involves sending to the GA1000 hardware a firmware file for its embedded processor.
<b>Syntax:</b>	<b>wln.boot(offset as dword) as ok_ng</b>
<b>Returns:</b>	One of ok_ng constants: 0- OK: completed successfully. 1- NG: boot failed.

**See Also:** [Booting Up the Hardware](#)<sup>[549]</sup>

Part	Description
offset	Offset of the "ga1000fw.bin" file within the compiled binary of your project. The offset is obtained using the <a href="#">romfile.offset</a> <sup>[375]</sup> read-only property.

**Details**

For wln.boot to succeed, *ga1000fw.bin* file must be present in your project as a binary resource file.

**.Buffrq Method**

**Function:** Pre-requests "numpages" number of buffer pages (1 page= 256 bytes) for the TX buffer of the wln. object.

**Syntax:** **wln.buffrq(numpages as byte) as byte**

**Returns:** Actual number of pages that can be allocated (byte).

**See Also:** [Allocating Buffer Memory](#)<sup>[547]</sup>  
[wln.buffsize](#)<sup>[559]</sup>

Part	Description
numpages	Requested numbers of buffer pages to allocate (recommended value is <b>5</b> )

**Details**

This method will not work if the GA1000 is already operational ([wln.enabled](#)<sup>[562]</sup>= 1-YES).

**.Buffsize R/O Property**

**Function:** Returns the current capacity (in bytes) of the wln. object's TX buffer.

**Type:** Word

**Value Range:** 0-65535, **default**= 0 (0 bytes).

**See Also:** [Allocating Buffer Memory](#)<sup>[547]</sup>  
[wln.buffrq](#)<sup>[559]</sup>

**Details**

---

## .Clkmap Property

<b>Function:</b>	Sets/returns the number of the I/O line to serve as the clock (CLK) line of the GA1000's SPI interface.
<b>Type:</b>	Enum (pl_io_num, byte)
<b>Value Range:</b>	Platform-specific. See the list of pl_io_num constants in the platform specifications. <b>Default</b> = PL_IO_NULL (NULL line).
<b>See Also:</b>	<a href="#">Configuring Interface Lines</a> <sup>[545]</sup> <a href="#">wln.csmmap</a> <sup>[560]</sup> , <a href="#">wln.dimap</a> <sup>[560]</sup> , <a href="#">wln.domap</a> <sup>[562]</sup>

### Details

The selection cannot be changed once the Wi-Fi hardware is already operational ([wln.enabled](#)<sup>[562]</sup>= 1- YES).

This property has no effect on the [EM500W](#)<sup>[138]</sup> platform.

## .Csmmap Property

<b>Function:</b>	Sets/returns the number of the I/O line to serve as the chip select (CS) line of the GA1000's SPI interface.
<b>Type:</b>	Enum (pl_io_num, byte)
<b>Value Range:</b>	Platform-specific. See the list of pl_io_num constants in the platform specifications. <b>Default</b> = PL_IO_NULL (NULL line).
<b>See Also:</b>	<a href="#">Configuring Interface Lines</a> <sup>[545]</sup> <a href="#">wln.clkmap</a> <sup>[560]</sup> , <a href="#">wln.dimap</a> <sup>[560]</sup> , <a href="#">wln.domap</a> <sup>[562]</sup>

### Details

The selection cannot be changed once the Wi-Fi hardware is already operational ([wln.enabled](#)<sup>[562]</sup>= 1- YES).

This property has no effect on the [EM500W](#)<sup>[138]</sup> platform.

## .Dimap Property

<b>Function:</b>	Sets/returns the number of the I/O line to serve as the data in (DI) line of the GA1000's SPI interface.
<b>Type:</b>	Enum (pl_io_num, byte)
<b>Value Range:</b>	Platform-specific. See the list of pl_io_num constants in the platform specifications. <b>Default</b> = PL_IO_NULL (NULL line).
<b>See Also:</b>	<a href="#">Configuring Interface Lines</a> <sup>[545]</sup> <a href="#">wln.clkmap</a> <sup>[560]</sup> , <a href="#">wln.csmmap</a> <sup>[560]</sup> , <a href="#">wln.domap</a> <sup>[562]</sup>

## Details

The selection cannot be changed once the Wi-Fi hardware is already operational ([wln.enabled](#)<sup>[562]</sup>= 1- YES).

This DI line must be connected to the DO pin of the GA1000.

The property has no effect on the [EM500W](#)<sup>[138]</sup> platform.

## **.Disassociate Method**

<b>Function:</b>	Causes the Wi-Fi interface to commence disassociation from the wireless network.
<b>Syntax:</b>	<b>wln.disassociate() as accepted_rejected</b>
<b>Returns:</b>	One of accepted_rejected constants: 0- ACCEPTED. 1- REJECTED.
<b>See Also:</b>	<a href="#">Disassociating From the Network</a> <sup>[556]</sup> , <a href="#">Wln Tasks</a> <sup>[539]</sup> <a href="#">wln.associate</a> <sup>[557]</sup> , <a href="#">wln.associationstate</a> <sup>[558]</sup>

---

## Details

The disassociation process is a task and there is a certain [correct way](#)<sup>[539]</sup> of handling tasks.

## **.Domain Property**

<b>Function:</b>	Selects the domain (area of the world) in which this device is operating. This defines the list of channels on which the Wi-Fi interface will perform active scanning or associate with wireless networks.
<b>Type:</b>	Enum (pl_wln_domains, byte)
<b>Value Range:</b>	0- PL_WLN_DOMAIN_FCC ( <b>default</b> ): FCC domain (US). Allowed channels: 1-11. 1- PL_WLN_DOMAIN_EU: European Union. Allowed channels: 1-13. 2- PL_WLN_DOMAIN_JAPAN: Japan. Allowed channels: 1-14. 3- PL_WLN_DOMAIN_OTHER: All other countries. Allowed channels: 1-11.
<b>See Also:</b>	<a href="#">Selecting Domain</a> <sup>[547]</sup>

---

## Details

This property can't be changed while the Wi-Fi hardware is operational ([wln.enabled](#)<sup>[562]</sup>= 1- YES). Note that domain selection only affects active scanning ([wln.activescan](#)<sup>[558]</sup>) and association ([wln.associate](#)<sup>[557]</sup>). Passive scanning ([wln.scan](#)<sup>[567]</sup>) is not restricted by the selected domain in any way, because the GA1000 will only listen for incoming Wi-Fi signals, without actually transmitting

anything. Selected domain also doesn't limit the ability of the Wi-Fi interface to start its own ad-hoc network ([wln.networkstart](#)<sup>[564]</sup>) on whatever channel you specify.

## .Domap Property

<b>Function:</b>	Sets/returns the number of the I/O line to serve as the data out (DO) line of the GA1000's SPI interface.
<b>Type:</b>	Enum (pl_io_num, byte)
<b>Value Range:</b>	Platform-specific. See the list of pl_io_num constants in the platform specifications. <b>Default</b> = PL_IO_NULL (NULL line).
<b>See Also:</b>	<a href="#">Configuring Interface Lines</a> <sup>[545]</sup> <a href="#">wln.clkmap</a> <sup>[560]</sup> , <a href="#">wln.csmmap</a> <sup>[560]</sup> , <a href="#">wln.dimap</a> <sup>[560]</sup>

---

### Details

The selection cannot be changed once the Wi-Fi hardware is already operational ([wln.enabled](#)<sup>[562]</sup>= 1- YES).

The DO line must be connected to the DI pin of the GA1000.

This property has no effect on the [EM500W](#)<sup>[138]</sup> platform.

## .Enabled R/O Property

<b>Function:</b>	Indicates whether the Wi-Fi interface is operational.
<b>Type:</b>	Enum (no_yes, byte)
<b>Value Range:</b>	0- NO ( <b>default</b> ): The Wi-Fi interface is not operational. 1- YES: The Wi-Fi interface is operational.
<b>See Also:</b>	<a href="#">Bringing Up the Hardware</a> <sup>[549]</sup> , <a href="#">Detecting Disassociation or Offline State</a> <sup>[556]</sup>

---

### Details

The Wi-Fi hardware becomes operational after a successful boot using the [wln.boot](#)<sup>[558]</sup> method, at which time wln.enabled is set to 1- YES.

The Wi-Fi interface is disabled and the wln.enabled is reset to 0- NO if the Wi-Fi hardware is disconnected, powered down, malfunctioned, or was [intentionally reset](#)<sup>[546]</sup>. When this happens, the [on wln event](#)<sup>[565]</sup> event is generated with its wln\_event argument set to 0- PL\_WLN\_EVENT\_DISABLED.

## .Gatewayip Property

<b>Function:</b>	Sets/returns the IP address of the default gateway for the Wi-Fi interface of your device.
<b>Type:</b>	Dot-decimal string
<b>Value Range:</b>	Any IP address, such as "192.168.1.1". <b>Default</b> = "0.0.0.0".

**See Also:** [Setting IP, Gateway, and Netmask](#)<sup>[549]</sup>  
[wln.ip](#)<sup>[563]</sup>, [wln.netmask](#)<sup>[564]</sup>

---

### Details

This property can only be written to when no socket is engaged in communicating through the Wi-Fi interface, i.e. there is no socket for which [sock.statesimple](#)<sup>[505]</sup><> 0- PL\_SSTS\_CLOSED and [sock.currentinterface](#)<sup>[478]</sup>= 2- PL\_INTERFACE\_WLN.

## **.Ip Property**

**Function:** Sets/returns the IP address of the Wi-Fi interface of your device.  
**Type:** Dot-decimal string  
**Value Range:** Any IP address, such as "192.168.100.40". **Default=** "1.0.0.1".  
**See Also:** [Setting IP, Gateway, and Netmask](#)<sup>[549]</sup>  
[wln.gatewayip](#)<sup>[562]</sup>, [wln.netmask](#)<sup>[564]</sup>

---

### Details

This property can only be written to when no socket is engaged in communications through the Wi-Fi interface, i.e. there is no socket for which [sock.statesimple](#)<sup>[505]</sup><> 0- PL\_SSTS\_CLOSED and [sock.currentinterface](#)<sup>[478]</sup>= 2- PL\_INTERFACE\_WLN.

## **.Mac Property**

**Function:** Sets/returns the MAC address of the Wi-Fi interface.  
**Type:** Dot-decimal string  
**Value Range:** Any valid MAC address, i.e. "0.1.2.3.4.5". **Default=** "0.0.0.0.0.0".  
**See Also:** [Setting MAC Address](#)<sup>[548]</sup>

---

### Details

This property can only be written to while the Wi-Fi hardware is not operational ([wln.enabled](#)<sup>[562]</sup>= 0- NO).

The GA1000 add-on board already has a proper MAC address internally. To use this MAC, leave the `wln.mac` at "0.0.0.0.0.0".

## .Netmask Property

<b>Function:</b>	Sets/returns the netmask of the Wi-Fi interface of your device.
<b>Type:</b>	Dot-decimal string
<b>Value Range:</b>	Any valid netmask, such as "255.255.255.0". <b>Default=</b> "0.0.0.0".
<b>See Also:</b>	<a href="#">Setting IP, Gateway, and Netmask</a> <sup>[549]</sup> <a href="#">wln.ip</a> <sup>[563]</sup> , <a href="#">wln.gatewayip</a> <sup>[562]</sup>

### Details

This property can only be written to when no socket is engaged in communications through the Wi-Fi interface, i.e. there is no socket for which [sock.statesimple](#)<sup>[505]</sup><> 0- PL\_SSTS\_CLOSED and [sock.currentinterface](#)<sup>[478]</sup>= 2- PL\_INTERFACE\_WLN.

## .Networkstart Method

<b>Function:</b>	Causes the Wi-Fi interface to commence creating its own ad-hoc network.
<b>Syntax:</b>	<b>wln.networkstart(byref ssid as string, channel as byte) as accepted_rejected</b>
<b>Returns:</b>	One of accepted_rejected constants: 0- ACCEPTED. 1- REJECTED.
<b>See Also:</b>	<a href="#">Creating Own Ad-hoc network</a> <sup>[555]</sup> , <a href="#">Setting Wi-Fi Security</a> <sup>[552]</sup> , <a href="#">Wln Tasks</a> <sup>[539]</sup> <a href="#">wln.networkstop</a> <sup>[564]</sup>

Part	Description
ssid	The name of the ad-hoc network to create.
channel	Channel on which the new ad-hoc network will operate.

### Details

The network creation process is a task and there is a certain [correct way](#)<sup>[539]</sup> of handling tasks. Task completion does not imply success -- the result has to be verified by reading the state of the [wln.associationstate](#)<sup>[558]</sup> read-only property after the task is completed.

## .Networkstop Method

<b>Function:</b>	Causes the Wi-Fi interface to commence the termination of its own ad-hoc network.
<b>Syntax:</b>	<b>wln.networkstop() as accepted_rejected</b>

**Returns:** One of accepted\_rejected constants:  
 0- ACCEPTED.  
 1- REJECTED.

**See Also:** [Terminating Own Ad-hoc Network](#)<sup>[556]</sup>, [Wln Tasks](#)<sup>[539]</sup>  
[wln.networkstart](#)<sup>[564]</sup>

**Details**

The network termination process is a task and there is a certain [correct way](#)<sup>[539]</sup> of handling tasks.

**On\_wln\_event Event**

**Function:** Generated when the wln object detects disassociation from the wireless network or the Wi-Fi hardware is disconnected, powered-down, reset, or is malfunctioning.

**Declaration:** **on\_wln\_event(wln\_event as pl\_wln\_events)**

**See Also:** [Detecting Disassociation or Offline State](#)<sup>[556]</sup>  
[on\\_wln\\_task\\_complete](#)<sup>[565]</sup>

Part	Description
wln_event	Registered event: 0- PL_WLN_EVENT_DISABLED: Wi-Fi hardware has been disconnected, powered down, or is malfunctioning. 1- PL_WLN_EVENT_DISASSOCIATED: Wi-Fi interface has been disassociated from the wireless network.

**Details**

Multiple on\_wln\_event events may be waiting in the event queue. For this reason the doevents statement will be skipped (not executed) if encountered within the event handler for this event or the body of any procedure in the related call chain.

**On\_wln\_task\_complete Event**

**Function:** Generated when the Wi-Fi interface completes executing a given task.

**Declaration:** **on\_wln\_task\_complete(completed\_task as pl\_wln\_tasks)**

**See Also:** [Wln Tasks](#)<sup>[539]</sup>  
[on\\_wln\\_event](#)<sup>[565]</sup>

Part	Description
completed_task	<p>The task just completed:</p> <ol style="list-style-type: none"> <li>1- PL_WLN_TASK_SCAN: Scan task completed (this task is initiated by the <a href="#">wln.scan</a><sup>[567]</sup> method).</li> <li>2- PL_WLN_TASK_ASSOCIATE: Association task completed (this task is initiated by the <a href="#">wln.associate</a><sup>[567]</sup> method).</li> <li>3- PL_WLN_TASK_SETTXPOWER: TX power adjustment task completed (this task is initiated by the <a href="#">wln.settxpower</a><sup>[570]</sup> method). This is an "immediate" task.</li> <li>4- PL_WLN_TASK_SETWEP: WEP mode and keys setup task completed (this task is initiated by the <a href="#">wln.setwep</a><sup>[570]</sup> method). This is an "immediate" task.</li> <li>5- PL_WLN_TASK_DISASSOCIATE: Disassociation task completed (this task is initiated by the <a href="#">wln.disassociate</a><sup>[561]</sup> method).</li> <li>6- PL_WLN_TASK_NETWORK_START: Ad-hoc network creation completed (this task is initiated by the <a href="#">wln.networkstart</a><sup>[564]</sup> method).</li> <li>7- PL_WLN_TASK_NETWORK_STOP: Ad-hoc network termination completed (this task is initiated by the <a href="#">wln.networkstop</a><sup>[564]</sup> method).</li> <li>8- PL_WLN_TASK_SETWEP: WPA mode and keys setup task completed (this task is initiated by the <a href="#">wln.setwpa</a><sup>[571]</sup> method). This is an "immediate" task.</li> </ol>

### Details

The [wln.task](#)<sup>[572]</sup> read-only property will change to 0- PL\_WLN\_TASK\_IDLE along with this event generation.

Multiple on\_wln\_task\_complete events may be waiting in the event queue. For this reason the doevents statement will be skipped (not executed) if encountered within the event handler for this event or the body of any procedure in the related call chain.

## .Rssi R/O Property

<b>Function:</b>	Indicates the strength of the signal being received from the wireless network that the Wi-Fi interface is currently associated with, or wireless peer in case of the ad-hoc network.
<b>Type:</b>	Byte
<b>Value Range:</b>	0-255, <b>default= 0.</b>
<b>See Also:</b>	<a href="#">Associating With Selected Network</a> <sup>[554]</sup> <a href="#">wln.scanresultrssi</a> <sup>[569]</sup>

### Details

The signal strength is expressed in 256 arbitrary levels that do not correspond to any standard measurement unit.

This property is only updated while the Wi-Fi interface is in the non-idle state

([wln.associationstate](#)<sup>[558]</sup><>0- PL\_WLN\_NOT\_ASSOCIATED).

## .Scan Method

- Function:** Causes the Wi-Fi interface to commence either the passive detection of available wireless networks or obtainment of an additional information about a particular network specified by its SSID (name).
- Syntax:** **wln.scan(byref ssid as string) as accepted\_rejected**
- Returns:** One of accepted\_rejected constants:  
 0- ACCEPTED.  
 1- REJECTED.
- See Also:** [Scanning for Wi-Fi Networks](#)<sup>[550]</sup>, [Wln Tasks](#)<sup>[539]</sup>, [wln.activescan](#)<sup>[556]</sup>

Part	Description
ssid	Network name. Leave empty to detect all available networks -- after the scan, the comma-delimited list of networks will be in <a href="#">wln.scanresultssid</a> <sup>[569]</sup> . Alternatively, specify the network name. If the network is detected, its parameters will be available through <a href="#">wln.scanresultssid</a> <sup>[569]</sup> , <a href="#">wln.scanresultbssid</a> <sup>[567]</sup> , <a href="#">wln.scanresultbssmode</a> <sup>[568]</sup> , <a href="#">wln.scanresultchannel</a> <sup>[568]</sup> , <a href="#">wln.scanresultrssi</a> <sup>[569]</sup> , <a href="#">wln.scanresultwpainfo</a> <sup>[569]</sup> .

### Details

Passive scanning process is a task and there is a certain [correct way](#)<sup>[539]</sup> of handling tasks.

Scanning while the Wi-Fi interface is in the associated state ([wln.associationstate](#)<sup>[558]</sup> 1- PL\_WLN\_ASSOCIATED) or running its own ad-hoc network ([wln.associationstate](#)<sup>[558]</sup> 2- PL\_WLN\_OWN\_NETWORK) will temporarily disrupt communications between the device and the "current" access point.

Passive detection of networks is performed on all channels, regardless of the value of the [wln.domain](#)<sup>[561]</sup> property. This is because no radio signal is transmitted during the passive scanning.

Passive scanning won't work with networks that have their SSID (name) hidden. To work with "hidden networks", use [wln.activescan](#)<sup>[556]</sup> method instead.

## .Scanresultbssid R/O Property

- Function:** After a successful scan for a particular network ([wln.scan](#)<sup>[567]</sup> with the ssid specified) this property will contain the BSSID ("MAC address") of this network.
- Type:** Dot-decimal string
- Value Range:** Standard 6-byte MAC value
- See Also:** [Scanning for Wi-Fi Networks](#)<sup>[550]</sup>, [wln.scanresultbssmode](#)<sup>[568]</sup>, [wln.scanresultchannel](#)<sup>[568]</sup>, [wln.scanresultrssi](#)<sup>[569]</sup>, [wln.scanresultssid](#)<sup>[569]</sup>

[wln.scanresultwpainfo](#)<sup>[569]</sup>

---

### Details

This property will not be updated if the [wln.scan](#)<sup>[567]</sup> method is invoked with its ssid argument left empty ("search for all networks" mode).

## **.Scanresultbssmode R/O Property**

<b>Function:</b>	After a successful scan for a particular network ( <a href="#">wln.scan</a> <sup>[567]</sup> with the ssid specified) this property will contain the network mode of this network.
<b>Type:</b>	Enum, byte
<b>Value Range:</b>	0- PL_WLN_BSS_MODE_INFRASTRUCTURE: wireless network with an access point. 1- PL_WLN_BSS_MODE_ADHOC: device-to-device network without an access point.
<b>See Also:</b>	<a href="#">Scanning for Wi-Fi Networks</a> <sup>[550]</sup> <a href="#">wln.scanresultbssid</a> <sup>[567]</sup> , <a href="#">wln.scanresultchannel</a> <sup>[568]</sup> , <a href="#">wln.scanresultrssi</a> <sup>[569]</sup> , <a href="#">wln.scanresultssid</a> <sup>[569]</sup> , <a href="#">wln.scanresultwpainfo</a> <sup>[569]</sup>

---

### Details

This property will not be updated if the [wln.scan](#)<sup>[567]</sup> method is invoked with its ssid argument left empty ("search for all networks" mode).

## **.Scanresultchannel R/O Property**

<b>Function:</b>	After a successful scan for a particular network ( <a href="#">wln.scan</a> <sup>[567]</sup> with the ssid specified) this property will contain the number of the channel on which this network operates.
<b>Type:</b>	Byte
<b>Value Range:</b>	1-14
<b>See Also:</b>	<a href="#">Scanning for Wi-Fi Networks</a> <sup>[550]</sup> <a href="#">wln.scanresultbssid</a> <sup>[567]</sup> , <a href="#">wln.scanresultbssmode</a> <sup>[568]</sup> , <a href="#">wln.scanresultrssi</a> <sup>[569]</sup> , <a href="#">wln.scanresultssid</a> <sup>[569]</sup> , <a href="#">wln.scanresultwpainfo</a> <sup>[569]</sup>

---

### Details

This property will not be updated if the [wln.scan](#)<sup>[567]</sup> method is invoked with its ssid argument left empty ("search for all networks" mode).

## .Scanresultrssi R/O Property

<b>Function:</b>	After a successful scan for a particular network ( <a href="#">wln.scan</a> <sup>[567]</sup> with the ssid specified) this property will contain the strength of the signal received from this network.
<b>Type:</b>	Byte
<b>Value Range:</b>	0-255
<b>See Also:</b>	<a href="#">Scanning for Wi-Fi Networks</a> <sup>[550]</sup> <a href="#">wln.scanresultbssid</a> <sup>[567]</sup> , <a href="#">wln.scanresultbssmode</a> <sup>[568]</sup> , <a href="#">wln.scanresultchannel</a> <sup>[568]</sup> , <a href="#">wln.scanresultssid</a> <sup>[569]</sup> , <a href="#">wln.scanresultwpainfo</a> <sup>[569]</sup> , <a href="#">wln.rssi</a> <sup>[566]</sup>

### Details

This property will not be updated if the [wln.scan](#)<sup>[567]</sup> method is invoked with its ssid argument left empty ("search for all networks" mode).

## .Scanresultssid R/O Property

<b>Function:</b>	After the scan this property will contain a comma-delimited list of discovered networks or the name of a particular network depending on how the scan was performed.
<b>Type:</b>	String
<b>Value Range:</b>	Up to 95 characters of data
<b>See Also:</b>	<a href="#">Scanning for Wi-Fi Networks</a> <sup>[550]</sup> <a href="#">wln.scanresultbssid</a> <sup>[567]</sup> , <a href="#">wln.scanresultbssmode</a> <sup>[568]</sup> , <a href="#">wln.scanresultchannel</a> <sup>[568]</sup> , <a href="#">wln.scanresultrssi</a> <sup>[569]</sup> , <a href="#">wln.scanresultwpainfo</a> <sup>[569]</sup>

### Details

If the [wln.scan](#)<sup>[567]</sup> method was invoked with its name argument left empty, this property will contain the list of all discovered networks. If the name argument specified a particular network and scanning found this network to be present, then this property will contain the name of this network.

## .Scanresultwpainfo R/O Property

<b>Function:</b>	After a successful scan for a particular network ( <a href="#">wln.scan</a> <sup>[567]</sup> with the ssid specified) this property will contain binary data required for WPA/WPA2 security protocol.
<b>Type:</b>	Byte
<b>Value Range:</b>	0-255
<b>See Also:</b>	<a href="#">Scanning for Wi-Fi Networks</a> <sup>[550]</sup> <a href="#">wln.scanresultbssid</a> <sup>[567]</sup> , <a href="#">wln.scanresultbssmode</a> <sup>[568]</sup> ,

[wln.scanresultchannel](#)<sup>[568]</sup>, [wln.scanresultrssi](#)<sup>[569]</sup>,  
[wln.scanresultssid](#)<sup>[569]</sup>

### Details

This property will not be updated if the [wln.scan](#)<sup>[567]</sup> method is invoked with its ssid argument left empty ("search for all networks" mode).

This data is not intended for humans. The property exists to facilitate the operation of the [WLN library](#)<sup>[703]</sup>.

## .Settxpower Method

**Function:** Causes the Wi-Fi interface to commence the adjustment of TX power to the specified level.

**Syntax:** **wln.settxpower(level as byte) as accepted\_rejected**

**Returns:** One of accepted\_rejected constants:  
 0- ACCEPTED.  
 1- REJECTED.

**See Also:** [Setting TX Power](#)<sup>[550]</sup>, [Wln Tasks](#)<sup>[539]</sup>

### Details

Part	Description
level	Value between 4 and 15 that roughly corresponds to the transmitter's output power in dB. Attempting to specify the level < 4 results in level = 4; attempting to specify the level > 15 results in level = 15.

Adjusting TX power is an "immediate" task and there is a certain [correct way](#)<sup>[539]</sup> of handling tasks. "Immediate" means you don't have to wait for the task to complete -- it is finished as soon as wln.settxpower is done executing. The [on wln task complete](#)<sup>[565]</sup> event is still generated.

## .Setwep Method

**Function:** Causes the Wi-Fi interface to commence setting new WEP mode and key.

**Syntax:** **wln.setwep(byref wepkey as string, wepmode as pl\_wln\_wep\_modes) as accepted\_rejected**

**Returns:** One of accepted\_rejected constants:  
 0- ACCEPTED.  
 1- REJECTED.

**See Also:** [Setting WEP Mode and Key](#)<sup>[553]</sup>, [Wln Tasks](#)<sup>[539]</sup>  
[wln.setwpa](#)<sup>[571]</sup>

Part	Description
wep key	A string containing new WEP key. This is a "HEX strings" -- each character in the string represents one HEX digit. The string must contain 10 HEX digits for WEP64 and 26 HEX digits for WEP128. Excessive digits are ignored. Missing digits are assumed to be 0.
wep mode	WEP mode to set: 0- PL_WLN_WEP_MODE_DISABLED: WEP is to be disabled. 1- PL_WLN_WEP_MODE_64: 64-bit WEP is to be used. 0- PL_WLN_WEP_MODE_128: 128-bit WEP is to be used.

**Details**

Changing WEP mode and keys is an immediate task and there is a certain [correct way](#)<sup>[539]</sup> of handling tasks. "Immediate" means you don't have to wait for the task to complete -- it is finished as soon as wln.setwep is done executing. The [on\\_wln\\_task\\_complete](#)<sup>[565]</sup> event is still generated.

**.Setwpa Method**

- Function:** Causes the Wi-Fi interface to commence setting new WPA mode and key.
- Syntax:** **wln.setwpa**(wpa mode as **pl\_wln\_wpa\_modes**, algorithm as **pl\_wln\_wpa\_algorithms**, byref wpa key as **string**, cast as **pl\_wln\_wpa\_unicast\_multicast**) as **accepted\_rejected**
- Returns:** One of accepted\_rejected constants:  
 0- ACCEPTED.  
 1- REJECTED.
- See Also:** [Setting WPA Mode and Key](#)<sup>[553]</sup>, [Wln Tasks](#)<sup>[539]</sup>  
[wln.setwep](#)<sup>[570]</sup>

Part	Description
wep mode	WPA mode to set: 0- PL_WLN_WPA_DISABLED: WPA is to be disabled. 1- PL_WLN_WPA_WPA1_PSK: WPA1-PSK is to be used. 0- PL_WLN_WPA_WPA2_PSK: WPA2-PSK is to be used.
algorithm	Encryption algorithm to be used: 0- PL_WLN_WPA_ALGORITHM_TKIP: TKIP algorithm. 1- PL_WLN_WPA_ALGORITHM_AES: AES algorithm (also referred to as CCMP).
wpa key	A string containing new WPA key. Supposed to be 16 characters long.
cast	Type of key: 0- PL_WLN_WPA_CAST_UNICAST: unicast key.

1- PL\_WLN\_WPA\_CAST\_MULTICAST: multicast key.

### Details

WPA/WPA2 security is very complex. We recommend using the [WLN library](#)<sup>[703]</sup>.

Changing WPA mode and keys is an immediate task and there is a certain [correct way](#)<sup>[539]</sup> of handling tasks. "Immediate" means you don't have to wait for the task to complete -- it is finished as soon as `wln.setwpa` is done executing. The [on\\_wln\\_task\\_complete](#)<sup>[565]</sup> event is still generated.

## .Task R/O Property

<b>Function:</b>	Indicates current wln. task being executed.
<b>Type:</b>	Enum (pl_wln_tasks, byte)
<b>Value Range:</b>	<p>0- PL_WLN_TASK_IDLE (<b>default</b>): No task is in progress.</p> <p>1- PL_WLN_TASK_SCAN: Scan task is in progress (initiated by <a href="#">wln.scan</a><sup>[567]</sup>).</p> <p>2- PL_WLN_TASK_ASSOCIATE: Association task is in progress (initiated by <a href="#">wln.associate</a><sup>[557]</sup>).</p> <p>3- PL_WLN_TASK_SETTXPOWER: TX power adjustment task is in progress (initiated by <a href="#">wln.settxpower</a><sup>[570]</sup>).</p> <p>4- PL_WLN_TASK_SETWEP: WEP mode and keys setup task is in progress (initiated by <a href="#">wln.setwep</a><sup>[570]</sup>).</p> <p>5- PL_WLN_TASK_DISASSOCIATE: Disassociation task is in progress (initiated by <a href="#">wln.disassociate</a><sup>[561]</sup>).</p> <p>6- PL_WLN_TASK_NETWORK_START: Ad-hoc network creation task is in progress (initiated by <a href="#">wln.networkstart</a><sup>[564]</sup>).</p> <p>7- PL_WLN_TASK_NETWORK_STOP: Ad-hoc network termination task is in progress (initiated by <a href="#">wln.networkstop</a><sup>[564]</sup>).</p> <p>8- PL_WLN_TASK_SETWPA: WPA mode and keys setup task is in progress (initiated by <a href="#">wln.setwpa</a><sup>[571]</sup>).</p>
<b>See Also:</b>	<a href="#">Wln Tasks</a> <sup>[539]</sup>

### Details

The wln. object will only accept another task for execution after the previous task has been completed (`wln.task= 0- PL_WLN_TASK_IDLE`). Whenever a task completes, an [on\\_wln\\_task\\_complete](#)<sup>[565]</sup> event is generated.

## Libraries

Powerful as they are, our [platforms](#)<sup>[138]</sup> (with their [objects](#)<sup>[231]</sup> and [functions](#)<sup>[205]</sup>) still leave you with a fair amount of coding to do for many common tasks. Official Tibbo libraries aim to alleviate this burden by providing a framework of standard plug-and-play code modules that you can freely reuse in your projects.

---

In this section:

- [Common Library Info](#)<sup>[575]</sup> section explains how our libraries are organized.
- [Library Reference](#)<sup>[580]</sup> contains detailed documentation on all our libraries.

**... and here is something to GRAB YOUR ATTENTION:**

Many of our libraries now feature [configurators](#)<sup>[578]</sup> -- HTML/JavaScript-based editors for configuration files. Trust us, these really simplify your life. Instead of going on and on about why this is cool, we limit ourselves to a descriptive screenshot (it is from the [AggreGate library](#)<sup>[580]</sup>):

 **Library Options (mouse over for hint)**

Debug Printing  
 Login Control  
 Using Custom RTC  
 Reference Library (Settings):    
 Reference Library (Tables):  

 **Generic Info (root)**

Description	Context Type	Status
AGG_TEST_DEVICE	apoint	OK

 **Variables Definitions (root)**

Variable Name	Reference Source	Group/Description	Status
BR	Setting Library	Access Control/Baudrate	OK
EG	Setting Library	Access Control/Generate Event	OK
UT	Setting Library	Access Control/Unlock Time	OK
DS	Setting Library	Access Control/Door State	OK
user	Table Library	Access Control/user	OK

 **Functions Definitions (root)**

Function Name	Status
UL	OK

 **Events Definitions (root)**

Event Name	Event Type	Level	Status
DB	Instant Event	Notice	OK
ACE	Stored Event	None	OK

 **Summary Report**

Number of Event Field(s): 2

Max Event Field Value Length: 23

Total Number of Customized Item(s): 8

## Common Library Info

Below you will find:

- [Library Sets](#)<sup>[575]</sup>
- [Anatomy of Tibbo Libraries](#)<sup>[576]</sup>
- [Libraries and Platforms](#)<sup>[577]</sup>
- [Adding Library Files to Projects](#)<sup>[577]</sup>
- [About Get\\_info\(\) API Functions](#)<sup>[577]</sup>
- [Library Configurators](#)<sup>[578]</sup>


## Library Sets

By default, libraries reside in the platforms folder, in the `\src` subfolder ("src" stands for "sources").

Go there and you will discover several internal folders, with names like **0\_90** and **2\_00**. Each one of those is a **library set**.

All libraries employed in your project always come from the same library set. The idea behind library sets is that you want to freeze the libraries for use in a particular project, while we need to continue expanding them. Once the library set is selected, it stays unchanged (or, rather, we don't change it), and so does your project. If we want to add something, we create a new set and make changes there. You can then use this new library set in your future projects.

The current library set is selected in the [Project Settings](#)<sup>[38]</sup> dialog. When starting a new project, choose the library set with the highest version number. This will be the latest one we've got.



## Anatomy of Tibbo Libraries

Most Tibbo libraries are supplied as a pair of files -- a **.tbs** file with all the code, and a **.tbh** header file with declarations. Both must be [added](#)<sup>[577]</sup> to your project.

Tibbo libraries consist of a set of procedures (subs and functions) that typically fall into three categories:

- **API procedures** provide a way for your program to control and interact with the library. For example, the [DHCP](#)<sup>[668]</sup> library has a [dhcp\\_start\(\)](#)<sup>[636]</sup> function that launches the DHCP client on the specified network interface. It is usually up to you to select when and how to invoke API procedures.
- **Event procedures** must be called from corresponding event handlers and you don't have any leeway in how you implement this. Each event procedure must be properly called, or the library will not work correctly. Typically, you only need to call the procedure without any additional conditional code surrounding the call. If several libraries "hook" onto the same event then you can call event procedures of different libraries in any order.
- **Callback procedures** have their bodies outside of their library. That is, the libraries will expect you to create the bodies for callback procedures elsewhere in your code (and may we suggest that you choose to have them in the **device.tbs** file of your project). Callback procedures are used by libraries to inform your "other code" of events happening within the library. For example, the [DHCP](#)<sup>[668]</sup> library calls the [callback\\_dhcp\\_ok\(\)](#)<sup>[638]</sup> procedure whenever a DHCP process completes successfully. Arguments for this procedure carry the newly obtained IP and related parameters. You can then place necessary code within [callback\\_dhcp\\_ok\(\)](#). The is supposed to update your device's IP, etc. according to the data supplied by the DHCP library.

Virtually every library has a number of defines located in the **.tbh** (header) file of the library. Defines determine how the library operates -- they are library "options". Each define looks like this:

```
#ifndef DHCP_DEBUG_PRINT
    #define DHCP_DEBUG_PRINT 0
#endif
```

Libraries that come with [configurators](#)<sup>[578]</sup> take care of all defines automatically. Just edit the stuff in the configurator and you are done. Some libraries don't have configurators, mostly because there isn't much to configure. With such libraries you need to add your own `#define` statements as described in the documentation.

Do not edit library header files! Instead, put your `#define` statements into the [global.tbh](#)<sup>[578]</sup> file, like this:

```
global.tbh:

'DEFINES-----
#define DHCP_DEBUG_PRINT 1 'this overrides the default value, which is 0

'INCLUDES-----
include "dhcp\trunk\dhcp.tbh"
```

## Libraries and Platforms

Some libraries can't run on every [platform](#)<sup>[136]</sup> -- there may be conditions or requirements that the platform must satisfy in order for a certain library to run on it. For example, the [WLN library](#)<sup>[703]</sup> can only run on platforms that support the Wi-Fi ([wln](#)<sup>[538]</sup>) network interface.

Such limitations, if any, are described under "Supported platforms" in the library info table (found on the title page of each library manual).

## Adding Library Files to Projects

Most Tibbo libraries are supplied as a pair of files -- a **.tbs** file with all the code, and a **.tbh** header file with declarations. Both must be added to your project.

Reminder: library files you are adding always come from the selected [library set](#)<sup>[575]</sup>.

To add library files to your project, follow the instructions under [Adding, Removing and Saving Files](#)<sup>[18]</sup> (the section about adding existing files).

Library files are not copied into your project's directory. They are just "referenced". Notice also how they appear in the Libraries tree node of the [project tree](#)<sup>[134]</sup>. Added library files are initially locked for editing. This is why you will see their file names in gray, with the "lib, lock" label printed next to them as well.

You can unlock the files (by right-clicking on the file in the tree and selecting "Unlock"), but this is not recommended.



Do not change the code in the library files. If you feel that a certain library doesn't fully answer your needs and requires modifications, copy the library files into your project's directory, add these files as the project files and then modify the code in the "derivative" files.

## About `_get_info()` API Functions

Most libraries include `_get_info()` API functions (as an example, see [dhcp\\_get\\_info](#)<sup>[636]</sup>). These are created with a purpose of providing a standard interface for obtaining various library information. "Questions" you application may want to "ask" will depend on the nature of the library.

Each `_get_info()` procedure accepts, as the main parameter, the **info\_element** argument which specifies what kind of information is being requested. There is always a corresponding **\_info\_elements** enum, which lists all information elements available.

There is also a second argument -- **extra\_data** (string) -- which is used for passing additional information when necessary.

For universality, `_get_info()` functions return data in a string form. It is your application's responsibility to handle the returned data correctly. For example, if you requested the number of buffer pages required for correct library operation, then your application should convert the returned string into a value.

## Library Configurators

Configurators are HTML/JavaScript-based editors for configuration files.

Internally, configuration files are text files that contain (define) necessary data (for the library to operate). For example, the configuration file for the AGG (AggreGate) library contains text describing AggreGate variables, functions, and events. Looking at the "unshielded" file reveals some really heavy stuff:

```

==info root      <R=<AGG_TEST_DEVICE><apoint>>
==variables root  <R=<version><<<version><S>> <M=1>
<X=1>><V=Version><1><0><^><remote|General><^>>
~~<R=<date><<<date><D>> <M=1> <X=1>><Date/Time><1><0><^><remote|General><^>>
~~<R=<modtime><<<variable><S>> <<modtime><D><F=N>>><Modification
time><1><0><^><^>>
>>BR S          <R=<BR><<<BR><I><V=<L=0
13>><S=<1200=0><2400=1><4800=2><9600=3><19200=4><38400=5><57600=6><115200=7>
<150=8><300=9><600=10><28800=11><230400=12><460800=13>>><M=1><X=1>><Baudrate>
<1><1><^><remote|Access Control><^>>
>>EG S          <R=<EG><<<EG><B>><M=1><X=1>><Generate Event><1><1><^><remote|Access
Control><^>>
>>UT S          <R=<UT><<<UT><I><V=<L=0 255>>><M=1><X=1>><Unlock
Time><1>><1><^><remote|Access Control><^>>
>>DS S          <R=<DS><<<DS><I><S=<Closed=0><Open=1>>><V=<L=0
1>>><M=1><X=1>><Door State><1><0><^><remote|Access Control><^>>
>>user T        <R=<user><<<user_id><S><V=<L=1 14>><A=123456>><<name><S><V=<L=0
31>>><M=0><X=1024>><user><1><1><^><remote|Access Control><^>>
==functions root
<R=<hash><<<<context><S>><<variable><S>>><M=1><X=1>><<<hash><I>>><M=1><X=1>>><Table
Hash><^><^>>
~~<R=<finishTable><<<<context><S>><<variable><S>>><M=1><X=1>><<<hash><I>>><M=1><X=1>>><
Finish Table><^><^>>
~~<R=<startTable><<<<context><S>><<variable><S>>><M=1><X=1>><<M=0><X=0>>><Start
Table><^><^>>
~~<R=<addRecord><<<<context><S>><<variable><S>><<record><S>>><M=1><X=1>><<M=0><X=0>>>
<Add Record><^><^>>

```

We are sure you'd rather look at this (see below).

Descriptor files are added like any other files (see [Adding, Removing and Saving Files](#)<sup>[18]</sup>). The **Type** is set to *Configuration File*, and then the **Format** is set to the format of the library you are dealing with.

 **Library Options (mouse over for hint)**

- Debug Printing
- Login Control
- Using Custom RTC
- Reference Library (Settings):  
- Reference Library (Tables):  

 **Generic Info (root)**

Description	Context Type	Status
AGG_TEST_DEVICE	apoint	OK

 **Variables Definitions (root)**

- 

Variable Name	Reference Source	Group/Description	Status
BR	Setting Library	Access Control/Baudrate	OK
EG	Setting Library	Access Control/Generate Event	OK
UT	Setting Library	Access Control/Unlock Time	OK
DS	Setting Library	Access Control/Door State	OK
user	Table Library	Access Control/user	OK

- 

 **Functions Definitions (root)**

- 

Function Name	Status
UL	OK

- 

 **Events Definitions (root)**

- 

Event Name	Event Type	Level	Status
DB	Instant Event	Notice	OK
ACE	Stored Event	None	OK

- 

 **Summary Report**

Number of Event Field(s): 2  
 Max Event Field Value Length: 23  
 Total Number of Customized Item(s): 8

## Library Reference

This library reference documents the library set **V2.0.0**.

This is the library set which is recommended for use with all new projects.

Here is the breakdown of available libraries, by levels. The levels reflect library dependencies. For example, the [SOCK](#)<sup>[664]</sup> and [FILENUM](#)<sup>[641]</sup> libraries are on the lowest level because they do not depend on any other libraries. The [STG](#)<sup>[668]</sup> (settings) library is one level higher because its operation requires the services of the FILENUM library (albeit optionally).

Dependencies may be "hard", soft, or conditional. Hard dependency is when "library A relies on library B". For example, the [DHCP](#)<sup>[618]</sup> library needs the SOCK library, or the project won't even compile.

Soft dependencies are caused by the anticipated logic of operation. For example, the DHCP library does not technically need the STG library. However, as demonstrated in the [DHCP sample code](#)<sup>[622]</sup>, it is nice to have the STG library in the project because it can help us store the obtained IP. Hence, the DHCP library sits higher than the STG library.

Example of a conditional dependency: the DHCP library doesn't require the [WLN](#)<sup>[703]</sup> library, unless you want to run DHCP over the Wi-Fi interface, in which case the WLN library becomes necessary.

<b>High (top)</b>
<a href="#">AGG</a> <sup>[580]</sup> (AggreGate)
<a href="#">DHCP</a> <sup>[618]</sup>
<a href="#">WLN</a> <sup>[703]</sup> (Wi-Fi Association); <a href="#">GPRS</a> <sup>[645]</sup> (PPP link negotiation); <a href="#">PPPOE</a> <sup>[655]</sup> (PPPoE Login)
<a href="#">STG</a> <sup>[668]</sup> (Settings); TBL (Tables) [not yet documented]
<a href="#">SOCK</a> <sup>[664]</sup> (Socket numbers); <a href="#">FILENUM</a> <sup>[641]</sup> (File numbers); TIME (Date/Time) [not yet documented]
<b>Low (bottom)</b>

The Library Reference section introduces libraries in the top-to-bottom order.

### AGG (AggreGate) Library

The AGG library implements an interface to Tibbo AggreGate Server (<http://aggregate.tibbo.com>). It is the "agent" that runs on your Tibbo BASIC device and connects it to the server using Tibbo's proprietary AggreGate Communication Protocol, or ACP ([http://aggregate.tibbo.com/docs/ap\\_protocol.htm](http://aggregate.tibbo.com/docs/ap_protocol.htm)). Among the six ways to connect a device to the AggreGate server (<http://aggregate.tibbo.com/technology/connectivity.html>), using the library fast-tracks you through either the "second way" or the "fourth way".

The second way -- "Connecting An Existing Device With AggreGate Agent" -- assumes that there is a "legacy" device which is already designed, and possibly in production. This device knows nothing about Tibbo's AggreGate technology, yet you want to connect it to the AggreGate server. In order to achieve this, you use a Tibbo BASIC module or controller ([EM1000](#)<sup>[143]</sup>, [DS1206](#)<sup>[158]</sup>, etc.) to act as an

"adaptor" that translates between the native protocol (or signals) of the legacy device and the AggreGate server. The fastest way to get this done is to write a Tibbo BASIC application that relies on the AGG library for the ACP implementation.

The fourth way -- "Designing A New Device Based On Programmable Module" -- is for when you are building a new device from scratch and you want this device to work with AggreGate. You take one of our very capable modules (such as the [EM1000](#)<sup>[143]</sup>) and use it as the "CPU" of the new device. You then task this "CPU" with all kinds of things that make your device operational. One of the tasks -- communicating with the AggreGate server -- is handled by the AGG library.

The AggreGate Communication Protocol (ACP) is rather complex and would take you quite some time to read through, comprehend, and implement -- have you not had the AGG library. When you are using the library, all this complexity is hidden behind an easy-to-use [configurator](#)<sup>[583]</sup>. Fill in all the necessary "items", and the server will know how to work with your device.

Without resorting to rewriting the AggreGate manual (<http://aggregate.tibbo.com/docs/>), let's remind ourselves that from the AggreGate's point of view, your device is an "object" which comprises items of three kinds: variables (properties), functions (methods), and events. To avoid confusion with the internal variables, methods, and events of Tibbo BASIC, we will refer to AggreGate ones as **A-variables**, **A-functions**, and **A-events**.

An A-variable can be a simple single-value affair, an array of values, or a full-blown data table (and it will still be a "variable" in the AggreGate's view). The AGG library relies on the [STG \(settings\)](#)<sup>[668]</sup> library for storing single-value and array A-variables. This provides for persistent and reliable storage of A-variables, and also -- through [pre-gets and post-sets](#)<sup>[683]</sup> -- for controlling and monitoring the device operation through A-variables (settings). Naturally, the latter will require the custom code to be written and placed into [callback\\_stg\\_pre\\_get\(\)](#)<sup>[700]</sup> and [callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup>.

Table A-variables are handled through the **TBL (tables)** library [not yet documented].

A-functions and A-events require custom code to be written, so it's not enough to just put necessary data into the [configurator](#)<sup>[583]</sup>.

## Library Info

### Supported platforms:

Any platform. If the platform of your choice doesn't support the [RTC](#)<sup>[375]</sup> you will have to implement date/time-keeping in your own way (for example, by connecting an external RTC chip and writing necessary code).

### Files to include:

aggregate.tbs, aggregate.tbh (from *current\_library\_set\aggregate\trunk\*).

### Dependencies:

[SOCK](#)<sup>[664]</sup> library;

TIME library [not yet documented];

[WLN](#)<sup>[703]</sup> library if your application will be connecting to the AggreGate server through Wi-Fi;

[GPRS](#)<sup>[645]</sup> library if your application will be connecting to the AggreGate server through GPRS.

### API procedures:

[agg\\_start\(\)](#)<sup>[607]</sup> -- starts the AGG library, parses the configuration file, prepares all necessary variables.

Use [API procedures](#) <sup>[576]</sup> to interact with the library.

[agg\\_stop\(\)](#) <sup>[608]</sup> -- stops the AGG library causing it to release occupied buffers.

[agg\\_get\\_connection\\_state\(\)](#) <sup>[609]</sup> -- gets the current state of the connection to the AggreGate server

[agg\\_record\\_decode\(\)](#) <sup>[609]</sup> -- extracts the value of the specified argument from the encoded string containing the values of all arguments for an A-function.

[agg\\_record\\_encode\(\)](#) <sup>[610]</sup> -- appends the argument's value to the encoded A-function's argument string in preparation for sending this string to the AggreGate server.

[agg\\_fire\\_instant\\_event\(\)](#) <sup>[610]</sup> -- generates an A-event and sends it to the AggreGate server without storing it into the log.

[agg\\_stored\\_event\\_added\(\)](#) <sup>[611]</sup> -- must be called every time a stored A-event is added to the log file.

[agg\\_proc\\_stored\\_events\(\)](#) <sup>[612]</sup> -- nudges the AGG library to process stored A-events.

#### Event procedures:

[agg\\_proc\\_timer\(\)](#) <sup>[612]</sup> -- call this from the [on\\_sys\\_timer\(\)](#) <sup>[533]</sup> event handler.

[agg\\_proc\\_data\(\)](#) <sup>[612]</sup> -- call this from the [on\\_sock\\_data\\_arrival\(\)](#) <sup>[489]</sup> event handler.

[agg\\_proc\\_data\\_sent\(\)](#) <sup>[613]</sup> -- call this from the [on\\_sock\\_data\\_sent\(\)](#) <sup>[489]</sup> event handler.

[agg\\_proc\\_sock\\_event\(\)](#) <sup>[612]</sup> -- call this from the [on\\_sock\\_event\(\)](#) <sup>[490]</sup> event handler.

#### Callback procedures:

Implement the bodies of [callback procedures](#) <sup>[576]</sup> elsewhere in your project.

[callback\\_agg\\_get\\_firmware\\_version\(\)](#) <sup>[613]</sup> -- requests the version string for the current application.

[callback\\_agg\\_device\\_function\(\)](#) <sup>[613]</sup> -- invoked when the device needs to execute an A-function.

[callback\\_agg\\_synchronized\(\)](#) <sup>[614]</sup> -- informs of the completion of the synchronization process between the device and the AggreGate server.

[callback\\_agg\\_pre\\_buffrq\(\)](#) <sup>[614]</sup> -- called when the library needs to allocate buffer space and the required space is not available.

[callback\\_agg\\_buff\\_released\(\)](#) <sup>[615]</sup> -- called when the library no longer needs buffers and released them.

[callback\\_agg\\_error\(\)](#) <sup>[615]</sup> -- informs of an error or condition detected within the library.

[callback\\_agg\\_convert\\_setting\(\)](#) <sup>[616]</sup> -- invoked every time an A-variable is being read or written. Provides an opportunity to change the value or type before writing to a setting or after reading from a setting.

[callback\\_agg\\_convert\\_event\\_field\(\)](#)<sup>[617]</sup> -- invoked every time a stored A-event is being extracted from the log and sent to the server. Provides an opportunity to change the value or type of A-event arguments before sending the stored A-event to the server.

[callback\\_agg\\_rtc\\_sg\(\)](#)<sup>[618]</sup> -- invoked when the library needs to get or set the device's date and time. Necessary only when "use custom RTC" option is selected in the [configurator](#)<sup>[583]</sup>.

**Required buffer space:**

4 buffer pages

## AggreGate Configurator

The AggreGate configurator is a [JavaScript-based editor](#)<sup>[578]</sup> for the AggreGate configuration file. Do not confuse the two. The AggreGate configuration file is a part of your project (it is a resource file). The configurator is a "representer" -- it provides a convenient interface for the editing of the configuration file. Along with providing a pleasant interface, the configurator masks the enormous complexity of the underlying configuration file.

The following [access control demo](#)<sup>[585]</sup> will teach you how to use the configurator. For now, enjoy this screenshot...

**Library Options (mouse over for hint)**

Debug Printing  
 Login Control  
 Using Custom RTC  
 Reference Library (Settings):    
 Reference Library (Tables):

**Generic Info (root)**

Description	Context Type	Status
AGG_TEST_DEVICE	apoint	OK

**Variables Definitions (root)**

Variable Name	Reference Source	Group/Description	Status
BR	Setting Library	Access Control/Baudrate	OK
EG	Setting Library	Access Control/Generate Event	OK
UT	Setting Library	Access Control/Unlock Time	OK
DS	Setting Library	Access Control/Door State	OK
user	Table Library	Access Control/user	OK

**Functions Definitions (root)**

Function Name	Status
UL	OK

**Events Definitions (root)**

Event Name	Event Type	Level	Status
DB	Instant Event	Notice	OK
ACE	Stored Event	None	OK

**Summary Report**

Number of Event Field(s): 2

Max Event Field Value Length: 23

Total Number of Customized Item(s): 8


## The Access Control Demo

We are going to teach the AGG library by creating a simple access control application. The application is super-minimalistic but it still implements the core of access control functionality:

- Monitoring one door;
- Maintaining a user table (a list of allowed users and their access codes) and granting access;
- Sounding alarm when the door is forced;
- Allowing for remote door opening by the AggreGate operator.

The plan is to allow running this access control demo on most of our BASIC-programmable devices. You will need a bit of a "make believe" to be able to see an access control system in a product like our DS1206:

- We will pretend that the [green status LED](#)<sup>[200]</sup> is the door lock. Green LED ON = unlocked.
- We will further pretend that the [red status LED](#)<sup>[200]</sup> is the alarm relay. Red LED ON = alarm (door forced).
- We will imagine that the [MD button](#)<sup>[201]</sup> is our door sensor. MD button pressed = door opened.
- Finally, we will use the serial port for receiving user codes. You can connect a real card reader, or use I/O NINJA to type in the codes.



The application will work on BASIC-programmable Tibbo devices with RTC. Examples

of such devices:

- [DS1206](#)<sup>[186]</sup> (shown above)
- [DS1202](#)<sup>[181]</sup>
- [DS1000](#)<sup>[164]</sup>
- [EM1000](#)<sup>[143]</sup> (EM1000EV, EM1000TEV)
- [EM1206](#)<sup>[158]</sup> (EM1206EV)
- ...

If you are designing a real access control system based on our module or device, you will have no difficulty converting this demo application to driving real relays, monitoring real sensors, etc.

## The Steps.1.3

Here is our action plan for creating a simple access control application. To follow the steps, download **test\_agg\_lib.zip** archive from our website:

<http://tibbo.com/basic/resources.html>.

The archive contains all the implementation steps as listed below:

1. [Prepare](#)<sup>[586]</sup> (install, configure) the AggreGate server and client.
2. [Embryonic project](#)<sup>[587]</sup> -- the device connects to the server, does nothing else (**test\_agg\_lib\_1**).
3. [Add setting A-variables](#)<sup>[588]</sup> for storing the device configuration (**test\_agg\_lib\_2**).
4. [Add table A-variable](#)<sup>[593]</sup> for storing user codes (**test\_agg\_lib\_3**).
5. [Add an A-function](#)<sup>[596]</sup> for remote door unlocking (**test\_agg\_lib\_4**).
6. [Generate instant A-event](#)<sup>[598]</sup> on device boot (**test\_agg\_lib\_5**).
7. [Generate stored A-event](#)<sup>[601]</sup> for access control activity reporting (**test\_agg\_lib\_6**).
8. [Add the glue code](#)<sup>[605]</sup> that ties it all together (**test\_agg\_lib\_6**).

## Preparing the AggreGate Server

The AggreGate Server and AggreGate client software can be downloaded here:

<http://aggregate.tibbo.com/downloads.html>

Be careful to select correct files!

You can install both the Server and Client components on the same PC.

The demo application you are about to test expects the AggreGate server to have an account named **admin**.

## Step 1: The Embryo

This step corresponds to **test\_agg\_lib\_1**.

In this step we are going to create an embryonic application. It will be able to connect to the AggreGate server and transmit the minimally necessary identifying information.

The success of this step depends on many factors. You have to [correctly install and prepare](#)<sup>[586]</sup> the **AggreGate Server** and **AggreGate Client** software. You have to use matching account names on the server and on the device. Passwords must match. The IP address of your device must be correctly chosen. The IP address of the server must be specified correctly, and so on. In other words, pay attention to all the details!

### The steps

We assume you are not going to type everything in from scratch and just open the **test\_agg\_lib\_1** project. Notice that...

1. The project contains the [SOCK](#)<sup>[664]</sup> and TIME libraries [not yet documented].
2. **Aggregate.tbs** and **aggregate.tbh** are [added](#)<sup>[577]</sup> to the project as well (from *current\_library\_set\aggregate\trunk\*). There is also a necessary line in **global.tbh**: **include "aggregate\trunk\aggregate.tbh"**.
3. There is an **aggregate.txtxt** [configuration file](#)<sup>[583]</sup> with type= **configuration file**, and format= **AggreGate (AGG) library**. There is a line in **global.tbh** that is required for the configuration file to work correctly: [includepp](#)<sup>[96]</sup> **"aggregate.txtxt"**.
4. In the configuration file, **Debug Printing** is *enabled*. This allows you to "see what's going on". Don't forget to *disable* this later, after you've made sure that the library operates as expected.
5. Also, the **Description** field is set to *AGG\_TEST\_DEVICE*. The **Context Type** is *Apoint*.
6. AGG library event procedures are added to event handlers:
  - [agg\\_proc\\_timer\(\)](#)<sup>[612]</sup> is in the [on\\_sys\\_timer\(\)](#)<sup>[533]</sup> event handler (this library assumes that this event is generated twice per second);
  - [agg\\_proc\\_data\(\)](#)<sup>[612]</sup> is in the [on\\_sock\\_data\\_arrival\(\)](#)<sup>[489]</sup> event handler;
  - [agg\\_proc\\_sock\\_event\(\)](#)<sup>[612]</sup> is in the [on\\_sock\\_event\(\)](#)<sup>[490]</sup> event handler (the exact line is **agg\_proc\_sock\_event(newstate,newstatesimple)**).
7. There are empty callback procedures in **device.tbs**:
  - [callback\\_agg\\_get\\_firmware\\_version\(\)](#)<sup>[613]</sup>;
  - [callback\\_agg\\_pre\\_buffrq\(\)](#)<sup>[614]</sup>;
  - [callback\\_agg\\_buff\\_released\(\)](#)<sup>[615]</sup>;
  - [callback\\_agg\\_error\(\)](#)<sup>[615]</sup>;
  - [callback\\_agg\\_device\\_function\(\)](#)<sup>[613]</sup>;
  - [callback\\_agg\\_synchronized\(\)](#)<sup>[614]</sup>.
8. [Callback\\_agg\\_get\\_firmware\\_version\(\)](#)<sup>[613]</sup> contains the code that returns the firmware version string. There is a **#define FIRMWARE\_VERSION** in **global.tbh**.
9. [on\\_sys\\_init\(\)](#)<sup>[533]</sup> calls [agg\\_start\(\)](#)<sup>[607]</sup> -- this is required to make the library

operational. Notice how we check the code returned by `agg_start()`!


- Ours is a simple demo and we are sure we won't have memory shortage. In large projects where a lot of things compete for memory you may get the `callback_agg_pre_buffrq()` call. This will indicate that the AGG library doesn't have enough memory for its buffers and that you need to clear up this memory right inside `callback_agg_pre_buffrq()`. Failure to do so will result in the `EN_AGG_STATUS_INSUFFICIENT_BUFFER_SPACE` code returned by `agg_start()`.

## The result

With debug printing enabled, you will see the following output in TIDE:

```
AGG() > ---START---
AGG() > connection established
AGG() > Device synchronized with the server
```

At the same time your device will appear in AggreGate. Nothing fancy yet, just the basics:



## Step 2: Adding Setting A-variables

This step corresponds to `test_agg_lib_2`.

In this step we are going to add necessary setting A-variables. These will be used to store the few configuration and status parameters our application requires.

A-variables we are going to have are:

- The **BR** setting to store the baudrate of the serial port. This will allow us to select a standard baudrate from a list of baudrates (like 9600, 19200, etc.)
- The **EG** setting to enable/disable access control event generation.
- The **UT** setting to store the unlock time for the door. This is the number of *half-second intervals* that the door lock will stay unlocked for (once it is unlocked).
- The **DS** setting for *reading* the current door state (closed or opened).

## The steps

Looking now at the **test\_agg\_lib\_2** project, notice that...

1. The [STG](#)<sup>[668]</sup> library is now in the project (and all related steps were taken, including calling [stg\\_start\(\)](#)<sup>[691]</sup> in [on\\_sys\\_init\(\)](#)<sup>[533]</sup>, etc.).
2. A way to [initialize settings](#)<sup>[677]</sup> is provided. After each boot, the device will start blinking its red and green [status LEDs](#)<sup>[200]</sup>. This will continue for 5 seconds. If you press the [MD button](#)<sup>[201]</sup> within this time, [stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup> will be called. Reboot the device after the green status LED is turned on. If you do not press the button within the 5-second time window, the application will continue running. All related code is in the [on\\_sys\\_init\(\)](#)<sup>[533]</sup> event handler.
3. **Settings.txt** [defines required settings](#)<sup>[590]</sup>. Notice that the **Timestamp** option is enabled in the setting [configurator](#)<sup>[670]</sup>. This is because the AGG library requires settings to carry timestamps.
4. **AggreGate.txt** [lists required A-variables](#)<sup>[591]</sup>.
5. There is an additional [callback procedure](#)<sup>[576]</sup> in **device.tbs** -- for [callback\\_agg\\_convert\\_setting\(\)](#)<sup>[616]</sup>. Examine the code -- it "converts" between the UT setting (measuring time in half-second intervals) and the UT A-variable (measuring time in seconds). You can now see this procedure's usefulness -- it allows you to store values differently compared to how they are perceived in AggreGate.


## The result

You will now be able to see newly created A-variables in the AggreGate Client (as shown on the screenshot below). Notice how all four A-variables appear on the **Access Control** tab? This is [defined](#)<sup>[591]</sup> in the AggreGate configurator.

Notice also that each A-variable is displayed/edited differently:

- The Baudrate (**BR**) setting has a drop-down which shows all available values;
- The Generate Event (**GE**) setting as a checkbox because it is of the boolean type;
- The Unlock Time (**UT**) setting is just a plain value that is expressed in seconds (although the **UT** setting is in half-seconds).
- The Door State (**DS**) setting displays custom values "closed" and "opened" and is read-only.

Setting A-variables as we have them now are not doing anything useful on the device just yet. They simply exist as values. We will [glue it all together](#)<sup>[605]</sup> later.



## Define Required Settings

Add **BR**, **EG**, **UT**, and **DS** variables using STG library's [configurator](#)<sup>[670]</sup>. You should end up with a setting table as shown below. Some things to notice:

- The **Timestamp** is enabled. This is *required* by the AggreGate library.
- The **BR** setting has the maximum value of 13. This is because we will support 14 different baudrates (0~13).
- The **EG** setting has the maximum value of 1. On the AggreGate side it will be boolean, hence there are only two possible values for it: 0 and 1.
- The **UT** setting is limited to 255 max. This is measure in half-second intervals (this is how often the [on\\_sys\\_timer](#)<sup>[533]</sup> event is generated).
- The **DS** setting resides in the volatile memory (RAM). This is a read-only parameter that simply reflects the door state, so it makes no sense to put it into the EEPROM.

The screenshot shows the AGG Configurator software interface. The top window title bar includes tabs for 'aggregate.xbt', 'settings.xbt', 'main.tbs', 'global.tbh', 'device.tbs', 'aggregate.tbh', and 'aggregate.tbs'. The main window is titled 'Library Options (mouse over for hint)' and 'Configurator Version(STG) - 0.9.1.e'.

**Library Options:**

- Debug Printing
- Use EEPROM  Use Flash Disk
- Filename:
- Timestamp
- Redundancy: 0 - No redundancy (dropdown menu)

**Setting Definitions:**


Buttons: Add, Edit, Delete, Insert, Move Up, Move Down

Name	Storage	Data type	Member(s)	P1(min)	P2(max)	Ini mode	Default value	Comment	Status
BR	Non-volatile	Byte	1	0	13	A	0	Baudrate	OK
EG	Non-volatile	Byte	1	0	1	A	0	Event generation	OK
UT	Non-volatile	Byte	1	0	255	A	10	Unlock time	OK
DS	Volatile	Byte	1	0	1	A	0	Door state	OK

Buttons: Add, Edit, Delete, Insert, Move Up, Move Down

## Define Required A-variables


Add **BR**, **EG**, **UT**, and **DS** setting A-variables using AGG library's [configurator](#)<sup>583</sup>. You should end up with a setting table as shown below:



Note that **Reference Library (Settings)** must be *enabled* and correct [setting configurator](#)<sup>[670]</sup> file must be specified (*settings.txt*). We are sure you will quickly find your way around the AggreGate configurator. Let's just briefly review some things worth noting. Double-click on the **BR** A-variable line -- the **Edit (A-variables)** dialog will open.

- On the **General** tab, notice that the A-variable is **Linked to** the *Settings Library*. The **Variable Name** drop-down contents reflect available settings. Your A-variable is basically a "propagated" setting! You can also link to tables -- this will be our [next step's task](#)<sup>[593]</sup>.
- Notice also that the A-variable is **Readable** and **Writable**. All our A-variables are, except **DS**, which is only **Readable** (read-only).
- **Description** is set to *Baudrate*, and this is how this A-variable is visible in AggreGate.
- The **Group** is set to *Access Control*. This is where the **Access Control** tab you see in the AggreGate client comes from. The client will create separate tabs for all groups encountered. We only use one custom group in this project.
- Now switch to the **Advanced** tab and press **Edit**. Don't we have a lot here!
- Notice how the **Field Type** is *Integer*. The AggreGate server supports a different type set, and *byte* isn't on the list. The nearest suitable type is selected, which is *integer*.
- **Selection Value** is enabled and if you click ... you will see the whole list. Now you know where the drop-down selector on the **Baudrate** A-variable comes from.

- **Maximum Limit** will not allow you to set anything above 13.
- There are numerous other fields we haven't touched. Explore and you shall discover!



Moving now to the remaining A-variables, and only touching on the notable differences:

- The **EG** A-variable has its **Field Type** = *Boolean*.
- The **UT** A-variable is limited to 127.
- The **DS** A-variable has two custom **Selection Values** (*opened* and *closed*). it is only **Readable**, and not **Writable**.

### Step 3: Adding Table A-variables

This step corresponds to **test\_agg\_lib\_3**.

This is an access control project, hence it requires a user table which will keep user names and ID codes. In this step we create this **user** table.

#### The steps


Notice that...

1. The **TBL library** [not yet documented] is now in the project. Inspect the [on\\_sys\\_init\(\)](#)<sup>[533]</sup> event handler -- it contains several things related to the library's operation: the flash disk is mounted and formatted if necessary. The flash disk is also formatted during the initialization. **Tbl\_start()** [not yet documented] is called.
2. The **FILENUM**<sup>[641]</sup> library is now in the project -- it is required by the TBL library.
3. **Tables.txt** defines the **USER table**<sup>[594]</sup>.
4. **Aggregate.txt** contains new **table A-variable**<sup>[595]</sup>.

5. Notice how the **AggreGate Hash** option is enabled in the table **configurator** [not yet documented]. This is because the AGG library requires this.

### The result

Now you have an editable **user** table! It isn't yet "connected" to anything in any useful way -- we will [take care of this](#) [605] later.



### Define the User Table

This table **configurator** [not yet documented] screenshot shows the added **user** table. Note that...

- **AggreGate Hash** is enabled. This is required by the AggreGate library.
- The **user** table has *one key field*. It is the first one in the list -- the **user\_id** field.

The screenshot shows the 'Library Options' and 'Table(s) Definitions' sections of the AggreGate configurator. The 'Table(s) Definitions' section contains a table with the following data:

Table Name	Max Records	Table Struct	Number of Key Field(s)	Comment	Status
user	1024	Table	1		OK

The 'Field(s) Definitions' section contains a table with the following data:


Field Name	Type	P1(min)	P2(max)	Default Value	Comment	Status
user_id	String	1	14	123456		OK
name	String	0	31	^		OK

### Add the Table A-variable

These AggreGate [configurator](#) <sup>583</sup> screenshots show the added **user** table A-variable.

The screenshot shows the 'Variables Definitions (root)' section of the configurator. It contains a table with the following data:

Variable Name	Reference Source	Group/Description	Status
BR	Setting Library	Access Control/Baudrate	OK
EG	Setting Library	Access Control/Generate Event	OK
UT	Setting Library	Access Control/UT	OK
DS	Setting Library	Access Control/Door State	OK
user	Table Library	Default/user	OK



## Step 4: Adding A-functions

This step corresponds to **test\_agg\_lib\_4**.

A-functions are methods that the AggreGate server can execute on the device. In our access control project, we will add an "open door" A-function which will be used for remote unlocking of the door. This A-function will have an argument -- for how long the door will have to remain unlocked.

The A-function's argument will be of an overriding nature. When set to 0, it will have no effect and the door will be unlocked for the period of time specified by the [UT A-variable](#)<sup>[588]</sup>. When not zero, the argument will override the **UT** A-variable *once*.

### The steps

Notice that...


1. **Aggregate.txt** now [contains the UL A-function](#)<sup>[597]</sup>.
2. [Callback\\_agg\\_device\\_function\(\)](#)<sup>[613]</sup> implements necessary code for executing the **UL** A-function.
3. Notice how [Agg\\_record\\_decode\(\)](#)<sup>[609]</sup> is used to extract the argument of the A-function.
4. [Agg\\_record\\_encode\(\)](#)<sup>[610]</sup> is used to return A-function value to the AggreGate server. The value is always "success" in our case.

### The result

Single-click on the device in the AggreGate tree, and locate **Unlock the Door** in the **Related Actions** pane below. Click **Unlock the Door**, and you will get a dialog requesting **Door Unlock Duration**. Input a value, press **OK**. The function will be executed and return *Success*.

Of course, there is no code (yet) that actually unlocks the door. We will take care of this [later](#)<sup>605</sup>.


- Can't see **Unlock the Door** in the list? Navigate away from your test device, i.e. click on something else in the tree. Come back -- and you will see the newly added A-function.



### Adding A-function

These AggreGate [configurator](#)<sup>583</sup> screenshots show the added **UL** A-function.





## Step 5: Firing Instant A-events

This step corresponds to **test\_agg\_lib\_5**.

Instant A-events are sent to the AggreGate server "on the spot". They are "lightweight" -- there is no dealing with storing them on the flash disk, etc. They are fast(er) -- just send! They are more reliable -- no flash disk complexity involved. They are also easier to be lost. Should your device lose power at a wrong

moment, the instant A-event will be forgotten. Another limitation: instant A-events can only be fired successfully when there is an active connection to the AggreGate server. Bottom line: use instant A-events for events that are not-so-important and/or numerous.

In this step we add an instant A-event for reporting the booting (powering up) of the device.

### The steps


Notice that...

1. **Aggregate.txt** now [contains the DB instant A-event](#)<sup>[600]</sup>. This event has only one field -- the date/time of the event. It is possible to have additional fields, of course.
2. There is a new **generate\_boot\_event()** sub in **device.tbs**. It calls [agg\\_fire\\_instant\\_event\(\)](#)<sup>[610]</sup> to send the instant A-event to the AggreGate server. We call **generate\_boot\_event()** from [callback\\_agg\\_synchronized\(\)](#)<sup>[614]</sup>, not [on\\_sys\\_init\(\)](#)<sup>[533]</sup>. As was explained above, you need to have an established connection to the AggreGate server in order to be able to fire instant A-events, and the connection is ready when [callback\\_agg\\_synchronized\(\)](#) is called.
3. Notice how this procedure uses [agg\\_record\\_encode\(\)](#)<sup>[610]</sup>.
4. Notice also the use of the TIME library [not yet documented] for producing the date/time field of correct format.

Notice how the [add\\_fire\\_instant\\_event\(\)](#)<sup>[610]</sup> call has the **event\_level** argument. The level defined by this argument will override the [default\\_level set in the configurator](#)<sup>[600]</sup>, unless you set the **event\_level=EN\_AGG\_EVENT\_LEVEL\_USE\_DEFAULT**, in which case the default event level will be used.


### The result


To be able to see *instances* of your new event, right-click on the device in the tree and choose **Monitor Related Events**.



## Adding Instant A-event

These AggreGate [configurator](#)<sup>[683]</sup> screenshots show the added instant A-event. Notice the **Default Level** field. This is the event level that will be reported if [agg\\_fire\\_instant\\_event\(\)](#)<sup>[610]</sup> is called with **event\_level=EN\_AGG\_EVENT\_LEVEL\_USE\_DEFAULT**.





## Step 6: Handling Stored A-events

This step corresponds to `test_agg_lib_6`.

Stored A-events, as their name implies, are first stored on the device. Stored A-events are kept in the log table, and log tables are handled by the **TBL library** [not yet documented]. Each stored A-event is kept in the log until the AGG library has a chance to send it to the AggreGate server. Once recorded, these A-events won't be lost. Having an AggreGate server connection is *not* a precondition for the generation of stored A-events. The disadvantage is somewhat heavier implementation and slower event handling speed.

There will be a separate log table [not yet documented] (and a file on the [flash disk](#) [236]) for each *type* of stored A-event in your application. This is because different A-event types can potentially have a different set of fields and, hence, the different storage format.

Another important point to discuss: if you come from a field like access control or IT, then you may be accustomed to a certain way of using the term "event". You probably dealt with events like "access granted", "access violation", "access denied", and so on. Each one of those is considered to be a separate "event".

With AggreGate, if it comes from the same log table, then it is the same A-event. The ACE A-event below is generated on "access granted", "access violation", etc., yet it is all the same single event called the "Access Control Event (ACE)". It is the *event description* that differentiates each ACE A-event *instance*. Keep this in mind when reviewing the code added in step 6.

### The steps


Notice that...

1. The **TBL library** [not yet documented] is already in the project. We added it when we were [creating the USER table](#) [593].

2. **Tables.txt** now [contains](#)<sup>[603]</sup> the **ACE** table. Note how there are three fields:
  - The **DT** field for storing the date and time of the event.
  - The **AEL** field for event the level. Stored A-events, like [instant A-events](#)<sup>[598]</sup>, have the [default event level](#)<sup>[604]</sup> which can be overridden. To be able to override, have a special field named **AEL** (A-event level) in your [log table](#)<sup>[603]</sup>. This field must be of the byte type, with [possible values from 0 to 5](#)<sup>[606]</sup>. Once you have the **AEL** field in the table, the event level for each particular event *instance* will come from this field.
  - The **DS** field carrying the event description (like "access granted", "access violation", etc.). Notice how this field's size is only four characters -- how can we possible fit a meaningful description in four characters?.. Read on and you will know!
3. **Aggregate.txt** now [contains](#)<sup>[604]</sup> the **ACE stored A-event**<sup>[600]</sup>. It "links" to the **ACE** table.
4. Call to [agg\\_proc\\_data\\_sent\(\)](#)<sup>[613]</sup> is in [on\\_sock\\_data\\_sent\(\)](#)<sup>[489]</sup> event handler.
5. New **generate\_door\_event()** sub is in **device.tbs**. We call this from [on\\_button\\_pressed\(\)](#)<sup>[234]</sup>. You don't have to be connected to the AggreGate server in order to be able to generate this event -- that's the beauty of stored A-events. Whenever you press the [MD button](#)<sup>[201]</sup>, one ACE event is generated. The description it carries for now is always "ACE". This is temporary -- we will add real descriptions in the [next step](#)<sup>[605]</sup>.
6. Notice how this procedure uses [agg\\_stored\\_event\\_added\(\)](#)<sup>[611]</sup>. You have to use it every time you add a stored A-event. It "nudges" the AGG library, i.e. tells it that there are stored events that haven't been sent to the server yet.
7. Notice that [agg\\_proc\\_stored\\_events\(\)](#)<sup>[612]</sup> is also called(). **This is completely optional** and serves to speed up the sending of the stored A-event to the AggreGate server. The AGG library already uses this procedure internally. Calling this "manually" just after doing [agg\\_stored\\_event\\_added\(\)](#) may speed things up a bit, especially on big projects with heavy and complicated code.
8. Our sample code also makes use of [callback\\_agg\\_convert\\_event\\_field\(\)](#)<sup>[617]</sup>. If you put a breakpoint there you will notice that this procedure is invoked every time you generate a stored A-event. The procedure is called separately for each event's field, except the **ACE** field. The idea is the same as for the [callback\\_agg\\_convert\\_setting](#)<sup>[616]</sup> call, which was discussed in [Adding Setting A-variables](#)<sup>[588]</sup>: you get a chance to convert or change a field's value before sending it to the AggreGate Server. In our code we use the call to convert short event descriptions (abbreviations, really) into comprehensible lines of text!

## The result

To be able to see *instances* of your new event, right-click on the device in the tree and choose **Monitor Related Events**.



## Define the ACE Table

This table **configurator** [not yet documented] screenshot shows the added **ACE** log table.

- Notice the **AEL** (A-Event level) field. Since the **ACE** log table has this field, the level of each ACE event *instance* will be taken from this field.
- Notice also that the **DS** (description) field accommodates up to 4 characters -- read about our processing technique for this field [here](#)<sup>[60]</sup>.

**Library Options (mouse over for hint)**

Debug Printing  
 AggreGate Hash

**Table(s) Definitions**

Table Name	Max Records	Table Struct	Number of Key Field(s)	Comment	Status
user	1024	Table	1		OK
ACE	1000	Log	0	Access Control Events	OK

**Field(s) Definitions**

Special field Only up to 4 characters!


Field Name	Type	P1(min)	P2(max)	Default Value	Comment	Status
DT	Date/Time	6	0	20000101010101001	Date/Time	OK
AEL	Byte	0	5	0	A-event Level	OK
DS	String	0	4	^	Description	OK

### Define the ACE Stored Event

These AggreGate [configurator](#) <sup>583</sup> screenshots show the added **ACE** stored A-event. Notice the note in red under the **Default Level**. It means that the AEL (A-event level) field is found in the ACE table and the event level will be defined separately for each event *instance* in accordance with the AEL field's value.

**Events Definitions (root)**

Event Name	Event Type	Level	Status
DB	Instant Event	Notice	OK
ACE	Stored Event	None	OK



## Step 7: Gluing it All Together

This step corresponds to `test_agg_lib_7`.

And now, ladies and gentlemen, let's crown this application with some glue code. Observe the code and notice the following...

1. Handling of the [BR<sup>\[588\]</sup> setting A-variable<sup>\[588\]</sup>](#):
  - Every time we select new baudrate in AggreGate, [callback\\_stg\\_post\\_set\(\)<sup>\[701\]</sup>](#) is invoked. Our code there calls `baudrate_set()`. Don't understand how this works? Read [Using Pre-gets and Post-sets<sup>\[683\]</sup>](#).
  - We also call `baudrate_get()` from [callback\\_stg\\_pre\\_get\(\)<sup>\[701\]</sup>](#).
  - `Baudrate_get()` is also invoked from `setup_serial_port()`, which is called from the [on\\_sys\\_init\(\)<sup>\[533\]</sup>](#).
2. Handling of the [UT<sup>\[588\]</sup> setting A-variable<sup>\[588\]</sup>](#): again, we just return the actual door status in [callback\\_stg\\_pre\\_get\(\)<sup>\[701\]</sup>](#). If you may [recall<sup>\[585\]</sup>](#), the [MD button<sup>\[201\]</sup>](#)

is used as a make-believe door sensor.

3. The [GE<sup>\[588\]</sup> setting A-variable<sup>\[588\]</sup>](#) now properly allows or prevents the events from generating.
4. Handling of user access codes is in the [on\\_ser\\_data\\_arrival<sup>\[412\]</sup>](#) event handler.

## Step 8: Adding Bells and Whistles

This step does not exist yet -- you can just go ahead and create it yourself.

You can enhance the access control demo in a myriad ways. We will just point out additional facilities offered by the AGG library.

Note that...

1. You can always stop the library and free up buffer memory by calling [agg\\_stop\(\)<sup>\[608\]</sup>](#). When your application does this, it will get [callback\\_agg\\_buff\\_released\(\)<sup>\[615\]</sup>](#) invoked.
2. You can use [agg\\_get\\_connection\\_state\(\)<sup>\[609\]</sup>](#) to poll the AGG library for its connection state. You can then display the state on the LCD screen (if your device has it), using LEDs, or in some other way.
3. [Callback\\_agg\\_error\(\)<sup>\[615\]</sup>](#) provides a unified place to respond to errors generated by the AGG library.
4. Some hardware projects require precise timekeeping (don't we know this!). If you are not satisfied with the internal RTC of your device (such as the [EM1000<sup>\[143\]</sup>](#)), or you are using a device that has no RTC ([EM500<sup>\[138\]</sup>](#)) then you can always connect your own RTC chip and write your own RTC routines:
  - *Enable* (check) **Using Custom RTC** in the AggreGate configurator.
  - Add the [Callback\\_agg\\_rtc\\_sg\(\)<sup>\[618\]</sup>](#) procedure to your code.

## En\_agg\_event\_levels

Available event levels apply both to [instant A-events<sup>\[598\]</sup>](#) and [stored A-events<sup>\[601\]</sup>](#).

- 0- EN\_AGG\_EVENT\_LEVEL\_NONE
- 1- EN\_AGG\_EVENT\_LEVEL\_NOTICE
- 2- EN\_AGG\_EVENT\_LEVEL\_INFO
- 3- EN\_AGG\_EVENT\_LEVEL\_WARNING
- 4- EN\_AGG\_EVENT\_LEVEL\_ERROR
- 5- EN\_AGG\_EVENT\_LEVEL\_FATAL
- 6- EN\_AGG\_EVENT\_LEVEL\_USE\_DEFAULT

In the above list, the last value ("DEFAULT") can only be used as the value of the **event\_level** argument of [instant A-events<sup>\[598\]</sup>](#) and as the value of the **AEL** field for stored [A-events<sup>\[601\]</sup>](#).

## En\_agg\_status\_codes

Several procedures in the library utilize the `en_agg_status_codes` enum. This enum has the following members:

- 0- EN\_AGG\_STATUS\_OK: success.

- 1- EN\_AGG\_STATUS\_NOT\_STARTED: [agg\\_start\(\)](#)<sup>[607]</sup> was not used or failed.
- 2- EN\_AGG\_STATUS\_WRONG\_DESCRIPTOR: wrong [descriptor](#)<sup>[583]</sup> file data.
- 3- EN\_AGG\_STATUS\_OUT\_OF\_SOCKETS: no free sockets available for the library to operate.
- 4- EN\_AGG\_STATUS\_INVALID\_INTERFACE: unsupported network interface specified.
- 5- EN\_AGG\_STATUS\_INSUFFICIENT\_BUFFER\_SPACE: insufficient number of buffer pages available and the call to [callback\\_agg\\_pre\\_buffrq\(\)](#)<sup>[614]</sup> failed to cure the problem.
- 6- EN\_AGG\_STATUS\_CONNECTION\_LOST: lost connection to the AggreGate server.
- 7- UNABLE TO CONNECT: unable to connect to the AggreGate server.
- 8- EN\_AGG\_STATUS\_SETTING\_ERROR: a problem with a [setting A-variable](#)<sup>[588]</sup>.
- 9- EN\_AGG\_STATUS\_TABLE\_ERROR: a problem with a [table A-variable](#)<sup>[593]</sup>.
- 10- EN\_AGG\_STATUS\_FUNCTION\_ERROR: a problem with an [A-function](#)<sup>[596]</sup>.
- 11- EN\_AGG\_STATUS\_ITEM\_NOT\_FOUND: unknown item specified.

## Library Procedures

In this section:

- [Agg\\_start\(\)](#)<sup>[607]</sup>
- [Agg\\_stop\(\)](#)<sup>[608]</sup>
- [Agg\\_get\\_connection\\_state\(\)](#)<sup>[609]</sup>
- [Agg\\_record\\_decode\(\)](#)<sup>[609]</sup>
- [Agg\\_record\\_encode\(\)](#)<sup>[610]</sup>
- [Agg\\_fire\\_instant\\_event\(\)](#)<sup>[610]</sup>
- [Agg\\_proc\\_stored\\_events\(\)](#)<sup>[612]</sup>
- [Agg\\_proc\\_timer\(\)](#)<sup>[612]</sup>
- [Agg\\_proc\\_data\(\)](#)<sup>[612]</sup>
- [Agg\\_proc\\_sock\\_event\(\)](#)<sup>[612]</sup>
- [Agg\\_proc\\_data\\_sent\(\)](#)<sup>[613]</sup>
- [Callback\\_agg\\_get\\_firmware\\_version\(\)](#)<sup>[613]</sup>
- [Callback\\_agg\\_device\\_function\(\)](#)<sup>[613]</sup>
- [Callback\\_agg\\_synchronized\(\)](#)<sup>[614]</sup>
- [Callback\\_agg\\_pre\\_buffrq\(\)](#)<sup>[614]</sup>
- [Callback\\_agg\\_buff\\_released\(\)](#)<sup>[615]</sup>
- [Callback\\_agg\\_error\(\)](#)<sup>[615]</sup>
- [Callback\\_agg\\_convert\\_setting\(\)](#)<sup>[616]</sup>
- [Callback\\_agg\\_convert\\_event\\_field\(\)](#)<sup>[617]</sup>
- [Callback\\_agg\\_rtc\\_sg\(\)](#)<sup>[618]</sup>

### Agg\_start()

**Description:**

API procedure, starts the AGG library, parses the [configuration file](#)<sup>[583]</sup>, prepares the library for operation.

**Syntax:** `function agg_start(interface as pl_sock_interfaces, byref owner_name as string, byref device_name as string, byref password as string, byref agg_server_ip as string, agg_server_port as word, agg_server_tout as word, auto_reg as no_yes) as en_agg_status_codes`

**Returns:** One of the [en\\_agg\\_status\\_codes](#)<sup>[606]</sup>

**See Also:** [The Embryo](#)<sup>[587]</sup>

Part	Description
interface	The network interface through which the library will be connecting to the AggreGate server. The list of available interfaces is <a href="#">platform-dependent</a> <sup>[138]</sup> (look for the Enum pl_sock_interfaces topic inside your platform's documentation).
owner_name	Must match your account on the AggreGate server ("admin" by default).
device_name	The name under which the device will appear in the list of devices under your account.
password	The password your device will use to login to the AggreGate server.
agg_server_ip	The IP address of the AggreGate server.
agg_server_port	The listening port on the AggreGate server (6480 by default).
agg_server_tout	Maximum waiting time for the AggreGate server interactions. The recommended value is 600.
auto_reg	Whether or not the device will be allowed to register on the AggreGate server if the server does not already have this device under the specified <b>owner_name</b> account

### Details

MUST be called first, before any other procedure in this library is invoked, or [EN\\_AGG\\_STATUS\\_NOT\\_STARTED](#)<sup>[606]</sup> will be returned by every other procedure you call.

### **Agg\_stop()**

**Description:** API procedure, stops the AGG library causing it to release occupied buffers.

**Syntax:** `declare sub agg_stop()`

**Returns:** ---

**See Also:** [Adding Bells and Whistles](#)<sup>[606]</sup>

[callback\\_agg\\_buff\\_released\(\)](#)<sup>[615]</sup>

Details

---

**Agg\_get\_connection\_state()**

**Description:** API procedure, returns the current state of the device's connection to the AggreGate server as well as the synchronization status.

**Syntax:** **sub agg\_get\_connection\_state(byref link\_state as en\_agg\_link\_states, byref sock\_state as pl\_sock\_state\_simple)**

**Returns:** TCP connection state and synchronization status

**See Also:** [Adding Bells and Whistles](#)<sup>[606]</sup>

Part	Description
link_state	Indirectly returns the synchronization status:  0- EN_AGG_LINK_STATE_IDLE: no connection to the AggreGate server.  1- EN_AGG_LINK_STATE_CONNECTING: connecting now.  2- EN_AGG_LINK_STATE_SYNCRONIZING: synchronizing now.  3- EN_AGG_LINK_STATE_DISCONNECTED: disconnected (by the server).  4- EN_AGG_LINK_STATE_ESTABLISHED: connected and fully synchronized.
sock_state	Indirectly returns the state of the TCP link to the server. This is directly from the <a href="#">sock.statesimple</a> <sup>[505]</sup> property of the socket used for connecting to the AggreGate server.

Details

---

**Agg\_record\_decode()**

**Description:** API procedure, extracts the value of the specified argument from the encoded string containing the values of all arguments for an A-function.

**Syntax:** **function agg\_record\_decode(byref encode\_string as string, field\_index as byte) as string**

**Returns:** The specified argument's value

**See Also:** [Adding A-functions](#)<sup>[609]</sup>

Part	Description
encode_string	The argument string sent by the server.
field_index	The index (counting from 0) of the argument that needs to be extracted.

### Details

Only works for argument strings containing simple single-value arguments. Need to pass complex arguments containing entire tables? Write your own decoder. String format is described here:

[http://aggregate.tibbo.com/docs/en/ap\\_data\\_tables\\_encoding.htm](http://aggregate.tibbo.com/docs/en/ap_data_tables_encoding.htm)

## Agg\_record\_encode()

- Description:** API procedure, appends the argument's value to the encoded A-function's or A-event's argument string in preparation for sending this string to the AggreGate server.
- Syntax:** **sub agg\_record\_encode(byref encode\_string as string, byref field\_value as string)**
- Returns:** Updated encode\_string
- See Also:** [Adding A-functions](#)<sup>[596]</sup>, [Firing Instant A-events](#)<sup>[598]</sup>

Part	Description
encode_string	The argument string being prepared.
field_index	New value to be appended to the string.

### Details

Should be called repeatedly if the A-function has multiple arguments.

Can only handle simple single-value arguments. Need to pass complex arguments containing entire tables? Write your own encoder. String format is described here:

[http://aggregate.tibbo.com/docs/en/ap\\_data\\_tables\\_encoding.htm](http://aggregate.tibbo.com/docs/en/ap_data_tables_encoding.htm)

## Agg\_fire\_instant\_event()

- Description:** API procedure, generates an instant A-event and sends it directly to the AggreGate server.
- Syntax:** **sub agg\_fire\_instant\_event(byref context\_name as**

**string, byref event\_name as string, byref event\_string as string, event\_level as en\_agg\_event\_levels)**

**Returns:** ---

**See Also:** [Firing Instant A-events](#)<sup>[598]</sup>

Part	Description
context_name	Always set this to "root".
event_name	Name of the instant A-event, must match one of the A-events you've defined through the <a href="#">configurator</a> <sup>[583]</sup> .
event_string	The encoded string containing the values of the A-event's arguments. Use <a href="#">agg_record_encode()</a> <sup>[610]</sup> to prepare. Use <a href="#">agg_record_encode()</a> <sup>[610]</sup> to prepare.
event_level	A-event level as defined by the <a href="#">en_agg_event_levels</a> <sup>[606]</sup> enum. If you set this to EN_AGG_EVENT_LEVEL_USE_DEFAULT then the event level <a href="#">defined through the configurator</a> <sup>[600]</sup> will be used. Specifying any other event level will override the default level specified in the configurator.

### Details

---

## Agg\_stored\_event\_added()

**Description:** API procedure, must be called every time a stored A-event is added to the log file.

**Syntax:** **sub agg\_stored\_event\_added(byref event\_name as string)**

**Returns:** ---

**See Also:** [Handling Stored A-events](#)<sup>[601]</sup>

Part	Description
event_name	Name of the A-event, must match the event that's been added.

### Details

---

### Agg\_proc\_stored\_events()

**Description:** API procedure, nudges the AGG library to process stored A-events.

**Syntax:** **sub agg\_proc\_stored\_events()**

**Returns:** ---

**See Also:** [Handling Stored A-events](#)<sup>[601]</sup>

---

#### Details

The use of this procedure is completely optional.

### Agg\_proc\_timer()

**Function:** Event procedure, call it from the [on\\_sys\\_timer\(\)](#)<sup>[533]</sup> event handler.

**Syntax:** **sub agg\_proc\_timer()**

**Returns:** ---

**See Also:** [The Embryo](#)<sup>[587]</sup>

#### Details

The AGG library expects that the [system timer](#)<sup>[528]</sup> is running at half-second intervals.

### Agg\_proc\_data()

**Function:** Event procedure, call it from the [on\\_sock\\_data\\_arrival\(\)](#)<sup>[489]</sup> event handler.

**Syntax:** **sub agg\_proc\_data()**

**Returns:** ---

**See Also:** [The Embryo](#)<sup>[587]</sup>

#### Details

---

### Agg\_proc\_sock\_event()

**Function:** Event procedure, call it from the [on\\_sock\\_event\(\)](#)<sup>[490]</sup> event handler.

**Syntax:** **sub agg\_proc\_sock\_event(sock\_state as pl\_sock\_state, sock\_state\_simple as pl\_sock\_state\_simple)**

**Returns:** ---

**See Also:** [The Embryo](#)<sup>[587]</sup>

### Details

This procedure's arguments are the same as for [on\\_sock\\_event\(\)](#)<sup>[490]</sup>.

## Agg\_proc\_data\_sent()

**Function:** Event procedure, call it from the [on\\_sock\\_data\\_sent\(\)](#)<sup>[489]</sup> event handler.

**Syntax:** **sub agg\_proc\_data\_sent()**

**Returns:** ---

**See Also:** [Handling Stored A-events](#)<sup>[601]</sup>

### Details

---

## Callback\_agg\_get\_firmware\_version()

**Description:** Callback procedure, requests the version string for the current application. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **function callback\_agg\_get\_firmware\_version() as string**

**Returns:** Version string

**See Also:** [The Embryo](#)<sup>[587]</sup>

---

### Details

This isn't required, but customarily we enclose version strings in braces ("{}"). For example: **{agg\_demo.1.01.01}**.

## Callback\_agg\_device\_function()

**Description:** Callback procedure, invoked when the device needs to execute an AggreGate function. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **function callback\_agg\_device\_function(byref function\_name as string ,byref context\_name as string, byref function\_input as string, byref function\_output as string) as ok\_ng**

**Returns:** ---

**See Also:** [Firing Instant A-events](#)<sup>[598]</sup>

Part	Description
function_name	AggreGate function name.
context_name	This library only supports the root context, so context_name should be ignored.
function_input	The encoded string containing the values of all arguments of the AggreGate function. Use <a href="#">agg_record_decode()</a> <sup>[609]</sup> to process.
function_output	The encoded string containing the values of the function's output. Use <a href="#">agg_record_encode()</a> <sup>[610]</sup> to process.

### Details

---

## Callback\_agg\_synchronized()

**Description:** Callback procedure, informs of the completion of the synchronization process between the device and the AggreGate server. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_agg\_synchronized()**

**Returns:** Version string

**See Also:** [Firing Instant A-events](#)<sup>[598]</sup>

### Details

---

## Callback\_agg\_pre\_buffrq()

**Description:** Callback procedure, informs of the insufficient number of free buffer pages available for use by the library. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_agg\_pre\_buffrq(required\_buff\_pages as byte)**

**Returns:** ---

**See Also:** [The Embryo](#)<sup>[587]</sup>

Part	Description
required_buffer_pages	The number of additional buffer pages that the AGG library needs to operate. Your application must free up at least this number of buffer pages within <code>callback_agg_pre_buffrq()</code> or <code>agg_start()</code> <sup>[607]</sup> will fail with the <code>AGG_STATUS_INSUFFICIENT_BUFFER_SPACE</code> <a href="#">code</a> <sup>[606]</sup> .

### Details

This procedure will be called only if there are not enough buffer pages available.

## Callback\_agg\_buff\_released()

<b>Description:</b>	Callback procedure, informs of the release of buffer pages by the library. Procedure body has to be created elsewhere in the project (externally with respect to the library).
<b>Syntax:</b>	<b>sub callback_agg_buff_released()</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Adding Bells and Whistles</a> <sup>[606]</sup> <a href="#">agg_stop()</a> <sup>[608]</sup>

### Details

The number of free buffer pages can be checked through the `sys.freebuffpages`<sup>[531]</sup> R/O property.

## Callback\_agg\_error()

<b>Description:</b>	Callback procedure, informs of an error or condition detected within the library. Procedure body has to be created elsewhere in the project (externally with respect to the library).
<b>Syntax:</b>	<b>sub callback_agg_error(failure_code as en_agg_status_codes, byref error_item as string)</b>
<b>Returns:</b>	---
<b>See Also:</b>	---

Part	Description
failure_code	One of the <a href="#">en_agg_status_codes</a> <sup>[606]</sup>
error_item	Name of the item in question, for example, the name of a setting A-variable.

## Details

---

### Callback\_agg\_convert\_setting()

**Description:** Callback procedure, invoked every time a setting A-variable is being read or written. Provides an opportunity to convert the value before writing to a setting or after reading from a setting.

Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_agg\_convert\_setting**(byref setting\_name as string, index as byte, byref setting\_value as string, op as en\_agg\_rdwr)

**Returns:** ---

**See Also:** [Adding Setting A-variables](#)<sup>[588]</sup>

[Callback\\_agg\\_convert\\_event\\_field\(\)](#)<sup>[617]</sup>

Part	Description
setting_name	Name of the setting being read or written.
index	Setting index (zero for single-value settings).
setting_value	Value to be converted. This argument is also used for returning the converted value: take setting_value, modify as needed, and store back.
op	EN_AGG_GET- reading from the setting EN_AGG_SET- writing to the setting

## Details

This procedure allows to store the value in a format or type that is different from the way the same is perceived in AggreGate.

Here is a simple example: Supposing, there is a setting that stores device temperature. The setting data originates from a temperature measuring IC, which outputs a byte value. Seven most significant bits are degrees. The least significant bit represent a 0.5-degree step. The output of 0 corresponds to -40 degrees C. Therefore, the output of 255 corresponds to +87.5 degrees C.

Now, the operator in AggreGate would surely prefer to see "natural" temperature values like -40 and +87.5, rather than 0 and 255. This procedure can provide a place to do the conversion.

The same possibility exists for stored event's fields (see [Callback\\_agg\\_convert\\_event\\_field\(\)](#)<sup>[617]</sup>) but not for [table A-variables](#)<sup>[593]</sup>. Tables

must be stored in exactly the same way that the AggreGate server "believes" them to be stored. This is because table synchronization is based on hash strings.

## Callback\_agg\_convert\_event\_field()

**Description:** Callback procedure, invoked every time a stored A-event is being extracted from the log and sent to the server. Provides an opportunity to change the value or type of A-event fields before sending the stored A-event to the server.

Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **declare sub callback\_agg\_convert\_event\_field**(byref table\_name **as string**, byref field\_name **as string**, byref field\_value **as string**)

**Returns:** ---

**See Also:** [Handling Stored A-events](#)<sup>[601]</sup>  
[Callback\\_agg\\_convert\\_setting\(\)](#)<sup>[616]</sup>

Part	Description
table_name	The name of the stored A-event (and the log table which stores it).
field_name	The name of the field.
field_value	The value of the field.

### Details

For every stored A-event being sent to the server, this procedure will be called separately for each event's field.

Type/value conversion possibility also exists for setting A-variables (see [callback\\_agg\\_convert\\_setting\(\)](#)<sup>[616]</sup>) but not for [table A-variables](#)<sup>[593]</sup>. Tables must be stored in exactly the same way that the AggreGate server "believes" them to be stored. This is because table synchronization is based on hash strings.

## Callback\_agg\_rtc\_sg()

**Description:** Callback procedure, invoked when the library needs to get or set the device's date and time. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_agg\_rtc\_sg**(byref wdaycount as word, byref wmincount as word, byref bsec as byte, byref wmilsec as word, op as en\_agg\_rdwr)

**Returns:** ---

**See Also:** ---

Part	Description
wdaycount	Number of elapsed days.
wmincount	Number of elapsed minutes.
bsec	Number of elapsed seconds.
wmilsec	Number of elapsed milliseconds.
op	EN_AGG_GET or EN_AGG_SET

### Details

Necessary only when **Use custom RTC** option is *enabled* in the [configurator](#)<sup>[583]</sup>.

## DHCP Library

The DHCP library implements DHCP client on Ethernet ([net.](#)<sup>[358]</sup>) and Wi-Fi ([wln.](#)<sup>[536]</sup>) network interfaces. The DHCP protocol is used for automatic configuration of your device's IP address, netmask, and gateway IP address. More on the protocol here: <http://en.wikipedia.org/wiki/Dhcp>.

The library is capable of running DHCP clients on both network interfaces concurrently. The library is event-based and non-blocking -- it quietly runs in the background and takes a minimal amount of CPU time.

### Library Info

**Supported platforms:** Any platform with at least the Ethernet ([net.](#)<sup>[358]</sup>) or Wi-Fi ([wln.](#)<sup>[536]</sup>) interface except for EM202.

**Files to include:** Dhcp.tbs, dhcp.tbh (from *current\_library\_set*\dhcp\trunk\)

**Dependencies:** [SOCK](#)<sup>[664]</sup> library;

You may also need [WLN library](#)<sup>[703]</sup>

**API procedures:** dhcp\_get\_info() -- returns library-specific information (such as required buffer space).

Use [API procedures](#)<sup>[576]</sup> to interact with

[dhcp\\_start\(\)](#)<sup>[636]</sup> -- starts the DHCP client on the specified

<p>the library.</p> <p><b>Event procedures:</b></p> <p>Call <a href="#">event procedures</a> from corresponding event handlers, as described <a href="#">here</a>.</p> <p><b>Callback procedures:</b></p> <p>Implement the bodies of <a href="#">callback procedures</a> elsewhere in your project.</p> <p><b>Required buffer space:</b></p>	<p>network interface.</p> <p><a href="#">dhcp_stop()</a> -- stops the DHCP client on the specified network interface.</p> <p><a href="#">dhcp_proc_timer()</a> -- call this from the <a href="#">on_sys_timer()</a> event handler.</p> <p><a href="#">dhcp_proc_data()</a> -- call this from the <a href="#">on_sock_data_arrival()</a> event handler.</p> <p><a href="#">callback_dhcp_ok()</a> -- called when the library completes successfully on one of the interfaces.</p> <p><a href="#">callback_dhcp_failure()</a> -- called when the library fails on one of the interfaces after <a href="#">DHCP_MAX_RETRIES</a>.</p> <p><a href="#">callback_dhcp_pre_clear_ip()</a> -- called when the library is about to set the interface's IP to 0.0.0.0.</p> <p><a href="#">callback_dhcp_pre_buffrq()</a> -- called when the library needs to allocate buffer space and the required space is not available.</p> <p><a href="#">callback_dhcp_buff_released()</a> -- called when the library no longer needs buffers and released them.</p> <p>6 buffer pages. These are utilized when needed and released when the DHCP client completes its job. The amount of buffer space needed is constant and does not depend on the number of network interfaces involved.</p>
--	--

## Step-by-step Usage Instructions

### Minimal steps

1. Make sure you have the [SOCK](#) library in your project.
2. Add [dhcp.tbs](#) and [dhcp.tbh](#) files to your project (they are in `current_library_set\dhcp\trunk`).
3. Add `#define DHCP_DEBUG_PRINT 1` to the defines section of the `global.tbh` file of your project. This way you will "see what's going on". Don't forget to remove this later, after you've made sure that the library operates as expected.
4. Add `include "dhcp\trunk\dhcp.tbh"` to the includes section of the `global.tbh` file.
5. Add [dhcp\\_proc\\_timer\(\)](#) to the [on\\_sys\\_timer\(\)](#) event handler code (see "Further considerations" below).
6. Add [dhcp\\_proc\\_data\(\)](#) to the [on\\_sock\\_data\\_arrival\(\)](#) event handler code.
7. Create empty [callback function](#) bodies (presumably in the `device.tbs`): [callback\\_dhcp\\_ok\(\)](#), [callback\\_dhcp\\_failure\(\)](#), [callback\\_dhcp\\_pre\\_clear\\_ip\(\)](#), [callback\\_dhcp\\_pre\\_buffrq\(\)](#), and [callback\\_dhcp\\_buff\\_released\(\)](#). Hint: copy from declarations in the `dhcp.tbh` or from our [code example](#).
8. Call [dhcp\\_start\(\)](#) from somewhere -- once for every interface you want to

use DHCP on. How you will do this depends on your program's logic. The no-brainer decision is to call from the [on\\_sys\\_init\(\)](#)<sup>[533]</sup> event handler. In the simplest case, leave the `suggested_ip` and `host_name` arguments empty. Note that `dhcp_start()` may fail, so it is wise to check the returned status code.

9. Implement meaningful code for the [callback\\_dhcp\\_ok\(\)](#)<sup>[638]</sup> function. Typically, once the DHCP process completes, you should update the IP, netmask, and gateway IP of the corresponding interface.

All of the above is illustrated in the [Code Examples](#)<sup>[622]</sup>.

### Additional recommended steps

1. Store the obtained IP address in the EEPROM and provide it with the [dhcp\\_start\(\)](#)<sup>[636]</sup>. The [STG](#)<sup>[668]</sup> library comes handy for this -- see our [example](#)<sup>[631]</sup>. This way your device will be (mostly) able to keep using the same IP.
2. Optionally provide the device (host) name with the [dhcp\\_start\(\)](#)<sup>[636]</sup>. Some DHCP servers are linked to DNS servers and sending the host name will automatically register your device with the DNS server. By default, device names are disabled. To enable names, add a line like this to the `global.tbh`: [#define DHCP\\_MAX\\_HOST\\_NAME\\_LEN 32](#)<sup>[634]</sup> (this will allow names of up to 32 chars).
3. The use of [dhcp\\_stop\(\)](#)<sup>[637]</sup> is optional. In fact, under the normal circumstances you should let the DHCP client run continuously. This is because the library needs to take care of the "lease expiration" and renew the lease at proper times (see [Operation Details](#)<sup>[627]</sup>). However, you may choose to terminate the DHCP client on a particular interface if the DHCP configuration fails (too many times).
4. The use of [callback\\_dhcp\\_failure\(\)](#)<sup>[639]</sup> is optional. You may leave the procedure empty. Alternatively, once DHCP fails (too many times), you can set an alternative IP, netmask, and gateway IP for the corresponding network interface of your device.
5. [Callback\\_dhcp\\_pre\\_buffrq\(\)](#)<sup>[640]</sup> is only called when there isn't enough free buffer space for the DHCP library's needs. Leave the procedure empty if you are supremely confident that there is always enough free buffer space. Alternatively, free up the required space when asked for it, or the DHCP will fail.
6. [Callback\\_dhcp\\_buff\\_released\(\)](#)<sup>[641]</sup> is called when the DHCP library no longer needs buffer space. A smart application would seize on the opportunity to redistribute newly available buffer pages to other needy parts of your system. Then, again, you can just ignore this chance.

See [Code Examples](#)<sup>[622]</sup> for illustration of the points above.



Not enough buffer space to run DHCP? Take some space away from your [socket buffers](#)<sup>[422]</sup>. Without properly configured IP, sockets are of no use, right? So, deallocate socket buffer space in the `callback_dhcp_pre_buffalloc()` and give buffers back to sockets in the `callback_dhcp_buff_released()`.

### Further considerations

The DHCP library expects the [dhcp\\_proc\\_timer\(\)](#)<sup>[637]</sup> to be called at 0.5 sec intervals. This is the default value which can be changed through the [sys\\_onsystemerperiod](#)<sup>[533]</sup> property. If your project needs to have the [on\\_sys\\_timer\(\)](#)<sup>[533]</sup> event at a different rate, please make sure that `dhcp_proc_timer()` is still called 2 times/second. For example, if the `on_sys_timer()` is set to trigger 4 times/second,

you need to add "divider" code that only calls `dhcp_proc_timer()` on every second invocation of the `on_sys_timer()`.

## Operation Details

The DHCP client, once started on a particular interface with the [`dhcp\_start\(\)`](#)<sup>[636]</sup>, will run continuously until stopped through the [`dhcp\_stop\(\)`](#)<sup>[637]</sup>. The operation of the library may be observed in the [`debug mode`](#)<sup>[27]</sup> by adding [`#define DHCP\_DEBUG\_PRINT 1`](#)<sup>[634]</sup> to the defines section of the `global.tbh` file of your project. A wealth of status information will then be printed in the console pane as the DHCP library operates.

Once `dhcp_start()` is called successfully (and it can fail -- observe returned code!), the library attempts to obtain the IP address, netmask, and the gateway IP address from the DHCP server. If the process fails, the library will retry. A total of [`DHCP\_MAX\_RETRIES`](#)<sup>[634]</sup> attempts are performed (with randomized waiting times between retries, but not exceeding [`DHCP\_MAX\_RETRY\_DELAY`](#)<sup>[634]</sup> seconds), after which [`callback\_dhcp\_failure\(\)`](#)<sup>[639]</sup> is called and the library goes into the waiting period of [`DHCP\_POST\_FAIL\_DELAY`](#)<sup>[634]</sup> seconds. When the period is over, another batch of `DHCP_MAX_RETRIES` attempts is performed, and so on ad infinitum, until the [`dhcp\_stop\(\)`](#)<sup>[637]</sup> is called or DHCP configuration succeeds.

DHCP configuration requires that the initial IP address of the client device be 0.0.0.0. If the IP address of the specified interface is different, the library will set it to 0.0.0.0. Changing the IP address on a particular interface requires all socket connections operating on this interface to be closed first. The DHCP library will take care of that by calling [`sock\_discard`](#)<sup>[478]</sup> for each involved socket. Before doing that, the DHCP library will invoke [`callback\_dhcp\_pre\_clear\_ip\(\)`](#)<sup>[639]</sup>. This way, your application may "prepare" for what is coming. For example, you can add code for gracefully closing TCP connections (instead of letting the DHCP library to do a rude discard).

A buffer space of 6 pages is required while a batch of `DHCP_MAX_RETRIES` attempts is performed on either network interface. The library will check if the required buffer space is available and call [`callback\_dhcp\_pre\_buffrq\(\)`](#)<sup>[640]</sup> if more space is needed. Once the batch of retry attempts finishes (either successfully or unsuccessfully), the buffer space is no longer needed and is released by the library. The [`callback\_dhcp\_buff\_released\(\)`](#)<sup>[640]</sup> is called to notify your system of the fact. Your system can then check the total number of free pages available (now that the DHCP library released some pages) through the [`sys.freebuffpages`](#)<sup>[531]</sup> R/O property.

The library can run DHCP configuration on both the Ethernet ([`net.`](#)<sup>[358]</sup>) and Wi-Fi ([`wln.`](#)<sup>[538]</sup>) interfaces concurrently. This does not increase buffer space requirements. The library will appropriate buffer pages when needed by either of the interfaces and release buffer pages when neither network interface requires them any longer.

Once the DHCP configuration completes successfully on a particular network interface, the [`callback\_dhcp\_ok\(\)`](#)<sup>[638]</sup> is invoked. You can then program the new IP (and the netmask, and the gateway IP) into the [`net.`](#)<sup>[358]</sup> or [`wln.`](#)<sup>[538]</sup> object. Doing so is only possible when no sockets are active on the network interface whose properties you are about to change.

After the successful DHCP configuration, the library goes into counting lease time. Once 90% of the lease time passes, the library will attempt to renew the lease. Buffer pages will be needed for this again. The IP address does not have to be reset to 0.0.0.0 for the lease renewal, so `callback_dhcp_pre_clear_ip()` will not be called, either.

Note that even in case of the lease renewal the IP address offered by the DHCP server may change. Don't forget to take care of this! Actually, it may be easier to just reboot the device than deal with all the implications of the changed IP. [Code](#)

[Examples](#)<sup>[622]</sup> topic shows how to deal with this.

The library also monitors the link state of network interfaces. If the Ethernet cable is unplugged and then re-plugged (this is monitored through the [net.linstate](#)<sup>[361]</sup> R/O property), the DHCP process (if enabled) will restart automatically for the Ethernet interface. Similarly, if the access point association is lost and then reestablished ([wln.associationstate](#)<sup>[558]</sup>), the DHCP process (if enabled) will restart automatically for the Wi-Fi interface.

## Code Examples

*Projects in the Code Examples section are published on our website under the name "test\_wln\_lib".*

In this section:

- [Step 1: Code Example For the Ethernet Interface](#)<sup>[622]</sup>
- [Step 2: Code Example For the Wi-Fi Interface](#)<sup>[624]</sup>
- [Step 3: Adding Bells and Whistles](#)<sup>[628]</sup>
- [Step 4: Adding More Bells and Whistles](#)<sup>[631]</sup>

### Step 1: Code Example for the Ethernet Interface

*This and other projects in the Code Examples section are published on our website under the name "test\_dhcp\_lib".*

Here is a simple example of using DHCP on the Ethernet ([net](#)<sup>[358]</sup>) interface. Notice how the [callback\\_dhcp\\_ok\(\)](#)<sup>[638]</sup> procedure is implemented! This is a good illustration of the protracted explanation in the [Operations Details](#)<sup>[621]</sup> topic (not that we think you will read it all).

Note also the use of the NET\_AVAILABLE define. This comes from the platform. If the Ethernet interface is available on the currently selected platform, then NET\_AVAILABLE is "1". Similarly, if the Wi-Fi interface is available, then WLN\_AVAILABLE is "1". Using such defines you can create applications that will compile on any platform, as long as this platform has at least the Ethernet, or the Wi-Fi interface.

Here is a sample debug output we've got after running the code:

```
DHCP(net)> ---START---
DHCP(net)> TX discovery message
DHCP(net)> RX offer message
DHCP(net)> TX request message
DHCP(net)> RX confirmation message
DHCP(net)> ---OK(ip: 192.168.1.246, gateway: 192.168.1.1, netmask:
255.255.255.0, lease: 529200 sec.)---
```

- If you are compiling on one of the "W" platforms (that is, platforms with Wi-Fi), then you need to disable the [wln](#)<sup>[536]</sup> object, or this project won't compile. Go Project -> Settings -> Customize and set Wi-Fi (wln.) object to "Disabled".

And here is the code itself...

#### **global.tbh:**

```
'DEFINES-----
#define DHCP_DEBUG_PRINT 1 'to see debug output by the DHCP lib

'INCLUDES-----
include "sock\trunk\sock.tbh" 'this lib is necessary for the DHCP lib's
operation
include "dhcp\trunk\dhcp.tbh"
```

#### **main.tbs:**

```
include "global.tbh"

'=====
sub on_sys_init()
    #if NET_AVAILABLE
        dhcp_start(PL_SOCK_INTERFACE_NET,"","")
    #endif
end sub

'-----
sub on_sys_timer()
    dhcp_proc_timer()
end sub

'-----
sub on_sock_data_arrival()
    dhcp_proc_data()
end sub
```

#### **device.tbs:**

```
include "global.tbh"

'=====
sub callback_dhcp_ok(renew as no_yes, interface as pl_sock_interfaces, byref
ip as string, byref gateway_ip as string, byref netmask as string,
lease_time as dword)
    dim f as byte

    #if NET_AVAILABLE
        if interface=PL_SOCK_INTERFACE_NET then
            if renew=YES and net.ip<>ip then
                'this is a lease renewal and the DHCP server has
issues new IP
                'it is better to reboot than deal with the
implications of the changed IP
                sys.reboot
            end if

            if net.ip<>ip then
                'no need to close sockets -- this is definitely
NOT a renewal an the DHCP lib
```

```

                                'has already closed all socket connections on
this interface prior to setting
                                'the IP to 0.0.0.0
                                net.ip=ip
                                net.gatewayip=gateway_ip
                                net.netmask=netmask
                                end if
                                end if
                                #endif
end sub

'-----
sub callback_dhcp_failure(interface as pl_sock_interfaces, failure_code as
en_dhcp_status_codes)
end sub

'-----
sub callback_dhcp_pre_clear_ip(interface as pl_sock_interfaces)
end sub

'-----
sub callback_dhcp_pre_buffrq(required_buff_pages as byte)
end sub

'-----
sub callback_dhcp_buff_released()
end sub

```

## Step 2: Code Example for the Wi-Fi Interface

*This and other projects in the Code Examples section are published on our website under the name "test\_dhcp\_lib".*

Now let's add DHCP for the Wi-Fi interface ([wln](#)<sup>[536]</sup>) to the [previous sample code](#)<sup>[622]</sup>.

In order to even get to the DHCP stage, the Wi-Fi interface must first associate with the access point. We use our own handy [WLN library](#)<sup>[703]</sup> for that. Notice the use of the WLN\_AVAILABLE define. This example does not address Wi-Fi WPA security, see [Trying WPA](#)<sup>[711]</sup> for inspiration.

Sample debug output follows. Notice some error messages there. This is because our device, although working with two interfaces, was actually connected to the same LAN with the same DHCP server. DHCP messages are sent as broadcasts and both interfaces will get the same message. This results in one interface getting messages intended for the other interface and rejecting them as erroneous. This does not affect the operation of the library.

```

DHCP(net)> ---START---
DHCP(wln)> ---START---
DHCP(net)> TX discovery message
DHCP(net)> RX offer message
DHCP(net)> INFO: RX unexpected message (wasn't expecting anything at the
moment)
DHCP(net)> INFO: RX unexpected, invalid, or unrelated message (it was
discarded)
DHCP(net)> TX request message

```

```
DHCP(net)> RX confirmation message
DHCP(net)> ---OK(ip: 192.168.1.215, gateway: 192.168.1.1, netmask:
255.255.255.0, lease: 529200 sec.)---
DHCP(wln)> Wi-Fi interface associated with the AP -- DHCP (re)started
DHCP(wln)> TX discovery message
DHCP(wln)> RX offer message
DHCP(wln)> INFO: RX unexpected message (wasn't expecting anything at the
moment)
DHCP(wln)> INFO: RX unexpected, invalid, or unrelated message (it was
discarded)
DHCP(wln)> TX request message
DHCP(wln)> RX confirmation message
DHCP(wln)> ---OK(ip: 192.168.1.216, gateway: 192.168.1.1, netmask:
255.255.255.0, lease: 529200 sec.)---
```

- If you disabled the [wln](#) object in the [previous step](#), the you need to enable it now. Plus, you need to test on one of the "W" platforms (that is, platforms with Wi-Fi). Go Project -> Settings -> Customize and set Wi-Fi (wln.) object to "Enabled".

And now the code (plus don't forget to add ga1000fw.bin into your project)...

```
global.tbh:

'DEFINES-----
#define DHCP_DEBUG_PRINT 1 'to see debug output by the DHCP lib

'this is for WLN library
#if PLATFORM_ID=EM500 or PLATFORM_ID=EM500W
    #define WLN_RESET_MODE 1 'there will be no dedicated reset, and all
other lines are fixed
#elif PLATFORM_ID=EM1206 or PLATFORM_ID=EM1206W
    #define WLN_CLK PL_IO_NUM_14
    #define WLN_CS PL_IO_NUM_15
    #define WLN_DI PL_IO_NUM_12
    #define WLN_DO PL_IO_NUM_13
    #define WLN_RST PL_IO_NUM_11
#else
    'EM1000, NB1010,...
    #define WLN_CLK PL_IO_NUM_53
    #define WLN_CS PL_IO_NUM_49
    #define WLN_DI PL_IO_NUM_52
    #define WLN_DO PL_IO_NUM_50
    #define WLN_RST PL_IO_NUM_51
#endif

'INCLUDES-----
include "sock\trunk\sock.tbh" 'this lib is necessary for the DHCP lib's
operation
include "wln\trunk\wln.tbh" 'this lib is necessary for the DHCP on Wi-Fi
interface
include "dhcp\trunk\dhcp.tbh"
```

```
main.tbs:
```

```

include "global.tbh"

'=====
sub on_sys_init()

    #if NET_AVAILABLE
        dhcp_start(PL_SOCK_INTERFACE_NET,"","")
    #endif

    #if WLN_AVAILABLE
        wln_start("TIBB1",WLN_SECURITY_MODE_WEP64,"1234567890",
PL_WLN_DOMAIN_FCC) '<-- set what you need here, see WLN lib docs
        dhcp_start(PL_SOCK_INTERFACE_WLN,"","")
    #endif
end sub

'-----
sub on_sys_timer()
    dhcp_proc_timer()

    #if WLN_AVAILABLE
        wln_proc_timer() 'see WLN lib docs
    #endif
end sub

'-----
sub on_sock_data_arrival()
    dhcp_proc_data()

    #if WLN_AVAILABLE
        wln_proc_data() 'see WLN lib docs
    #endif
end sub

'-----
#if WLN_AVAILABLE
sub on_wln_task_complete(completed_task as pl_wln_tasks)
    wln_proc_task_complete(completed_task) 'see WLN lib docs
end sub
#endif

'-----
#if WLN_AVAILABLE
sub on_wln_event(wln_event as pl_wln_events)
    wln_proc_event(wln_event)
end sub
#endif

```

**device.tbs:**

```

include "global.tbh"

'=====
sub callback_dhcp_ok(renew as no_yes, interface as pl_sock_interfaces, byref
ip as string, byref gateway_ip as string, byref netmask as string,
lease_time as dword)
    dim f as byte

    #if NET_AVAILABLE

```

```
        if interface=PL SOCK_INTERFACE_NET then
            if renew=YES and net.ip<>ip then
                'this is a lease renewal and the DHCP server has
issues new IP
                'it is better to reboot than deal with the
implications of the changed IP
                sys.reboot
            end if

            if net.ip<>ip then
                'no need to close sockets -- this is definitely
NOT a renewal an the DHCP lib
                'has already closed all socket connections on
this interface prior to setting
                'the IP to 0.0.0.0
                net.ip=ip
                net.gatewayip=gateway_ip
                net.netmask=netmask
            end if
        end if
    #endif

    #if WLN_AVAILABLE
        if interface=PL SOCK_INTERFACE_WLN then
            if renew=YES and wln.ip<>ip then
                'this is a lease renewal and the DHCP server has
issues new IP
                'it is better to reboot than deal with the
implications of the changed IP
                sys.reboot
            end if

            if wln.ip<>ip then
                'no need to close sockets -- this is definitely
NOT a renewal an the DHCP lib
                'has already closed all socket connections on
this interface prior to setting
                'the IP to 0.0.0.0
                wln.ip=ip
                wln.gatewayip=gateway_ip
                wln.netmask=netmask
            end if
        end if
    #endif
end sub

'-----
sub callback_dhcp_failure(interface as pl_sock_interfaces, failure_code as
en_dhcp_status_codes)
end sub

'-----
sub callback_dhcp_pre_clear_ip(interface as pl_sock_interfaces)
end sub

'-----
sub callback_dhcp_pre_buffrq(required_buff_pages as byte)
end sub

'-----
sub callback_dhcp_buff_released()
```

```

end sub

'-----
#if WLN_AVAILABLE
sub callback_wln_ok()
end sub
#endif

'-----
#if WLN_AVAILABLE
sub callback_wln_failure(wln_state as en_wln_status_codes)
end sub
#endif

'-----
#if WLN_AVAILABLE
sub callback_wln_pre_buffrq(required_buff_pages as byte)
end sub
#endif

'-----
#if WLN_AVAILABLE
sub callback_wln_rescan_result(current_rssi as byte, scan_rssi as byte,
different_ap as no_yes)
end sub
#endif

```

### Step 3: Adding Bells and Whistles

*This and other projects in the Code Examples section are published on our website under the name "test\_dhcp\_lib".*

Writing quality code means anticipating things to go wrong and not as planned. Here are some ideas on fortifying your code:

#### Check the result of `dhcp_start()`

This one returns one of the [en\\_dhcp\\_status\\_codes\(\)](#)<sup>[635]</sup> and you should check what's returned! Decide for yourself what to do in each particular case or simply halt the execution if there is an error:

```

...
if dhcp_start(PL_SOCK_INTERFACE_NET) <> DHCP_STATUS_OK then sys.halt 'do the
same for the Wi-Fi interface
...

```

#### What to do when `callback_dhcp_failure()` is called

The DHCP client, once started, continues to run indefinitely. Still, at some point your application has to face the simple fact that the DHCP configuration has, indeed, failed, and it is time to do something about it. A set of alternative configuration parameters will come handy at that time. In the code below,

`net_dhcp_fail_ctr` and `wln_dhcp_fail_ctr` accumulate failures. Notice how `dhcp_stop` (637) is called once the count reaches `DHCP_FAIL_LIMIT`:

```
device.tbs:

include "global.tbh"

'-----
const DHCP_FAIL_LIMIT=1 'max number of DHCP retry "batches"
const ALT_NET_IP="192.168.1.40"
const ALT_NET_GATEWAY_IP="192.168.1.1"
const ALT_NET_NETMASK="255.255.255.0"
const ALT_WLN_IP="192.168.1.41"
const ALT_WLN_GATEWAY_IP="192.168.1.1"
const ALT_WLN_NETMASK="255.255.255.0"

'-----
#if NET_AVAILABLE
    dim net_dhcp_fail_ctr as byte 'no need to init to 0 (this is automatic
for global vars)
#endif

#if WLN_AVAILABLE
    dim wln_dhcp_fail_ctr as byte 'no need to init to 0 (this is automatic
for global vars)
#endif

'=====
sub callback_dhcp_ok(renew as no_yes, interface as pl_sock_interfaces, byref
ip as string, byref gateway_ip as string, byref netmask as string,
lease_time as dword)
    dim f as byte

    #if NET_AVAILABLE
        if interface=PL_SOCK_INTERFACE_NET then
            if renew=YES and net.ip<>ip then
                'this is a lease renewal and the DHCP server has
issues new IP
                'it is better to reboot than deal with the
implications of the changed IP
                sys.reboot
            end if

            if net.ip<>ip then
                'no need to close sockets -- this is definitely
NOT a renewal an the DHCP lib
                'has already closed all socket connections on
this interface prior to setting
                'the IP to 0.0.0.0
                net.ip=ip
                net.gatewayip=gateway_ip
                net.netmask=netmask
                net_dhcp_fail_ctr=0
            end if
        end if
    #endif

    #if WLN_AVAILABLE
        if interface=PL_SOCK_INTERFACE_WLN then
            if renew=YES and wln.ip<>ip then
```

```

        'this is a lease renewal and the DHCP server has
issues new IP
        'it is better to reboot than deal with the
implications of the changed IP
        sys.reboot
    end if

    if wln.ip<>ip then
        'no need to close sockets -- this is definitely
NOT a renewal an the DHCP lib
        'has already closed all socket connections on
this interface prior to setting
        'the IP to 0.0.0.0
        wln.ip=ip
        wln.gatewayip=gateway_ip
        wln.netmask=netmask
        wln_dhcp_fail_ctr=0
    end if
end if
#endif
end sub

'-----
sub callback_dhcp_failure(interface as pl_sock_interfaces, failure_code as
en_dhcp_status_codes)
    #if NET_AVAILABLE
        if interface=PL_SOCKET_INTERFACE_NET then
            if net_dhcp_fail_ctr>=DHCP_FAIL_LIMIT then
                net.ip=ALT_NET_IP
                net.gatewayip=ALT_NET_GATEWAY_IP
                net.netmask=ALT_NET_NETMASK
                dhcp_stop(PL_SOCKET_INTERFACE_NET)
            else
                net_dhcp_fail_ctr=net_dhcp_fail_ctr+1
            end if
        end if
    #endif

    #if WLN_AVAILABLE
        if interface=PL_SOCKET_INTERFACE_WLN then
            if wln_dhcp_fail_ctr>=DHCP_FAIL_LIMIT then
                wln.ip=ALT_WLN_IP
                wln.gatewayip=ALT_WLN_GATEWAY_IP
                wln.netmask=ALT_WLN_NETMASK
                dhcp_stop(PL_SOCKET_INTERFACE_WLN)
            else
                wln_dhcp_fail_ctr=wln_dhcp_fail_ctr+1
            end if
        end if
    #endif
end sub
...

```

### What to do when `callback_dhcp_pre_clear_ip()` is called

This is very application-specific but we'd say, close your existing TCP connections nicely. Whatever you leave unattended will be brutally squashed by the DHCP library (using the [sock.discard](#)<sup>[478]</sup> hammer), so you may have to tend to your socket

connections in advance. Here is an example where you wait for the unsent data to be sent out on a "SOCK\_DATA" socket:

```
...
    sock.num=SOCK_DATA
    while sock.txlen>0
        doevents 'optional, allows other things in your app to execute
    wend
...

```

### What to do when `callback_dhcp_pre_buffrq()` is called

If it is called then you don't have enough buffer pages. OK, don't panic... you can always take some buffers away from somebody. Supposing you have a lot of buffers in the "SOCK\_DATA" socket of your project. Sockets are useless without properly configured IP, so you could just temporary use this buffer space:

```
...
'-----
sub callback_dhcp_pre_buffrq(required_buff_pages as byte)
    sock_release(SOCK_DATA) 'this deallocates buffers
end sub

'-----
sub callback_dhcp_buff_released()
    sock.num=SOCK_DATA
    sock.rxbuffrq(sys.freebuffpages/2)
    sock.txbuffrq(sys.freebuffpages/2)
    sys.buffalloc
    'proceed with socket setup
end sub
...

```

## Step 4: Adding More Bells and Whistles

*This and other projects in the Code Examples section are published on our website under the name "test\_dhcp\_lib".*

OK, DHCP now works but your device is probably getting a new IP each time it boots. This is because the device does not "suggest" an IP address when calling [dhcp\\_start\(\)](#)<sup>[636]</sup>. It is a good practice to do so -- memorize the previously obtained IP, then request the same from the DHCP server during the next boot.

Since the IP address must be preserved between boots, your device needs to store it in the EEPROM. Use the [STG](#)<sup>[668]</sup> (settings) library for the purpose (this is, by the way, a shining example of STG's immense usefulness). In the code below, two settings -- "IPN" and "IPW" -- remember the IP addresses for the Ethernet and Wi-Fi interfaces. Note that the STG library is integrated here in a rather sloppy way. Everything will work but don't take this as a golden standard for STG library use.

Suggested IP address is provided in the [on\\_sys\\_init\(\)](#)<sup>[533]</sup> handler, when executing [dhcp\\_start\(\)](#)<sup>[636]</sup>, first for Ethernet, and then for Wi-Fi. When you run the code for the first time, settings won't have valid values, so [stg\\_get\(\)](#)<sup>[696]</sup> will return default values of the settings, which are "0.0.0.0" (see settings.txt descriptor file). This means that no specific IP is being requested.

Notice also how device names ("tibbo\_net" and "tibbo\_wln") are supplied with [dhcp\\_start\(\)](#).

#### global.tbh:

```
'DEFINES-----
#define DHCP_DEBUG_PRINT 1 'to see debug output by the DHCP lib

'this is for WLN library
#if PLATFORM_ID=EM500 or PLATFORM_ID=EM500W
    #define WLN_RESET_MODE 1 'there will be no dedicated reset, and all
    other lines are fixed
#elif PLATFORM_ID=EM1206 or PLATFORM_ID=EM1206W
    #define WLN_CLK PL_IO_NUM_14
    #define WLN_CS PL_IO_NUM_15
    #define WLN_DI PL_IO_NUM_12
    #define WLN_DO PL_IO_NUM_13
    #define WLN_RST PL_IO_NUM_11
#else
    'EM1000, NB1010,...
    #define WLN_CLK PL_IO_NUM_53
    #define WLN_CS PL_IO_NUM_49
    #define WLN_DI PL_IO_NUM_52
    #define WLN_DO PL_IO_NUM_50
    #define WLN_RST PL_IO_NUM_51
#endif

'INCLUDES-----
include "sock\trunk\sock.tbh" 'this lib is necessary for the DHCP lib's
operation
include "settings\trunk\settings.tbh" 'this lib is for saving obtained IPs
includepp "settings.txt" 'for STG library
include "wln\trunk\wln.tbh" 'this lib is necessary for the DHCP on Wi-Fi
interface
include "dhcp\trunk\dhcp.tbh"
```

#### main.tbs:

```
...
sub on_sys_init()

    stg_start()

    #if NET_AVAILABLE
        dhcp_start(PL_SOCKET_INTERFACE_NET, stg_get("IPN", 0), "tibbo_net")
    #endif

    #if WLN_AVAILABLE
        wln_start("TIBB1", WLN_SECURITY_MODE_WEP64, "1234567890",
        PL_WLN_DOMAIN_FCC) '<-- set what you need here, see WLN lib docs
        dhcp_start(PL_SOCKET_INTERFACE_WLN, stg_get("IPW", 0), "tibbo_wln")
    #endif
```

```
end sub
...
```

When DHCP configuration completes successfully, `callback_dhcp_ok()` is called and the obtained IP is saved into the corresponding setting using `stg_set()`<sup>[697]</sup>. This also "repairs" the setting if its previous data was invalid. This way, when the device boots next time, `stg_get()`<sup>[696]</sup> will return the actual saved data.

```
device.tbs:
```

```
...
sub callback_dhcp_ok(renew as no_yes, interface as pl_sock_interfaces, byref
ip as string, byref gateway_ip as string, byref netmask as string,
lease_time as dword)
    dim f as byte

    #if NET_AVAILABLE
        if interface=PL_SOCKET_INTERFACE_NET then
            if renew=YES and net.ip<>ip then
                'this is a lease renewal and the DHCP server has
issues new IP
                'it is better to reboot than deal with the
implications of the changed IP
                sys.reboot
            end if

            if net.ip<>ip then
                'no need to close sockets -- this is definitely
NOT a renewal an the DHCP lib
                'has already closed all socket connections on
this interface prior to setting
                'the IP to 0.0.0.0
                net.ip=ip
                net.gatewayip=gateway_ip
                net.netmask=netmask
                net_dhcp_fail_ctr=0

                'save this IP into the EEPROM for future use
                if stg_get("IPN",0)<>ip then
                    stg_set("IPN",0,ip)
                end if
            end if
        end if
    #endif

    #if WLN_AVAILABLE
        if interface=PL_SOCKET_INTERFACE_WLN then
            if renew=YES and wln.ip<>ip then
                'this is a lease renewal and the DHCP server has
issues new IP
                'it is better to reboot than deal with the
implications of the changed IP
                sys.reboot
            end if

            if wln.ip<>ip then
                'no need to close sockets -- this is definitely
NOT a renewal an the DHCP lib
```

```

        'has already closed all socket connections on
this interface prior to setting
        'the IP to 0.0.0.0
        wln.ip=ip
        wln.gatewayip=gateway_ip
        wln.netmask=netmask
        wln_dhcp_fail_ctr=0

        'save this IP into the EEPROM for future use
        if stg_get("IPW",0)<>ip then
            stg_set("IPW",0,ip)
        end if
    end if
end if
#endif
end sub
...
'-----
sub callback_stg_error(byref stg_name_or_num as string,index as byte,status
as en_stg_status_codes)
end sub

'-----
sub callback_stg_pre_get(byref stg_name_or_num as string,index as byte,byref
stg_value as string)
end sub

'-----
sub callback_stg_post_set(byref stg_name_or_num as string, index as byte,
byref stg_value as string)
end sub
...

```

**settings.txt (the underlying configuration file):**

```

>>IPNE    D    1    4    4    A    0.0.0.0    Ethernet IP
>>IPWE    D    1    4    4    A    0.0.0.0    Wi-Fi IP

#define STG_DESCRIPTOR_FILE "settings.txt"
#define STG_MAX_NUM_SETTINGS 2
#define STG_MAX_SETTING_NAME_LEN 3
#define STG_MAX_SETTING_VALUE_LEN 15

```

## Library Defines (Options)

Any of the options below look cryptic? Read the [Operation Details](#)<sup>[627]</sup> section.

### DHCP\_DEBUG\_PRINT (default= 0)

0- no debug information.

1- print debug information into the output pane. Debug printing only works when the project is in the [debug mode](#)<sup>[27]</sup>. However, still set this option to 0 for release, as this will save memory and code space.

**DHCP\_MAX\_RETRIES (default= 3)**

The number of retry attempts in one batch of DHCP configuration attempts.

**DHCP\_WAIT\_TIME (default= 2)**

Maximum waiting time, in seconds, for the DHCP server to respond to the device's request.

**DHCP\_MAX\_RETRY\_DELAY (default= 10)**

Maximum waiting time, in seconds, between the retry attempts within one batch of retries. Actual waiting time is randomized between 1 and DHCP\_RANDOM\_RETRY\_DELAY seconds.

**DHCP\_POST\_FAIL\_DELAY (default= 180)**

Delay, in seconds, between the batches of retries.

**DHCP\_MAX\_HOST\_NAME\_LEN (default=0 )**

Maximum device (host) name length.

## En\_dhcp\_status\_codes

Several procedures in the library utilize the en\_dhcp\_status\_codes enum. This enum has the following members:

0- DHCP\_STATUS\_OK: success.

1- DHCP\_STATUS\_OUT\_OF\_SOCKETS: no free sockets available for the library to operate.

2- DHCP\_STATUS\_INVALID\_INTERFACE: unsupported network interface specified (use PL\_SOCK\_INTERFACE\_NET or PL\_SOCK\_INTERFACE\_WLN only).

3- DHCP\_STATUS\_INSUFFICIENT\_BUFFER\_SPACE: insufficient number of buffer pages available and the call to [callback\\_dhcp\\_pre\\_buffrq\(\)](#)<sup>[640]</sup> failed to cure the problem.

4- DHCP\_STATUS\_FAILURE: interaction with the DHCP server failed (because there was no reply, the reply was unrecognized, invalid, etc.).

## Library Procedures

In this section:

- [Dhcp\\_get\\_info\(\)](#)<sup>[636]</sup>
- [Dhcp\\_start\(\)](#)<sup>[636]</sup>
- [Dhcp\\_stop\(\)](#)<sup>[637]</sup>

- [Dhcp\\_proc\\_timer\(\)](#)<sup>[637]</sup>
- [Dhcp\\_proc\\_data\(\)](#)<sup>[638]</sup>
- [Callback\\_dhcp\\_ok\(\)](#)<sup>[638]</sup>
- [Callback\\_dhcp\\_failure\(\)](#)<sup>[639]</sup>
- [Callback\\_dhcp\\_pre\\_clear\\_ip\(\)](#)<sup>[639]</sup>
- [Callback\\_dhcp\\_pre\\_buffrq\(\)](#)<sup>[640]</sup>
- [Callback\\_dhcp\\_buff\\_released\(\)](#)<sup>[640]</sup>

## Dhcp\_get\_info()

- Description:** API procedure, returns library-specific information according to the requested information element.
- Syntax:** **function dhcp\_get\_info**(info\_element as **dhcp\_info\_elements**, byref extra\_data as **string**) as **string**
- Returns:** Requested data in *string* form
- See Also:** [About\\_get\\_info\(\) API Functions](#)<sup>[577]</sup>

Part	Description
info_element	Information element being requested:  0- DHCP_INFO_ELEMENT_REQUIRED_BUFFERS: total number of buffer pages required for the library to operate.
extra_data	Leave this string argument empty.

### Details

---

## Dhcp\_start()

- Description:** API procedure, starts DHCP client on the specified network interface.
- Syntax:** **function dhcp\_start**(interface as **pl\_sock\_interfaces**, byref requested\_ip as **string**, byref host\_name as **string**) as **en\_dhcp\_status\_codes**
- Returns:** One of these [en\\_dhcp\\_status\\_codes](#)<sup>[635]</sup>:  
DHCP\_STATUS\_OK, DHCP\_STATUS\_OUT\_OF\_SOCKETS,  
DHCP\_STATUS\_INVALID\_INTERFACE
- See Also:** [Step-by-step Usage Instructions](#)<sup>[619]</sup>, [Operation Details](#)<sup>[621]</sup>

Part	Description
------	-------------

interface	<p>Network interface to start the DHCP client on:</p> <p>0- PL_SOCK_INTERFACE_NULL: do not choose this one, it is for a "non-existing interface".</p> <p>1- PL_SOCK_INTERFACE_NET: Ethernet (<a href="#">net.</a><sup>[358]</sup>) interface.</p> <p>2- PL_SOCK_INTERFACE_WLN: Wi-Fi (<a href="#">wln.</a><sup>[536]</sup>) interface.</p>
requested_ip	<p>Optionally provide an IP address that the device wishes to use or continue using. This is typically an IP address that was previously obtained. Leave this argument empty if no IP is being requested specifically. This argument will be ignored if the data format is wrong (for example, "192.168.1").</p>
host_name	<p>The device name to register with the DHCP server. Add <a href="#">DHCP_MAX_HOST_NAME_LEN</a><sup>[634]</sup> option to global.tbh for this to work. Leave this argument empty if you don't wish to send the host name. Name length can't exceed the value set by DHCP_MAX_HOST_NAME_LEN.</p>

### Details

The interface option 0- PL\_SOCK\_INTERFACE\_NULL exists because the interface argument is of the pl\_sock\_interfaces type, which defines available network interfaces for the [sock.](#)<sup>[421]</sup> object (see, for example, [sock.targetinterface](#)<sup>[506]</sup>). Obviously, there is no point selecting this option for dhcp\_start().

## Dhcp\_stop()

<b>Description:</b>	API procedure, stops DHCP client on the specified network interface.
<b>Syntax:</b>	<b>function dhcp_stop(interface as pl_sock_interfaces) as en_dhcp_status_codes</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Step-by-step Usage Instructions</a> <sup>[619]</sup> , <a href="#">Operation Details</a> <sup>[621]</sup>

### Details

---

## Dhcp\_proc\_timer()

<b>Function:</b>	Event procedure, call it from the <a href="#">on_sys_timer()</a> <sup>[533]</sup> event handler.
<b>Syntax:</b>	<b>sub dhcp_proc_timer()</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Step-by-step Usage Instructions</a> <sup>[619]</sup> , <a href="#">Operation Details</a> <sup>[621]</sup> (see "Additional Considerations"!)

### Details

---

#### Dhcp\_proc\_data()

- Function:** Event procedure, call it from the [on\\_sock\\_data\\_arrival\(\)](#) <sup>[489]</sup> event handler.
- Syntax:** **sub dhcp\_proc\_data()**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#) <sup>[619]</sup>, [Operation Details](#) <sup>[621]</sup>

### Details

---

#### Callback\_dhcp\_ok()

- Description:** Callback procedure, informs of the successful procurement of configuration parameters from the DHCP server. Procedure body has to be created elsewhere in the project (externally with respect to the library).
- Syntax:** **sub callback\_dhcp\_ok(renew as no\_yes, interface as pl\_sock\_interfaces, byref dhcp\_obtained\_ip as string, byref dhcp\_obtained\_gateway as string, byref dhcp\_obtained\_netmask as string, dhcp\_obtained\_lease\_time as dword)**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#) <sup>[619]</sup>, [Operation Details](#) <sup>[621]</sup>

Part	Description
renew	0- NO: this is an initial configuration of the IP, etc. 1- YES: this is a lease renewal (watch out for IP changes!).
interface	Network interface on which the DHCP configuration has completed successfully: 1- PL_SOCK_INTERFACE_NET: Ethernet ( <a href="#">net.</a> <sup>[358]</sup> ) interface. 2- PL_SOCK_INTERFACE_WLN: Wi-Fi ( <a href="#">wln.</a> <sup>[536]</sup> ) interface.
dhcp_obtained_ip	Obtained IP address in the human-readable form, i.e. "192.168.1.40".
dhcp_obtained_gateway	Obtained gateway IP address in the human-readable form, i.e. "192.168.1.1".
dhcp_obtained_netmask	Obtained netmask in the human-readable form, i.e.

tmask "255.255.255.0".

dhcp\_obtained\_lease\_time Obtained lease time expressed as the number of seconds.

### Details

---

## Callback\_dhcp\_failure()

**Description:** Callback procedure, informs of the failure to procure configuration parameters from the DHCP server after [DHCP\\_MAX\\_RETRIES](#)<sup>[634]</sup>. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_dhcp\_failure**(interface as **pl\_sock\_interfaces**, failure\_code as **en\_dhcp\_status\_codes**)

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[619]</sup>, [Operation Details](#)<sup>[621]</sup>

Part	Description
interface	Network interface on which the DHCP client has failed: 1- PL_SOCK_INTERFACE_NET: Ethernet ( <a href="#">net</a> . <sup>[358]</sup> ) interface. 2- PL_SOCK_INTERFACE_WLN: Wi-Fi ( <a href="#">wln</a> . <sup>[536]</sup> ) interface.
failure_code	One of the <a href="#">en_dhcp_status_codes</a> <sup>[635]</sup>

### Details

---

## Callback\_dhcp\_pre\_clear\_ip()

**Description:** Callback procedure, informs that the DHCP library will set the specified interface's IP address to 0.0.0.0. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_dhcp\_pre\_clear\_ip**(interface as **pl\_sock\_interfaces**)

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[619]</sup>, [Operation Details](#)<sup>[621]</sup>

Part	Description
interface	Network interface on which the library will set the IP to 0.0.0.0:  1- PL_SOCK_INTERFACE_NET: Ethernet ( <a href="#">net.</a> <sup>358</sup> ) interface. 2- PL_SOCK_INTERFACE_WLN: Wi-Fi ( <a href="#">wln.</a> <sup>536</sup> ) interface.

### Details

This procedure will only be called if the IP address is not already set to 0.0.0.0.

## Callback\_dhcp\_pre\_buffrq()

<b>Description:</b>	Callback procedure, informs of the insufficient number of free buffer pages available for use by the library. Procedure body has to be created elsewhere in the project (externally with respect to the library).
<b>Syntax:</b>	<b>sub callback_dhcp_pre_buffrq(required_buff_pages as byte)</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Step-by-step Usage Instructions</a> <sup>619</sup> , <a href="#">Operation Details</a> <sup>621</sup>

Part	Description
required_buffer_pages	The number of additional buffer pages that the DHCP library needs to operate. Your application must free up at least this number of buffer pages within the callback_dhcp_pre_buffrq () or DHCP configuration will fail with the DHCP_STATUS_INSUFFICIENT_BUFFER_SPACE <a href="#">code</a> <sup>635</sup> .

### Details

This procedure will be called only if there are not enough buffer pages available.

## Callback\_dhcp\_buff\_released()

<b>Description:</b>	Callback procedure, informs of the release of buffer pages by the library. Procedure body has to be created elsewhere in the project (externally with respect to the library).
<b>Syntax:</b>	<b>sub callback_dhcp_buff_released()</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Step-by-step Usage Instructions</a> <sup>619</sup> , <a href="#">Operation Details</a> <sup>621</sup>

### Details

The number of free buffer pages can be checked through the [sys.freebuffpages](#)<sup>[531]</sup> R/O property.

## FILENUM (File Numbers) Library

The FILENUM library automates file number assignment. The [fd](#)<sup>[236]</sup> object supports up to [fd.maxopenedfiles](#)<sup>[282]</sup> opened files. Using the FILENUM library, your code can get an unused file number, work with the file "on" this number, then release the file number into a pool of free file numbers.

### Library Info

<b>Supported platforms:</b>	Any platform with the <a href="#">fd</a> <sup>[236]</sup> object.
<b>Files to include:</b>	Filenum.tbs, filenum.tbh (from <i>current_library_set</i> \filenum\trunk\).
<b>Dependencies:</b>	---
<b>API procedures:</b>	<a href="#">filenum_get()</a> <sup>[644]</sup> -- returns a free file number or 255 if no free file numbers left. Use <a href="#">API procedures</a> <sup>[576]</sup> to interact with the library.
	<a href="#">filenum_who_uses()</a> <sup>[644]</sup> -- returns the signature of the specified file number's user.
	<a href="#">filenum_release()</a> <sup>[645]</sup> -- releases the file number.
<b>Event procedures:</b>	---
<b>Callback procedures:</b>	---
<b>Required buffer space:</b>	---

## Step-by-step Usage Instructions

### Minimal steps

1. Add [filenum.tbs](#)<sup>[577]</sup> and [filenum.tbh](#) files to your project (they are in *current\_library\_set*\filenum\trunk).
2. Add **include "filenum\trunk\filenum.tbh"** to the includes section of the **global.tbh** file.
3. Add [#define FILENUM\\_MAX\\_FILENAME\\_LEN](#)<sup>[643]</sup> to the defines section of the **global.tbh** file; set it to the value that reflects the longest filename you are going to use.
4. Call [filenum\\_get\(\)](#)<sup>[644]</sup> whenever you need a free file number. Observe the result -- if it is 255 then there are no free file numbers available!
5. Call [filenum\\_release\(\)](#)<sup>[645]</sup> when you no longer need a particular file number. This way, the file number can be reused by something else in your code.

### Additional recommended steps

1. The use of [filenum\\_who\\_uses\(\)](#)<sup>[644]</sup> is optional. This call will return a string signature left by the caller when obtaining the file number. [FILENUM\\_MAX\\_SIGNATURE\\_LEN](#)<sup>[643]</sup> must be >0 for signatures to be saved.

We have provided a [code snippet](#)<sup>[642]</sup> illustrating the use of the FILENUM library.



Using the FILENUM library? Then, use it everywhere in your code! Do not "appropriate" file numbers without going through this library.

## Operation Details

The FILENUM library maintains a list of free and occupied file numbers. This is kept in the `filenum_in_use` array. You can see this array's contents under the debugger. To get a free file number, call [filenum\\_get\(\)](#)<sup>[644]</sup> and it will return a file number, which will now be marked as used. The function will return 255 if there are no free file numbers left, so watch out for this number!

When calling `filenum_get()`, you can supply a meaningful short name of the caller. For example, if the file number is to be used for accessing the log file, set the signature to "LOG". The `filenum_user_signature` array keeps the signatures left by `filenum_get()` callers. Observing this array's contents under the debugger will provide a clear picture of who is using which file number. The signature of free file numbers is "-". Note that `FILENUM_MAX_SIGNATURE_LEN` defines maximum signature length and the default value is 0. Set this to anything above 0 to be able to observe the signatures. You can set it back to 0 when the debugging process is over.

Another way to observe the operation of the library in the [debug mode](#)<sup>[27]</sup> is by adding `#define FILENUM_DEBUG_PRINT 1`<sup>[643]</sup> to the defines section of the `global.tbh` file of your project. A wealth of status information will be printed in the console pane as the FILENUM library operates.

To release the file number, call [filenum\\_release\(\)](#)<sup>[645]</sup>. This will mark the file number as free and the next caller of the `filenum_get()` will have a chance to reuse this file number.

[Filenum\\_who\\_uses\(\)](#)<sup>[644]</sup> returns a signature left by the specified file number's user. This function doesn't have to be used and exists only for convenience.

## A Code Snippet

Here is a small code snippet illustrating the process of getting and releasing file numbers. We sacrificed robustness for simplicity, so don't take the code below for a shining example of [fd.](#)<sup>[236]</sup> object's usage. Just see the parts related to the FILENUM library -- that's the point right now.

```
...
'set "#define FILENUM_MAX_SIGNATURE_LEN 3" and "#define FILENUM_DEBUG_PRINT
1" before running this test

'prepare the disk and create a file
fd.format(fd.availableflashspace,16)
fd.mount()
fd.create("log.txt")
```

```
'get a file number...
log_filenum=filenum_get("LOG")
if log_filenum=255 then
    sys.halt '...uh-uh, out of sockets!
end if

'add data to the file, then close
fd.filenum=log_filenum
fd.open("LOG")
fd.setdata(filenum_who_uses(log_filenum))
fd.close

'release the file number
filenum_release(log_filenum)
...
```

And here is what appeared in the output pane of TIDE as the code executed:

```
FILENUM> 'LOG' got file #0
FILENUM> 'LOG' released file #0
```

The first message corresponds to [filenum\\_get\(\)](#)<sup>[644]</sup>, the second one -- to [filenum\\_release\(\)](#)<sup>[645]</sup>. "LOG" is the signature left by us, because this code deals with a log file.

Notice that the data saved into the log file consists of the file number's signature. As a result, the file will contain the string "LOG".

## Library Defines (Options)

Any of the options below look cryptic? Read the [Operation Details](#)<sup>[642]</sup> section.

### **FILENUM\_DEBUG\_PRINT (default= 0)**

0- no debug information.

1- print debug information into the output pane. Debug printing only works when the project is in the [debug mode](#)<sup>[27]</sup>. However, still set this option to 0 for release, as this will save memory and code space.

### **FILENUM\_MAX\_SIGNATURE\_LEN (default= 0)**

Size of members of the `filenum_user_signature` array. Set to >0 to be able to observe the signatures left by the callers of the [filenum\\_get\(\)](#)<sup>[644]</sup>.

### **FILENUM\_MAX\_FILENAME\_LEN (default= 0)**

Maximum filename length. This must be set to at least the length of the longest filename you are planning to use in your project.

## Library Procedures

In this section:

- [Filenum\\_get\(\)](#)<sup>[644]</sup>
- [Filenum\\_who\\_uses\(\)](#)<sup>[644]</sup>
- [Filenum\\_release\(\)](#)<sup>[645]</sup>

### Filenum\_get()

- Description:** API procedure, returns a free file number or 255 if no free file numbers left.
- Syntax:** **function filenum\_get(byref signature as string) as byte**
- Returns:** The number of the unused file number or 255 if all file numbers are in use.
- See Also:** [Step-by-step Usage Instructions](#)<sup>[641]</sup>, [Operation Details](#)<sup>[642]</sup>

Part	Description
signature	A string with a short description of the file number's purpose. You may leave the signature empty, too.

#### Details

Set [FILENUM\\_MAX\\_SIGNATURE\\_LEN](#)<sup>[643]</sup> to anything above 0 in order to be able to use signatures.

### Filenum\_who\_uses()

- Description:** API procedure, returns the signature of the specified file number's user.
- Syntax:** **function filenum\_who\_uses(file\_num as byte) as string**
- Returns:** The signature left by the file number's user on [filenum\\_get\(\)](#)<sup>[644]</sup> invocation.
- See Also:** [Step-by-step Usage Instructions](#)<sup>[641]</sup>, [Operation Details](#)<sup>[642]</sup>

Part	Description
file_num	File number.

#### Details

Set [FILENUM\\_MAX\\_SIGNATURE\\_LEN](#)<sup>[643]</sup> to anything above 0 in order to be able to use signatures.

## Filenum\_release()

<b>Description:</b>	API procedure, releases the file number.
<b>Syntax:</b>	<b>sub filenum_release(file_num as byte)</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Step-by-step Usage Instructions</a> <sup>[641]</sup> , <a href="#">Operation Details</a> <sup>[642]</sup>

Part	Description
file_num	The file number to be released.

### Details

---

## GPRS (PPP) Library

The GPRS library handles PPP link establishment and is primarily targeted for GPRS modems. Together with the [ppp](#)<sup>[366]</sup> object, it forms a complete GPRS/PPP solution for your device.

Although the library can theoretically work with any GPRS modem, it has been specifically tested with GC864 GPRS module manufactured by TELIT ([www.telit.com](http://www.telit.com)). This module can be installed on the NB1010 board offered by Tibbo.

The library is event-based and non-blocking -- it quietly runs in the background and takes a minimal amount of CPU time.

### Library Info

<b>Supported platforms:</b>	Any platform with a serial port.
<b>Files to include:</b>	Gprs.tbs, gprs.tbh (from <i>current_library_set</i> \gprs\trunk\).
<b>Dependencies:</b>	<a href="#">SOCK</a> <sup>[664]</sup> library.
<b>API procedures:</b>	<a href="#">gprs_start()</a> <sup>[652]</sup> -- starts the PPP login/configuration process.
Use <a href="#">API procedures</a> <sup>[576]</sup> to interact with the library.	<a href="#">gprs_stop()</a> <sup>[653]</sup> -- stops (aborts) PPP link establishment or session.
<b>Event procedures:</b>	<a href="#">gprs_proc_timer()</a> <sup>[653]</sup> -- call this from the <a href="#">on_sys_timer()</a> <sup>[533]</sup> event handler.
Call <a href="#">event procedures</a> <sup>[576]</sup> from corresponding event handlers, as described <a href="#">here</a> <sup>[619]</sup> .	<a href="#">gprs_proc_sock_data()</a> <sup>[653]</sup> -- call this from the <a href="#">on_sock_data_arrival()</a> <sup>[489]</sup> event handler.
	<a href="#">gprs_proc_ser_data()</a> <sup>[654]</sup> -- call this from the <a href="#">on_ser_data_arrival()</a> <sup>[412]</sup> event handler.
<b>Callback procedures:</b>	<a href="#">callback_gprs_ok()</a> <sup>[654]</sup> -- called when the library completes PPP login/configuration.

Implement the bodies of [callback procedures](#)<sup>[576]</sup> elsewhere in your project.

[callback\\_gprs\\_failure\(\)](#)<sup>[654]</sup> -- called when PPP login/configuration or established link fails.

[callback\\_gprs\\_pre\\_buffrq\(\)](#)<sup>[655]</sup> -- called when the library needs to allocate buffer space and the required space is not available.

**Required buffer space:**

10 buffer pages minimum with [GPRS\\_PAYLOAD\\_SIZE](#)<sup>[650]</sup> of 1. Released when [gprs\\_stop\(\)](#)<sup>[653]</sup> is called.

## Step-by-step Usage Instructions

Steps below assume that you are using the NB1010 board (DS101x device) for testing.

1. Make sure you have the [SOCK](#)<sup>[664]</sup> library in your project.
2. Add [gprs.tbs](#)<sup>[577]</sup> and [gprs.tbh](#) files to your project (they are in `current_library_set\gprs\trunk`).
3. Add [#define GPRS\\_DEBUG\\_PRINT 1](#)<sup>[651]</sup> to the defines section of the global.tbh file of your project. This way you will "see what's going on". Don't forget to remove this later, after you've made sure that the library operates as expected.
4. Add [include "gprs\trunk\gprs.tbh"](#) to the includes section of the global.tbh file.
5. Add [gprs\\_proc\\_timer\(\)](#)<sup>[653]</sup> to the [on\\_sys\\_timer\(\)](#)<sup>[533]</sup> event handler code (see "further considerations" below).
6. Add [pppoe\\_proc\\_sock\\_data\(\)](#)<sup>[653]</sup> to the [on\\_sock\\_data\\_arrival\(\)](#)<sup>[489]</sup> event handler code.
7. Add [pppoe\\_proc\\_ser\\_data\(\)](#)<sup>[654]</sup> to the [on\\_ser\\_data\\_arrival\(\)](#)<sup>[412]</sup> event handler code.
8. Create empty [callback function](#)<sup>[576]</sup> bodies (presumably in the device.tbs): [callback\\_gprs\\_ok\(\)](#)<sup>[654]</sup>, [callback\\_gprs\\_failure\(\)](#)<sup>[654]</sup>, [callback\\_gprs\\_pre\\_buffrq\(\)](#)<sup>[655]</sup>. Hint: copy from declarations in the pppoe.tbh or from our [code example](#)<sup>[647]</sup>.
9. Call [gprs\\_start\(\)](#)<sup>[652]</sup> from somewhere. The no-brainer decision is to call from the [on\\_sys\\_init\(\)](#)<sup>[533]</sup> event handler. Supply correct ATDT line and APN. In our tests on *Taiwan Cellular* network, we have to use **\*99#** and **INTERNET**. Your network may require a different string. Note that pppoe\_start() may fail, so it is wise to check the returned status code.
10. Implement meaningful code for the [callback\\_gprs\\_ok\(\)](#)<sup>[654]</sup>. Once it is called, you know that your PPP link is up.

All of the above is illustrated in the [code example](#)<sup>[647]</sup>.

### Further considerations

The GPRS library expects the [gprs\\_proc\\_timer\(\)](#)<sup>[653]</sup> to be called at 0.5 sec intervals. This is the default value which can be changed through the [sys.onsystemerperiod](#)<sup>[533]</sup> property. If your project needs to have the [on\\_sys\\_timer\(\)](#)<sup>[533]</sup> event at a different rate, please make sure that gprs\_proc\_timer() is still called 2 times/second. For example, if the on\_sys\_timer() is set to trigger 4 times/second, you need to add "divider" code that only calls gprs\_proc\_timer() on every second invocation of the on\_sys\_timer().

If you are using an external GPRS modem, you need to add [#define](#)

[GPRS\\_MODULE\\_EXTERNAL\\_1](#) to global.tbh.

Depending on how you connect the GPRS modem, you may also need to add the following custom defines:

- [GPRS\\_SER\\_PORT](#)
- [GPRS\\_SER\\_PORT\\_RTSMAP](#)
- [GPRS\\_SER\\_PORT\\_CTSMAP](#)
- [GPRS\\_SWITCH](#)
- [GPRS\\_RESET](#)

## Operation Details

Enter topic text here.

## Operation Details

GPRS library's operation is persistent: once you start it by calling [gprs\\_start\(\)](#), it will "persist" to keep PPP link established. No matter how many times the link fails, the library will keep trying. If the successfully established PPP link fails, the library will attempt to reestablish the link. This can only be halted by calling [gprs\\_stop\(\)](#).

GPRS library is buffer-hungry. Even if you set [GPRS\\_PAYLOAD\\_SIZE](#) to 1, you will need 10 buffer pages for the GPRS library to operate. With default payload size of 4, this increases to 25 buffer pages. [GPRS\\_PAYLOAD\\_SIZE](#) defines the maximum size of TCP and UDP packets that the PPP interface will be able to handle. Unless you specifically want to send out large UDP packets, it is actually OK to set the payload size to the minimum -- GPRS links are slow and you won't feel any performance decrease just because you limit the size of packets.

Buffer space is allocated when [gprs\\_start\(\)](#) is called. The library will check if the required buffer space is available and call [callback\\_ppp\\_pre\\_buffrq\(\)](#) if more space is needed. Buffer pages allocated to the PPP library will only be released if [gprs\\_stop\(\)](#) is called.

Successful PPP link establishment is a multi-step process and involves link configuration using LCP protocol, followed by the login and the configuration of device's IP address. To observe the process, add [#define GPRS\\_DEBUG\\_PRINT 1](#) to the defines section of the global.tbh file of your project (and don't forget to remove this later).

Once the PPP link is successfully established, the library will set [ppp\\_ip](#) and call [callback\\_gprs\\_ok\(\)](#). The library will then start monitoring PPP link's "health". The library will periodically send echo request packets and expect echo replies from the other end. If this times out, the library will assume that the PPP link has failed, call [gprs\\_failure\(\)](#), and attempt to reestablish the link.

If your application calls [pppoe\\_stop\(\)](#), the library will apply the hardware reset to the GPRS module (provided that [GPRS\\_MODULE\\_EXTERNAL](#) is 0), release all buffers, and go into the idle state until [gprs\\_start\(\)](#) is called again.

## Code Example

```
global.tbh:
```

```
'DEFINES-----  
#define SUPPORTS_GPRS 1  
#define GPRS_DEBUG_PRINT 1  
#define GPRS_PAYLOAD_SIZE 1
```

```
' INCLUDES-----
include "sock\trunk\sock.tbh"
include "gprs\trunk\gprs.tbh"

' DECLARATIONS-----
declare tcp_sock_o as byte
```

**main.tbs:**

```
include "global.tbh"
'-----

const AT_DT_COMMAND="*99#"
const REMOTE_IP="124.155.161.141"           '<----- CHANGE THIS AS
NEEDED
const REMOTE_PORT=1001                     '<----- CHANGE THIS AS
NEEDED
'-----

dim tcp_sock_o as byte

'=====
sub on_sys_init()
    dim res as en_gprs_status_codes

    '----- this is for the outgoing test connection
    tcp_sock_o=sock_get("TCPA")
    sock.num=tcp_sock_o
    sock.txbuffrq(1)
    sock.rxbuffrq(1)
    sys.buffalloc
    sock.protocol=PL_SOCKET_PROTOCOL_TCP
    sock.targetip=REMOTE_IP
    sock.targetport=REMOTE_PORT
    sock.targetinterface=PL_SOCKET_INTERFACE_PPP
    '----- end

    res=gprs_start(AT_DT_COMMAND)
end sub

'-----

sub on_ser_data_arrival()
    gprs_proc_ser_data()
end sub

'-----

sub on_sock_data_arrival()
    dim s as string(32)

    gprs_proc_sock_data()

    '----- this is for the outgoing test connection
    if sock.num=tcp_sock_o then
        s=sock.getdata(255)
        pat.play("-***", PL_PAT_CANINT)
    end if
    '----- end
end sub
```

```

'-----
sub on_sys_timer()
  gprs_proc_timer()

  '----- this is for the outgoing test connection
  sock.num=tcp_sock_o
  if sock.statesimple=PL_SSTS_EST then
    sock.setdata("ABC")
    sock.send
  end if
  '----- end
end sub

'-----
sub on_sock_event(newstate as pl_sock_state, newstatesimple as
pl_sock_state_simple)
  '----- this is for the outgoing test connection
  if sock.num=tcp_sock_o then
    pat.play("-***", PL_PAT_CANINT)
  end if
  '----- end
end sub

'-----
sub on_pat()
  '----- this is for the outgoing test connection
  sock.num=tcp_sock_o
  if sock.statesimple=PL_SSTS_EST then
    pat.play("G~", PL_PAT_CANINT)
  end if
  '----- end
end sub

```

**device.tbs:**

```

include "global.tbh"

'=====
sub callback_gprs_ok()
  sock.num=tcp_sock_o
  sock.connect
end sub

'-----
sub callback_gprs_failure()
  sock.num=tcp_sock_o
  sock.discard
end sub

'-----
sub callback_gprs_pre_buffrq(required_buff_pages as byte)
end sub

```

## Library Defines (Options)

Any of the options below look cryptic? Read [Operation Details](#)<sup>[647]</sup> section.

### **SUPPORTS\_GPRS (default= 0)**

- 0- GPRS disabled (library code won't be compiled into the project).
- 1- GPRS enabled.

### **GPRS\_DEBUG\_PRINT (default= 0)**

- 0- no debug information.
- 1- print debug information into the output pane. Debug printing only works when the project is in the [debug mode](#)<sup>[27]</sup>. However, still set this option to 0 for release, as this will save memory and code space.

### **GPRS\_SEND\_PING (default= 0)**

- 0- suppress pinging.
- 1- ping GPRS\_PING\_IP in the end of PPP link establishment (as a proof of success).

### **GPRS\_PING\_IP (default= 0.0.0.0)**

This is the IP address that will be pinged when GPRS\_SEND\_PING is set.  
Only relevant when GPRS\_SEND\_PING is 1.

### **GPRS\_SER\_PORT (default= 3)**

The serial port to which the GPRS modem is connected.  
Like with [ser.num](#)<sup>[411]</sup>, serial ports are numbered from 0. Keep at default value for NB1010 and DS101x devices.

### **GPRS\_SER\_PORT\_RTSMAP (default depends on GPRS\_SER\_PORT)**

The mapping of the RTS line connected to the GPRS modem.  
If GPRS\_SER\_PORT is 0, the default value of GPRS\_SER\_PORT\_RTSMAP is 0.  
If GPRS\_SER\_PORT is 1, the default value of GPRS\_SER\_PORT\_RTSMAP is 1.  
If GPRS\_SER\_PORT is 2, the default value of GPRS\_SER\_PORT\_RTSMAP is 2.  
If GPRS\_SER\_PORT is 3, the default value of GPRS\_SER\_PORT\_RTSMAP is 3.  
Keep at default value for NB1010 and DS101x devices.

### **GPRS\_SER\_PORT\_CTSMAP (default depends on GPRS\_SER\_PORT)**

The mapping of the CTS interrupt line connected to the GPRS modem.

If GPRS\_SER\_PORT is 0, the default value of GPRS\_SER\_PORT\_CTSMAP is 0.  
If GPRS\_SER\_PORT is 1, the default value of GPRS\_SER\_PORT\_CTSMAP is 1.  
If GPRS\_SER\_PORT is 2, the default value of GPRS\_SER\_PORT\_CTSMAP is 2.  
If GPRS\_SER\_PORT is 3, the default value of GPRS\_SER\_PORT\_CTSMAP is 3.  
Keep at default value for NB1010 and DS101x devices.

#### **GPRS\_MODULE\_EXTERNAL (default= 0)**

0- the GPRS module is internal (like on the NB1010 and DS101x), GPRS\_SWITCH and GPRS\_RESET lines are used to control the module; there is a proper reset and startup delay when [gprs\\_start\(\)](#)<sup>[652]</sup> is called.

1- the GPRS module is external, GPRS\_SWITCH and GPRS\_RESET GPIO lines are not in use, there is no startup delay- the GPRS module is supposed to be up and running by the time [gprs\\_start\(\)](#)<sup>[652]</sup> is called.

Keep at default value for NB1010 and DS101x devices.

#### **GPRS\_SWITCH (default= 54)**

GPIO line that, when set LOW, diverts traffic on GPRS\_SER\_PORT to the GPRS module. When the line is HIGH or disabled, serial port traffic goes elsewhere in the device.

Only relevant when GPRS\_MODULE\_EXTERNAL is 0.

Keep at default value for NB1010 and DS101x devices.

#### **GPRS\_RESET (default= 55)**

GPIO line that, when set HIGH, applies hardware reset to the GPRS module. The line is set to LOW to release the GPRS module from reset.

'Only relevant when GPRS\_MODULE\_EXTERNAL is 0.

Keep at default value for NB1010 and DS101x devices.

#### **GPRS\_PAYLOAD\_SIZE (default= 4)**

Size of TCP and UDP packets that the GPRS interface will be able to carry, expressed in 256-byte units.

'Do not set >4 or <1. Smaller value reduces the total number of buffer pages required by the library (see [gprs\\_get\\_info\(\)](#)<sup>[652]</sup>).

## **En\_gprs\_status\_codes**

Several procedures in the library utilize the en\_gprs\_status\_codes enum. This enum has the following members:

0- GPRS\_STATUS\_OK: success.

1- GPRS\_STATUS\_INSUFFICIENT\_BUFFER\_SPACE: insufficient number of buffer pages available and the call to [callback\\_gprs\\_pre\\_buffrq\(\)](#)<sup>[655]</sup> failed to cure the problem.

## Library Procedures

In this section:

[Gprs\\_get\\_info\(\)](#)<sup>[652]</sup>

[Gprs\\_start\(\)](#)<sup>[652]</sup>

[Gprs\\_stop\(\)](#)<sup>[653]</sup>

[Gprs\\_proc\\_timer\(\)](#)<sup>[653]</sup>

[Gprs\\_proc\\_sock\\_data\(\)](#)<sup>[653]</sup>

[Gprs\\_proc\\_ser\\_data\(\)](#)<sup>[654]</sup>

[Callback\\_gprs\\_ok\(\)](#)<sup>[654]</sup>

[Callback\\_gprs\\_failure\(\)](#)<sup>[654]</sup>

[Callback\\_gprs\\_pre\\_buffrq\(\)](#)<sup>[655]</sup>

### Gprs\_get\_info()

- Description:** API procedure, returns library-specific information according to the requested information element.
- Syntax:** **function gprs\_get\_info**(info\_element as **gprs\_info\_elements**, byref extra\_data as **string**) as **string**
- Returns:** Requested data in *string* form
- See Also:** [About\\_get\\_info\(\) API Functions](#)<sup>[577]</sup>

Part	Description
info_element	Information element being requested:  0- GPRS_INFO_ELEMENT_REQUIRED_BUFFERS: total number of buffer pages required for the library to operate.
extra_data	Leave this string argument empty.

#### Details

---

### Gprs\_start()

- Description:** API procedure, starts the PPP login/configuration process.
- Syntax:** **function gprs\_start**(byref at\_dt\_command\_param as **string**, byref apn as **string**) as **en\_gprs\_status\_codes**
- Returns:** One of these [en\\_pppoe\\_status\\_codes](#)<sup>[660]</sup>:  
PPP\_STATUS\_OK,  
PPP\_STATUS\_INSUFFICIENT\_BUFFER\_SPACE
- See Also:** [Step-by-step Usage Instructions](#)<sup>[646]</sup>, [Operation Details](#)<sup>[647]</sup>

Part	Description
at_dt_command_param	This depends on the mobile network. Here is an actual line to be used with <i>Taiwan Cellular</i> : <b>*99#</b> .
apn	Again, the APN depends on the network. In here we have to use <b>INTERNET</b> .

### Details

GPRS library operation is persistent -- once you start it with this call, the library will "persist" to keep the PPP link established. No matter how many times this fails, the library will keep trying. If the successfully established PPP link fails, the library will attempt to reestablish the link.

## Gprs\_stop()

**Description:** API procedure, stops (aborts) PPP link establishment or session.

**Syntax:** **sub gprs\_stop()**

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[646]</sup>, [Operation Details](#)<sup>[647]</sup>

---

### Details

---

## Gprs\_proc\_timer()

**Function:** Event procedure, call it from the [on\\_sys\\_timer\(\)](#)<sup>[533]</sup> event handler.

**Syntax:** **sub gprs\_proc\_timer()**

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[646]</sup>, [Operation Details](#)<sup>[647]</sup>

### Details

---

## Gprs\_proc\_sock\_data()

**Function:** Event procedure, call it from the [on\\_sock\\_data\\_arrival\(\)](#)<sup>[489]</sup> event handler.

**Syntax:** **sub gprs\_proc\_sock\_data()**

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[646]</sup>, [Operation Details](#)<sup>[647]</sup>

### Details

---

## Gprs\_proc\_ser\_data()

- Function:** Event procedure, call it from the [on\\_ser\\_data\\_arrival\(\)](#)<sup>[412]</sup> event handler.
- Syntax:** **sub gprs\_proc\_ser\_data()**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#)<sup>[646]</sup>, [Operation Details](#)<sup>[647]</sup>

### Details

---

## Callback\_gprs\_ok()

- Description:** Callback procedure, informs of the successful establishment of the PPP link. Procedure body has to be created elsewhere in the project (externally with respect to the library).
- Syntax:** **sub callback\_gprs\_ok()**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#)<sup>[646]</sup>, [Operation Details](#)<sup>[647]</sup>

---

### Details

By the time this procedure is called, the GPRS library will have already set [ppp.ip](#)<sup>[368]</sup>.

## Callback\_gprs\_failure()

- Description:** Callback procedure, informs that PPP login/configuration or established link failed. Procedure body has to be created elsewhere in the project (externally with respect to the library).
- Syntax:** **sub callback\_gprs\_failure()**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#)<sup>[646]</sup>, [Operation Details](#)<sup>[647]</sup>

---

### Details

---

## Callback\_gprs\_pre\_buffrq()

<b>Description:</b>	Callback procedure, informs of the insufficient number of free buffer pages available for use by the library. Procedure body has to be created elsewhere in the project (externally with respect to the library).
<b>Syntax:</b>	<b>sub callback_gprs_pre_buffrq(required_buff_pages as byte)</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Step-by-step Usage Instructions</a> <sup>[646]</sup> , <a href="#">Operation Details</a> <sup>[647]</sup>

Part	Description
required_buffer_pages	The number of additional buffer pages that the GPRS library needs to operate. Your application must free up at least this number of buffer pages within callback_gprs_pre_buffrq() or PPP login/configuration will fail with the GPRS_STATUS_INSUFFICIENT_BUFFER_SPACE <a href="#">code</a> <sup>[651]</sup> .

### Details

This procedure will be called only if there are not enough buffer pages available.

## PPPOE Library

The PPPOE library handles PPPoE login and configuration. Together with the [pppoe](#)<sup>[369]</sup> object, it forms a complete PPPoE solution for your device.

The library is event-based and non-blocking -- it quietly runs in the background and takes a minimal amount of CPU time.

### Library Info

<b>Supported platforms:</b>	Any platform with the Ethernet ( <a href="#">net.</a> <sup>[358]</sup> ) interface.
<b>Files to include:</b>	Pppoe.tbs, pppoe.tbh (from <i>current_library_set\pppoe\trunk\</i> ).
<b>Dependencies:</b>	<a href="#">SOCK</a> <sup>[664]</sup> library.
<b>API procedures:</b>	<a href="#">pppoe_start()</a> <sup>[661]</sup> -- starts the PPPoE login/configuration process. Use <a href="#">API procedures</a> <sup>[576]</sup> to interact with the library.
<b>Event procedures:</b>	<a href="#">pppoe_stop()</a> <sup>[661]</sup> -- stops (aborts) PPPOE login/configuration or session. <a href="#">pppoe_proc_timer()</a> <sup>[662]</sup> -- call this from the <a href="#">on_sys_timer()</a> <sup>[533]</sup> event handler. Call <a href="#">event procedures</a> <sup>[576]</sup> from corresponding event handlers, as <a href="#">pppoe_proc_data()</a> <sup>[662]</sup> -- call this from the <a href="#">on_sock_data_arrival()</a> <sup>[489]</sup> event handler.

described [here](#)<sup>[619]</sup>.

<b>Callback procedures:</b>	<a href="#">callback_pppoe_ok()</a> <sup>[662]</sup> -- called when the library completes PPPoE login/configuration.
Implement the bodies of <a href="#">callback procedures</a> <sup>[576]</sup> elsewhere in your project.	<a href="#">callback_pppoe_failure()</a> <sup>[662]</sup> -- called when PPPoE login/configuration or established link fails.  <a href="#">callback_pppoe_pre_buffrq()</a> <sup>[663]</sup> -- called when the library needs to allocate buffer space and the required space is not available.
<b>Required buffer space:</b>	2 buffer pages. These are never released, even when you do <a href="#">pppoe_stop()</a> <sup>[661]</sup> .

## Step-by-step Usage Instructions

1. Make sure you have the [SOCK](#)<sup>[664]</sup> library in your project.
2. Add [pppoe.tbs](#)<sup>[577]</sup> and [pppoe.tbh](#) files to your project (they are in `current_library_set\pppoe\trunk`).
3. Add [#define PPOE\\_DEBUG\\_PRINT 1](#)<sup>[659]</sup> to the defines section of the global.tbh file of your project. This way you will "see what's going on". Don't forget to remove this later, after you've made sure that the library operates as expected.
4. Add **include "pppoe\trunk\pppoe.tbh"** to the includes section of the global.tbh file.
5. Add [pppoe\\_proc\\_timer\(\)](#)<sup>[662]</sup> to the [on\\_sys\\_timer\(\)](#)<sup>[533]</sup> event handler code (see "further considerations" below).
6. Add [pppoe\\_proc\\_data\(\)](#)<sup>[662]</sup> to the [on\\_sock\\_data\\_arrival\(\)](#)<sup>[489]</sup> event handler code.
7. Create empty [callback function](#)<sup>[576]</sup> bodies (presumably in the device.tbs): [callback\\_pppoe\\_ok\(\)](#)<sup>[662]</sup>, [callback\\_pppoe\\_failure\(\)](#)<sup>[662]</sup>, [callback\\_pppoe\\_pre\\_buffrq\(\)](#)<sup>[663]</sup>. Hint: copy from declarations in the pppoe.tbh or from our [code example](#)<sup>[657]</sup>.
8. Call [pppoe\\_start\(\)](#)<sup>[661]</sup> from somewhere. The no-brainer decision is to call from the [on\\_sys\\_init\(\)](#)<sup>[533]</sup> event handler. Supply correct ADSL login and password (suggestion: use [STG library](#)<sup>[668]</sup> to keep them). Note that pppoe\_start() may fail, so it is wise to check the returned status code.
9. Implement meaningful code for the [callback\\_pppoe\\_ok\(\)](#)<sup>[662]</sup>. Once it is called, you know that your PPPoE interface is up.

All of the above is illustrated in the [code example](#)<sup>[657]</sup>.

### Further considerations

The PPOE library expects the [pppoe\\_proc\\_timer\(\)](#)<sup>[662]</sup> to be called at 0.5 sec intervals. This is the default value which can be changed through the [sys.onsystemperiod](#)<sup>[533]</sup> property. If your project needs to have the [on\\_sys\\_timer\(\)](#)<sup>[533]</sup> event at a different rate, please make sure that pppoe\_proc\_timer() is still called 2 times/second. For example, if the on\_sys\_timer() is set to trigger 4 times/second, you need to add "divider" code that only calls pppoe\_proc\_timer() on every second invocation of the on\_sys\_timer().

## Operation Details

PPPoE library's operation is persistent: once you start it by calling `pppoe_start()`, it will "persist" to connect to the ADSL modem. No matter how many times the connection fails, the library will keep trying. If the successfully established PPPOE link fails, the library will attempt to reestablish the link. This can only be halted by calling `pppoe_stop()`.

The PPPoE specification envisions the use of more than one ADSL modem (a.k.a. "access concentrator") on the network. The protocol provides the means for the device to choose which access concentrator it wants to communicate through. In reality, most networks only have a single ADSL modem. Since this is a norm, the PPPOE library is designed to attempt to use whatever access concentrator responds to the device's "discovery" packets first.

A buffer space of 2 pages is required for the library operation. These are allocated when `pppoe_start()` is called. The library will check if the required buffer space is available and call `callback_pppoe_pre_buffrq()` if more space is needed. Buffer pages allocated to the PPPOE library are never released, even when successful PPPoE link is established or `pppoe_stop()` is called.

Successful PPPoE link establishment is a multi-step process and involves link configuration using LCP protocol, followed by the login and the configuration of device's IP address. To observe the process, add `#define PPPOE_DEBUG_PRINT 1` to the defines section of the global.tbh file of your project (and don't forget to remove this later).

Once the PPPoE link is successfully established, the library will set the properties of the `pppoe` object and call `callback_pppoe_ok()`. The library will then start monitoring PPPoE link's "health". The library will periodically send echo request packets and expect echo replies from the ADSL modem. If this times out, the library will assume that the PPPoE link has failed, call `pppoe_failure()`, and attempt to reestablish the link.

If your application calls `pppoe_stop()`, the library will properly terminate the PPPoE link (if it was established) and go into the idle state until `pppoe_start()` is called again.

You can learn more about PPPoE here: <http://en.wikipedia.org/wiki/Pppoe>.

## Code Example

Here is a simple example of using the PPPOE library. `pppoe_start()` is called on boot (). Once the PPPoE link is established, the device will open an outgoing TCP connection to a certain remote IP and port.

Green status LED is used to indicate the TCP connection status: it will be on when the TCP connection is established.

To test the TCP connection, the code will periodically send a small string of data to the remote end of the connection. If any reply is received, the green status LED will momentarily turn off.

Before running the code, do not forget to change `ADSL_NAME`, `ADSL_LOGIN`, `REMOTE_IP`, and `REMOTE_PORT` constants.

```
global.tbh:

'DEFINES-----
#define PPPOE_DEBUG_PRINT 1

'INCLUDES-----
include "sock\trunk\sock.tbh"
```

```
include "pppoe\trunk\pppoe.tbh"
```

```
'DECLARATIONS-----
declare tcp_sock_o as byte
```

```
main.tbs:
```

```
include "global.tbh"
```

```
'-----
const ADSL_NAME="correct_name"           '<----- CHANGE THIS AS NEEDED
const ADSL_PASSWORD="correct_password"   '<----- CHANGE THIS AS NEEDED
const REMOTE_IP="59.120.32.27"           '<----- CHANGE THIS AS NEEDED
const REMOTE_PORT=40000                   '<----- CHANGE THIS AS
NEEDED
```

```
'-----
dim tcp_sock_o as byte
```

```
'=====
sub on_sys_init()
```

```
    dim res as en_pppoe_status_codes
```

```
    '----- this is for the outgoing test connection
```

```
    tcp_sock_o=sock_get("TCPA")
```

```
    sock.num=tcp_sock_o
```

```
    sock.txbuffrq(1)
```

```
    sock.rxbuffrq(1)
```

```
    sys.buffalloc
```

```
    sock.protocol=PL_SOCKET_PROTOCOL_TCP
```

```
    sock.targetip=REMOTE_IP
```

```
    sock.targetport=REMOTE_PORT
```

```
    sock.targetinterface=PL_SOCKET_INTERFACE_PPPOE
```

```
    '----- end
```

```
    res=pppoe_start(ADSL_NAME,ADSL_PASSWORD)
```

```
end sub
```

```
'-----
sub on_sock_data_arrival()
```

```
    dim s as string(32)
```

```
    pppoe_proc_data()
```

```
    '----- this is for the outgoing test connection
```

```
    if sock.num=tcp_sock_o then
```

```
        s=sock.getdata(255)
```

```
        pat.play("-***",PL_PAT_CANINT)
```

```
    end if
```

```
    '----- end
```

```
end sub
```

```
'-----
sub on_sys_timer()
```

```
    pppoe_proc_timer()
```

```
    '----- this is for the outgoing test connection
```

```
    sock.num=tcp_sock_o
```

```
    if sock.statesimple=PL_SOCKET_STATE_EST then
```

```

        sock.setdata("ABC")
        sock.send
    end if
    '----- end
end sub

'-----
sub on_sock_event(newstate as pl_sock_state, newstatesimple as
pl_sock_state_simple)
    '----- this is for the outgoing test connection
    if sock.num=tcp_sock_o then
        pat.play("-***", PL_PAT_CANINT)
    end if
    '----- end
end sub

'-----
sub on_pat()
    '----- this is for the outgoing test connection
    sock.num=tcp_sock_o
    if sock.statesimple=PL_SSTS_EST then
        pat.play("G~", PL_PAT_CANINT)
    end if
    '----- end
end sub

```

#### device.tbs:

```

include "global.tbh"

'=====
sub callback_pppoe_ok()
    sock.num=tcp_sock_o
    sock.connect
end sub

'-----
sub callback_pppoe_failure(pppoe_code as en_pppoe_status_codes)
    sock.num=tcp_sock_o
    sock.discard
end sub

'-----
sub callback_pppoe_pre_buffrq(required_buff_pages as byte)
end sub

```

## Library Defines (Options)

There is only one define for this library:

### PPPOE\_DEBUG\_PRINT (default= 0)

0- no debug information.

1- print debug information into the output pane. Debug printing only works when the project is in the [debug mode](#)<sup>[27]</sup>. However, still set this option to 0 for release,

as this will save memory and code space.

## En\_pppoe\_status\_codes

Several procedures in the library utilize the `en_pppoe_status_codes` enum. This enum has the following members:

- 0- `PPPOE_STATUS_OK`: success.
- 1- `PPPOE_STATUS_OUT_OF_SOCKETS`: no free sockets available for the library to operate.
- 2- `PPPOE_STATUS_INSUFFICIENT_BUFFER_SPACE`: insufficient number of buffer pages available and the call to [callback\\_pppoe\\_pre\\_buffrq\(\)](#)<sup>[663]</sup> failed to cure the problem.
- 3- `PPPOE_TIMEOUT`: PPPoE login/configuration or established link failed -- timeout while waiting for the reply from the ADSL modem (access concentrator).
- 4- `PPPOE_CONFIGURATION_ERROR`: PPPoE login/configuration failed -- something went wrong... and on the PPPoE many things can go wrong. Perhaps, login name or password should be re-checked?
- 5- `PPPOE_STOPPED`: [pppoe\\_stop\(\)](#)<sup>[661]</sup> was called.

## Library Procedures

In this section:

- [Pppoe\\_get\\_info\(\)](#)<sup>[660]</sup>
- [Pppoe\\_start\(\)](#)<sup>[661]</sup>
- [Pppoe\\_stop\(\)](#)<sup>[661]</sup>
- [Pppoe\\_proc\\_timer\(\)](#)<sup>[662]</sup>
- [Pppoe\\_proc\\_data\(\)](#)<sup>[662]</sup>
- [Callback\\_pppoe\\_ok\(\)](#)<sup>[662]</sup>
- [Callback\\_pppoe\\_failure\(\)](#)<sup>[662]</sup>
- [Callback\\_pppoe\\_pre\\_buffrq\(\)](#)<sup>[663]</sup>

### Pppoe\_get\_info()

<b>Description:</b>	API procedure, returns library-specific information according to the requested information element.
<b>Syntax:</b>	<b>function pppoe_get_info</b> (info_element as <b>pppoe_info_elements</b> , byref extra_data as string) as string
<b>Returns:</b>	Requested data in <i>string</i> form
<b>See Also:</b>	<a href="#">About_get_info() API Functions</a> <sup>[577]</sup>

Part	Description
info_element	Information element being requested: 0- <code>PPPOE_INFO_ELEMENT_REQUIRED_BUFFERS</code> : total number

of buffer pages required for the library to operate.

extra\_data Leave this string argument empty.

### Details

---

## PPpoe\_start()

- Description:** API procedure, starts the PPPoE login/configuration process.
- Syntax:** **function pppoe\_start(byref login as string, byref password as string) as en\_pppoe\_status\_codes**
- Returns:** One of these [en\\_pppoe\\_status\\_codes](#)<sup>[660]</sup>:  
PPPOE\_STATUS\_OK, PPPOE\_STATUS\_OUT\_OF\_SOCKETS,  
PPPOE\_STATUS\_INSUFFICIENT\_BUFFER\_SPACE
- See Also:** [Step-by-step Usage Instructions](#)<sup>[666]</sup>, [Operation Details](#)<sup>[657]</sup>

Part	Description
login	ADSL login name.
password	ADSL login password.

### Details

PPPOE library operation is persistent -- once you start it with this call, the library will "persist" to connect to the ADSL modem. No matter how many times the connection fails, the library will keep trying. If the successfully established PPPOE link fails, the library will attempt to reestablish the link.

## PPpoe\_stop()

- Description:** API procedure, stops (aborts) PPPOE login/configuration or session.
- Syntax:** **sub pppoe\_stop()**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#)<sup>[666]</sup>, [Operation Details](#)<sup>[657]</sup>

### Details

---

### Pppoe\_proc\_timer()

- Function:** Event procedure, call it from the [on\\_sys\\_timer\(\)](#)<sup>[533]</sup> event handler.
- Syntax:** **sub pppoe\_proc\_timer()**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#)<sup>[656]</sup>, [Operation Details](#)<sup>[657]</sup>

#### Details

---

### Pppoe\_proc\_data()

- Function:** Event procedure, call it from the [on\\_sock\\_data\\_arrival\(\)](#)<sup>[489]</sup> event handler.
- Syntax:** **sub pppoe\_proc\_data()**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#)<sup>[656]</sup>, [Operation Details](#)<sup>[657]</sup>

#### Details

---

### Callback\_pppoe\_ok()

- Description:** Callback procedure, informs of the successful establishment of the PPPoE link. Procedure body has to be created elsewhere in the project (externally with respect to the library).
- Syntax:** **sub callback\_pppoe\_ok()**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#)<sup>[656]</sup>, [Operation Details](#)<sup>[657]</sup>

---

#### Details

By the time this procedure is called, the PPPOE library will have already set [pppoe.ip](#)<sup>[370]</sup>, [pppoe.acmac](#)<sup>[369]</sup>, and [pppoe.sessionid](#)<sup>[370]</sup>.

### Callback\_pppoe\_failure()

- Description:** Callback procedure, informs that PPPoE login/configuration or established link failed. Procedure body has to be created elsewhere in the project (externally with respect to the library).
- Syntax:** **sub callback\_pppoe\_failure(pppoe\_code as**

**en\_pppoe\_status\_codescodes)****Returns:** ---**See Also:** [Step-by-step Usage Instructions](#)<sup>[656]</sup>, [Operation Details](#)<sup>[657]</sup>

Part	Description
pppoe_state	Reason for failure:  3- PPPOE_TIMEOUT: timeout while waiting for the reply from the ADSL modem (access concentrator).  4- PPPOE_CONFIGURATION_ERROR: something went wrong... and on the PPPoE many things can go wrong. Perhaps, login name or password should be re-checked?.  5- PPPOE_STOPPED: <a href="#">pppoe_stop()</a> <sup>[661]</sup> was called.

**Details**

As follows from the above, this procedure is called even if your application "manually" aborts PPPoE by calling [pppoe\\_stop\(\)](#)<sup>[661]</sup>.

**Callback\_pppoe\_pre\_buffrq()**

**Description:** Callback procedure, informs of the insufficient number of free buffer pages available for use by the library. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_pppoe\_pre\_buffrq(required\_buff\_pages as byte)**

**Returns:** ---**See Also:** [Step-by-step Usage Instructions](#)<sup>[656]</sup>, [Operation Details](#)<sup>[657]</sup>

Part	Description
required_buffer_pages	The number of additional buffer pages that the PPPOE library needs to operate. Your application must free up at least this number of buffer pages within the <a href="#">callback_pppoe_pre_buffrq()</a> or PPPoE login/configuration will fail with the PPPOE_STATUS_INSUFFICIENT_BUFFER_SPACE <a href="#">code</a> <sup>[660]</sup> .

**Details**

This procedure will be called only if there are not enough buffer pages available.

## SOCK (Socket Numbers) Library

The SOCK library automates socket number assignment. The [sock](#)<sup>[421]</sup> object supports up to [sock.numofsock](#)<sup>[488]</sup> sockets. Using the SOCK library, your code can get an unused socket, use the socket as needed, then release the socket into a pool of free sockets.

### Library Info

<b>Supported platforms:</b>	Any platform with the <a href="#">sock</a> <sup>[421]</sup> object.
<b>Files to include:</b>	sock.tbs, sock.tbh (from <i>current_library_set</i> \sock\trunk\).
<b>Dependencies:</b>	---
<b>API procedures:</b>	<a href="#">sock_get()</a> <sup>[667]</sup> -- returns a free socket number or 255 if no free sockets left.
Use <a href="#">API procedures</a> <sup>[576]</sup> to interact with the library.	<a href="#">sock_who_uses()</a> <sup>[668]</sup> -- returns the signature of the specified socket's user.
	<a href="#">sock_release()</a> <sup>[668]</sup> -- releases the socket (number), discards socket connection, restores socket's properties to their default states.
<b>Event procedures:</b>	---
<b>Callback procedures:</b>	---
<b>Required buffer space:</b>	---

## Step-by-step Usage Instructions

### Minimal steps

1. [Add](#)<sup>[577]</sup> **sock.tbs** and **sock.tbh** files to your project (they are in *current\_library\_set*\sock\trunk).
2. Add **include "sock\trunk\sock.tbh"** to the includes section of the global.tbh file.
3. Call [sock\\_get\(\)](#)<sup>[667]</sup> whenever you need a free socket. Observe the result -- if it is 255 then there are no free sockets available!
4. Call [sock\\_release\(\)](#)<sup>[668]</sup> when you no longer need a particular socket. This way, the socket can be reused by something else in your code.

### Additional recommended steps

1. The use of [sock\\_who\\_uses\(\)](#)<sup>[668]</sup> is optional. This call will return a string signature left by the caller when obtaining the socket. [SOCK\\_MAX\\_SIGNATURE\\_LEN](#)<sup>[667]</sup> must be >0 for signatures to be saved.

We have provided a [code snippet](#)<sup>[665]</sup> illustrating the use of the SOCK library.



Using the SOCK library? Then, use it everywhere in your code! Do not "appropriate" sockets without going through this library.

## Operation Details

The SOCK library maintains a list of free and occupied sockets. This is kept in the `sock_in_use` array. You can see this array's contents under the debugger. To get a free socket (number), call [sock\\_get\(\)](#)<sup>[667]</sup> and it will return a socket number, which will now be marked as used. The function will return 255 if there are no free sockets left, so watch out for this number!

When calling `sock_get()`, you can supply a meaningful short name of the caller. For example, if the socket is to be used for TELNET-style communications with the device, set the signature to "TLNT". The `sock_user_signature` array keeps the signatures left by `sock_get()` callers. Observing this array's contents under the debugger will provide a clear picture of who is using which socket. The signature of free sockets is "-". Note that [SOCK\\_MAX\\_SIGNATURE\\_LEN](#)<sup>[667]</sup> defines maximum signature length and the default value is 0. Set this to anything above 0 to be able to observe the signatures. You can set it back to 0 when the debugging process is over.

Another way to observe the operation of the library in the [debug mode](#)<sup>[27]</sup> is by adding [#define SOCK\\_DEBUG\\_PRINT 1](#)<sup>[667]</sup> to the defines section of the `global.tbh` file of your project. A wealth of status information will be printed in the console pane as the SOCK library operates.

To release the socket, call [sock\\_release\(\)](#)<sup>[668]</sup>. This will mark the socket as free and the next caller of the `sock_get()` will have a chance to reuse this socket number. Additionally, the socket will be "cleaned up for reuse". Any socket connection in progress will be discarded (with [sock.discard](#)<sup>[478]</sup>) and each property will be returned to its original, post-reset value.

[Sock\\_who\\_uses\(\)](#)<sup>[668]</sup> returns a signature left by the specified socket's user. This function doesn't have to be used and exists only for convenience.

## A Code Snippet

Here is a small code snippet illustrating the process of getting and releasing sockets. We sacrificed robustness for simplicity, so don't take the code below for a shining example of [sock](#)<sup>[421]</sup> object's usage. Just see the parts related to the SOCK library -- that's the point right now.

```
...
'set "#SOCK_MAX_SIGNATURE_LEN 4" and "#define SOCK_DEBUG_PRINT 1" before
running this test

dim tcp_sock as byte 'to remember the socket number we've got

net.ip="192.168.1.93" '<--- edit as needed

'get a socket
```

```
tcp_sock=sock_get("TCPS")
'gotta check if there was a free socket for us...
if tcp_sock=255 then
    sys.halt '...uh-huh, out of sockets!
end if

'setup the socket
sock.num=tcp_sock
sock.rxbufreq(1)
sock.txbufreq(1)
sys.bufalloc
sock.protocol=PL_SOCKET_PROTOCOL_TCP
sock.targetip="192.168.1.67" '<--- edit as needed
sock.targetport=10000 '<--- edit as needed
sock.connect
while sock.statesimple<>PL_SSTS_EST
wend

'send data -- we use the signature of the socket's user
sock.setdata(sock_who_uses(tcp_sock))
sock.send
while sock.txlen>0
wend

'close the connection
sock.close
while sock.statesimple<>PL_SSTS_CLOSED
wend

'release the socket
sock_release(tcp_sock)
...
```

And here is what appeared in the output pane of TIDE as the code executed:

```
SOCK> 'TCPS' got socket #2
SOCK> 'TCPS' released socket #2
```

The first message corresponds to [sock\\_get\(\)](#)<sup>[667]</sup>, the second one -- to [sock\\_release\(\)](#)<sup>[668]</sup>. "TCPS" is the signature left by us, it stands for "TCP socket". The socket number obtained is 2 because we ran this code within a large program that uses a lot of other sockets for a lot of other things.

The example above establishes an outgoing connection to 192.168.1.67:10000. In our test, this was a PC running I/O Ninja, our sniffer/terminal software (you can get it at [ninja.tibbo.com](http://ninja.tibbo.com)). We opened a "listener socket" on I/O Ninja, and here is what we saw:

```
Accepted TCP connection from 192.168.1.93:10254
TCPS
Remote node 192.168.1.93:10254 has closed TCP connection
```

This "TCPS" is the signature our code provided when calling `sock_get()`. The reason it appeared in Ninja is because of the `sock.setdata(sock_who_uses(tcp_sock))` line in the code.

## Library Defines (Options)

Any of the options below look cryptic? Read the [Operation Details](#)<sup>[665]</sup> section.

### SOCK\_DEBUG\_PRINT (default= 0)

0- no debug information.

1- print debug information into the output pane. Debug printing only works when the project is in the [debug mode](#)<sup>[27]</sup>. However, still set this option to 0 for release, as this will save memory and code space.

### SOCK\_MAX\_SIGNATURE\_LEN (default= 0)

Size of members of the `sock_user_signature` array. Set to >0 to be able to observe the signatures left by the callers of the `sock_get()`<sup>[667]</sup>.

## Library Procedures

In this section:

- [Sock\\_get\(\)](#)<sup>[667]</sup>
- [Sock\\_who\\_uses\(\)](#)<sup>[668]</sup>
- [Sock\\_release\(\)](#)<sup>[668]</sup>

### Sock\_get()

<b>Description:</b>	API procedure, returns a free socket number or 255 if no free sockets left.
<b>Syntax:</b>	<b>function sock_get(byref signature as string) as byte</b>
<b>Returns:</b>	The number of the unused socket or 255 if all sockets are in use.
<b>See Also:</b>	<a href="#">Step-by-step Usage Instructions</a> <sup>[664]</sup> , <a href="#">Operation Details</a> <sup>[665]</sup>

Part	Description
signature	A string with a short description of the socket's purpose. You may leave the signature empty, too.

### Details

Set [SOCK\\_MAX\\_SIGNATURE\\_LEN](#)<sup>[667]</sup> to anything above 0 in order to be able to use signatures.

## Sock\_who\_uses()

- Description:** API procedure, returns the signature of the specified socket's user.
- Syntax:** **function sock\_who\_uses(sock\_num as byte) as string**
- Returns:** The signature left by the socket's user on [sock\\_get\(\)](#)<sup>[667]</sup> invocation.
- See Also:** [Step-by-step Usage Instructions](#)<sup>[664]</sup>, [Operation Details](#)<sup>[665]</sup>

Part	Description
sock_num	Socket number.

### Details

Set [SOCK\\_MAX\\_SIGNATURE\\_LEN](#)<sup>[667]</sup> to anything above 0 in order to be able to use signatures.

## Sock\_release()

- Description:** API procedure, releases the socket (number), discards socket connection, restores socket's properties to their default states.
- Syntax:** **sub sock\_release(sock\_num as byte)**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#)<sup>[664]</sup>, [Operation Details](#)<sup>[665]</sup>

Part	Description
sock_num	The number of the socket to be released.

### Details

---

## STG (Settings) Library

The STG library offers a persistent, convenient storage for your device's settings (operational parameters). It can also play a pivotal role in the device [control and monitoring](#)<sup>[670]</sup>. The library is extremely easy to use -- just define a list of all desired settings using a [setting configurator](#)<sup>[670]</sup> and employ simple API calls to work with them.

Setting configurator allows you to specify the names, types, value constraints, etc. of your device's settings and the STG library uses this to automatically calculate memory addresses for storing settings, protect the settings with a checksum, verify the validity of their values, etc. Your code is then able to reference setting values

by their names, like this: `s=stg_get("IP",0), stg_set("IP",0,"192.168.1.40")`.

The library keeps your settings in the non-volatile memory or RAM. The non-volatile memory used can be the EEPROM memory ([stor](#)) or the flash disk ([fd](#)). For RAM, you can choose to go with "regular" RAM (the one that stores variables), or "custom" RAM, for which you can create your own [access routines](#).

## Library Info

### Supported platforms:

Any platform.

### Files to include:

settings.tbs, settings.tbh (from `current_library_set/settings/trunk\`).

### Dependencies:

[FILENUM](#) library when the **Use Flash Disk** option is selected.

### API procedures:

Use [API procedures](#) to interact with the library.

[stg\\_start\(\)](#) -- starts the STG library, parses the descriptor file, restores all volatile (RAM) settings to default values.

[stg\\_check\\_all\(\)](#) -- verifies each setting by reading its value.

[stg\\_get\\_def\(\)](#) -- returns the default value for the specified setting's member.

[stg\\_restore\\_multiple\(\)](#) -- initializes (sets the default values for) all or multiple settings.

[stg\\_restore\\_member\(\)](#) -- initializes (sets the default value for) the specified setting's member.

[stg\\_get\\_num\\_settings\(\)](#) -- returns the number of settings defined in your project.

[stg\\_get\\_num\\_members\(\)](#) -- returns the number of members for the specified setting.

[stg\\_find\(\)](#) -- returns the number of the specified setting or zero if the setting wasn't found.

[stg\\_stype\\_get\(\)](#) -- returns the type of the specified setting.

[stg\\_get\(\)](#) -- reads (gets) the value of the specified setting's member; reports errors through [callback\\_stg\\_error\(\)](#).

[stg\\_set\(\)](#) -- writes (sets) the value of the specified setting's member; reports errors through [callback\\_stg\\_error\(\)](#).

[stg\\_sg\(\)](#) -- writes (sets) or reads (gets) the specified setting's member; directly returns the execution result.

[stg\\_sg\\_ts\(\)](#) -- available when the **Timestamp** option is enabled (checked), reads or writes the setting modification time /date.

**Event procedures:** ---

**Callback procedures:** [callback\\_stg\\_error\(\)](#)<sup>[700]</sup> -- informs of the error during the execution of [stg\\_get\(\)](#)<sup>[696]</sup> or [set\\_set\(\)](#)<sup>[697]</sup>.

Implement the bodies of [callback procedures](#)<sup>[576]</sup> elsewhere in your project. [callback\\_stg\\_pre\\_get\(\)](#)<sup>[700]</sup> -- informs that the setting member's value is being read through one of the STG library's procedures; allows to update the setting member's value before it is returned by the STG library.

[callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup> -- informs that the setting member's value is being written to through one of the STG library's procedures; allows to respond to the value change.

[callback\\_stg\\_vm\\_read\(\)](#)<sup>[702]</sup> -- should implement necessary code for reading a byte of data from "custom" volatile memory. Needed only when the **Custom RAM** option is enabled (checked).

[callback\\_stg\\_vm\\_write\(\)](#)<sup>[703]</sup> -- should implement necessary code for writing a byte of data to "custom" volatile memory. Needed only when the **Custom RAM** option is enabled (checked).

**Required buffer space:** ---

## Controlling Your Device Through Settings

Like the Windows registry, the STG library may be used to provide a well-organized, persistent storage for your device's operational parameters. In many cases, settings will be the backbone of your Tibbo BASIC project, as numerous other libraries utilize settings for parameter (variable) storage.

One less obvious and very powerful concept of setting usage is that settings can serve as *transit points* for controlling and/or monitoring the device. That is, writing to a setting can cause the related code to be executed *after* the new value is set ([post-set](#)<sup>[683]</sup>), and this code will put the new value "into action". Reading a setting can cause the value of the setting to be updated *first* ([pre-get](#)<sup>[683]</sup>), and only then returned to the caller.

In other words, it is possible to change your device's operation (behavior, mode, etc.) just by writing a new value to a setting. It is also possible to get the current device status just by reading a setting's value. This is a very powerful concept. Master it, and you will be able to create clean, structured applications.

[Using Pre-gets and Post-sets](#)<sup>[683]</sup> continues this discussion.

## Setting Configurator

Setting configurator is a [JavaScript-based editor](#)<sup>[578]</sup> for the setting configuration file. Do not confuse the two. Setting descriptor file is a part of your project (it is a resource file). The editor is a "representer" -- it provides a convenient interface for the editing of the configuration file. The configurator also masks the complexity of the underlying configuration file.

In this section:

- [Library options](#)<sup>[671]</sup>
- [Editing settings](#)<sup>[673]</sup>
- [Dot-decimal settings](#)<sup>[674]</sup>
- [Max number of members](#)<sup>[675]</sup>
- [P1 and P2 parameters](#)<sup>[675]</sup>
- [Default setting values](#)<sup>[675]</sup>

 **Library Options (mouse over for hint)**

Debug Printing

Use EEPROM  Use Flash Disk

Filename:

Timestamp

Redundancy: 0 - No redundancy

 **Setting Definitions**

Name	Storage	Data type	Member(s)	P1(min)	P2(max)	Ini mode	Default value	Comment	Status
DN	Non-volatile	String	1	0	10	I	^	Device Name	OK
IP	Non-volatile	Dot-decimal	1	4	4	A	192.168.1.93	IP address <-- set the one you want as the default value	OK
PN	Non-volatile	Word	1	0	65535	A	1000	Port number	OK
PTN	Non-volatile	String	3	0	16	A	G~/R~/B~/	LED patterns	OK
CPTN	Volatile	Byte	1	0	2	A	0	Current pattern to play	OK

 **Summary Report**

Number of settings: 5

Non-volatile memory space required: 74

RAM(volatile memory)space required: 2

## Library Options

The Library Options section of the configurator screen lists all configurable options.

### Debug Printing check box

Check (enable) to print debug information into the output pane. Debug printing only works when the project is in the [debug mode](#)<sup>[27]</sup>. Always uncheck this for release, as this will save memory and code space.

### Use EEPROM / Use Flash Disk option boxes

Defines whether non-volatile settings are to be stored in the EEPROM or in the file (on the flash disk). Choose *Use EEPROM* whenever possible.

### Filename text box

When **Use Flash Disk** is selected, defines the filename in which the setting values will be stored on the flash disk.

### **Timestamp check box**

When checked (enabled), stores the date and time of the most recent setting modification. One timestamp is kept for all members of each setting.

### **Redundancy drop-down**

*No Redundancy* - only one copy of data is stored for all settings.

*Two copies for EEPROM* - two copies of data are stored for non-volatile settings. Only one copy is maintained for volatile settings.


*Two copies for ALL* - two copies of data are stored for all settings (non-volatile as well as volatile).

### **Custom RAM**

Check (enable) to be able to create your own routines for writing and reading volatile settings through [callback\\_stg\\_vm\\_read\(\)](#)<sup>[702]</sup> and [callback\\_stg\\_vm\\_write\(\)](#)<sup>[703]</sup>.

## Editing Settings

Use **Add**, **Edit**, and **Delete** buttons to create the list of settings.



### Setting name

It is this name that you will use to reference settings in [stg\\_set\(\)](#)<sup>[697]</sup>, [stg\\_get\(\)](#)<sup>[696]</sup>, etc. Names are case-sensitive and cannot start with a digit (i.e. 0-9 char). This is because the STG library's procedures would interpret this as a [setting number](#)<sup>[680]</sup>, not name. Try to keep the names short, this saves RAM memory space (by reducing the amount of memory needed to keep the list of setting names).

### Storage Location

Specifies whether the setting will be stored in the non-volatile memory (EEPROM or flash as defined by the global **Use EEPROM** / **Use Flash Disk** option) or volatile memory (RAM). Obviously, settings that go into the RAM are those that you don't have to keep while the device is powered off. If so, why even use settings?

Wouldn't regular variables suffice? Yes and no. Regular variables are fast to access, but using settings for the purpose has its own [advantages](#)<sup>[670]</sup>.

## Setting Type

You've got byte (0-255 range), word (0-65535 range), string (up to 253 characters), and [dot-decimal string](#)<sup>[674]</sup> (up to 63 bytes).

## Number of Members

Each setting must have at least one member, and can be set to include multiple members (like in an array). The [maximum number of members](#)<sup>[675]</sup> for the setting depends on this setting's type.

## P1 Parameter (Min)

The [minimum value](#)<sup>[675]</sup> for byte and word settings, minimum length for string and dot-decimal settings.

## P2 Parameter (Max)

The [maximum value](#)<sup>[675]</sup> for byte and word settings, maximum length for string and dot-decimal settings.

## Initialization Mode

*Initialize always* -- the setting is unconditionally initialized during [stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup> execution.

*Initialize when invalid* -- the setting is only initialized during [stg\\_restore\\_multiple\(\)](#) execution if found to contain an invalid or corrupted value.

## Default values

A separate [default value](#)<sup>[675]</sup> can be provided for each setting member, but not necessarily.

## Comment

Any comment you like. Do add comments -- they really help. These get compiled into the final application binary, so having longer comments increases the size of your application.

## Dot-decimal Settings

Dot-decimal settings exist to store parameters such as IP and MAC address. Like strings, they consist of a number of bytes. The difference is that when a dot-decimal setting is read, [ddstr\(\)](#)<sup>[210]</sup> is executed on its members. For example, if the internal value of the setting consists of bytes 192, 168, 1, and 40, then "192.168.1.40" is returned when the setting is read. When the setting is written to, the [ddval\(\)](#)<sup>[210]</sup> is executed, so "192.168.1.40" because a set of 4 bytes (192, 168,

1, and 40) again.

## Max Number of Members

Here is what you have when the **Timestamp option**  is unchecked:

- **Byte** settings: up to 254 members.
- **Word** settings : up to 127 members.
- **String** and **dot-decimal** settings: up to  $254/(P2+1)$ , see above for explanation on the P2 parameter. Example: if P2=10 then a setting can have up to 23 members.

You get less with timestamps enabled:

- **Byte** settings: up to 247 members.
- **Word** settings : up to 123 members.
- **String** and **dot-decimal** settings: up to  $247/(P2+1)$ , see above for explanation on the P2 parameter. Example: if P2=10 then a setting can have up to 23 members.

## P1 and P2 Parameters

These define minimum (P1) and maximum (P2) values for byte and word settings, and minimum and maximum length for string and dot-decimal settings. Conditions:

- P2 must be greater or equal to P1.
- P2 can't be 0.
- For byte settings, P1 and P2 can't exceed 255.
- For word settings, P1 and P2 can't exceed 65535.
- For string and dot-decimal settings, P1 and P2 can't exceed 254.

## Default Setting Values

In the simplest case, you have a setting with one member, and one default value to provide for it... but what to do when the setting is of string or dot-decimal type and the intended default value for this setting is NULL? Don't just leave the field empty, use a special character ^ instead!

Several default values may be supplied, in which case they should be separated by /, like this: "abc/def/123". This string defines three default values. And what if you have, say, five members in this setting? Then, member 0 will be initialized to "abc", member 1 -- to "def", and members 2 through 4 -- to "123". And how about this string -- "abc/^/123"? It specifies that the second initialization value is NULL.

Naturally, ^ and / can't be used in setting strings because they are "special" characters carrying a special meaning. If you need to have them inside the initialization value itself, use C style escape sequences. For example, if the default value is supposed to be "2/3" then write "2\x2F3".

The total size of the default value field cannot exceed 255 characters. Hence, you may not be able to provide all the default values you want to. Say, you have a byte setting with 100 members. The default value for each member can take three characters plus the separator. That's up to four characters per one default value. Only 64 such values will fit in 255 characters.

## Step-by-step Usage Instructions

In this section:

- [Getting started](#)<sup>[676]</sup>
- [Verifying and Initializing Settings](#)<sup>[677]</sup>
- [Writing and Reading Settings](#)<sup>[678]</sup>

## Getting Started

### Minimal steps

1. [Add](#)<sup>[577]</sup> **settings.tbs** and **settings.tbh** files to your project (they are in *current\_library\_set\settings\trunk*).
2. Add the following to the includes section of the **global.tbh** file:

```
includepp "settings.txtxt"
include "settings\trunk\settings.tbh"
```

3. Create empty [callback procedure](#)<sup>[576]</sup> bodies (presumably in the device.tbs, and according to declarations in **settings.tbh**):
  - [callback\\_stg\\_error\(\)](#)<sup>[700]</sup>;
  - [callback\\_stg\\_pre\\_get\(\)](#)<sup>[700]</sup>;
  - [callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup>.
4. [Add](#)<sup>[18]</sup> an empty **settings.txtxt** file to your project. In the **Add New File to Project** dialog set the **Type** to *Definition File*, and the **Format** to *STG (Settings) Library*.
5. Define desired settings through the [configurator](#)<sup>[670]</sup>.
6. In the [On\\_sys\\_init\(\)](#)<sup>[533]</sup> event handler (or some other place you deem logical), add a call to the [stg\\_start\(\)](#)<sup>[691]</sup>. This function may fail, so check the returned [status code](#)<sup>[690]</sup>.
7. Take care of [setting initialization](#)<sup>[677]</sup>.

### Additional Steps

1. By default, non-volatile settings are stored in the EEPROM. You can also store the settings on the flash disk. EEPROM offers limited (but usually sufficient) storage with a faster access, while the flash disk offers a virtually unlimited storage with a slower access. Go with the EEPROM whenever possible. If you want to use the flash disk, select *Use Flash Disk* option in the [configurator](#)<sup>[670]</sup>; then set the desired **Filename** (this is the name of the file that will store setting values).
2. Set **Redundancy** to *Non-volatile only* to increase the reliability of settings by keeping two independent copies of their values. The penalty is in the reduced performance of the library (increased setting access time) and doubling of the EEPROM (or flash) memory storage needs (see [Operation Details](#)<sup>[684]</sup> for explanation how memory is allocated for both copies).

## Verifying and Initializing Settings

Initialization is the process of making setting values "sane". To be considered sane, the setting value must have correct checksum, and its members must conform to the constraints of [P1 and P2 parameters](#)<sup>[675]</sup>.

Non-volatile settings are never initialized automatically -- it is your responsibility as the developer to decide just when and how this happens. If you load a settings-using application onto a device that has never run this application before, then each non-volatile setting will be invalid because all setting checksums will be wrong. Volatile settings are always initialized when you call [stg\\_start\(\)](#)<sup>[691]</sup>.

Any setting can be "repaired" by writing a valid value into it. You can do this using [stg\\_sg\(\)](#)<sup>[698]</sup> or [stg\\_set\(\)](#)<sup>[697]</sup> -- see [Writing and Reading Settings](#)<sup>[678]</sup>.

A more "automatic" way is to use [stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup>. This will restore all settings to their default values as defined in the setting descriptor file. In the following example, settings are initialized if the MD button is kept pressed for more than 2 seconds and then released:

```
sub on_button_released()
    if button.time>4 then
        if stg_restore_multiple(EN_STG_INIT_MODE_NORMAL)
<>EN_STG_STATUS_OK then sys.halt
        end if
    end sub
```

You can also verify the sanity of each setting in your project by calling [stg\\_check\\_all\(\)](#)<sup>[691]</sup>. Here is some code you *can* place in [on\\_sys\\_init\(\)](#)<sup>[533]</sup> -- it verifies *all* settings and performs initialization if *any* setting is found to be invalid. Notice how we check the code returned by [stg\\_check\\_all\(\)](#). [EN\\_STG\\_STATUS\\_INVALID](#)<sup>[690]</sup> is a "good" error, that is, we expect it to happen. There are other errors, however, that are "fatal", for example, [EN\\_STG\\_STATUS\\_FAILURE](#)<sup>[690]</sup>. We halt on those.

```
sub on_sys_init()
    dim x as en_stg_status_codes
    dim stg_name as string(STG_MAX_SETTING_NAME_LEN)

    if stg_start()<>EN_STG_STATUS_OK then sys.halt

    x=stg_check_all(stg_name)
    select case x
    case EN_STG_STATUS_OK:
        '--- all good ---

    case EN_STG_STATUS_INVALID, EN_STG_STATUS_FAILURE:
        if stg_restore_multiple(EN_STG_INIT_MODE_NORMAL)
<>EN_STG_STATUS_OK then sys.halt

    case else:
        'some other trouble
        sys.halt
    end select

    comms_init()
end sub
```

There is also a library procedure to restore a single member of a single setting -- [stg\\_restore\\_member\(\)](#)<sup>[693]</sup>. The default value for any member of any setting can be obtained by calling [stg\\_get\\_def\(\)](#)<sup>[692]</sup>.

## Writing and Reading Settings

In this section:

- [Writing and reading settings with stg\\_sg\(\)](#)<sup>[678]</sup>
- [Writing and reading settings with stg\\_set\(\) and stg\\_get\(\)](#)<sup>[679]</sup>
- [Using setting numbers instead of names](#)<sup>[680]</sup>
- [Working with multi-value settings](#)<sup>[681]</sup>
- [Understanding timestamps](#)<sup>[681]</sup>
- [Using Pre-gets and Post-sets](#)<sup>[683]</sup>

### Using Stg\_sg()

[Stg\\_sg\(\)](#)<sup>[698]</sup> allows you to set (write) or get (read) a setting and directly returns the execution result so you can check if the setting operation was successful (hence, the name "\_sg", which means "set/get"). In the following example, we set the setting "IP" to "192.168.1.40":

```
dim result as en_stg_status_codes
...
result=stg_sg("IP",0,"192.168.1.40",EN_STG_SET)
select case result
case EN_STG_STATUS_OK:
    'all good
case EN_STG_STATUS_UNKNOWN, EN_STG_STATUS_INVALID_INDEX:
    'bad setting name or index
case EN_STG_STATUS_FAILURE:
    'failure ro write
case EN_STG_STATUS_INVALID:
    'new setting value is invalidinvalid value
case else:
    'some weird error
end select
...
```

Here is another example where we read the value of the same setting. Notice that [stg\\_sg\(\)](#) returns the setting value indirectly, through one of its arguments:

```
dim result as en_stg_status_codes
```

```

dim s as string
...
result=stg_sg("IP",0,s,EN_STG_GET)
select case result
case EN_STG_STATUS_OK:
    'all good, s now contains current setting value
case EN_STG_STATUS_UNKNOWN, EN_STG_STATUS_INVALID_INDEX:
    'bad setting name or index
case EN_STG_STATUS_FAILURE:
    'failure ro write
case EN_STG_STATUS_INVALID:
    'new setting value is invalid
case else:
    'some weird error
end select
...

```

## Using Stg\_get() and Stg\_set()

Extensive [use of the stg\\_sg\(\)](#) can quickly bloat your project because of all this result checking that you must do everywhere you call stg\_sg(). Fortunately, there is another way, but do exercise caution with it -- see details below.

[Stg\\_set\(\)](#) and [stg\\_get\(\)](#) do not return the execution result directly. Instead, they invoke [callback\\_stg\\_error\(\)](#) whenever any error is detected. This procedure then can be a catch-all point for setting-related errors in your project. Here is an example:

```

...
sub procedure1 ()
    dim s,s2 as string(STG_MAX_SETTING_VALUE_LEN)
    ...
    s=stg_get("IP",0)
    s2=stg_get("PN",0)
end sub

sub procedure2 ()
    stg_set("CPTN",0,"2")
end sub

sub callback_stg_error(byref stg_name_or_num as string,index as byte,status
as en_stg_status_codes)
    pat.play("R-",PL_PAT_CANINT) 'setting error -- blink red LED!
aaa: goto aaa 'This is a "halt" so we hang here forever.
end sub

```

Notice how readable and simple the code above is. You simply read and write settings, and when some error happens, you handle it in callback\_stg\_error(). Since this is a single place for handling setting errors, you usually include some dramatic code there... something equivalent to the "blue screen of death" in old Windows.

A sobering note -- think when it is OK (and not OK) to use stg\_get() and stg\_set(). Typically, "it is not OK" when the setting is being written to after some sort of user input. Let's say the user is editing settings via a web-browser interface. He makes a mistake and inputs an invalid new value for the setting. If this part of your code relies on stg\_set() then this simple user mistake will lead to the halt of device

operation, which is totally unwarranted.

So, as a rule of thumb, use `stg_set()` and `stg_get()` "internally", in places where incorrect user input can't cause errors. In places where user input is processed use [stg\\_sg\(\)](#)<sup>[698]</sup>, which will allow you to check execution result "right there" and respond to the user if there was an erroneous input.

We use the same approach in our own [sample project](#)<sup>[686]</sup>.

One additional fact about the [stg\\_get\(\)](#)<sup>[696]</sup>. Not only does it invoke `callback_stg_error()` whenever there is an error, but also returns the default value of the setting (defined with the [setting configurator](#)<sup>[670]</sup>) when possible. This way, if the setting can't be read, you get its default value and your reliable product can continue operating somehow.

Because the TIDE compiler does not allow [recursions](#)<sup>[66]</sup>, some STG library's own procedures can't be called from within [callback\\_stg\\_error\(\)](#)<sup>[700]</sup>. These procedures are:

- [Stg\\_get\(\)](#)<sup>[696]</sup>
- [Stg\\_set\(\)](#)<sup>[697]</sup>

## Using Setting Numbers

Up until now we referred to settings by their names. It is also possible to call settings by their number. Settings are numbered in the order of their appearance in the [setting configurator](#)<sup>[670]</sup>. Settings are counted from 0.

Here is a neat example where we read (the first member of) every available setting. Notice how the error condition ([EN\\_STG\\_STATUS\\_UNKNOWN](#)<sup>[690]</sup>) is used to exit the loop:

```
...
dim s as string
dim f as byte
dim result as en_stg_status_codes
f=0
do
    result=stg_sg(str(f),0,s,EN_STG_GET)
    f=f+1
loop until result<>EN_STG_STATUS_OK

if result<>EN_STG_STATUS_UNKNOWN then
    sys.halt 'some error has occurred!
end if
...
```

Of course, the above example can be implemented in a more conventional way using [stg\\_get\\_num\\_settings\(\)](#)<sup>[694]</sup>:

```
...
```

```
dim s as string
dim f as byte
dim result as en_stg_status_codes

for f=0 to stg_get_num_settings()-1
    s=stg_get(str(f),0)
next f
...
```

So, how does the STG library know when to interpret your input as a setting name or number? Simple! If it starts with a digit (0-9), then this is a setting number, otherwise it is a setting name. Names, therefore, can't start with a digit.

```
...
s=stg_get("CPTN",0) 'refer to the setting by its name
s=stg_get("4",0) 'refer to the setting by its number
...
```

## Working With Multi-value Settings

A single setting may contain several members, like in an array. [Stg\\_sg\(\)](#)<sup>[698]</sup>, as well as [stg\\_get\(\)](#)<sup>[696]</sup> and [stg\\_set\(\)](#)<sup>[697]</sup> require that you specify the setting member you want to read or write. Setting members are counted starting from 0. [Get\\_stg\\_num\\_members\(\)](#) will tell you how many members each setting has.

Here is a modified example from the [previous topic](#)<sup>[680]</sup>, it goes through every member of every setting:

```
...
dim s as string
dim f,f2,num as byte
dim result as en_stg_status_codes

for f=0 to stg_get_num_settings()-1
    stg_get_num_members(str(f),num)
    for f2=0 to num-1
        s=stg_get(str(f),f2)
    next f2
next f
...
```

## Understanding Timestamps

Sometimes it is necessary to remember the date/time of the most recent setting modification. This can be useful, for instance, when synchronizing settings between several devices.

To enable timestamps, click (enable) the **Timestamp** option in the [configurator](#)<sup>[670]</sup>. Timestamps occupy an additional 7 bytes of memory for each setting (in the EEPROM, flash disk file, or in RAM, depending on how the setting is stored). This is why timestamps are disabled by default.

There is a single timestamp for each setting, even if this setting includes [multiple members](#)<sup>[681]</sup>. Timestamps are read and written through the [stg\\_timestamp](#)<sup>[689]</sup> global variable. Note that it is the responsibility of your application to set and interpret timestamps. The STG library does not access the real-time clock of your system and does not verify the contents of stg\_timestamp variable.

To set the new timestamp for the setting, fill out the stg\_timestamp variable with desired data prior to calling [stg\\_set\(\)](#)<sup>[697]</sup> or [stg\\_sg\(,,,EN\\_STG\\_SET\)](#)<sup>[698]</sup>. Here is an example:

```
...
rtc.getdata(stg_timestamp.ts_daycount,stg_timestamp.ts_mincount,
stg_timestamp.ts_seconds)
stg_timestamp.ts_milsec=0 'our RTC does not provide ms data
stg_set("IP",0,"192.168.1.50")
...
```

You can also set *just the timestamp*, without altering setting value:

```
...
rtc.getdata(stg_timestamp.ts_daycount,stg_timestamp.ts_mincount,
stg_timestamp.ts_seconds)
stg_timestamp.ts_milsec=0 'our RTC does not provide ms data
if stg_set_ts("IP")<>EN_STG_STATUS_OK then sys.halt
...
```

Note that [initializing settings](#)<sup>[677]</sup> (restoring their values to defaults) through [stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup> and [stg\\_restore\\_member\(\)](#)<sup>[693]</sup> also sets the timestamp of each affected setting.

Stg\_timestamp variable is updated every time you read the setting with [stg\\_get\(\)](#)<sup>[696]</sup> or [stg\\_sg\(,,,EN\\_STG\\_GET\)](#)<sup>[698]</sup>. In the following example, we read the setting in order to get its timestamp, then set new setting value if the setting hasn't been yet modified today:

```
...
dim daycount,mincount as word
dim seconds as byte

rtc.getdata(daycount,mincount,seconds)
stg_get("IP",0)
if stg_timestamp.ts_daycount<daycount then
    stg_set("IP",0,"ABC")
end if
...
```

## Using Pre-gets and Post-sets

Like the Windows registry, STG library may be used to provide a well-organized, persistent storage for your device's operational parameters. One less obvious and very powerful concept of setting usage is that settings can serve as transit points for controlling and/or monitoring the device. That is, writing to a setting can cause some related code to be executed *after* the new value is set (post-write), and this code will put the new value "into action". Reading a setting can cause the value of the setting to be updated *first* (pre-read), and only then returned to the caller.

Imagine, for instance, that there is an "LS" (Lamp State) setting that defined if the "lamp" is on or off. Once we change the setting value through, say, a telnet command, or some kind of setup screen, the state of the lamp should change, too.

The elegant way of achieving this is by using [callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup>. It is invoked every time [stg\\_set\(\)](#)<sup>[697]</sup> or [stg\\_sg\(...,EN\\_STG\\_SET\)](#)<sup>[698]</sup> is used. This callback procedure offers a catch-all place where you can respond to changing setting values.

Here is the code template for handling the lamp. The beauty of this approach is that the setting may be modified in several different places in your application, but you only need to respond to the setting value change in a single place -- `callback_stg_post_set()` procedure:

```
sub callback_stg_post_set (byref stg_name_or_num as string, index as byte,
byref stg_value as string)
    if stg_name_or_num="LS" then
        if stg_value=0 then
            'turn the lamp off
        else
            'turn the lamp on
        end if
    end if
end sub
```

Note that [stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup> and [stg\\_restore\\_member\(\)](#)<sup>[693]</sup> also write to settings and `callback_stg_post_set()` will be called for them too -- once for each setting affected.

Another callback procedure -- [callback\\_stg\\_pre\\_get\(\)](#)<sup>[700]</sup> -- is called every time your application reads a setting through [stg\\_get\(\)](#)<sup>[696]</sup> or [stg\\_sg\(...,EN\\_STG\\_GET\)](#)<sup>[698]</sup>. This allows to update the setting value *before* returning it to the caller.

Example: Let's say you have a setting called "CT" (Current Temperature). Here is a code template for automatically updating the setting each time its value is requested:

```

sub callback_stg_pre_get(byref stg_name_or_num as string,index as byte,byref
stg_value as string)
    if stg_name_or_num="CPTN" then
        stg_value=get_temperature() 'some function in your project that
returns current T
    end if
end sub

```

The use of pre-gets and post-sets is further illustrated in our [sample project](#)<sup>[686]</sup>.

Because TIDE compiler does not allow [recursions](#)<sup>[66]</sup>, some STG library's own procedures can't be called from within [callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup> and [callback\\_stg\\_pre\\_get\(\)](#)<sup>[700]</sup>. These procedures are:

- [Stg\\_start\(\)](#)<sup>[691]</sup>
- [Stg\\_check\\_all\(\)](#)<sup>[691]</sup>
- [Stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup>
- [Stg\\_restore\\_member\(\)](#)<sup>[693]</sup>
- [Stg\\_get\(\)](#)<sup>[696]</sup>
- [Stg\\_set\(\)](#)<sup>[697]</sup>
- [Stg\\_sq\(\)](#)<sup>[698]</sup>

## Operation Details

STG library automatically allocates the storage for settings. That is, non-volatile and volatile memory addresses where individual settings are stored are calculated automatically.

When non-volatile settings are stored in the EEPROM (default configuration), they are located at the bottom of the EEPROM, right after the [special configuration area](#)<sup>[197]</sup>.

When non-volatile settings are stored on a flash disk (*Use Flash Disk option*<sup>[670]</sup> selected), they are stored in the file specified by the **Filename option**<sup>[670]</sup>.

When the **Custom RAM** option is not selected, the volatile (RAM) settings are stored in an array which is maintained by the library (stg\_ram\_array variable).

When the **Custom RAM** option is checked, the volatile (RAM) settings are stored using [callback\\_stg\\_vm\\_read\(\)](#)<sup>[702]</sup> and [callback-stg\\_vm\\_write\(\)](#)<sup>[703]</sup>, which should contain custom code for accessing whatever memory you have decided to use for storing volatile settings (example: internal memory of a real-time clock IC).

When the **Redundancy** option is set to *two copies for non-volatile settings*, the library maintains a second copy of data for non-volatile settings (this doubles the required amount of non-volatile memory) and keeps a single copy for volatile settings. When the **Redundancy** option is set to *two copies for ALL settings*, even volatile settings are stored as two independent copies.

Two copies of setting data are stored like this:

### Bottom of EEPROM (flash)

Data for all non-volatile settings (first copy)
Data for all non-volatile settings (second copy)

### Bottom of RAM

Data for all volatile settings (first copy)
Data for all volatile settings (second copy)

Each setting is stored in the following format:

### Setting storage

Setting data	Timestamp (7 bytes)*	Checksum byte
--------------	----------------------	---------------

\*Only when the **Timestamp** option is enabled.

The checksum is a 255 complement of the modulo 256 (8-bit) sum of all data bytes for the setting except the checksum itself. The amount of storage allocated for setting data depends on this setting's properties. The total amount of memory taken by the setting can't exceed 255 bytes.

Setting data includes one or more setting members depending on the [number of members](#)<sup>[673]</sup> in this setting.

### Setting data field for a setting with three members

Member0 data	Member1 data	Member2 data
--------------	--------------	--------------

Here is how member data for settings of different types is stored:

- **Byte** settings require a single byte of storage for each member.
- **Word** settings require two bytes of storage for each member, the data is stored like this:

HIGH byte	LOW byte
-----------	----------

- **String** and **dot-decimal** settings require the space equal to the [P2 parameter](#)<sup>[675]</sup> (max length) plus one additional byte to store the current length of the data:

Current length (1 byte)	P2 number of bytes for data storage
-------------------------	-------------------------------------

## Sample Project

This sample project is published on our website under the name **test\_stg\_lib.zip**:  
<http://tibbo.com/basic/resources.html>.

Let's build a sample application. It will have a listening control socket through which you will be able to send control commands and get replies. These commands will allow you to write and read settings. One of the settings, with multiple members, will define a number of LED patterns. Another setting will select the current pattern to be played. Yet another setting will let you put the selected pattern into play and check if it is still playing.

This application, although largely useless, will demonstrate all of the fine points and advantages of the settings library.

The project uses five settings:

- **DN** (Device Name) -- stores a string that can uniquely identify the device. This setting does nothing for the program's functionality, but it is a nice touch to be able to name the device.
- **IP** (IP address) -- stores the IP address of the device.
- **PN** (Port Number) -- stores the port number on which the device will accept a TCP connection. You will use this TCP connection to send commands and receive replies.
- **PTN** (PaTterNs) -- has three members, each member stores one LED pattern.
- **CPTN** (Current PaTterN) -- specifies which pattern is currently selected.

Design steps:

- [Step 1: The Embryo](#)<sup>686</sup>
- [Step 2: Adding Setting Initialization](#)<sup>687</sup>
- [Step 3: Adding Comms](#)<sup>688</sup>
- [Step 4: Completing the Project](#)<sup>689</sup>

### Step 1: The Embryo

This step corresponds to **test\_stg\_lib\_1**.

The embryonic project defines the settings and compiles correctly. It does nothing else.

#### The steps

We assume you are not going to type everything in from scratch and just open the **test\_agg\_lib\_1** project. Notice that...

1. **Settings.tbs** and **settings.tbh** are [added](#)<sup>577</sup> to the project (from

`current_library_set\settings\trunk\`). There is also a necessary line in **global.tbh**: **include "settings\trunk\settings.tbh"**.

2. There is a **settings.txt** [configuration file](#) with type= **configuration file**, and format= **Setting (STG) library**. There is a line in `global.tbh` that is required for the configuration file to work correctly: **includepp "settings.txt"**.
3. In the configuration file, **Debug Printing** is *enabled*. This allows you to "see what's going on". Don't forget to *disable* this later, after you've made sure that the library operates as expected.
4. There are empty callback procedures in **device.tbs**:
  - [callback\\_stg\\_error\(\)](#);
  - [callback\\_stg\\_pre\\_get\(\)](#);
  - [callback\\_stg\\_post\\_set\(\)](#);
5. [On\\_sys\\_init\(\)](#) calls [stg\\_start\(\)](#) -- this is required to make the library operational. Notice how we check the code returned by `stg_start()`!
6. All settings are defined, as on the screenshot shown [here](#).

## The result

Compile and run the project -- you will see the output like this:

```
STG> ---START---
STG> Initialize RAM (volatile) settings...
STG> STG_RESTORE_MULTIPLE(), init_mode= RAM ONLY
STG> STG_SG()
STG> SET 'CPTN(255)' to '0' : OK
STG> STG_SG()
STG> SET 'PIP(255)' to '0' : OK
STG> RAM (volatile) settings initialized
STG> Number of settings: 6
STG> Non-volatile memory space required: 193
```

You see this printout because the **Debug Printing option** is enabled (checked).

This sample printout from the output pane shows that both RAM settings got initialized -- it happens automatically because, obviously, RAM settings need initialization every time the program runs. As for our non-volatile settings, we are supposed to find a way to initialize them in some convenient way. [Read on...](#)

## Step 2: Adding Setting Initialization

This step corresponds to **test\_stg\_lib\_2**.

Non-volatile settings must be [initialized](#) at some point. In our sample project, we check the "health" of settings upon boot using [stg\\_check\\_all\(\)](#). Should *any* setting turn out to be invalid, we initialize *all* settings with [stg\\_restore\\_multiple\(\)](#). Granted, this is a very crude way of handling setting initialization, but it works just fine for a simple project like ours.

We also provided a way to initialize the settings at any time -- just press the MD button for more than 2 seconds, then release.

All related changes are in **main.tbs**.

### Step 3: Adding Comms

This step corresponds to **test\_stg\_lib\_3**. Procedures of interest are **comms\_init()** and **comms\_proc\_cmd()**. Both are in **device.tbs**.

#### New stuff

OK, now comms. We use terminal software, for example, our own I/O Ninja software ([ninja.tibbo.com](http://ninja.tibbo.com)) to send commands and receive replies. The "IP" setting defines the IP address of the device, while the "PN" setting specifies the port number on the device side. [Setting initialization](#)<sup>[687]</sup> will cause these settings to have default values of 192.168.1.93 and 1000, as specified through the [setting configurator](#)<sup>[670]</sup>.

[Writing and Reading Settings](#)<sup>[676]</sup> already explained the difference between the usage of [stg\\_get\(\)](#)<sup>[696]</sup>/[stg\\_set\(\)](#)<sup>[697]</sup> and [stg\\_sg\(\)](#)<sup>[698]</sup>. Here is a practical illustration: **comms\_init()** uses "simplified" **stg\_get()**. With this, there is no need to check the execution result each time we need to read a setting -- should there be any problem, [callback\\_stg\\_error\(\)](#)<sup>[700]</sup> will be called and we respond to the error there.

**Comms\_proc\_cmd()**, on the contrary, needs to respond to each command with a meaningful status code. This is why it relies on **stg\_sg()**, which returns the status code directly.

There are two commands: "S" (set setting) and "G" (get setting). Both commands should end with the CR (shown as <CR> below).

Set command format is **Ssetting\_name,index,setting\_value**. The command returns the execution result, which is expressed by a single character (see below).

Get command format is **Gsetting\_name,index**. The command returns the execution result. If execution was successful, setting value is also returned.

Execution result codes are: **A** for OK, **C** for when the setting name is unknown or the index is invalid, **F** when there was some sort of failure, **I** when the setting value is invalid, and **U** for "weird internal errors".

#### The result

Here is a sample printout from I/O Ninja, we write and read one of the "PTN" setting's members. We set this member to "R-G-B-" and then read this value back:

```
Established TCP connection with 192.168.1.40:1000 from 3790
SPTN,2,R-G-B-<CR>
A<CR>
GPTN,2<CR>
AR-G-B-<CR>
```

## Step 4: Completing the Project

This step corresponds to `test_stg_lib_4`.

### New stuff

OK, settings defined, comms protocol is their to read and write them, now let's put all this to good use. Rules of engagement:

- Writing new value into the "CPTN" setting should play a corresponding pattern stored in the "PTN" setting.
- Briefly pressing the MD button should play the *next* pattern.

Our sample project nicely illustrates what was said in [Using Pre-gets and Post-sets](#)<sup>[683]</sup>. When the "CPTN" setting is being written to, [callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup> is called and this gives us a chance to "load" another pattern. Notice how this is done! We can't use [stg\\_get\(\)](#)<sup>[696]</sup> or [stg\\_sg\(\)](#)<sup>[698]</sup> inside `callback_stg_post_set()` -- this limitation is explained in [Using Pre-gets and Post-sets](#)<sup>[683]</sup>. We, however, need to read the "PTN" setting in order to play the new pattern!

Luckily, there is almost always a workaround. In our case, we load a very short blank pattern "-" instead. When this pattern is done playing, the [on\\_pat\(\)](#)<sup>[365]</sup> event is generated and then we read one of the "PTN" members according to the `pattern_num` variable.

[Callback\\_stg\\_pre\\_get\(\)](#)<sup>[701]</sup> is also useful in our project. When we send a command to read the current value of the "CPTN" setting, the setting is first updated with the current value of the `pattern_num` variable!

Notice also how [stg\\_get\\_num\\_members\(\)](#)<sup>[694]</sup> is used in `play_next_pattern()`. Each time the button is pressed, `pattern_num` is incremented by one, until it reaches the number of members in the "PTN" setting, after which it is reset back to 0.

### The result

Here is the I/O Ninja ([ninja.tibbo.com](http://ninja.tibbo.com)) session where we switched between different patterns:

```
Established TCP connection with 192.168.1.93:1000 from 1723
SCPTN,0,1<CR>
A<CR>
ASCPTN,0,2<CR>
A<CR>
```

Try this and observe how different patterns start playing on the LEDs.

## Stg\_timestamp Global Variable

`Stg_timestamp` variable is used for working with setting [timestamps](#)<sup>[661]</sup>. The variable is only available when the **Timestamp option**<sup>[670]</sup> is enabled.

Set this variable to the desired value prior to calling [stg\\_sg\(...,EN\\_STG\\_SET\)](#)<sup>[698]</sup>, [stg\\_set\(\)](#)<sup>[697]</sup>, [stg\\_set\\_ts\(\)](#)<sup>[699]</sup>, [stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup>, or [stg\\_restore\\_members\(\)](#)<sup>[694]</sup>.

The variable will contain the timestamp of the setting in question after the call to [stg\\_sg\(,,,EN\\_STG\\_GET\)](#)<sup>[698]</sup> or [stg\\_get\(\)](#)<sup>[696]</sup>.

The variable is defined as follows:

```
type struct_stg_timestamp
    ts_daycount as word
    ts_mincount as word
    ts_seconds as byte
    ts_milsec as word
end type
...
declare stg_timestamp as struct_stg_timestamp
```

Note that it is the responsibility of your application to set and interpret timestamps. The STG library does not access the real-time clock of your system and does not verify the contents of stg\_timestamp variable.

## En\_stg\_status\_codes

Several procedure in the library utilize the en\_stg\_status\_codes enum. This enum has the following members:

- 0- EN\_STG\_STATUS\_OK: operation completed successfully.
- 1- EN\_STG\_STATUS\_NOT\_STARTED: [stg\\_start\(\)](#)<sup>[691]</sup> was not used or failed.
- 2- EN\_STG\_STATUS\_OUT\_OF\_FILE\_NUMBERS: need to open a file and there are no free file numbers left (possible only when STG\_STORAGE\_MEMORY is "1").
- 3- EN\_STG\_STATUS\_WRONG\_DEFINE: wrong #define value.
- 4- EN\_STG\_STATUS\_WRONG\_DESCRIPTOR: wrong descriptor file data.
- 5- EN\_STG\_STATUS\_UNKNOWN: unknown setting or invalid setting number.
- 6- EN\_STG\_STATUS\_INVALID\_INDEX: invalid index (out-of-range).
- 7- EN\_STG\_STATUS\_FAILURE: read failure or write failure (checksum error, hardware malfunction, etc.).
- 8- EN\_STG\_STATUS\_INVALID: invalid setting value.

## Library Procedures

In this section:

- [Stg\\_start\(\)](#)<sup>[691]</sup>
- [Stg\\_check\\_all\(\)](#)<sup>[691]</sup>
- [Stg\\_get\\_def\(\)](#)<sup>[692]</sup>
- [Stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup>
- [Stg\\_restore\\_member\(\)](#)<sup>[693]</sup>
- [Stg\\_get\\_num\\_settings\(\)](#)<sup>[694]</sup>
- [Stg\\_get\\_num\\_members\(\)](#)<sup>[694]</sup>
- [Stg\\_find\(\)](#)<sup>[695]</sup>
- [Stg\\_stype\\_get\(\)](#)<sup>[696]</sup>

- [Stg\\_get\(\)](#)<sup>[696]</sup>
- [Stg\\_set\(\)](#)<sup>[697]</sup>
- [Stg\\_sg\(\)](#)<sup>[698]</sup>
- [Stg\\_set\\_ts\(\)](#)<sup>[699]</sup>
- [Callback\\_stg\\_error\(\)](#)<sup>[700]</sup>
- [Callback\\_stg\\_pre\\_get\(\)](#)<sup>[700]</sup>
- [Callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup>
- [Callback\\_stg\\_vm\\_read\(\)](#)<sup>[702]</sup>
- [Callback\\_stg\\_vm\\_write\(\)](#)<sup>[703]</sup>

## Stg\_start()

**Description:** API procedure, starts the STG library, parses the descriptor file, restores all volatile (RAM) settings to default values by calling [stg\\_restore\\_multiple \(EN\\_STG\\_INIT\\_MODE\\_RAM\\_ONLY\)](#)<sup>[692]</sup>

**Syntax:** **function stg\_start() as en\_stg\_status\_codes**

**Returns:** One of these [en\\_stg\\_status\\_codes](#)<sup>[690]</sup>:  
EN\_STG\_STATUS\_OK,  
EN\_STG\_STATUS\_OUT\_OF\_FILE\_NUMBERS,  
EN\_STG\_STATUS\_WRONG\_DEFINE,  
EN\_STG\_STATUS\_WRONG\_DESCRIPTOR,  
EN\_STG\_STATUS\_FAILURE

**See Also:** [Getting Started](#)<sup>[676]</sup>

### Details

MUST be called first, before any other procedure in this library is invoked, or [EN\\_STG\\_STATUS\\_NOT\\_STARTED](#)<sup>[690]</sup> will be returned by every other procedure you call.

When this procedure executes, [callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup> is called for each setting whose **Storage Location** is *Non-volatile*. See [Editing Settings](#)<sup>[673]</sup> for details.

## Stg\_check\_all()

**Description:** API procedure, verifies each setting by reading its value through [stg\\_sg\(\)](#)<sup>[698]</sup>.

**Syntax:** **function stg\_check\_all(byref problem\_stg as string) as en\_stg\_status\_codes**

**Returns:** One of these [en\\_stg\\_status\\_codes](#)<sup>[690]</sup>:  
EN\_STG\_STATUS\_OK, EN\_STG\_STATUS\_NOT\_STARTED,  
EN\_STG\_STATUS\_FAILURE, EN\_STG\_STATUS\_INVALID

**See Also:** [Verifying and Initializing Settings](#)<sup>[677]</sup>

Part	Description
problem_stg	After the procedure execution will contain the name of the problem setting, if any. Will be NULL if no problems were encountered.

### Details

Execution stops once any problem for any setting is encountered. Thus, only one problem is reported.

## Stg\_get\_def()

**Description:** API procedure, returns the default value for the specified setting's member.

**Syntax:** **function stg\_get\_def(byref stg\_name\_or\_num as string, index as byte, byref def\_value as string) as en\_stg\_status\_codes**

**Returns:** One of these [en\\_stg\\_status\\_codes](#)<sup>[690]</sup>:  
EN\_STG\_STATUS\_OK, EN\_STG\_STATUS\_NOT\_STARTED,  
EN\_STG\_STATUS\_UNKNOWN,  
EN\_STG\_STATUS\_INVALID\_INDEX.

In case of successful execution returns the default value for the specified setting's member through the def\_value argument.

**See Also:** [Verifying and Initializing Settings](#)<sup>[677]</sup>

Part	Description
stg_name_or_num	Setting name or number. If the supplied string does not start with a digit (0-9), then the string is interpreted as the name of the setting. If the string starts with a digit, then this will be interpreted as the setting number. Settings are numbered counting from 0, and in the order of their appearance in the <a href="#">setting configurator</a> <sup>[670]</sup> .
index	Setting member.
def_value	The default setting member's value will be returned through this argument.

### Details

This function only accesses and reads the data from the [configuration file](#)<sup>[670]</sup>.

## Stg\_restore\_multiple()

**Description:** API procedure, initializes (sets the default values for) all or multiple settings.

- Syntax:** `function stg_restore_multiple(init_mode as en_stg_init_modes) as en_stg_status_codes`
- Returns:** One of these [en\\_stg\\_status\\_codes](#)<sup>[690]</sup>:  
EN\_STG\_STATUS\_OK, EN\_STG\_STATUS\_NOT\_STARTED,  
EN\_STG\_STATUS\_FAILURE, EN\_STG\_STATUS\_INVALID.
- See Also:** [Verifying and Initializing Settings](#)<sup>[677]</sup>

Part	Description
init_mode	<p>Initialization mode:</p> <p>Modes 0- EN_STG_INIT_MODE_NORMAL and 1- 1- EN_STG_INIT_MODE_OVERRIDE work on non-volatile and volatile settings.</p> <p>Modes 2- EN_STG_INIT_MODE_RAM_ONLY and 3- EN_STG_INIT_MODE_RAM_ONLY_OVERRIDE only work on volatile settings. Non-volatile settings are not checked at all.</p> <p>Modes 0- EN_STG_INIT_MODE_NORMAL and 2- EN_STG_INIT_MODE_RAM_ONLY cause conditional initialization of settings according to their <a href="#">Initialization Mode</a><sup>[673]</sup>. If it is <i>Initialize Always</i>, then this setting is initialized unconditionally, if it is <i>Initialize When Invalid</i>, then this setting will be initialized only if its current value is invalid (<a href="#">EN_STG_STATUS_INVALID</a><sup>[690]</sup>) or corrupted (<a href="#">EN_STG_STATUS_FAILURE</a><sup>[690]</sup>).</p> <p>Modes 1- EN_STG_INIT_MODE_OVERRIDE and 3- EN_STG_INIT_MODE_RAM_ONLY_OVERRIDE cause initialization of settings regardless of their validity.</p>
<a href="#">stg_timestamp</a> <sup>[689]</sup> variable	<p>When <a href="#">STG_TIMESTAMP</a><sup>[690]</sup> is 1, this variable should be preset with the desired timestamp prior to calling <code>stg_restore_member()</code>. All affected settings will receive the same timestamp.</p>

## Details

[Default values](#)<sup>[675]</sup> for setting members can be defined through the [setting configurator](#)<sup>[670]</sup>.

When this procedure executes, [callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup> is called for each setting being initialized.

## Stg\_restore\_member()

- Description:** API procedure, initializes (sets the default value for) the specified setting's member.
- Syntax:** `function stg_restore_member(byref stg_name_or_num as string, index as byte) as en_stg_status_codes`

- Returns:** One of these [en\\_stg\\_status\\_codes](#)<sup>[690]</sup>:  
 EN\_STG\_STATUS\_OK, EN\_STG\_STATUS\_NOT\_STARTED,  
 EN\_STG\_STATUS\_UNKNOWN,  
 EN\_STG\_STATUS\_INVALID\_INDEX,  
 EN\_STG\_STATUS\_FAILURE.
- See Also:** [Verifying and Initializing Settings](#)<sup>[677]</sup>

Part	Description
stg_name_or_num	Setting name or number. If the supplied string does not start with a digit (0-9), then the string is interpreted as the name of the setting. If the string starts with a digit, then this will be interpreted as the setting number. Settings are numbered counting from 0, and in the order of their appearance in the <a href="#">setting configurator</a> <sup>[670]</sup> .
index	Setting member.
<a href="#">stg_timestamp</a> <sup>[689]</sup> <i>variable</i>	When <a href="#">STG_TIMESTAMP</a> <sup>[690]</sup> is 1, this variable should be preset with the desired timestamp prior to calling <code>stg_restore_member()</code> .

### Details

[Default values](#)<sup>[675]</sup> for setting members can be defined through the [setting configurator](#)<sup>[670]</sup>.

The setting's member is restored regardless of the value of the initialization mode field in the descriptor file.

When this procedure executes, [callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup> is called for the setting being initialized.

### Stg\_get\_num\_settings()

- Description:** API procedure, returns the number of settings defined in your project.
- Syntax:** **function stg\_get\_num\_settings() as byte**
- Returns:** Total number of settings.
- See Also:** [Using Setting Numbers](#)<sup>[680]</sup>

### Details

---

### Stg\_get\_num\_members()

- Description:** API procedure, returns the number of members for the specified setting.
- Syntax:** **function stg\_get\_num\_members(byref**

stg\_name\_or\_num **as string**, byref num\_members **as byte**) as en\_stg\_status\_codes

**Returns:**

One of these [en\\_stg\\_status\\_codes](#)<sup>[690]</sup>:  
EN\_STG\_STATUS\_OK, EN\_STG\_STATUS\_NOT\_STARTED,  
EN\_STG\_STATUS\_UNKNOWN.

In case of successful execution returns the number of members through the num\_members argument.

**See Also:**

[Working with Multi-value Settings](#)<sup>[681]</sup>

Part	Description
stg_name_or_num	Setting name or number. If the supplied string does not start with a digit (0-9), then the string is interpreted as the name of the setting. If the string starts with a digit, then this will be interpreted as the setting number. Settings are numbered counting from 0, and in the order of their appearance in the <a href="#">setting configurator</a> <sup>[670]</sup> .
num_members	The number of members for this setting will be returned through this argument.

**Details**

This function only accesses and reads the data from the [configuration file](#)<sup>[670]</sup>.

**Stg\_find()****Description:**

API procedure, returns the number of the specified setting.

**Syntax:**

**function stg\_find(byref stg\_name\_or\_num as string) as byte**

**Returns:**

0 if the specified setting wasn't found, or  
setting number +1 if the setting was found. Settings are numbered counting from 0, and in the order of their appearance in the [setting configurator](#)<sup>[670]</sup>.

**See Also:**

Part	Description
stg_name_or_num	Setting name or number. If the supplied string does not start with a digit (0-9), then the string is interpreted as the name of the setting. If the string starts with a digit, then this will be interpreted as the setting number.

**Details**

If `stg_name_or_num` argument starts with the digit, this function will simply return the setting number +1, but only if the setting with the specified number does exist (zero will be returned if it doesn't).

## Stg\_stype\_get()

**Description:** API procedure, returns the type of the specified setting.

**Syntax:** **function stg\_stype\_get(byref stg\_name\_or\_num as string) as byte**

**Returns:** 0 if the specified setting wasn't found, or  
ASCII code of the character representing the setting type: `B` (byte), `W` (word), `S` (string), `D` (dot-decimal string).

**See Also:**

Part	Description
<code>stg_name_or_num</code>	Setting name or number. If the supplied string does not start with a digit (0-9), then the string is interpreted as the name of the setting. If the string starts with a digit, then this will be interpreted as the setting number.

### Details

---

## Stg\_get()

**Description:** API procedure, reads (gets) the value of the specified setting's member; reports errors through [callback\\_stg\\_error\(\)](#)<sup>[700]</sup>.

**Syntax:** **function stg\_get(byref stg\_name\_or\_num as string, index as byte) as string**

**Returns:** Successful execution: the current value of the specified setting's member.

Some error, except [EN\\_STG\\_STATUS\\_UNKNOWN](#)<sup>[690]</sup> or [EN\\_STG\\_STATUS\\_INVALID\\_INDEX](#)<sup>[690]</sup>: the default value of this setting's member, plus the [callback\\_stg\\_error\(\)](#) is called, too. One of the following errors could be reported: `EN_STG_STATUS_OK`, `EN_STG_STATUS_NOT_STARTED`, `EN_STG_STATUS_UNKNOWN`, `EN_STG_STATUS_INVALID_INDEX`, `EN_STG_STATUS_FAILURE`, `EN_STG_STATUS_INVALID`.

When [STG\\_TIMESTAMP](#)<sup>[690]</sup> is 1, also returns the setting change timestamp through the [stg\\_timestamp](#)<sup>[689]</sup> global variable.

**See Also:** [Using Stg\\_get\(\) and Stg\\_set\(\)](#)<sup>[679]</sup>

Part	Description
stg_name_or_num	Setting name or number. If the supplied string does not start with a digit (0-9), then the string is interpreted as the name of the setting. If the string starts with a digit, then this will be interpreted as the setting number. Settings are numbered counting from 0, and in the order of their appearance in the <a href="#">setting configurator</a> <sup>[670]</sup> .
index	Setting member.

### Details

[Callback stg\\_error\(\)](#)<sup>[700]</sup> is invoked if any error is detected during this procedure's execution. One of the following errors could be reported: EN\_STG\_STATUS\_OK, EN\_STG\_STATUS\_NOT\_STARTED, EN\_STG\_STATUS\_UNKNOWN, EN\_STG\_STATUS\_INVALID\_INDEX, EN\_STG\_STATUS\_FAILURE, EN\_STG\_STATUS\_INVALID.

[Callback stg\\_pre\\_get\(\)](#)<sup>[700]</sup> is called when this procedure executes. This provides a "central location" for updating setting values before returning them through [stg\\_get\(\)](#).

## Stg\_set()

**Description:** API procedure, writes (sets) the value of the specified setting's member; reports errors through [callback stg\\_error\(\)](#)<sup>[700]</sup>.

**Syntax:** **sub stg\_set(byref stg\_name\_or\_num as string, index as byte, byref stg\_value as string)**

**See Also:** [Using Stg\\_get\(\) and Stg\\_set\(\)](#)<sup>[679]</sup>

Part	Description
stg_name_or_num	Setting name or number. If the supplied string does not start with a digit (0-9), then the string is interpreted as the name of the setting. If the string starts with a digit, then this will be interpreted as the setting number. Settings are numbered counting from 0, and in the order of their appearance in the <a href="#">setting configurator</a> <sup>[670]</sup> .
index	Setting member.
stg_value	New setting member's value to be set.
<a href="#">stg_timestamp</a> <sup>[689]</sup> variable	When <a href="#">STG_TIMESTAMP</a> <sup>[690]</sup> is 1, this global variable should be preset with the desired timestamp prior to calling <a href="#">stg_set()</a> .

### Details

[Callback\\_stg\\_error\(\)](#)<sup>[700]</sup> is invoked if any error is detected during this procedure's execution. One of the following errors could be reported: EN\_STG\_STATUS\_OK, EN\_STG\_STATUS\_NOT\_STARTED, EN\_STG\_STATUS\_UNKNOWN, EN\_STG\_STATUS\_INVALID\_INDEX, EN\_STG\_STATUS\_FAILURE, EN\_STG\_STATUS\_INVALID.

[Callback\\_stg\\_post\\_set\(\)](#)<sup>[701]</sup> is called when this procedure executes. This provides a "central location" for responding to changing setting values.

## Stg\_sg()

- Description:** API procedure, writes (sets) or reads (gets) the specified setting's member; directly returns the execution result.
- Syntax:** **function stg\_sg(byref stg\_name\_or\_num as string, index as byte, byref stg\_value as string, op as en\_stg\_rdwr) as en\_stg\_status\_codes**
- Returns:** One of these [en\\_stg\\_status\\_codes](#)<sup>[690]</sup>:  
 EN\_STG\_STATUS\_OK, EN\_STG\_STATUS\_NOT\_STARTED,  
 EN\_STG\_STATUS\_UNKNOWN,  
 EN\_STG\_STATUS\_INVALID\_INDEX,  
 EN\_STG\_STATUS\_FAILURE, EN\_STG\_STATUS\_INVALID.
- For op= 1- EN\_STG\_SET, also indirectly returns the current value of the specified setting's member through the stg\_value argument.
- For op=0- EN\_STG\_GET, and when [STG\\_TIMESTAMP](#)<sup>[690]</sup> is 1, also returns the setting change timestamp through the [stg\\_timestamp](#)<sup>[689]</sup> global variable.
- See Also:** [Using Stg\\_sg\(\)](#)<sup>[678]</sup>

Part	Description
stg_name_or_num	Setting name or number. If the supplied string does not start with a digit (0-9), then the string is interpreted as the name of the setting. If the string starts with a digit, then this will be interpreted as the setting number. Settings are numbered counting from 0, and in the order of their appearance in the <a href="#">setting configurator</a> <sup>[670]</sup> .
index	Setting member.
stg_value	Setting value. For set operations, the desired new setting value should be supplied through this variable. For get operations, the current setting value will be found in this variable after the stg_sg() executes.
op	Operation: 0- EN_STG_GET: get (read) the setting value. 1- EN_STG_SET: set (write) the setting value.
<a href="#">stg_timestamp</a> <sup>[689]</sup>	For op=1- EN_STG_SET, and when <a href="#">STG_TIMESTAMP</a> <sup>[690]</sup> is 1,

*variable* this global variable should be preset with the desired timestamp prior to calling `stg_sg()`.

### Details

[Callback `stg\_pre\_get\(\)`](#)<sup>[700]</sup> is called when this procedure executes with `op= 0- EN_STG_GET`. This provides a central location for updating setting values before returning them through the `stg_get()`. [Callback `stg\_post\_set\(\)`](#)<sup>[701]</sup> is called for `op= 1- EN_STG_SET`. Again, this provides a "central location" for responding to changing setting values.

[Callback `stg\_error\(\)`](#)<sup>[700]</sup> is never called from within this procedure, so make sure to analyse the status code returned by the `stg_sg()`.

## Stg\_set\_ts()

**Description:** API procedure, writes (sets) the timestamp for the specified setting. Only available when [STG\\_TIMESTAMP](#)<sup>[690]</sup> is 1.

**Syntax:** **function `stg_set_ts(byref stg_name_or_num as string) as en_stg_status_codes`**

**See Also:** [Understanding Timestamps](#)<sup>[681]</sup>

Part	Description
<code>stg_name_or_num</code>	Setting name or number. If the supplied string does not start with a digit (0-9), then the string is interpreted as the name of the setting. If the string starts with a digit, then this will be interpreted as the setting number. Settings are numbered counting from 0, and in the order of their appearance in the <a href="#">setting configurator</a> <sup>[670]</sup> .
<a href="#">stg_timestamp</a> <sup>[689]</sup> <i>variable</i>	This global variable should be preset with the desired timestamp prior to calling <code>stg_set_ts()</code> .

### Details

This procedure allows to modify the timestamp of the setting without affecting the values of setting members.

New timestamp is *also* set for the setting also when one of the following procedures executes:

- [Stg\\_start\(\)](#)<sup>[691]</sup> -- for all settings whose [Storage Location](#)<sup>[673]</sup> is *Non-volatile*.
- [Stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup> -- for each setting being restored.
- [Stg\\_restore\\_member\(\)](#)<sup>[693]</sup> -- for the setting being restored.
- [Stg\\_set\(\)](#)<sup>[697]</sup> -- for the setting being written to.
- [Stg\\_sg\(\)](#)<sup>[698]</sup> when `op= 1- EN_STG_SET` -- for the setting being written to.

## Callback\_stg\_error()

- Description:** Callback procedure, informs of the error during the execution of [stg\\_get\(\)](#)<sup>[696]</sup> or [set\\_set\(\)](#)<sup>[697]</sup>. Procedure body has to be created elsewhere in the project (externally with respect to the library).
- Syntax:** **sub callback\_stg\_error(byref stg\_name\_or\_num as string, index as byte, status as en\_stg\_status\_codes)**
- Returns:** ---
- See Also:** [Using Stg\\_get\(\) and Stg\\_set\(\)](#)<sup>[679]</sup>

Part	Description
stg_name_or_num	Setting name or number. If the supplied string does not start with a digit (0-9), then the string should be interpreted as the name of the setting. If the string starts with a digit, then this should be interpreted as the setting number. Settings are numbered counting from 0, and in the order of their appearance in the <a href="#">setting configurator</a> <sup>[670]</sup> .
index	Setting member.
status	One of the <a href="#">en_stg_status_codes</a> <sup>[690]</sup> codes indicating the type of the detected error.

### Details

This procedure is invoked when the following procedures execute:

- [Stg\\_get\(\)](#)<sup>[696]</sup>
- [Stg\\_set\(\)](#)<sup>[697]</sup>

Notice that this procedure is never called during the execution of other procedures, even though many of them access settings!

The following procedures can't be called from within `callback_stg_error()` or [recursion](#)<sup>[66]</sup> error will be generated by the compiler:

- [Stg\\_get\(\)](#)<sup>[696]</sup>
- [Stg\\_set\(\)](#)<sup>[697]</sup>

## Callback\_stg\_pre\_get()

- Description:** Callback procedure, informs that the setting member's value is being read through one of the STG library's procedures; allows to update the setting member's value before it is returned by the STG library. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** `sub callback_stg_pre_get(byref stg_name_or_num as string, index as byte, byref stg_value as string)`

**Returns:** ---

**See Also:** [Using Pre-gets and Post-sets](#)<sup>[683]</sup>

Part	Description
stg_name_or_num	Setting name or number. If the supplied string does not start with a digit (0-9), then the string should be interpreted as the name of the setting. If the string starts with a digit, then this should be interpreted as the setting number. Settings are numbered counting from 0, and in the order of their appearance in the <a href="#">setting configurator</a> <sup>[670]</sup> .
index	Setting member.
stg_value	Current value of the specified setting's member. Leave the value unchanged if there is no need to update the setting. Change the value of this argument to have the STG library set the setting's member to this new value.

### Details

This procedure is invoked when the following procedures execute:

- [Stg\\_check\\_all\(\)](#)<sup>[691]</sup> -- for each setting being checked.
- [Stg\\_get\(\)](#)<sup>[696]</sup> -- for the setting being read from.
- [stg\\_sg\(..., EN\\_STG\\_GET\)](#)<sup>[698]</sup> -- for the setting being read from.

The following procedures can't be called from within `callback_stg_pre_get()` or [recursion](#)<sup>[66]</sup> error will be generated by the compiler:

- [Stg\\_start\(\)](#)<sup>[691]</sup>
- [Stg\\_check\\_all\(\)](#)<sup>[691]</sup>
- [Stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup>
- [Stg\\_restore\\_member\(\)](#)<sup>[693]</sup>
- [Stg\\_get\(\)](#)<sup>[696]</sup>
- [Stg\\_set\(\)](#)<sup>[697]</sup>
- [Stg\\_sg\(\)](#)<sup>[698]</sup>

### Callback\_stg\_post\_set()

**Description:** Callback procedure, informs that the setting member's value is being written to through one of the STG library's procedures; allows to respond to the value change. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** `sub callback_stg_post_set(byref stg_name_or_num as`

**string**, index **as byte**,byref stg\_value **as string**)

**Returns:** ---

**See Also:** [Using Pre-gets and Post-sets](#)<sup>[683]</sup>

Part	Description
stg_name_or_num	Setting name or number. If the supplied string does not start with a digit (0-9), then the string should be interpreted as the name of the setting. If the string starts with a digit, then this should be interpreted as the setting number. Settings are numbered counting from 0, and in the order of their appearance in the <a href="#">setting configurator</a> <sup>[670]</sup> .
index	Setting member.
stg_value	New setting member's value that has just been set.

### Details

This procedure is invoked when the following procedures execute:

- [Stg\\_start\(\)](#)<sup>[691]</sup> -- for all settings whose [Storage Location](#)<sup>[673]</sup> is *Non-volatile*.
- [Stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup> -- for each setting being restored.
- [Stg\\_restore\\_member\(\)](#)<sup>[693]</sup> -- for the setting being restored.
- [Stg\\_set\(\)](#)<sup>[697]</sup> -- for the setting being written to.
- [stg\\_sg\(...,EN\\_STG\\_SET\)](#)<sup>[698]</sup> -- for the setting being written to.

The following procedures can't be called from within `callback_stg_post_set()` or [recursion](#)<sup>[68]</sup> error will be generated by the compiler:

- [Stg\\_start\(\)](#)<sup>[691]</sup>
- [Stg\\_check\\_all\(\)](#)<sup>[691]</sup>
- [Stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup>
- [Stg\\_restore\\_member\(\)](#)<sup>[693]</sup>
- [Stg\\_get\(\)](#)<sup>[696]</sup>
- [Stg\\_set\(\)](#)<sup>[697]</sup>
- [Stg\\_sg\(\)](#)<sup>[698]</sup>

### Callback\_stg\_vm\_read()

**Description:** Callback procedure, should implement necessary code for reading a byte of data from "custom" volatile memory. Needed only when the **Custom RAM option**<sup>[670]</sup> is enabled. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **function** `callback_stg_vm_read`(address **as word**) **as byte**

**Returns:** ---

**See Also:** [Operation Details](#)<sup>[684]</sup>

Part	Description
address	Memory address to read.

### Details

---

## Callback\_stg\_vm\_write()

**Description:** Callback procedure, should implement necessary code for writing a byte of data to "custom" volatile memory. Invoked only when the **Custom RAM option**<sup>[670]</sup> is enabled. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_stg\_vm\_write**(data\_to\_write **as byte**, address **as word**)

**Returns:** ---

**See Also:** [Operation Details](#)<sup>[684]</sup>

Part	Description
data_to_write	Data byte to save to the "custom" volatile memory.
address	Memory address to write.

### Details

---

## WLN (Wi-Fi Association) Library

The WLN library works with the GA1000 add-on Wi-Fi module (see Programmable Hardware Manual). The library complements the Wi-Fi ([wln.](#)<sup>[536]</sup>) object by providing the following:

- Persistent association with an access point of choice;
- Implementation of WPA1-PSK and WPA2-PSK security protocols (the wln. object doesn't fully support them per se);
- Support for access point switchover (roaming);
- Generation of keepalive messages to prevent disassociation.

The library is event-based and non-blocking -- it quietly runs in the background and

takes a minimal amount of CPU time.

## Library Info

### Supported platforms:

Any platform with Wi-Fi ([wln](#),<sup>[536]</sup>) interface.

Special case: WPA/WPA2 functionality is not supported on the [EM500W](#),<sup>[138]</sup> platform.

### Files to include:

Wln.tbs, wln.tbh (from *current\_library\_set*\wln\trunk\).

### Dependencies:

[SOCK](#),<sup>[664]</sup> library (only if you have [#define WLN\\_WPA\\_1](#),<sup>[721]</sup> or [#define WLN\\_KEEP\\_ALIVE\\_1](#),<sup>[721]</sup>);

You may also need [STG library](#),<sup>[668]</sup> (for storing WPA/WPA2 parameters as described in [Trying WPA](#),<sup>[711]</sup> code example).

### API procedures:

Use [API procedures](#),<sup>[576]</sup> to interact with the library.

[wln\\_start\(\)](#),<sup>[724]</sup> -- commences attempts to bring up (boot) the Wi-Fi interface, find and associate with the specified wireless network, and then keep associated at all times.

[wln\\_stop\(\)](#),<sup>[725]</sup> -- shuts down the Wi-Fi interface.

[wln\\_change\(\)](#),<sup>[725]</sup> -- sets a different target wireless network for the WLN library.

[wln\\_rescan\(\)](#),<sup>[726]</sup> -- starts the search for the specified access point in order to obtain its signal strength.

[wln\\_wpa\\_mkey\\_get\(\)](#),<sup>[727]</sup> -- calculates the pre-shared master key for WPA1 and WPA2 security modes.

[wln\\_check\\_association\(\)](#),<sup>[728]</sup> -- informs whether your device is currently associated with an access point.

### Event procedures:

Call [event procedures](#),<sup>[576]</sup> from corresponding event handlers, as described [here](#),<sup>[619]</sup>.

[wln\\_proc\\_timer\(\)](#),<sup>[728]</sup> -- call it from the [on\\_sys\\_timer\(\)](#),<sup>[533]</sup> event handler.

[wln\\_proc\\_data\(\)](#),<sup>[728]</sup> -- call it from the [on\\_sock\\_data\\_arrival\(\)](#),<sup>[489]</sup> event handler.

[wln\\_proc\\_task\\_complete\(\)](#),<sup>[729]</sup> -- call it from the [on\\_wln\\_task\\_complete\(\)](#),<sup>[565]</sup> event handler.

[wln\\_proc\\_event\(\)](#),<sup>[729]</sup> -- call it from the [on\\_wln\\_event\(\)](#),<sup>[565]</sup> event handler.

### Callback procedures:

Implement the bodies of [callback procedures](#),<sup>[576]</sup> elsewhere in your project.

[callback\\_wln\\_ok\(\)](#),<sup>[729]</sup> -- informs of the successful association with the target wireless network.

[callback\\_wln\\_failure\(\)](#),<sup>[730]</sup> -- informs of the failure to find the target wireless network, associate with it, or maintain association.

[callback\\_wln\\_pre\\_buffrq\(\)](#),<sup>[730]</sup> -- informs of the insufficient number of free buffer pages available for use by the library.

[callback\\_wln\\_mkey\\_progress\\_update\(\)](#),<sup>[731]</sup> -- periodically called from [wln\\_wpa\\_mkey\\_get\(\)](#),<sup>[727]</sup> to inform about the

progress of pre-shared key calculation.

[callback\\_wln\\_rescan\\_result\(\)](#) <sup>[731]</sup> -- informs of the completion of the re-scanning initiated by [wln\\_rescan\(\)](#) <sup>[726]</sup>

**Required buffer space:**

5 buffer pages minimum;

+1 additional buffer page if keepalive packets are enabled (see [WLN\\_KEEP\\_ALIVE](#) <sup>[721]</sup>);

+2 additional buffer pages if WPA/WPA2 support is enabled (see [WLN\\_WPA](#) <sup>[721]</sup>).

## Step-by-step Usage Instructions

### Minimal steps

1. Make sure you have the [SOCK](#) <sup>[664]</sup> library in your project (actually, you only need this if you have [#define WLN\\_WPA 1](#) <sup>[721]</sup> or [#define WLN\\_KEEP\\_ALIVE 1](#) <sup>[721]</sup>).
2. [Add](#) <sup>[577]</sup> **wln.tbs** and **wln.tbh** files to your project (they are in `current_library_set\wln\trunk`).
3. Add [#define WLN\\_DEBUG\\_PRINT 1](#) <sup>[721]</sup> to the defines section of the global.tbh file of your project. This way you will "see what's going on". Don't forget to remove this later, after you've made sure that the library operates as expected.
  - Some access points, notably CISCO devices, are so impatient during the WPA1/WPA2 handshake process, that printing debug info makes them timeout. If you notice that the WLN library is stuck in the endless association loop, and you are sure that your password is set correctly, then try disabling debug printing!
4. Define GA1000 interface line mapping. The following code is suggested (unless you built your own hardware, in which case study the [Configuring Interface Lines](#) <sup>[545]</sup> topic of the [wln](#) <sup>[536]</sup> object's documentation):

```
#if PLATFORM_ID=EM500 or PLATFORM_ID=EM500W
    #define WLN_RESET_MODE 1 'there will be no dedicated reset, and all
other lines are fixed
#elif PLATFORM_ID=EM1206 or PLATFORM_ID=EM1206W
    #define WLN_CLK PL_IO_NUM_14
    #define WLN_CS PL_IO_NUM_15
    #define WLN_DI PL_IO_NUM_12
    #define WLN_DO PL_IO_NUM_13
    #define WLN_RST PL_IO_NUM_11
#else
    'EM1000, NB1010,...
    #define WLN_CLK PL_IO_NUM_53
    #define WLN_CS PL_IO_NUM_49
    #define WLN_DI PL_IO_NUM_52
    #define WLN_DO PL_IO_NUM_50
    #define WLN_RST PL_IO_NUM_51
```

```
#endif
```

5. Add **include "wln\trunk\wln.tbh"** to the includes section of the global.tbh file.
  6. Add [wln\\_proc\\_timer\(\)](#) to the [on\\_sys\\_timer\(\)](#) event handler code (this library assumes that this event is generated twice per second).
  7. Add [wln\\_proc\\_data\(\)](#) to the [on\\_sock\\_data\\_arrival\(\)](#) event handler code.
  8. Add [wln\\_proc\\_task\\_complete\(\)](#) to the [on\\_wln\\_task\\_complete\(\)](#) event handler code. Pass *completed\_task* argument of [on\\_wln\\_task\\_complete\(\)](#) directly to [wln\\_proc\\_task\\_complete\(\)](#).
  9. Add [wln\\_proc\\_event\(\)](#) to the [on\\_wln\\_event\(\)](#) event handler code. Pass *wln\_event* argument of [on\\_wln\\_event\(\)](#) directly to [wln\\_proc\\_event\(\)](#).
  10. Create empty [callback function](#) bodies (presumably in device.tbs): [callback\\_wln\\_ok\(\)](#), [callback\\_wln\\_failure\(\)](#), [callback\\_wln\\_pre\\_buffrq\(\)](#), [callback\\_wln\\_rescan\\_result\(\)](#). Hint: copy from declarations in wln.tbh or from our [code example](#).
  11. Add **ga1000fw.bin** file to your project. This is the firmware file for the GA1000 Wi-Fi add-on module. You can get it at <http://tibbo.com/downloads/basic/firmware.html>.
  12. Call [wln\\_start\(\)](#) from somewhere. The no-brainer decision is to call from the [on\\_sys\\_init\(\)](#) event handler. Note that [wln\\_start\(\)](#) may fail, so it is wise to check the returned status code.
- All of the above is illustrated in a [code example](#).

### If you are going to use WPA/WPA2 security

1. Add [#define WLN\\_WPA\\_1](#) to the defines section of the global.tbh file.
2. Add an empty [callback function](#) body (presumably in device.tbs) for [callback\\_wln\\_mkey\\_progress\\_update\(\)](#).
3. Use [wln\\_wpa\\_mkey\\_get\(\)](#) to calculate a pre-shared master key, which is required for WPA/WPA2 security. Assign this function's output result to the *key* argument of the [wln\\_start\(\)](#) function.



[Wln\\_wpa\\_mkey\\_get\(\)](#) takes up to two minutes to complete. [Trying WPA](#) code example not only shows how to deal with WPA/WPA2, but also how to avoid calculating the pre-shared master key repeatedly.

## Operation Details

The operation of the WLN library can be observed in the [debug mode](#) by adding [#define WLN\\_DEBUG\\_PRINT\\_1](#) to the defines section of the global.tbh file of your project. A wealth of status information will then be printed in the console pane as the WLN library operates.

Once the [wln\\_start\(\)](#) is called, the WLN library will attempt to bring up the Wi-Fi interface, then find the specified wireless network and associate with it. The library uses active scanning ([wln.activescan](#)), which means that it can handle wireless networks that do not broadcast their SSIDs. The operation is persistent -- the library will repeatedly try to find the target wireless network and associate with it. There is no limit on the number of attempts. If the association with the wireless network is lost, the library will try to find the network and associate with it again. If

there are several access points with the same SSID (name) in range, the library will always choose the access point with the strongest signal.

A buffer space of 5 to 8 pages is required for the library to operate. During `wln_start()` execution, the library will check if the required buffer space is available and call `callback_wln_pre_buffrq()`<sup>[730]</sup> if more space is needed. Once successful association is achieved, `callback_wln_ok()`<sup>[729]</sup> is called. If scanning or association fails, `callback_wln_failure()`<sup>[730]</sup> is invoked to notify your system of the fact. Current association status can also be checked through `wln_check_association()`<sup>[728]</sup>.

One of the most important features of the WLN library is the support for WPA/WPA2 security. The library will associate your device with any access point configured for WPA-PSK, WPA2-PSK, or mixed WPA-PSK/WPA2-PSK modes.



To connect to an access point configured for the mixed WPA-PSK/WPA2-PSK mode, use WPA2 on the device side. At the moment, WPA security will not work correctly on ad-hoc networks.

Using WPA1 or WPA2 involves calculating the pre-shared master key.

`Wln_wpa_mkey_get()`<sup>[727]</sup> is provided for key calculation. This function takes up to two minutes to complete. Fortunately, you don't have to recalculate the key all the time -- see `Trying WPA`<sup>[717]</sup> code example for details. While `wln_wpa_mkey_get()` is executing, `callback_wln_mkey_progress_update()`<sup>[731]</sup> is called periodically to tell your application of the calculation progress.

The library can simultaneously maintain association with the selected access point and search for another access point with the same or different SSID (name). The search is initiated through `wln_rescan()`<sup>[726]</sup> and delivers the result via `callback_wln_rescan_result()`<sup>[731]</sup>. The primary purpose of rescanning is to find out if there are access points in range that offer a better signal than the current access point. Your application can switch to another access point by calling `wln_change()`<sup>[725]</sup>. For illustration see `Roaming Between Access Points`<sup>[716]</sup> code example.

Some access points disassociate devices after a period of inactivity. To prevent this, you can add `#define WLN_KEEP_ALIVE 1`<sup>[721]</sup> to your project. The WLN library will then periodically send out broadcast UDP datagrams (the period is defined by `WLN_KEEP_ALIVE_TIMEOUT`<sup>[721]</sup>). This is normally enough to prevent access points from kicking your device out.

Calling `wln_stop()`<sup>[725]</sup> terminates library operation and shuts down the Wi-Fi interface. Related buffers are released at that time.

## Code Examples

*Projects in the Code Examples section are published on our website under the name "test\_wln\_lib".*

In this section:

[Step 1: The Simplest Example](#)<sup>[708]</sup>

[Step 2: Adding TCP Comms](#)<sup>[710]</sup>

[Step 3: Trying WPA](#)<sup>[711]</sup>

[Step 4: Roaming Between Access Points](#)<sup>[716]</sup>

## Step 1: The Simplest Example

*This and other projects in the Code Examples section are published on our website under the name "test\_wln\_lib".*

Let's start with a simple example of connecting to an access point named "TIBB1", which is configured for WEP64 security. The password is "12345678AB". All your code really has to do is start the "Wi-Fi engine" by calling [wln\\_start\(\)](#)<sup>[724]</sup>.

To illustrate the use of callback procedures, we set green status LED on in [callback\\_wln\\_ok\(\)](#)<sup>[729]</sup>. We turn this LED off in [callback\\_wln\\_failure\(\)](#)<sup>[730]</sup>.

Debug output we've got after running the code:

```
WLN> ---START---
WLN> ACTIVE SCAN for TIBB1
WLN> ASSOCIATE with TIBB1 (bssid: 192.63.14.197.236.216, ch: 11)
WLN> ---OK(associated in WEP64, WEP128, or no-security mode)---
```

You can test the "association persistence" by turning your access point off and on. You will see how the library will restore the association:

```
WLN> ERROR: disassociation (or link loss with the access point)
WLN> ACTIVE SCAN for TIBB1
WLN> ERROR: access point not found
WLN> ACTIVE SCAN for TIBB1
WLN> ERROR: access point not found
...
WLN> ACTIVE SCAN for TIBB1
WLN> ASSOCIATE with TIBB1 (bssid: 192.63.14.197.236.216, ch: 11)
WLN> ---OK(associated in WEP64, WEP128, or no-security mode)---
```

And here is the code itself...

```
global.tbh:

'DEFINES-----
#define WLN_DEBUG_PRINT 1

#if PLATFORM_ID=EM500 or PLATFORM_ID=EM500W
    #define WLN_RESET_MODE 1 'there will be no dedicated reset, and all
```

```

other lines are fixed
#elif PLATFORM_ID=EM1206 or PLATFORM_ID=EM1206W
    #define WLN_CLK PL_IO_NUM_14
    #define WLN_CS PL_IO_NUM_15
    #define WLN_DI PL_IO_NUM_12
    #define WLN_DO PL_IO_NUM_13
    #define WLN_RST PL_IO_NUM_11
#else
    'EM1000, NB1010,...
    #define WLN_CLK PL_IO_NUM_53
    #define WLN_CS PL_IO_NUM_49
    #define WLN_DI PL_IO_NUM_52
    #define WLN_DO PL_IO_NUM_50
    #define WLN_RST PL_IO_NUM_51
#endif

'INCLUDES-----
include "sock\trunk\sock.tbh" 'this lib is necessary for the WLN lib's
operation
include "wln\trunk\wln.tbh"

```

**main.tbs:**

```

include "global.tbh"

'=====
sub on_sys_init()
    if wln_start("TIBB1",WLN_SECURITY_MODE_WEP64,"12345678AB",
PL_WLN_DOMAIN_FCC)<>WLN_STATUS_OK then
        sys.halt
    end if
end sub

'-----
sub on_sys_timer()
    wln_proc_timer()
end sub

'-----
sub on_sock_data_arrival()
    wln_proc_data()
end sub

'-----
sub on_wln_task_complete(completed_task as pl_wln_tasks)
    wln_proc_task_complete(completed_task)
end sub

'-----
sub on_wln_event(wln_event as pl_wln_events)
    wln_proc_event(wln_event)
end sub

```

**device.tbs:**

```

include "global.tbh"

```

```

'=====
sub callback_wln_ok()
    pat.play("G~", PL_PAT_CANINT)
end sub

'-----

sub callback_wln_failure(wln_state as en_wln_status_codes)
    pat.play("-", PL_PAT_CANINT)
end sub

'-----

sub callback_wln_pre_buffrq(required_buff_pages as byte)
end sub

'-----

sub callback_wln_rescan_result(current_rssi as byte, scan_rssi as byte,
different_ap as no_yes)
end sub

```

## Step 2: Adding TCP Comms

*This and other projects in the Code Examples section are published on our website under the name "test\_wln\_lib".*

Now let's take the previous example and create a TCP socket that will accept connections over the Wi-Fi interface. We will make a simple loopback socket that echoes back the data.



May we suggest our very own [I/O NINJA](#) terminal/sniffer software as the tool for testing the loopback socket? Hint: use Connection Socket plugin.

Only main.tbs needs to be changed from the [previous example](#)<sup>[708]</sup>. The socket is configured in [on\\_sys\\_init\(\)](#)<sup>[533]</sup>. Notice how we don't just pick a random socket number to use. We obtain the socket from the [SOCK library](#)<sup>[664]</sup> by calling [sock\\_get\(\)](#)<sup>[667]</sup>. This is very important! Once any part of your project uses the SOCK library (and WLN library does), all other parts of your project must do the same. Mess will ensue if you fail to handle socket numbers correctly.

In the code below, we first call [wln\\_start\(\)](#)<sup>[724]</sup> and then configure the loopback socket. There is no significance to this order and you can reverse it. Same goes for [on\\_sock\\_data\\_arrival\(\)](#)<sup>[489]</sup>. There is no special reason to call [wln\\_proc\\_data\(\)](#)<sup>[728]</sup> first, and handle the loopback socket next. You can reverse the order and everything will still work.

```

main.tbs:

include "global.tbh"

dim tcp_sock as byte

'=====
sub on_sys_init()
    wln.ip="192.168.1.50" '<--- set suitable IP here

    if wln_start("TIBB1", WLN_SECURITY_MODE_WEP64, "12345678AB",

```

```
PL_WLN_DOMAIN_FCC)<>WLN_STATUS_OK then
    sys.halt
end if

'configure loopback socket
tcp_sock=sock_get("TCP")
sock.num=tcp_sock
sock.rxbufirq(1)
sock.txbufirq(1)
sys.bufalloc
sock.protocol=PL_SOCK_PROTOCOL_TCP
sock.localportlist="1000"
sock.allowedinterfaces="WLN"
sock.inconmode=PL_SOCK_INCONMODE_ANY_IP_ANY_PORT
sock.reconmode=PL_SOCK_RECONMODE_3
end sub

'-----
sub on_sys_timer()
    wln_proc_timer()
end sub

'-----
sub on_sock_data_arrival()
    wln_proc_data()

    'loopback tcp data
    if sock.num=tcp_sock then
        sock.setdata(sock.getdata(sock.txfree))
        sock.send
    end if
end sub

'-----
sub on_wln_task_complete(completed_task as pl_wln_tasks)
    wln_proc_task_complete(completed_task)
end sub

'-----
sub on_wln_event(wln_event as pl_wln_events)
    wln_proc_event(wln_event)
end sub
```

### Step 3: Trying WPA

*This and other projects in the Code Examples section are published on our website under the name "test\_wln\_lib".*

OK then, now let's try to associate with an access point configured for WPA2-PSK security. You can try WPA-PSK by yourself.



If your access point is configured for WPA-PSK/WPA2-PSK mode, select WPA2 on the device side.

With WPA, things get a bit trickier because of a pre-shared master key (PMK). This is the actual password used between your device and the access point. The key is

calculated from a "human" password (that you define) and the access point's SSID (name). [Wln\\_wpa\\_mkey\\_get\(\)](#)<sup>[727]</sup> does the math. The bad news is that it takes 2 minutes... yep, sorry, 8000 iterations involving [sha1](#)<sup>[223]</sup> need that long. The good news is that you only need to do this once after changing the password or SSID. You can then just save the resulting key for the future use. [STG library](#)<sup>[668]</sup> comes handy for this.

Our project now has a new function -- `connect_to_ap()` -- that calls [wln\\_start\(\)](#)<sup>[724]</sup>. This function takes all the same arguments as `wln_start()`. `connect_to_ap()` stores the SSID, human password, and pre-shared master key into the EEPROM. `Wln_wpa_mkey_get()` is only called if the SSID or human password change, or if the "PMK" setting is invalid. For the "PMK" setting to be valid, it must contain a 32-character string -- the PMK always has this length. Keeping the PMK in the EEPROM allows us to avoid recalculating it -- a huge time saver.

[Callback\\_wln\\_mkey\\_progress\\_update\(\)](#)<sup>[731]</sup> is called repeatedly from within `wln_wpa_mkey_get()` while the PMK calculation is in progress. We put [pat.play](#)<sup>[365]</sup> there to assure the user that the system isn't dead.

Below is the debug output we've got when connecting to the access point named "TIBB1".

```
WLN> ---START---
WLN> ACTIVE SCAN for TIBB1
WLN> ASSOCIATE with TIBB1 (bssid: 192.63.14.197.236.216, ch: 11)
WLN> Pre-associated for WPA1-PSK or WPA2-PSK, starting handshake process
WLN> Pairwise handshake, process step 1 of 4
WLN> Pairwise handshake, process step 2 of 4
WLN> Pairwise handshake, process step 3 of 4
WLN> Pairwise handshake, process step 4 of 4
WLN> ---OK(associated in WPA2-PSK mode)---
```

- Some access points, notably CISCO devices, are so impatient during the WPA1/WPA2 handshaking process, that printing debug info makes them timeout. If you notice that the WLN library is stuck in the endless association loop, and you are sure that your password is set correctly, then try disabling debug printing! It may be the reason why the association fails.

The new iteration of our project is listed below. Notice how we set [#define WLN\\_WPA 1](#)<sup>[721]</sup> in `global.tbh`. This is necessary to enable WPA support.

We show one more trick in this example. Instead of having a listening TCP socket, we have a loopback socket that connects to a certain destination IP whenever there is a successful association. To ensure persistent connection, we put a polling code into [on\\_sys\\_timer](#)<sup>[533]</sup>. Not the most beautiful of solutions, but gets the job done. The TCP connection is discarded whenever we get [callback\\_wln\\_failiure\(\)](#)<sup>[730]</sup>.



Test outgoing connections by setting [sock.targetip](#)<sup>[506]</sup> to your PC's address and using our [I/O NINJA](#) terminal/sniffer software. This software has a unique Listener Socket plugin that will allow your PC to receive incoming TCP connections.

```
global.tbh:
```

```
'DEFINES-----
#define WLN_DEBUG_PRINT 1
#define WLN_WPA 1

#if PLATFORM_ID=EM500 or PLATFORM_ID=EM500W
    #define WLN_RESET_MODE 1 'there will be no dedicated reset, and all
other lines are fixed
#elif PLATFORM_ID=EM1206 or PLATFORM_ID=EM1206W
    #define WLN_CLK PL_IO_NUM_14
    #define WLN_CS PL_IO_NUM_15
    #define WLN_DI PL_IO_NUM_12
    #define WLN_DO PL_IO_NUM_13
    #define WLN_RST PL_IO_NUM_11
#else
    'EM1000, NB1010,...
    #define WLN_CLK PL_IO_NUM_53
    #define WLN_CS PL_IO_NUM_49
    #define WLN_DI PL_IO_NUM_52
    #define WLN_DO PL_IO_NUM_50
    #define WLN_RST PL_IO_NUM_51
#endif

'INCLUDES-----
include "sock\trunk\sock.tbh" 'this lib is necessary for the WLN lib's
operation
include "settings\trunk\settings.tbh" 'this lib is necessary to save pre-
shared master key
includepp "settings.txt"
include "wln\trunk\wln.tbh"

'DECLARATIONS-----
declare function connect_to_ap(byref ap_name as string, security_mode as
pl_wln_security_modes, byref key as string, domain as pl_wln_domains) as
en_wln_status_codes
declare tcp_sock as byte
```

**main.tbs:**

```
include "global.tbh"

dim tcp_sock as byte

'=====
sub on_sys_init()
    wln.ip="192.168.1.50" '<---
set suitable IP here

    stg_start()

    if connect_to_ap("TIBB1",WLN_SECURITY_MODE_WPA2,"12345678",
PL_WLN_DOMAIN_FCC)<>WLN_STATUS_OK then
        sys.halt
    end if

    'configure loopback socket
tcp_sock=sock_get("TCP")
sock.num=tcp_sock
sock.rxbuffrq(1)
```

```

    sock.txbufreq(1)
    sys.buffalloc
    sock.protocol=PL_SOCK_PROTOCOL_TCP
    sock.targetinterface=PL_SOCK_INTERFACE_WLN
    sock.targetip="192.168.1.67"           '<----- set
suitable target IP here
    sock.targetport=1000                 '<----- set
suitable target port here
end sub

'-----
sub on_sys_timer()
    wln_proc_timer()

    'this code ensures persistent connection to the target IP
    if wln_check_association()=PL_WLN_ASSOCIATED then
        sock.num=tcp_sock
        if sock.statesimple=PL_SSTS_CLOSED then
            sock.connect
        end if
    end if
end sub

'-----
sub on_sock_data_arrival()
    wln_proc_data()

    'loopback tcp data
    if sock.num=tcp_sock then
        sock.setdata(sock.getdata(sock.txfree))
        sock.send
    end if
end sub

'-----
sub on_wln_task_complete(completed_task as pl_wln_tasks)
    wln_proc_task_complete(completed_task)
end sub

'-----
sub on_wln_event(wln_event as pl_wln_events)
    wln_proc_event(wln_event)
end sub

```

**device.tbs:**

```

include "global.tbh"

'=====
function connect_to_ap(byref ap_name as string, security_mode as
pl_wln_security_modes, byref key as string, domain as pl_wln_domains) as
en_wln_status_codes
    dim pmk as string(32)

    #if WLN_WPA
        if security_mode=WLN_SECURITY_MODE_WPA1 or
security_mode=WLN_SECURITY_MODE_WPA2 then
            if stg_get("APN",0)<>ap_name or stg_get("PW",0)<>key or
stg_sg("PMK",0,pmk,EN_STG_GET)<>EN_STG_STATUS_OK then

```

```
        'recalculate the key
        pmk=wln_wpa_mkey_get(key,ap_name)
        stg_set("PMK",0,pmk)
        stg_set("APN",0,ap_name)
        stg_set("PW",0,key)
    else
        pmk=stg_get("PMK",0) 'the key stays the same
    end if
else
    pmk=key
end if
#else
    pmk=key
#endif

    connect_to_ap=wln_start(ap_name,security_mode,pmk,domain)
end function

'-----
sub callback_wln_ok()
    pat.play("G~",PL_PAT_CANINT)
end sub

'-----
sub callback_wln_failure(wln_state as en_wln_status_codes)
    pat.play("-",PL_PAT_CANINT)
    sock.num=tcp_sock
    sock.discard
end sub

'-----
sub callback_wln_pre_buffrq(required_buff_pages as byte)
end sub

'-----
sub callback_wln_rescan_result(current_rssi as byte, scan_rssi as byte,
different_ap as no_yes)
end sub

'-----
sub callback_wln_mkey_progress_update(progress as byte)
    pat.play("B-**",PL_PAT_CANINT)
end sub

'-----
sub callback_stg_error(byref stg_name_or_num as string,index as byte,status
as en_stg_status_codes)
end sub

'-----
sub callback_stg_pre_get(byref stg_name_or_num as string,index as byte,byref
stg_value as string)
end sub

'-----
sub callback_stg_post_set(byref stg_name_or_num as string, index as byte,
byref stg_value as string)
end sub
```

```

settings.txt (the underlying configuration file):

>>APN E      S      1      0      32      A      ^
    Access point name
>>PW  E      S      1      0      32      A      ^
    Password
>>PMK E      S      1      32     32      A
12345678901234567890123456789012 Pre-shared master key

#define STG_DESCRIPTOR_FILE "settings.txt"
#define STG_MAX_NUM_SETTINGS 3
#define STG_MAX_SETTING_NAME_LEN 3
#define STG_MAX_SETTING_VALUE_LEN 32

```

## Step 4: Roaming Between Access Points

*This and other projects in the Code Examples section are published on our website under the name "test\_wln\_lib".*

Finally, here is the coolest example of them all -- the code for a mobile device that roams between several access points that all have the same SSID (name). Typically, you use such a setup to create a larger wireless network. The example from the previous topic would work, but not very well if your device was mobile.

Say, you walk around with your GA1000-based gadget in your pocket. At boot, it would execute [wln\\_start\(\)](#)<sup>[724]</sup>, which would in turn search for the target wireless network, find several access points, and select the one with the strongest signal. The GA1000 would then latch onto this access point and won't let go until the signal gets so bad that the association is lost. The WLN library would then try to find a better access point to work with. Sounds like there is no problem, right?

Wrong! In practice, you will find that at a certain distance from the access point you get into the "grey area of communications" where the link between your gadget and the access point becomes spotty, but not quite bad enough for the association to fail. And, since the association won't quite fail, your device won't try to find a better access point to link to. Meanwhile, you will experience data delivery delays, unstable comms, etc.

Here is the solution. Additional code in [on\\_sys\\_timer](#)<sup>[533]</sup> periodically checks current signal strength ([wln.rssi](#)<sup>[568]</sup>). Whenever it falls below a predefined constant `RSSI_THRESHOLD`, the code will do [wln\\_rescan\(\)](#)<sup>[726]</sup> in an attempt to "find a better deal". Rescan result is checked in [callback\\_wln\\_rescan\\_result\(\)](#)<sup>[731]</sup>. If a different and better access point is found, [wln\\_change\(\)](#)<sup>[725]</sup> will switch your device to using it.

It is important to understand why the program searches for better access points only when the signal drops below `RSSI_THRESHOLD`. Scanning is a disruptive process that temporarily interferes with data comms. There is no reason to scan if the current signal is perfect! Exactly what value should `RSSI_THRESHOLD` have depends on your device, antenna, etc. Find it through trial and error.

```

global.tbh:

```

```

'DEFINES-----

#define WLN_DEBUG_PRINT 1
#define WLN_WPA 1

```

```

#if PLATFORM_ID=EM500 or PLATFORM_ID=EM500W
    #define WLN_RESET_MODE 1 'there will be no dedicated reset, and all
other lines are fixed
#elif PLATFORM_ID=EM1206 or PLATFORM_ID=EM1206W
    #define WLN_CLK PL_IO_NUM_14
    #define WLN_CS PL_IO_NUM_15
    #define WLN_DI PL_IO_NUM_12
    #define WLN_DO PL_IO_NUM_13
    #define WLN_RST PL_IO_NUM_11
#else
    'EM1000, NB1010,...
    #define WLN_CLK PL_IO_NUM_53
    #define WLN_CS PL_IO_NUM_49
    #define WLN_DI PL_IO_NUM_52
    #define WLN_DO PL_IO_NUM_50
    #define WLN_RST PL_IO_NUM_51
#endif

'INCLUDES-----
include "sock\trunk\sock.tbh" 'this lib is necessary for the WLN lib's
operation
include "settings\trunk\settings.tbh" 'this lib is necessary to save pre-
shared master key
includepp "settings.txtxt"
include "wln\trunk\wln.tbh"

'DECLARATIONS-----
declare function connect_to_ap(byref ap_name as string, security_mode as
pl_wln_security_modes, byref key as string, domain as pl_wln_domains) as
en_wln_status_codes
declare tcp_sock as byte

const RESCAN_PERIOD=30 '-----
change as needed
const RSSI_THRESHOLD=200 '----- change
as needed
const AP_NAME="TIBB1" '-----
change as needed
const AP_PASSWORD="12345678" '----- change
as needed
const AP_SECURITY=WLN_SECURITY_MODE_WPA2 '----- change as
needed
'use WLN_SECURITY_MODE_DISABLED, WLN_SECURITY_MODE_WEP64,
WLN_SECURITY_MODE_WEP128, WLN_SECURITY_MODE_WPA1, or WLN_SECURITY_MODE_WPA2

```

**main.tbs:**

```

include "global.tbh"

'-----
dim tcp_sock as byte
dim rescan_tmr as byte

'=====
sub on_sys_init()
    wln.ip="192.168.1.50" '-----
set suitable IP here

    stg_start()

```

```

        if connect_to_ap(AP_NAME,AP_SECURITY,AP_PASSWORD,PL_WLN_DOMAIN_FCC)
<>WLN_STATUS_OK then
            sys.halt
        end if

        'configure loopback socket
        tcp_sock=sock_get("TCP")
        sock.num=tcp_sock
        sock.rxbufirq(1)
        sock.txbufirq(1)
        sys.buffalloc
        sock.protocol=PL_SOCKET_PROTOCOL_TCP
        sock.targetinterface=PL_SOCKET_INTERFACE_WLN
        sock.targetip="192.168.1.67"           '<----- set
suitable target IP here
        sock.targetport=1000                 '<----- set
suitable target port here
    end sub

'-----
sub on_sys_timer()
    wln_proc_timer()

    if wln_check_association()=PL_WLN_ASSOCIATED then
        'this code ensures persistent connection to the target IP
        sock.num=tcp_sock
        if sock.statesimple=PL_SSTS_CLOSED then
            sock.connect
        end if

        'this code handles access point roaming
        if rescan_tmr>0 then
            rescan_tmr=rescan_tmr-1
            if rescan_tmr=0 then
                rescan_tmr=RESCAN_PERIOD
                if wln.rssi<=RSSI_THRESHOLD then
                    wln_rescan(AP_NAME)
                end if
            end if
        end if
    else
        rescan_tmr=RESCAN_PERIOD
    end if
end sub

'-----
sub on_sock_data_arrival()
    wln_proc_data()

    'loopback tcp data
    if sock.num=tcp_sock then
        sock.setdata(sock.getdata(sock.txfree))
        sock.send
    end if
end sub

'-----
sub on_wln_task_complete(completed_task as pl_wln_tasks)
    wln_proc_task_complete(completed_task)
end sub

```

```

'-----
sub on_wln_event(wln_event as pl_wln_events)
    wln_proc_event(wln_event)
end sub

device.tbs:

include "global.tbh"

'=====
function connect_to_ap(byref ap_name as string, security_mode as
pl_wln_security_modes, byref key as string, domain as pl_wln_domains) as
en_wln_status_codes
    dim pmk as string(32)

    #if WLN_WPA
        if security_mode=WLN_SECURITY_MODE_WPA1 or
security_mode=WLN_SECURITY_MODE_WPA2 then
            if stg_get("APN",0)<>ap_name or stg_get("PW",0)<>key or
stg_sg("PMK",0,pmk,EN_STG_GET)<>EN_STG_STATUS_OK then
                'recalculate the key
                pmk=wln_wpa_mkey_get(key,ap_name)
                stg_set("PMK",0,pmk)
                stg_set("APN",0,ap_name)
                stg_set("PW",0,key)
            else
                pmk=stg_get("PMK",0) 'the key stays the same
            end if
        else
            pmk=key
        end if
    #else
        pmk=key
    #endif

    connect_to_ap=wln_start(ap_name,security_mode,pmk,domain)
end function

'-----
sub callback_wln_ok()
    pat.play("G~",PL_PAT_CANINT)
end sub

'-----
sub callback_wln_failure(wln_state as en_wln_status_codes)
    pat.play("-",PL_PAT_CANINT)
    sock.num=tcp_sock
    sock.discard
end sub

'-----
sub callback_wln_pre_buffrq(required_buff_pages as byte)
end sub

'-----
sub callback_wln_rescan_result(current_rssi as byte, scan_rssi as byte,
different_ap as no_yes)
    dim s as string(32)

```

```

    if different_ap=NO or scan_rssi<current_rssi or scan_rssi-
current_rssi<5 then
        exit sub
    end if

    select case AP_SECURITY
    case WLN_SECURITY_MODE_DISABLED:
        s=""
    case WLN_SECURITY_MODE_WEP64,WLN_SECURITY_MODE_WEP128:
        s=AP_PASSWORD
    case else:
        s=stg_get("PMK",0)
    end select

    wln_change(AP_NAME,AP_SECURITY,s)
end sub

'-----
sub callback_wln_mkey_progress_update(progress as byte)
    pat.play("B-**",PL_PAT_CANINT)
end sub

'-----
sub callback_stg_error(byref stg_name_or_num as string,index as byte,status
as en_stg_status_codes)
end sub

'-----
sub callback_stg_pre_get(byref stg_name_or_num as string,index as byte,byref
stg_value as string)
end sub

'-----
sub callback_stg_post_set(byref stg_name_or_num as string, index as byte,
byref stg_value as string)
end sub

```

**settings.txt (the underlying configuration file):**

```

>>APN E      S      1      0      32      A      ^
    Access point name
>>PW  E      S      1      0      32      A      ^
    Password
>>PMK E      S      1      32      32      A
12345678901234567890123456789012 Pre-shared master key

#define STG_DESCRIPTOR_FILE "settings.txt"
#define STG_MAX_NUM_SETTINGS 3
#define STG_MAX_SETTING_NAME_LEN 3
#define STG_MAX_SETTING_VALUE_LEN 32

```

## Library Defines (Options)

Any of the options below look cryptic? Read the [Operation Details](#)<sup>[706]</sup> section.

### **WLN\_DEBUG\_PRINT (default= 0)**

0- no debug information.

1- print debug information into the output pane. Debug printing only works when the project is in the [debug mode](#)<sup>[27]</sup>. However, still set this option to 0 for release, as this will save memory and code space.

- Some access points, notably CISCO devices, are so impatient during the WPA1/WPA2 handshake process, that printing debug info makes them timeout. If you notice that the WLN library is stuck in the endless association loop, and you are sure that your password is set correctly, then try disabling debug printing!

### **WLN\_RESET\_MODE (default= 0)**

0- dedicated RST line. Remember to define this line's mapping with WLN\_RST.

1- CS and CLK lines are to generate reset. Use the reset generation circuit as shown on diagram B in [Connecting GA1000](#)<sup>[201]</sup> topic.

### **WLN\_RST (default= PL\_IO\_NULL)**

RST line mapping. Only relevant when WLN\_RESET\_MODE= 0.

### **WLN\_CS (default= PL\_IO\_NULL)**

CS line mapping.

### **WLN\_DI (default= PL\_IO\_NULL)**

DI line mapping.

### **WLN\_DO (default= PL\_IO\_NULL)**

DO line mapping.

### **WLN\_CLK (default= PL\_IO\_NULL)**

CLK line mapping.

### **WLN\_KEEP\_ALIVE (default= 0)**

- 0- do not send keepalive UDP datagrams (saves code and memory space).
- 1- send keepalive UDP datagrams to prevent disassociation from the access point.

### **WLN\_KEEP\_ALIVE\_TOUT (default= 120)**

Time interval, in 1/2 second increments, between keepalive UDP datagrams. This assumes that [on\\_sys\\_timer](#)<sup>[533]</sup> runs at 0.5 second intervals.

Only relevant when WLN\_KEEP\_ALIVE=1.

### **WLN\_WPA (default= 0)**

- 0- disable WPA1/WPA2 support (saves code and memory space).
- 1- enable WPA1/WPA2 support.

## **En\_wln\_status\_codes**

Several procedures in the library utilize the en\_wln\_status\_codes enum. This enum has the following members:

- 0- WLN\_STATUS\_OK: Success.
- 1- WLN\_STATUS\_OUT\_OF\_SOCKETS: No free sockets available for the library to operate.
- 2- WLN\_STATUS\_INSUFFICIENT\_BUFFER\_SPACE: Insufficient number of buffer pages available and the call to [callback\\_wln\\_pre\\_buffrq](#)<sup>[730]</sup> failed to cure the problem.
- 3- WLN\_STATUS\_MISSING\_FIRMWARE\_FILE: You forgot to [add](#)<sup>[132]</sup> "ga1000fw.bin" file to your project.
- 4- WLN\_STATUS\_BOOT\_FAILURE: Wi-Fi hardware could not be booted (improperly connected? turned off? ...).
- 5- WLN\_STATUS\_INVALID\_SECURITY\_MODE: Incorrect security mode specified in the security\_mode argument of the [wln\\_start](#)<sup>[724]</sup> function.
- 6- WLN\_STATUS\_INVALID\_WEP\_KEY: WEP64 or WEP128 was specified when calling to [wln\\_start](#)<sup>[724]</sup>, and the length of the key argument is incorrect. The length must be 10 HEX characters (characters `0`~`9`, `A`~`F`, or `a`~`f` ) for WEP64, and 26 HEX characters for WEP128.
- 7- WLN\_STATUS\_SCANNING\_FAILURE: Failed to discover the target wireless network.
- 8- WLN\_STATUS\_ASSOCIATION\_FAILURE: Failed to associate with the target

wireless network.

9- WLN\_STATUS\_DISASSOCIATION: Wi-Fi interface got disassociated from the target wireless network.

10- WLN\_STATUS\_UNEXPECTED\_ERROR: Well, this is something... unexpected :).

11- WLN\_STATUS\_NOT\_STARTED: The procedure couldn't be executed because the library hasn't been started (call [wln\\_start\(\)](#)<sup>[724]</sup> first).

12- WLN\_STATUS\_BUSY: The procedure couldn't be executed because the library is busy. Try again after a short delay.

## Library Procedures

In this section:

- [Wln\\_get\\_info\(\)](#)<sup>[723]</sup>
- [Wln\\_start\(\)](#)<sup>[724]</sup>
- [Wln\\_stop\(\)](#)<sup>[725]</sup>
- [Wln\\_change\(\)](#)<sup>[725]</sup>
- [Wln\\_rescan\(\)](#)<sup>[726]</sup>
- [Wln\\_wpa\\_mkey\\_get\(\)](#)<sup>[727]</sup>
- [Wln\\_check\\_association\(\)](#)<sup>[728]</sup>
- [Wln\\_proc\\_timer\(\)](#)<sup>[728]</sup>
- [Wln\\_proc\\_data\(\)](#)<sup>[728]</sup>
- [Wln\\_proc\\_task\\_complete\(\)](#)<sup>[729]</sup>
- [Wln\\_proc\\_event\(\)](#)<sup>[729]</sup>
- [Callback\\_wln\\_ok\(\)](#)<sup>[729]</sup>
- [Callback\\_wln\\_failure\(\)](#)<sup>[730]</sup>
- [Callback\\_wln\\_pre\\_buffrq\(\)](#)<sup>[730]</sup>
- [Callback\\_wln\\_mkey\\_progress\\_update\(\)](#)<sup>[731]</sup>
- [Callback\\_wln\\_rescan\\_result\(\)](#)<sup>[731]</sup>

### Wln\_get\_info()

<b>Description:</b>	API procedure, returns library-specific information according to the requested information element.
<b>Syntax:</b>	<b>function wln_get_info</b> (info_element as <b>wln_info_elements</b> , byref extra_data as string) as string
<b>Returns:</b>	Requested data in <i>string</i> form
<b>See Also:</b>	<a href="#">About_get_info() API Functions</a> <sup>[577]</sup>

Part	Description
info_element	Information element being requested: 0- WLN_INFO_ELEMENT_REQUIRED_BUFFERS: total number

of buffer pages required for the library to operate.

`extra_data` When `info_element = WLN_INFO_ELEMENT_REQUIRED_BUFFERS`, set this argument to the desired security mode. This is necessary because the security mode affects the amount of required buffer space. Available security modes are defined by the `pl_wln_security_modes` enum (see `security_mode` argument of [wln\\_start](#)<sup>[724]</sup>). Since the `extra_data` argument is of the string type, you have to convert the security mode into a string form, i.e. like this: `str(WLN_SECURITY_MODE_WPA1)`.

## Details

---

### Wln\_start()

**Description:** API procedure, commences attempts to bring up (boot) the Wi-Fi interface, find and associate with the specified wireless network, and then keep associated at all times.

**Syntax:** **wln\_start**(**byref** `ap_name` **as string**, `security_mode` **as pl\_wln\_security\_modes**, **byref** `key` **as string**, `domain` **as pl\_wln\_domains**) **as en\_wln\_status\_codes**

**Returns:** One of these [en\\_wln\\_status\\_codes](#)<sup>[722]</sup>: `WLN_STATUS_OK`, `WLN_STATUS_OUT_OF_SOCKETS`, `WLN_STATUS_INSUFFICIENT_BUFFER_SPACE`, `WLN_STATUS_MISSING_FIRMWARE_FILE`, `WLN_STATUS_BOOT_FAILURE`, `WLN_STATUS_INVALID_SECURITY_MODE`, `WLN_STATUS_INVALID_WEP_KEY`

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>, [The Simplest Example](#)<sup>[708]</sup>

Part	Description
<code>ap_name</code>	The SSID (name) of the wireless network to associate with.
<code>security_mode</code>	One of <code>pl_wln_security_modes</code> : 0- <code>WLN_SECURITY_MODE_DISABLED</code> , 1- <code>WLN_SECURITY_MODE_WEP64</code> , 2- <code>WLN_SECURITY_MODE_WEP128</code> , 3- <code>WLN_SECURITY_MODE_WPA1</code> (will be accepted only if <a href="#">WLN_WPA</a> <sup>[721]</sup> is defined as 1), 4- <code>WLN_SECURITY_MODE_WPA2</code> (will be accepted only if <a href="#">WLN_WPA</a> <sup>[721]</sup> is defined as 1)

key	For WEP64 mode, a string of 10 HEX characters (characters `0`~`9`, `A`~`F`, or `a`~`f` ). For WEP128 mode, a string of 26 HEX characters. For WPA1-PSK and WPA2-PSK modes, this is the pre-shared master key, which is <u>not</u> the "human" password. The key can be calculated using <a href="#">wln_wpa_mkey_get()</a> <sup>[727]</sup> .
domain	Defines the set of channels on which the Wi-Fi interface will operate. Possible values are:  0- PL_WLN_DOMAIN_FCC (default): FCC domain (US). Allowed channels: 1-11.  1- PL_WLN_DOMAIN_EU: European Union. Allowed channels: 1-13.  2- PL_WLN_DOMAIN_JAPAN: Japan. Allowed channels: 1-14.  3- PL_WLN_DOMAIN_OTHER: All other countries. Allowed channels: 1-11.

### Details

WLN library operation is non-blocking. `Wln_start()` will quickly return control to your application and the rest of the library's operation will continue in the background.

The WLN library uses [active scanning](#)<sup>[550]</sup> (`wln.activescan`<sup>[550]</sup>) and, therefore, will be able to find access points that do not broadcast their SSIDs.

If several access points with the same SSID are in range, the WLN library will automatically select the access point with the strongest signal.

## Wln\_stop()

<b>Description:</b>	API procedure, shuts down the Wi-Fi interface.
<b>Syntax:</b>	<b>sub wln_stop()</b>
<b>Returns:</b>	---
<b>See Also:</b>	<a href="#">Step-by-step Usage Instructions</a> <sup>[705]</sup> , <a href="#">Operation Details</a> <sup>[706]</sup>

### Details

Wi-Fi interface shutdown includes the hardware reset of the GA1000 module.

## Wln\_change()

<b>Description:</b>	API procedure, sets a different target wireless network for the WLN library.
<b>Syntax:</b>	<b>function wln_change(byref ap_name as string, security_mode as pl_wln_security_modes, byref key as string) as en_wln_status_codes</b>

- Returns:** One of these [en\\_wln\\_status\\_codes](#)<sup>[722]</sup>: WLN\_STATUS\_OK, WLN\_STATUS\_NOT\_STARTED, WLN\_STATUS\_INVALID\_SECURITY\_MODE, WLN\_STATUS\_INVALID\_WEP\_KEY, WLN\_STATUS\_BUSY
- See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>, [Roaming Between Access Points](#)<sup>[716]</sup>

Part	Description
ap_name	New SSID (name) of the wireless network to associate with.
security_mode	One of pl_wln_security_modes: 0- WLN_SECURITY_MODE_DISABLED, 1- WLN_SECURITY_MODE_WEP64, 2- WLN_SECURITY_MODE_WEP128, 3- WLN_SECURITY_MODE_WPA1 (will be accepted only if <a href="#">WLN_WPA</a> <sup>[721]</sup> is defined as 1), 4- WLN_SECURITY_MODE_WPA2 (will be accepted only if <a href="#">WLN_WPA</a> <sup>[721]</sup> is defined as 1)
key	For WEP64 mode, a string of 10 HEX characters (characters `0`~`9`, `A`~`F`, or `a`~`f` ). For WEP128 mode, a string of 26 HEX characters. For WPA1-PSK and WPA2-PSK modes, this is the pre-shared master key, which is <u>not</u> the "human" password. The key can be calculated using <a href="#">wln_wpa_mkey_get()</a> <sup>[727]</sup> .

### Details

WLN library operation is non-blocking. Wln\_change() will quickly return control to your application and the rest of the library's operation will continue in the background.

The WLN library uses [active scanning](#)<sup>[550]</sup> ([wln.activescan](#)<sup>[556]</sup>) and, therefore, will be able to find access points that do not broadcast their SSIDs.

If several access points with the same SSID are in range, the WLN library will automatically select the access point with the strongest signal.

You can't use this function before calling [wln\\_start\(\)](#)<sup>[724]</sup>.

### Wln\_rescan()

- Description:** API procedure, starts the search for the specified access point in order to obtain its signal strength.
- Syntax:** **function wln\_rescan(byref ap\_name as string) as en\_wln\_status\_codes**
- Returns:** One of these [en\\_wln\\_status\\_codes](#)<sup>[722]</sup>: WLN\_STATUS\_OK, WLN\_STATUS\_NOT\_STARTED, WLN\_STATUS\_BUSY

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>, [Roaming Between Access Points](#)<sup>[716]</sup>

Part	Description
ap_name	The SSID (name) of the access point to search for.

### Details

The purpose of `wln_rescan()` is to help you find out if there is an access point in range that has a "better signal". This function starts the process, which then proceeds in the background without stalling your application. Once the scanning is finished, [callback\\_wln\\_rescan\\_result\(\)](#)<sup>[731]</sup> is called.

If several access points with the same SSID are in range, [callback\\_wln\\_rescan\\_result\(\)](#)<sup>[731]</sup> will return the signal strength for the access point with the strongest signal.

The WLN library uses [active scanning](#)<sup>[550]</sup> ([wln.activescan](#)<sup>[556]</sup>) and, therefore, will be able to find access points that do not broadcast their SSIDs.

You can't use this function before calling [wln\\_start\(\)](#)<sup>[724]</sup>.

## Wln\_wpa\_mkey\_get()

**Description:** API procedure, calculates the pre-shared master key for WPA1 and WPA2 security modes.

**Syntax:** **function wln\_wpa\_mkey\_get(byref password as string, byref ssid as string) as string**

**Returns:** Pre-shared master key string

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>, [Trying WPA](#)<sup>[711]</sup>

Part	Description
password	The "human" password for the access point.
ssid	SSID (name) of the access point.

### Details

In WPA1-PSK and WPA2-PSK security schemes, the password you set and the SSID of the access point are used to calculate a so-called pre-shared master key, which is the actual password used in communications between your device and the access point. The password and the pre-shared master key are not to be confused: the password is the string you manually enter (on the setup page) when configuring the access point. The pre-shared master key is a binary string that you never get to handle directly.

On Tibbo devices, pre-shared master key calculation takes up to 2 minutes. Fortunately, the key needs only be calculated when there is the password or SSID

change.

[Callback wln\\_mkey\\_progress\\_update\(\)](#)<sup>[731]</sup> is called periodically from within `wln_wpa_mkey_get()`. This enables your application to indicate the calculation progress to the user (i.e. by drawing a progress bar on the LCD screen).

## Wln\_check\_association()

**Description:** API procedure, informs whether your device is currently associated with an access point.

**Syntax:** **function wln\_check\_association() as pl\_wln\_association\_states**

**Returns:** 0- PL\_WLN\_NOT\_ASSOCIATED.

1- PL\_WLN\_ASSOCIATED.

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>, [Trying WPA](#)<sup>[711]</sup>

---

### Details

If you are running with no security or WEP security, then using this API call is the same as checking [wln.associationstate](#)<sup>[558]</sup>. For WPA1-PSK and WPA2-PSK security modes, the mere fact that `wln.associationstate` returns 1- PL\_WLN\_ASSOCIATED does not indicate association success. This is because WPA1-PSK and WPA2-PSK additionally involve a complex exchange of "handshake" messages. Only after the handshake is completed that the association is finished and `wln_check_association()` will return 1- PL\_WLN\_ASSOCIATED.

## Wln\_proc\_timer()

**Function:** Event procedure, call it from the [on\\_sys\\_timer\(\)](#)<sup>[533]</sup> event handler.

**Syntax:** **sub wln\_proc\_timer()**

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>, [The Simplest Example](#)<sup>[708]</sup>

### Details

---

## Wln\_proc\_data()

**Function:** Event procedure, call it from the [on\\_sock\\_data\\_arrival\(\)](#)<sup>[489]</sup> event handler.

**Syntax:** **sub wln\_proc\_data()**

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>,  
[The Simplest Example](#)<sup>[708]</sup>

### Details

---

## Wln\_proc\_task\_complete()

**Function:** Event procedure, call it from the [on\\_wln\\_task\\_complete\(\)](#)<sup>[565]</sup> event handler.

**Syntax:** **sub wln\_proc\_task\_complete()**

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>,  
[The Simplest Example](#)<sup>[708]</sup>

### Details

---

## Wln\_proc\_event()

**Function:** Event procedure, call it from the [on\\_wln\\_event\(\)](#)<sup>[565]</sup> event handler.

**Syntax:** **sub wln\_proc\_event()**

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>,  
[The Simplest Example](#)<sup>[708]</sup>

### Details

---

## Callback\_wln\_ok()

**Description:** Callback procedure, informs of the successful association with the target wireless network. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_wln\_ok()**

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>,  
[The Simplest Example](#)<sup>[708]</sup>

Details

---

**Callback\_wln\_failure()**

**Description:** Callback procedure, informs of the failure to find the target wireless network, associate with it, or maintain association. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_wln\_failure(wln\_state as en\_wln\_status\_codes)**

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>, [The Simplest Example](#)<sup>[708]</sup>

Part	Description
wln_state	One of these <a href="#">en_wln_status_codes</a> <sup>[722]</sup> : WLN_STATUS_SCANNING_FAILURE, WLN_STATUS_ASSOCIATION_FAILURE, WLN_STATUS_DISASSOCIATION, WLN_STATUS_UNEXPECTED_ERROR.

Details

---

**Callback\_wln\_pre\_buffrq()**

**Description:** Callback procedure, informs of the insufficient number of free buffer pages available for use by the library. Procedure body has to be created elsewhere in the project (externally with respect to the library).

**Syntax:** **sub callback\_wln\_pre\_buffrq(required\_buff\_pages as byte)**

**Returns:** ---

**See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>, [The Simplest Example](#)<sup>[708]</sup>

Part	Description
required_buffer_pages	The number of additional buffer pages that the WLN library needs to operate. Your application must free up at least this

number of buffer pages within `callback_wln_pre_buffrq()` or `wln_start()`<sup>[724]</sup> will fail with the `WLN_STATUS_INSUFFICIENT_BUFFER_SPACE` [status code](#)<sup>[722]</sup>.

### Details

This procedure will be called only if there are not enough buffer pages available.

## Callback\_wln\_mkey\_progress\_update()

- Description:** Callback procedure, informs of the pre-shared master key calculation progress. Procedure body has to be created elsewhere in the project (externally with respect to the library).
- Syntax:** **sub callback\_wln\_mkey\_progress\_update(progress as byte)**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>, [Trying WPA](#)<sup>[711]</sup>

Part	Description
progress	Current progress, in %.

### Details

`callback_wln_mkey_progress_update()` is called periodically from within `wln_wpa_mkey_get()`<sup>[727]</sup>. This enables your application to indicate the calculation progress to the user (i.e. by drawing a progress bar on the LCD screen).

## Callback\_wln\_rescan\_result()

- Description:** Callback procedure, informs of the completion of the re-scanning initiated by `wln_rescan()`<sup>[726]</sup>. Procedure body has to be created elsewhere in the project (externally with respect to the library).
- Syntax:** **sub callback\_wln\_rescan\_result(current\_rssi as byte, scan\_rssi as byte, different\_ap as no\_yes)**
- Returns:** ---
- See Also:** [Step-by-step Usage Instructions](#)<sup>[705]</sup>, [Operation Details](#)<sup>[706]</sup>, [Roaming Between Access Points](#)<sup>[716]</sup>

Part	Description
------	-------------

current_rssi	Signal strength for the access point your device is currently associated with. This argument will be 0 if your device is not associated with any access point.
scan_rssi	Signal strength for the access point you searched for with <a href="#">wln_rescan()</a> <sup>[726]</sup> . This argument will be 0 if the specified access point wasn't found.
different_ap	Indicates whether or not <a href="#">wln_rescan()</a> has found the same access point as the one your device is currently associated with, or a different access point:  0- NO: the same access point.  1- YES: different access point.

### Details

The WLN library determines whether the access point is the same or different by comparing BSSIDs ("MAC addresses") of the access point your device is currently associated with and the access point that was discovered by [wln\\_rescan\(\)](#)<sup>[726]</sup>. This comes handy for your application in case several access points in range have the same SSID (name).

If several access points with the same SSID are in range, [callback\\_wln\\_rescan\\_result\(\)](#) will return the signal strength for the access point with the strongest signal.

## Update History (for this Manual)

### **01SEP2012**

- Documented [DS1100](#)<sup>[164]</sup>, [DS1101W](#)<sup>[168]</sup>, and [DS1102W](#)<sup>[174]</sup> platforms.
- Almost completely rewritten the [Common Library Info](#)<sup>[575]</sup> section.
- Documented the [AggreGate \(AGG\) library](#)<sup>[580]</sup>.
- Significantly updated the [Setting \(SRG\) library](#)<sup>[668]</sup> documentation.
- Documented changes to the [gprs\\_start\(\)](#)<sup>[652]</sup> of the [GPRS library](#)<sup>[645]</sup> (new **apn** argument).

### **22DEC2011 release**

- Documented [ppp. object](#)<sup>[366]</sup> and [GPRS library](#)<sup>[645]</sup>.
- Documented [fd.copyfirmwarelzo](#), and edited [Upgrading the Firmware/Application](#)<sup>[243]</sup>.

### **21NOV2011 release**

- Documented [ssi.](#)<sup>[512]</sup> object.

### **18OCT2011 release**

- Documented [STG library](#)<sup>[668]</sup> improvements:
  - It is now possible to use escape sequences (i.e. "\xA5") in default value strings
  - see *Setting Descriptor File Format*.

- [Stg\\_restore\\_multiple\(\)](#)<sup>[692]</sup> now has now have 4 operation modes.
- **STG\_REDUNDANCY** now offers three choices.
- new **STG\_RAM\_TYPE** define added.
- new [Callback\\_stg\\_vm\\_read](#)<sup>[702]</sup> and [Callback\\_stg\\_vm\\_write](#)<sup>[703]</sup> topics.
- Documented changes in the [.romfile](#)<sup>[370]</sup> object, which now supports files over 64KB.
- New topic added: [About\\_get\\_info\(\) API Functions](#)<sup>[577]</sup>.
- Documented new API procedures: [pppoe\\_get\\_info\(\)](#)<sup>[660]</sup>, [wln\\_get\\_info\(\)](#)<sup>[723]</sup>, [dhcp\\_get\\_info\(\)](#)<sup>[636]</sup>.
- Edited [Using HTTP](#)<sup>[461]</sup> -- SWF files are now supported!

### 17AUG2011 release

- Documented [WLN library](#)<sup>[703]</sup>.
- Updated [wln.](#)<sup>[536]</sup> object documentation (many small edits). Notable changes:
  - Removed "Known Limitations" from [wln.](#)<sup>[536]</sup> object documentation -- these limitations do not exist any more.
  - Documented [wln.activescan](#)<sup>[556]</sup> and expanded [Scanning for Wi-Fi Networks](#)<sup>[550]</sup>.
  - Expanded on WPA security (for example, see [Setting WPA Mode and Keys](#)<sup>[553]</sup>).
- Documented two new API calls of the [STG library](#)<sup>[668]</sup>: [stg\\_find\(\)](#)<sup>[695]</sup> and [stg\\_stype\\_get\(\)](#)<sup>[696]</sup>.
- Updated [code examples](#)<sup>[622]</sup> in the [DPHP library](#)<sup>[618]</sup>.
- Updated the [sample project](#)<sup>[686]</sup> of the [STG library](#)<sup>[668]</sup>.
- Fixed error in [Serial Settings](#)<sup>[390]</sup> topic code sample.
- Added [Includepp Statement](#)<sup>[96]</sup> topic.

### 20JUL2011 release

- Updated [wln.](#)<sup>[536]</sup> object documentation:
  - Dropped "Migrating From the WA1000" and "Rebooting" topics.
  - Added "Known Limitations", [Setting Wi-Fi Security](#)<sup>[552]</sup>, [Setting WPA Mode and Key](#)<sup>[553]</sup>, [.Scanresultwpainfo R/O Property](#)<sup>[569]</sup>.
  - Reedited the entire text.
- Changed [Our Language Philosophy](#)<sup>[4]</sup> topic to reflect support for floating point variables.
- Documented [aes128dec](#)<sup>[205]</sup>, [aes128enc](#)<sup>[206]</sup>, [rc4](#)<sup>[222]</sup>, [strand](#)<sup>[225]</sup>, [stror](#)<sup>[227]</sup>, and [strxor](#)<sup>[228]</sup> functions.

### 23JUN2011 release

- Fixed [sock.allowedinterfaces](#)<sup>[474]</sup> topic to include new values (PPPoE and PPP)
- New topic: [sock.availableinterfaces](#)<sup>[475]</sup>

### 20JUN2011 release

- Documented [pppoe. object](#)<sup>[369]</sup> and [PPPOE library](#)<sup>[655]</sup>.
- New topics: [Protecting Your Device with a Password](#)<sup>[41]</sup>, [Setup \(MD\) Button \(Line\)](#)<sup>[201]</sup>.

- Updated: [Compiling a Final Binary](#)<sup>[15]</sup>, [The Structure of a Project](#)<sup>[16]</sup>, [Creating, Opening, and Saving Projects](#)<sup>[17]</sup>, [Adding, Removing, and Saving Files](#)<sup>[18]</sup>, [Project Settings](#)<sup>[38]</sup>, [Device Explorer](#)<sup>[39]</sup>, [Special Configuration Section of the EEPROM](#)<sup>[197]</sup>.
- Corrected: [Connecting GA1000](#)<sup>[201]</sup> (diagram C was wrong).
- Corrected: [.ip](#)<sup>[360]</sup> Property (of the [net.](#)<sup>[358]</sup> object).

### 30MAY2011 release

- [EM500](#)<sup>[138]</sup> platform change: [fd.](#)<sup>[236]</sup> and [wln.](#)<sup>[536]</sup> objects are now supported.
- [Fd.](#)<sup>[236]</sup> object docs change: there is a new 16-PL\_FD\_STATUS\_FLASH\_NOT\_DETECTED [error code](#)<sup>[239]</sup>, and [fd.format](#)<sup>[276]</sup>, [fd.formatj](#)<sup>[277]</sup>, [fd.mount](#)<sup>[283]</sup>, [fd.getsector](#)<sup>[281]</sup>, [fd.setsector](#)<sup>[290]</sup> may return it.
- New topics: Connecting [External Flash IC](#)<sup>[143]</sup>, [Connecting GA1000](#)<sup>[201]</sup>.
- Many small changes in [Platform Specifications](#)<sup>[138]</sup> (especially for the [EM500](#)<sup>[138]</sup> module).

### 12MAY2011 release

- Removed "EM202" platform documentation, it is no longer supported. We recommend using [EM1206](#)<sup>[156]</sup> or [EM1206W](#)<sup>[158]</sup> instead.
- Cleaned up [platform specifications](#)<sup>[138]</sup> -- many things rearranged:
  - Most specs for each platform now fit in a single topic;
  - The folder with [common information](#)<sup>[191]</sup> has been expanded and rewritten.
- Updated fd. object documentation:
  - [Using Checksums](#)<sup>[242]</sup>, [Fd.checksum](#)<sup>[268]</sup> -- several major corrections, original text contained many factual errors!
  - Documented [transactions](#)<sup>[259]</sup> (new feature).
  - Most topics were edited and updated.

### 09FEB2011 release

- Released all-new [Libraries](#)<sup>[572]</sup> section, with [SOCK](#)<sup>[664]</sup>, [FILENUM](#)<sup>[641]</sup>, [STG](#)<sup>[668]</sup> and [DHCP](#)<sup>[618]</sup> library documentation.
- Updated TIDE topic [Adding, Removing and Saving Files](#)<sup>[18]</sup> with new screenshots and "add existing files" option.

### 10OCT2010 release

- Corrected typographical errors in topics [Lbin Function](#)<sup>[214]</sup>, [Lhex Function](#)<sup>[216]</sup>.

### 04OCT2010 release

- Corrected typographical errors in topics [Instr Function](#)<sup>[214]</sup>, [.Insert Function](#)<sup>[213]</sup>, [Date Function](#)<sup>[208]</sup>, [Mincount Function](#)<sup>[220]</sup>.

### 27JUL2010 release

- Documented new feature, [incremental project uploads](#)<sup>[26]</sup>.

### 15JUNE2010 release

- Corrected EM1206 PLL status on boot (PLL ON by default, no PE pin) under Platform-dependent Programming Information.
- Corrected inter-pulse gaps in [Wiegand mode](#)<sup>[383]</sup> for the .ser object (2mS instead of 20mS)

### 02JUN2010 release

- Documented [EM500](#)<sup>[138]</sup> platform.
- Added Enum pl\_io\_port\_num topic to each platform's description.
- Added Device serial number section to the Platform-dependent Programming Information topic of each platform.
- Changed the [Serial Number](#)<sup>[530]</sup> topic -- it now refers to the Device serial number section (see above).
- Edited [Serialnum](#)<sup>[534]</sup> R/O Property and [Setserialnum](#)<sup>[535]</sup> method topics.

-----

### 29JUL2009 release

- Uncluttered platform documentation -- made these topics "common":
  - [Supported Variable Types \(T1000-based Devices\)](#)<sup>[192]</sup>;
  - [Supported Functions \(T1000-based Devices\)](#)<sup>[192]</sup>;
  - [LED Signals](#)<sup>[200]</sup>;
  - [Debug Communications](#)<sup>[204]</sup>;
  - Project Settings Dialog.
- Merged EM1000 and EM1000W platform documentation under a single manual -- [EM1000 and EM1000W Platforms](#)<sup>[143]</sup>.
- Added EM1202W platform documentation into the EM1000 platform docs, renamed the section into [EM1202 and EM1202W Platforms](#)<sup>[151]</sup>.
- Documented new platforms: [EM1206](#)<sup>[158]</sup> and [EM1206W](#)<sup>[158]</sup>, [DS1202](#)<sup>[181]</sup>, [DS1206](#)<sup>[186]</sup>.
- Reworked [Platform Specifications](#)<sup>[138]</sup> topic.
- Documented new [insert](#)<sup>[213]</sup> function.
- Changes in the [wln](#)<sup>[536]</sup> object manual:
  - Every topic was updated and edited;
  - Added "Migrating From the WA1000" to address the changes in the wln object operation;
  - "Configuring CS Line" renamed into [Configuring Interface Lines](#)<sup>[545]</sup>;
  - "Powering Down" renamed to "Rebooting";
  - "Detecting Disassociation or Powerdown" renamed into [Detecting Disassociation or Offline State](#)<sup>[556]</sup>;
  - "Enabling Port" renamed into [Applying Reset](#)<sup>[546]</sup>;
  - New [Creating Own Ad-hoc Network](#)<sup>[555]</sup> and [Terminating Own Ad-hoc Network](#)<sup>[556]</sup> topics;
- Changes in the [button](#)<sup>[234]</sup> object manual:
  - Expanded the [main](#)<sup>[234]</sup> topic;
  - Documented new [button.pressed](#)<sup>[235]</sup> R/O property;
  - Added information about "debouncing".

- Changes in the [pat](#)<sup>[363]</sup> object manual:
  - Documented [pat.greenmap](#)<sup>[364]</sup> and [pat.redmap](#)<sup>[366]</sup> properties;
  - Updated all other information in relation to the above.
- Changes in the [fd](#)<sup>[236]</sup> object manual:
  - Updated [fd.find](#)<sup>[274]</sup> method;
  - Documented new [fd.rename](#)<sup>[285]</sup> method.
  - In connection with the above, renamed "Creating and Deleting Files" into [Creating, Deleting, and Renaming Files](#)<sup>[250]</sup>, expanded topic content.
- Changes in the [sock](#)<sup>[421]</sup> object manual:
  - Updated [sock.close](#)<sup>[475]</sup>, [sock.reset](#)<sup>[495]</sup>, and [sock.discard](#)<sup>[478]</sup> topics -- these methods are ignored when called from within an HTML page;
  - Updated [HTTP-related Buffers](#)<sup>[462]</sup> -- an HTTP socket can now live without the RX buffer. Also, HTTP variables of any size can now be received;
  - Reworked [Working with HTTP Variables](#)<sup>[469]</sup> -- this is now a section; explained and documented [sock.gethttpprqstring](#)<sup>[480]</sup> and [on\\_sock\\_postdata](#)<sup>[491]</sup>;
  - Added "Redirection and UDP" to the [Redirecting Buffers](#)<sup>[454]</sup> topic;
  - Documented URL substitution: new [URL Substitution](#)<sup>[468]</sup> and [sock.urlsubstitutes](#)<sup>[511]</sup> topics;
  - Documented the data sinking feature: new [Sinking Data](#)<sup>[456]</sup> and [sock.sinkdata](#)<sup>[501]</sup> topics;
  - Documented the timeout counter: expanded [Closing Connections](#)<sup>[437]</sup> topic (see Connection Timeouts), added new [sock.toutcounter](#)<sup>[507]</sup> topic.
- Changes in the [ser](#)<sup>[378]</sup> object manual:
  - There is a new data sinking feature, so [Sinking Data](#)<sup>[399]</sup> and [sock.sinkdata](#)<sup>[501]</sup> topics were added;
  - Corrected schematic diagram (C) in the [Wiegand Mode](#)<sup>[383]</sup> topic.

-----

### 31AUG2008 release

- Documented [kp.object](#)<sup>[304]</sup>, [lcd.object](#)<sup>[317]</sup>.
- Documented [md5](#)<sup>[218]</sup>, [sha1](#)<sup>[223]</sup>, [ddstr](#)<sup>[210]</sup>, and [ddval](#)<sup>[210]</sup> syscalls.
- Documented [sys.serialnum](#)<sup>[534]</sup> and [sys.setserialnum](#)<sup>[535]</sup>. Added [Serial Number](#)<sup>[530]</sup> topic.
- Added [Using Preprocessor](#)<sup>[76]</sup> and [Scope of Preprocessor Directives](#)<sup>[78]</sup> topics.
- Updated [The Watch](#)<sup>[33]</sup> topic -- documented new capabilities such as true support for arrays, expressions ("x(y)"), etc.
- Update [Project Settings](#)<sup>[38]</sup> topic -- documented new Customize button.
- Updated EM202 platform -- this platform is now used by "203" devices as well.

-----

### 04AUG2008 release

- Documented [fd object](#)<sup>[236]</sup>.
- Added [Legal Information](#)<sup>[1]</sup> topic.
- Deleted "What's New in R2" and "Migration From Version 1" topics.

-----

### 10MAR2008 release

- Documented [wln object](#)<sup>[536]</sup>.
- Documented new EM1000W platform.
- Documented new [romfile.offset](#)<sup>[373]</sup> R/O property. In connection with this, updated the following topics: Supported Functions (Syscalls) (EM202/200 (-EV), DS202 platform), [Romfile Object](#)<sup>[370]</sup>.
- Documented new [sock.allowedinterfaces](#)<sup>[474]</sup>, [sock.targetinterface](#)<sup>[506]</sup>, and [sock.currentinterface](#)<sup>[478]</sup> properties. In connection with this, also edited the following topics: [Accepting Incoming Connections](#)<sup>[426]</sup>, [Establishing Outgoing Connections](#)<sup>[434]</sup>, and [Checking Connection Status](#)<sup>[439]</sup>. Changed information in the Supported Objects (EM202 platform) topic. Updated [sock.localportlist](#)<sup>[486]</sup>, [sock.targetinterface](#)<sup>[506]</sup> property topics. Also edited "Platform-dependent Programming Information" topics of all platforms. [EM1000](#)<sup>[143]</sup> and [EM1202](#)<sup>[151]</sup> platforms got new "Enum pl\_sock\_interfaces" topics.
- Corrected a mistake in the [Main Parameters](#)<sup>[358]</sup> topic ([net](#)<sup>[358]</sup> object). The topic incorrectly stated that the Tibbo Basic application can't change the MAC address, which is, in fact, possible.
- Correction: default value for the [net.ip](#)<sup>[360]</sup> property is "1.0.0.1", not "127.0.0.1".
- Corrected [net.ip](#)<sup>[360]</sup>, [net.netmask](#)<sup>[360]</sup>, [net.gatewayip](#)<sup>[361]</sup> (details portion).
- Correction: [EM1202](#)<sup>[151]</sup> platform does not support RTC ([rtc](#)<sup>[375]</sup>.) object.
- Edited [Enum pl\\_io\\_num](#)<sup>[147]</sup> topic of the [EM1000 platform](#)<sup>[143]</sup> manual to reflect newly supported I/O lines 49-53.
- Added to [Understanding TCP Reconnects topic](#)<sup>[428]</sup> (section about reconnects and HTTP). Note added also to [Sock.reconmode Property](#)<sup>[492]</sup> topic.
- Improved "Supported Functions" and "Supported Objects" topics for all platforms.

-----

### 04SEP2007 release

- Extended and renamed the [Project Browser](#)<sup>[22]</sup> topic (formerly called "Using the Project Browser"). Also made new screenshot.
- New screenshots in the [Code Auto-completion](#)<sup>[23]</sup> topic. Text edited slightly as well.
- Updated the [Tooltips](#)<sup>[24]</sup> topic, created [Supported HTML Tags](#)<sup>[26]</sup> topic. New data concerns using HTML elements in tooltips.
- Updated the [Watch](#)<sup>[33]</sup> and [Scopes in Watch](#)<sup>[37]</sup> topics -- new screenshots; the text was also edited.
- Extended the [Constants](#)<sup>[65]</sup> topic -- added a new section about escape sequences in string constants.
- Updated [Language Element Icons](#)<sup>[136]</sup> (slight changes only).

-----

### 09AUG2007 release

- Added the [EM1202](#)<sup>[151]</sup> platform description section.
- Corrected [RTC Object](#)<sup>[375]</sup> topic: should be rtc.getdata and rtc.setdata, not rtc.get and rtc.set.
- Minor corrections in the [EM1000](#)<sup>[143]</sup> platform description section.

-----

**12JUN2007 release**

- [Closing Connections](#)<sup>[437]</sup> topic contained references to sock.abort method, which does not exist. Correct method name is sock.reset.
- Expanded [Establishing Outgoing Connections](#)<sup>[434]</sup> and [Closing Connections](#)<sup>[437]</sup> topics. Both topics now contain "Do not forget! Connection Handling is fully asynchronous" sections.
- Added "Socket re-use after connection closing" section to the [Closing Connections](#)<sup>[437]</sup> topic.
- New [More On the Socket's Asynchronous Nature](#)<sup>[441]</sup> topic.

-----

**12FEB2007 release**

- Updated [Adding, Removing, and Saving Files](#)<sup>[18]</sup> topic.
- Added [Graphic File Properties Dialog](#)<sup>[133]</sup> topic.
- Updated [Working With HTML](#)<sup>[79]</sup> topic.
- Significantly expanded [Embedding Code Within an HTML File](#)<sup>[80]</sup> topic -- especially important: all code fragments on the HTML page are parts of one procedure.
- Updated [Using HTTP](#)<sup>[461]</sup>, [Generating Dynamic HTML pages](#)<sup>[466]</sup>, and [Working With HTTP Variables](#)<sup>[469]</sup> topics.

-----

**27DEC2006 release**

- Added "What's new in R2" and "Migration From Version 1" topics.
- Updated [The Watch](#)<sup>[33]</sup> -- described new functionality, provided more info on how watch works.
- [Scopes in Watch topics](#)<sup>[37]</sup> -- provided more info on how watch works.
- Updated Using the [Project Browser](#)<sup>[22]</sup> -- selected platform is now visible in the topmost tree node.
- Updated [Program Structure](#)<sup>[43]</sup> -- explained that event handlers can also accept arguments.
- New [Exceptions](#)<sup>[29]</sup> topic
- Updated [Variables and Their Types](#)<sup>[48]</sup> -- added info about dword, long, real, float, and structures.
- Updated [Type Conversion](#)<sup>[50]</sup> -- almost 100% new text.
- New [Type Conversion in Expressions](#)<sup>[52]</sup> -- this section has been "under construction" for a long time.
- New [Compile-time Calculations](#)<sup>[53]</sup> topic.
- Updated [Arrays](#)<sup>[54]</sup> topic -- new ways to declare, etc.
- New [Structures](#)<sup>[58]</sup> topic.
- Updated and renamed "User-defined Types" topic. Now it is called [Enumeration Types](#)<sup>[59]</sup>.
- Updated [Understanding the Scope of Variables](#)<sup>[61]</sup> topic.
- New [Declaring Variables](#)<sup>[64]</sup> topic.

- Updated [Introduction to Procedures](#)<sup>[66]</sup> -- explained that event handlers can also accept arguments and can never be functions procedures.
- Updated [Dim Statement](#)<sup>[86]</sup> topic -- new data about ways to define array variables.
- New [Type...End Type Statement](#)<sup>[100]</sup> topic.
- Updated [Passing Arguments to Procedures](#)<sup>[68]</sup> topic (strict byref argument match is now required).
- Updated [Goto Statement](#)<sup>[93]</sup> -- all labels are local!
- New Supported Variable Types topics for each platform (EM202, EM1000).
- Updated Platform-dependent Programming Information topics for each platform (EM202, EM1000).
- EM202 platform no longer supports redirection -- Enum pl\_redir topic has been updated.
- Updated Supported Functions (Syscalls) for EM202 and EM1000 platforms -- some stuff in, some stuff out.
- Updated [Generating Dynamic HTML Pages](#)<sup>[466]</sup> topic -- described changed behavior when the same code snippet has to be executed from two instances of the same HTML page being sent to the browser.
- Updated [Httpnoclose Property](#)<sup>[482]</sup> topic -- there is a new "separator" string.
- Updated [Pat.play](#)<sup>[365]</sup> and [Beep.play](#)<sup>[233]</sup> topics -- now "\*" means x4 speed.
- New [Sys.onsystemtimerperiod Property](#)<sup>[533]</sup> topic.
- Updated [On\\_sys\\_timer Event](#)<sup>[533]</sup> topic -- to reflect that there is a new [sys.onsystemtimerperiod](#)<sup>[533]</sup> property.
- New [Sock.inconenabledmaster Property](#)<sup>[484]</sup> topic.
- Updated Accepting Incoming Connections topic -- added material regarding [sock.inconenabledmaster](#)<sup>[484]</sup> property.
- Updated [Stor.getdata Method](#)<sup>[523]</sup>, [Stor.setdata Method](#)<sup>[524]</sup>, [Rtc.getdata Method](#)<sup>[376]</sup>, [Rtc.setdata Method](#)<sup>[377]</sup> topics because all four methods have been renamed.
- New [Cfloat Function](#)<sup>[207]</sup>, [ftostr Function](#)<sup>[211]</sup>, [Lbin Function](#)<sup>[214]</sup>, [Lhex Function](#)<sup>[216]</sup>, [Lstr Function](#)<sup>[216]</sup>, [Lstri Function](#)<sup>[217]</sup>, [Lval Function](#)<sup>[218]</sup>, [Strtof Function](#)<sup>[228]</sup> topics.
- Updated [Vali Function](#)<sup>[230]</sup> topic -- this function is no longer available since [val](#)<sup>[229]</sup> function now works both for word (unsigned) and short (signed) conversions.
- Updated [Val Function](#)<sup>[229]</sup> topic to reflect the fact that this function is now used both for word (unsigned) and short (signed) conversions.
- Updated [Str Function](#)<sup>[225]</sup>, [Stri Function](#)<sup>[226]</sup>, [Bin Function](#)<sup>[207]</sup>, [Hex Function](#)<sup>[212]</sup>, [Val Function](#)<sup>[229]</sup> topics -- more accurate description and examples.
- Added "declaration" to the description of all events.
- Updated [sock.event R/O Property](#)<sup>[480]</sup> and [sock.eventsimple R/O Property](#)<sup>[480]</sup> topics -- these properties are not longer available.
- Updated [On\\_sock\\_event Event](#)<sup>[480]</sup> topic -- this event now carries newstate and newstatesimple arguments that have replaced [sock.event](#)<sup>[480]</sup> and [sock.eventsimple](#)<sup>[480]</sup> R/O properties.
- Updated [Checking Connection Status](#)<sup>[439]</sup> topic to reflect the changes made to the [on\\_sock\\_event](#)<sup>[490]</sup>.
- New ["Split Packet" Mode of TCP Data Processing](#)<sup>[453]</sup>, [.Splittcppackets Property](#)<sup>[501]</sup>, and [On\\_sock\\_tcp\\_packet\\_arrival Event](#)<sup>[491]</sup> topics.
- Updated certain screenshots in several topics.

- Added Image Editor topics: [Built-in Image Editor](#)<sup>[20]</sup>, [Image Menu](#)<sup>[124]</sup>, [Image Editor Toolbar](#)<sup>[127]</sup>, [Tool Properties Toolbars](#)<sup>[128]</sup> (+ all subtopics).
- Updated [Adding, Removing, and Saving Files](#)<sup>[18]</sup> topic (added image editor-related info).

### 06JULY2006 release

- Added new platform -- [EM1000](#)<sup>[143]</sup>.
- Added "Platform revision Programming Information" topics to EM202 and [EM1000](#)<sup>[143]</sup> platform documentation.
- [Stor](#)<sup>[522]</sup> object got new property- [stor.base](#)<sup>[523]</sup>. Entire description of the object has been updated because of that.
- Clarification has been added to the [romfile](#)<sup>[370]</sup> object description. This object can only access first 65534 bytes of each file, even if the actual file is larger.
- Entire new [beep](#)<sup>[232]</sup> object has been added.
- New feature in [io](#)<sup>[294]</sup> object -- [io.enabled](#)<sup>[298]</sup> property was added.
- New feature in [system](#)<sup>[526]</sup> object- see PLL Management, [sys.currentpll](#)<sup>[531]</sup>, [sys.newpll](#)<sup>[532]</sup>, [sys.resettype](#)<sup>[535]</sup>.
- New features in [serial port](#)<sup>[378]</sup> object- support for Wiegand and clock/data interfaces. New topics include: [Three Modes of the Serial Port](#)<sup>[380]</sup> with subtopics, [ser.mode](#)<sup>[409]</sup>, and [ser.autoclose](#)<sup>[402]</sup>. A lot of other topics have been changed- too many to list here.
- Change in [sys.bufalloc](#)<sup>[530]</sup> behavior: now if the serial port (socket) to which the buffer belongs is not closed (idle) the buffer size will remain unchanged. This affects [ser.rxbufreq](#)<sup>[415]</sup>, [ser.txbufreq](#)<sup>[419]</sup>, [sock.rxbufreq](#)<sup>[497]</sup>, [sock.txbufreq](#)<sup>[509]</sup>, [sock.tx2bufreq](#)<sup>[508]</sup>, [sock.cmdbufreq](#)<sup>[476]</sup>, [sock.rplbufreq](#)<sup>[496]</sup>, [sock.varbufreq](#)<sup>[511]</sup>.
- Corrected errors in the Enum pl\_io\_num (pin descriptions were wrong- RTS, CTS, DTR, and DSR lines were shown at incorrect positions).
- Corrected [ser.txlen](#)<sup>[420]</sup>, [ser.txfree](#)<sup>[420]</sup>, [sock.txlen](#)<sup>[510]</sup>, [sock.txfree](#)<sup>[510]</sup> property descriptions. These properties *do not* take into account uncommitted data in the TX buffer (it was stated otherwise previously). Consequently these topics were also edited: [Buffer Memory Status](#)<sup>[394]</sup>, [TX and RX Buffer Memory Status](#)<sup>[447]</sup>, [Ser.notifysent](#)<sup>[410]</sup>, [on ser data sent](#)<sup>[412]</sup>, [sock.notifysent](#)<sup>[487]</sup>, [on sock data sent](#)<sup>[489]</sup>, [ser.setdata](#)<sup>[418]</sup>, and [sock.setdata](#)<sup>[500]</sup> have been amended accordingly.
- Corrected mistakes related to date/time conversion functions- [date](#)<sup>[208]</sup> function was erroneously documented as "day" function, [weekday](#)<sup>[230]</sup> function description was missing altogether. Topics of other date/time related functions- [year](#)<sup>[230]</sup>, [month](#)<sup>[221]</sup>, [daycount](#)<sup>[209]</sup>, [hours](#)<sup>[213]</sup>, [minutes](#)<sup>[221]</sup>, and [mincount](#)<sup>[220]</sup> were slightly corrected.

### 08MAY2006 release

- Corrected errors in [io.Num Property](#)<sup>[301]</sup> and [io.State Property](#)<sup>[303]</sup>

### 08MAR2006 release

- Updated [Preparing Your Hardware](#)<sup>[9]</sup> with the network upgrade procedure
- Updated [Starting a New Project](#)<sup>[10]</sup>
- Updated [Making, Uploading and Running an Executable Binary](#)<sup>[26]</sup>

- Updated [Project Menu](#)<sup>[123]</sup> with new entry description for Device Explorer
- Updated [Debug Toolbar](#)<sup>[126]</sup> with new button description for Device Explorer
- Updated and expanded Device Explorer
- Added new functions: [Day Function](#)<sup>[208]</sup>, [Daycount Function](#)<sup>[209]</sup>, [Hours Function](#)<sup>[213]</sup>, [Mincount Function](#)<sup>[220]</sup>, [Minutes Function](#)<sup>[221]</sup>, [Month Function](#)<sup>[221]</sup>, [Year Function](#)<sup>[230]</sup>

-----

#### **11JAN2006 release**

- Improved indexes -- better context search.
- Added [L1008](#)<sup>[118]</sup>, [L1009](#)<sup>[118]</sup>

-----

#### **02JAN2006 release**

- Initial release of manual.

# Index

- - -

- Operator 105

- & -

&b 45

&h 45

- \* -

\* Operator 105

- / -

/ Operator 105

- + -

+ Operator 105

- = -

= Operator 105

- A -

Abort 28

Accessing a Value Within an Array 54

active opens 434

Actively closing TCP connections 437

Actively closing UDP connections 437

add custom comments 24

Add File 18

AND Operator 105

arrays 54

    watching 33

asc 206

asynchronous operation 378

- B -

BASIC code snippet in HTTP file 465

BASIC files 16

baudrate 378

baudrate property 390

Beep 232

beep.divider 232

beep.play 233

Beeper 232

bin 207

blocking code 448

blue line 31

boolean 48

Break 28

breakpoint 30

Broadcast 428

buffer memory 526

buffer overruns 398, 454

buffer redirection 454

buffer shorting 378, 454

buffer sizes 378

buffers 526

Button 234

button.time 235

Buzz 10

Buzzer 232

By Reference 68

By Value 68

byte 48

- C -

C1001 107

C1002 107

C1003 107

C1004 108

C1005 108

C1006 108

C1007 109

C1008 109

C1009 110

C1010 110

C1011 111

C1012 111

C1013 111

C1014 112

C1015 112

C1016 113

C1017 113

C1018 113

C1019 114

C1020 114

C1021 114

C1022 115  
C1023 115  
C1024 116  
call stack 31, 133  
case 97  
Case Sensitive 45  
cfloat 207  
char 48  
chr 208  
CMD buffer 422, 457  
    overruns 458  
Code hinting 24  
Code Profiling 37  
code-completion 23  
Colons 45  
Comments 45  
Communication in progress 28  
Communication problem 28  
Compilation Unit 136  
Compiler 136  
connections close automatically 437  
const 65, 84  
Constants 65  
    In different bases 45  
Construct 136  
Conversion 50  
cross-debugging 28, 136  
Ctrl+Shift+space 24  
Ctrl+space 23  
CTS line 379  
CTS/RTS flow control 378  
custom comments for tooltips 24

## - D -

data overrun detection 378  
date 208  
daycount 209  
ddstr 210  
ddval 210  
Debug Mode 27, 120  
Debug version 15  
Decision Structures 72  
Declares 84  
Declaring Procedures 66  
Declaring Variables 61  
default gateway 358  
dim 86  
direction control via RTS 378

do 87  
doevents 73, 87, 466  
Double Quote Marks 45  
dynamic HTML 79, 462, 466

## - E -

Edit Mode 120  
EEPROM 522  
else 94  
elseif 94  
EM1000 143  
EM1000-EV 143  
EM1202 151  
EM1202-EV 151  
end 89  
end if 94  
end select 97  
end sub 99  
enum 59, 88  
enumeration types 48  
escape character 456  
escape sequence 80  
escape sequences 378  
Ethernet communications 358  
events 8  
    event handlers 11, 43  
exit 89  
exit do 89  
exit for 89  
exit function 89  
exit sub 89  
exit while 89

## - F -

F5 14, 26  
F7 26  
F9 30  
fd.availableflashspace 267  
fd.buffernum 267  
fd.capacity 268  
fd.checksum 268  
fd.close 269  
fd.copyfirmware 269  
fd.create 271  
fd.cutfromtop 271  
fd.delete 272  
fd.filenum 273

fd.fileopened 273  
 fd.filesize 274  
 fd.find 274  
 fd.flush 275  
 fd.format 276  
 fd.getattributes 278  
 fd.getbuffer 278  
 fd.getdata 279  
 fd.getfreespace 280  
 fd.getnextdirmember 280  
 fd.getnumfiles 281  
 fd.getsector 281  
 fd.laststatus 282  
 fd.maxopenedfiles 282  
 fd.maxstoredfiles 283  
 fd.mount 283  
 fd.numservicesectors 284  
 fd.open 284  
 fd.pointer 285  
 fd.ready 285  
 fd.resetdirpointer 286  
 fd.sector 287  
 fd.setattributes 287  
 fd.setbuffer 288  
 fd.setdata 289  
 fd.setfilesize 289  
 fd.setpointer 291  
 fd.setsector 290  
 fd.totalsize 292  
 file pointer 370  
 firewall 9  
 firmware file 9  
 for 90  
 form 469  
 freeze 448  
 ftostr 211  
 Full duplex 378  
 Function 91  
 Function Procedures 66

## - G -

GIF 461  
 Global Scope 61  
 Global Variables 43  
 goto 93  
 graceful disconnect 425  
 green LED 363  
 green status 28

GUI 119

## - H -

half duplex 378  
 halt 530  
 Handling RX buffer overruns 398  
 Header files 16  
 hex 212  
 hours 213  
 hover your mouse 24  
 HTML 79, 461  
   dynamic content 79  
   dynamic data 466  
   Dynamic pages 462  
   files 16  
   form 469  
   Pages 79  
   Scope 61  
 HTTP 424  
   mode 461  
   server 461  
   Variables 469

## - I -

icons 136  
 Identifier 137  
 Identifiers 47  
 if statement 94  
 illegal characters 466  
 Inband commands 456  
 Inband message 456  
 Inband replies 460  
 include 43, 95  
 includepp 96  
 incoming connections mode 426  
 instr 214  
 integer 48  
 Integers 48  
 IO Object 294  
 io.enabled 298  
 io.intenabed 299  
 io.intnum 299  
 io.invert 300  
 io.lineget 300  
 io.lineset 300  
 io.num 301  
 io.portenabed 302  
 io.portget 302

io.portnum 302  
io.portset 303  
io.portstate 303  
io.state 303

## - J -

JPG 461  
Jump to Cursor 33

## - K -

Keyword 137  
kp.autodisablecodes 312  
kp.enabled 312  
kp.longpressdelay 313  
kp.longreleasedelay 313  
kp.pressdelay 315  
kp.releasedelay 315  
kp.repeatdelay 315  
kp.returnlinesmapping 316  
kp.scanlinesmapping 317

## - L -

L1001 116  
L1002 116  
L1003 117  
L1004 117  
L1005 117  
L1006 117  
L1007 118  
L1008 118  
L1009 118  
label 93, 137  
lbin 214  
lcd.backcolor 339  
lcd.bitsperpixel 339  
lcd.bluebits 340  
lcd.bmp 340  
lcd.enabled 341  
lcd.error 342  
lcd.fill 342  
lcd.filledrectangle 343  
lcd.fontheight 343  
lcd.fontpixelpacking 344  
lcd.forecolor 344  
lcd.getprintwidth 345  
lcd.greenbits 345

lcd.height 346  
lcd.horline 346  
lcd.inverted 347  
lcd.iomapping 347  
lcd.line 348  
lcd.linewidth 348  
lcd.lock 348  
lcd.lockcount 349  
lcd.panelpixeltype 349  
lcd.pixelpacking 350  
lcd.print 351  
lcd.printaligned 351  
lcd.rectangle 352  
lcd.redbits 352  
lcd.rotated 353  
lcd.setfont 353  
lcd.setpixel 354  
lcd.textalignment 355  
lcd.texthorizontalspacing 355  
lcd.textorientation 356  
lcd.textverticalspacing 356  
lcd.unlock 356  
lcd.verline 357  
lcd.width 357  
LED 363  
left 215  
len 215  
lhex 216  
Linker 137  
link-level broadcasts 428  
Listening ports 426  
Local Scope 61  
loop 87  
Loop structures 72  
loopback 448  
lstr 216  
lstri 217  
lval 218

## - M -

main window 120  
Master Process 7  
md5 218  
memory allocation 393, 444, 526  
memory capacity 393  
menu 121  
messages embedded within the TCP data stream 456

mid 219  
 mincount 220  
 minimalistic 82  
 minutes 221  
 MOD Operator 105  
 month 221  
 more than one serial port 388  
 Multi-Dimensional Arrays 54  
 Multiple Sockets 432

## - N -

Net object 358  
 net.failure 361  
 net.gatewayip 361  
 net.ip 360  
 net.linkstate 361  
 net.mac 360  
 net.netmask 360  
 new project 10  
 next 90  
 No Communication 28  
 non-blocking operation 394  
 non-HTTP and HTTP processing on the same socket 463  
 NOT Operator 105

## - O -

Objects 8, 82  
 on\_beep 233  
 on\_button\_pressed 234  
 on\_button\_released 235  
 on\_io\_int 301  
 on\_kp 314  
 on\_kp\_overflow 314  
 on\_net\_link\_change 362  
 on\_net\_overrun 362  
 on\_pat 365  
 on\_ser\_data\_arrival 412  
 On\_ser\_data\_arrival Event 396  
 on\_ser\_data\_sent 412  
 on\_ser\_esc 413  
 on\_ser\_overrun 413  
 on\_sock\_data\_arrival 489  
 on\_sock\_data\_sent 489  
 on\_sock\_event 490  
 on\_sock\_inband 490  
 on\_sock\_overrun 491

on\_sock\_tcp\_packet\_arrival 491  
 on\_sys\_init 526, 533  
 on\_sys\_timer 533  
 on\_wln\_event 565  
 on\_wln\_task\_complete 565  
 OR Operator 105

## - P -

parity 378  
 passive open 425  
 Passive TCP connection termination 437  
 pat.play 365  
 Pause 28  
 P-Code 137  
 Philosophy 4  
 PL\_SST\_CL\_ARESET\_CMD 439  
 PL\_SSTS\_CLOSED 439  
 Platform Functions 82  
 point-to-point 424  
 polling 396, 448  
 Port Selection 388  
 port switchover 429  
 program pointer 30  
 project 15  
 Project file 16  
 Project pane 134  
 Project tree 18

## - Q -

queue 7

## - R -

RAM 70  
 random 222  
 read data from EEPROM 522  
 Real-time Clock 375  
 reboot your device manually 26  
 Receiving Data 394, 445, 446  
 receiving data with UDP 450  
 reconmode 428  
 reconnects 428, 429  
 Recursion 66  
 red dot 30  
 red LED 363  
 red status 28  
 Release Mode 27

Remove All Breakpoints 30  
Remove File 18  
Resource files 16, 20  
Restart 26  
right 223  
Romfile Object 370  
romfile.find 372  
romfile.getdata 373  
romfile.offset 373  
romfile.open 374  
romfile.pointer 374  
romfile.size 375  
RPL buffer 422, 457, 460  
rtc.get 376  
rtc.running 377  
rtc.set 377  
RTS line 379  
Run 28  
Run to Cursor 33  
RX buffer 379, 394, 422, 447, 462  
RX buffer overruns 454  
RX line 379

## - S -

sandbox 7, 137  
scope 61  
select case 97  
send UDP broadcasts 435  
Sending data 397, 445, 446, 451  
ser.autoclose 402  
ser.baudrate 402  
ser.bits 403  
ser.ctsmap 403  
ser.dircontrol 404  
ser.div9600 404  
ser.enabled 405  
ser.escchar 405  
ser.esctype 405  
ser.flowcontrol 407  
ser.getdata 407  
ser.interchardelay 408  
ser.interface 408  
ser.mode 409  
ser.newtxlen 410  
ser.notifysent 410  
ser.num 411  
ser.numofports 411  
ser.parity 413  
ser.redir 414  
ser.rtsmap 415  
ser.rxbufirq 415  
ser.rxbufsize 416  
ser.rxclear 416  
ser.rxlen 417  
ser.send 417  
ser.setdata 418  
ser.txbufirq 419  
ser.txbufsize 419  
ser.txclear 420  
ser.txfree 420  
ser.txlen 420  
serial port 379  
serial port object 378  
Serial Settings 390  
set the socket for HTTP 463  
Settings 38  
sha1 223  
short 48  
Single Quote Marks 45  
Sock Object 421  
sock.acceptbcast 474  
sock.allowedinterfaces 474  
sock.bcast 475  
sock.close 475  
sock.cmdbufirq 476  
sock.cmdlen 477  
sock.connect 477  
sock.connectiontout 477  
sock.currentinterface 478  
sock.discard 478  
sock.endchar 479  
sock.escchar 479  
sock.event 480  
sock.eventsimple 480  
sock.getdata 480  
sock.getinband 481  
sock.httpmode 481  
sock.httpnoclose 482  
sock.httpportlist 483  
sock.httpqrstring 483  
sock.inbandcommands 484  
sock.inconenablenmaster 484  
sock.inconmode 485  
sock.localport 485  
sock.localportlist 486  
sock.newtxlen 486  
sock.nextpacket 450, 487

- sock.notifysent 487
- sock.num 488
- sock.numofsock 488
- sock.outport 488
- sock.protocol 492
- sock.reconmode 492
- sock.redir 493
- sock.remoteip 494
- sock.remotemac 495
- sock.remoteport 495
- sock.reset 495
- sock.rplbuffrq 496
- sock.rplfree 497
- sock.rpllen 497
- sock.rxbuffrq 497
- sock.rxbuffsize 498
- sock.rxclear 498
- sock.rxlens 499
- sock.rpacketlen 499
- sock.send 500
- sock.setdata 500
- sock.setsendinband 500
- sock.splittcppackets 501
- sock.state 439, 502
- sock.statesimple 439, 505
- sock.targetbcast 505
- sock.targetinterface 506
- sock.targetip 506
- sock.targetport 507
- sock.tx2buffrq 508
- sock.tx2len 508
- sock.txbuffrq 509
- sock.txbuffsize 509
- sock.txclear 510
- sock.txfree 510
- sock.txlen 510
- sock.varbuffrq 511
- socket
  - automatic switching 423
- stack pointer 31
- state 28
- Statements 83
- status bar 130
- status messages 28
- stepping 33
- stor.base 523
- stor.get 523
- stor.set 524
- stor.size 525
- str 225
- strgen 226
- stri 226
- string 48
- strsum 227
- strtof 228
- sub 99
- Sub Procedures 66
- SYN-SYN-ACK 434
- Sys Object 526
- sys.buffalloc 530
- sys.currentpll 531
- sys.freebuffpages 531
- sys.halt 532
- sys.newpll 532
- sys.onsystimerperiod 533
- sys.reboot 534
- sys.resettype 535
- sys.runmode 534
- sys.serialnum 534
- sys.setserialnum 535
- sys.timercount 536
- sys.totalbuffpages 536
- sys.version 536
- Syscall 137
- system requirements 119

## - T -

- Target 137
- tbh 16
- tbs 16
- TCP 424
- terms 136
- Tibbo Basic code within an HTML file 80
- Timekeeping 375
- timeouts 437
- timer 37, 528
- toolbars 126
- tooltip 24
- total capacity of the buffer 394
- tpr 16
- tree 70
- TX buffer 379, 394, 422, 447, 462
- TX buffer overruns 398, 454
- TX line 379
- TX2 buffer 422, 457
- TXt 461

**- U -**

UDP "connections" 425  
UDP broadcasts  
  accept 428  
  send 435  
until 87  
Upload 26

**- V -**

val 229  
vali 230  
VAR buffer 422, 462  
Variable Types For Arrays 54  
Virtual Machine 7, 28, 137

**- W -**

watch 33  
watching arrays 33  
weekday 230  
wend 101  
while 87, 101  
who can connect 426  
window 120  
wln.associate 557  
wln.associationstate 558  
wln.boot 558  
wln.buffrq 559  
wln.buffersize 559  
wln.csmmap 560  
wln.disassociate 561  
wln.domain 561  
wln.enabled 562  
wln.gatewayip 562  
wln.ip 563  
wln.mac 563  
wln.netmask 564  
wln.rssi 566  
wln.scan 567  
wln.scanresultbssid 567  
wln.scanresultbssmode 568  
wln.scanresultchannel 568  
wln.scanresultrssi 569  
wln.scanresultssid 569  
wln.settxpower 570  
wln.setwep 570

wln.task 572  
word 48  
word length 378  
write data to EEPROM 522

**- X -**

XOR Operator 105

**- Y -**

year 230  
yellow line 30  
yellow status 28